

**TL81X/TL894 Automated Tape Library  
for DLT™ Cartridges**

**Diagnostic Software  
User's Manual**

**EK-TL810-UM**

**Revision C01**



EK-TL810-UM, Revision C01, January 27, 1997, Made in USA.

© Copyright 1997, Digital Equipment Corporation. All rights reserved.

Your right to copy this manual is limited by copyright law. Making copies or adaptations without prior written authorization of Digital Equipment Corporation is prohibited by law and constitutes a punishable violation of the law.

Digital Equipment Corporation provides this publication "as is" without warranty of any kind, either express or implied, including but not limited to the implied warranties of merchantability or fitness for a particular purpose. Digital Equipment Corporation may revise this publication from time to time without notice.

DLT and DLTape are claimed as trademarks of Quantum Corporation in the U.S. and other countries.

### **FCC STATEMENT**

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Any changes or modifications made to this equipment may void the user's authority to operate this equipment.

Operation of this equipment in a residential area may cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **INDUSTRY CANADA (DIGITAL APPARATUS) Interference-Causing Equipment Standard ICES-003 Issue 2**

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cer appareil numerique de la classe A respecte toutes les exigences du Reglement sur le materiel brouilleur du Canada.

### **CISPR-22 WARNING!**

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

### **ACHTUNG!**

Dieses ist ein Gerät der Funkstörgrenzwertklasse A. In Wohnbereichen können bei Betrieb dieses Gerätes Rundfunkstörungen auftreten, in welchen Fällen der Benutzer für entsprechende Gegenmassnahmen verantwortlich ist.

### **ATTENTION!**

Ceci est un produit de classe A. Dans un environnement domestique, ce produit peut causer des interférences radio lectriques. Il appartient alors a l'utilisateur de prendre les mesures appropriées.

### **NOTICE FOR USA AND CANADA ONLY**

If shipped to USA, use the UL LISTED power cord specified below for 100-120 V operation. If shipped to CANADA, use the CSA CERTIFIED power cord specified below for 100-120V operation.

Plug Cap	Parallel blade with ground pin (NEMA 5-15P Configuration)
Cord	Type: SJT, three 16 or 18 AWG wires
Length	Maximum 15 feet
Rating	Minimum 10 A, 125 V

## **ATTENTION**

LIRE LA REMARQUE DANS LE MODE D'EMPLOI

## **REMARQUE**

CETTE REMARQUE NE CONCERNE QUE LES ÉTATS-UNIS ET LE CANADA.

En cas d'envoi aux États-Unis, utiliser le cordon d'alimentation certifié UL et convenant pour 100-120 V.

En cas d'envoi au CANADA, utiliser le cordon d'alimentation CERTIFIÉ CSA et convenant pour 100-120 V.

Fiche	Broches paralléus avec une broche de mise à la terre (configuration NEMA 5-15P)
Cordon	Type: SJT, trifilaire 16 ou 18 AWG
Longeur	Maximum 15 pieds
Capacité	Minimum 10 A, 125 V

## **ZU IHRER SICHERHEIT**

### **Vorsicht**

Um Feuergefahr und die Gefahr eines elektrischen Schlages zu vermeiden, darf das Gerät weder Regen noch Feuchtigkeit ausgesetzt werden.

Um einen elektrischen Schlag zu vermeiden, darf das Gehäuse nicht geöffnet werden. Überlassen Sie Wartungsarbeiten stets nur einem Fachmann.

### **Achtung**

Da der interne Laserstrahl in Ihre Augen eindringen und Verletzungen verursachen kann, darf das Gehäuse nicht selbst geöffnet werden. Überlassen Sie Wartungsarbeiten stets nur einem Fachmann.

Die Verwendung von Brillen, Kontaktlinsen usw. vergrößert die Gefahr.

### **Zur besonderen Beachtung**

#### **Zur Sicherheit**

Sollte ein fester Gegenstand oder Flüssigkeit in das Geräteinnere gelangen, trennen Sie das Gerät von der Wandsteckdose ab und lassen Sie es von einem Fachmann überprüfen, bevor Sie es weiter verwenden.

Zum Abziehen des Kabels fassen Sie stets am Stecker und niemals am Kabel selbst an.

#### **Zur Aufstellung**

Stellen Sie das Gerät weder auf einer weichen Unterlage (z. B. Decke, Teppich) noch in der Nähe von Vorhängen, Tapeten usw. auf, da hierdurch die Ventilationsöffnungen blockiert werden können.

#### **Zur Reinigung**

Verwenden Sie zur Reinigung des Gehäuses, des Bedienungspultes und der Bedienelemente ein trockenes, weiches Tuch oder ein weiches, leicht mit mildem Haushaltsreiniger angefeuchtetes Tuch. Lösemittel wie Alkohol oder Benzin dürfen nicht verwendet werden, da diese die Gehäuseoberfläche ungreifen.

# Table of Contents

## Introduction

Purpose .....	1-3
Conventions Used in this Guide .....	1-3
Related Documentation .....	1-4

## Preparing for Diagnostic Procedures

Chapter Overview .....	2-3
Installing the Diagnostic Software Program .....	2-3
Modifying the AUTOEXEC.BAT File .....	2-4
Connecting the Diagnostic PC to the Library .....	2-4
Starting the Diagnostic Software .....	2-6
Modifying the LIB.BAT File .....	2-8
Using On-line Help .....	2-8
On-line Error Messages .....	2-9
Exiting the Diagnostic Software .....	2-9

## Menu Overview and Window Descriptions

Chapter Overview .....	3-3
Menu Structure .....	3-3
Main Menu Screen .....	3-4
Pull-Down Menus .....	3-5
Sub-Menus and Pop-Up Windows .....	3-6
Return Status Windows .....	3-7
Command Status Window .....	3-8
Function and Control Keys .....	3-9
Location of Bins and Tape Drives .....	3-10

## Diagnostic Functions and Procedures

Chapter Overview .....	4-3
Main Menu .....	4-4

User Tests Menu .....	4-6
Loop Mode .....	4-7
Track Mode .....	4-8
User Input Command .....	4-9
PP.TST .....	4-10
PP1.TST .....	4-10
PP2.TST .....	4-10
User-Defined Tests .....	4-11
Running a User Defined Test .....	4-11
System Tests Menu .....	4-12
Loop Mode .....	4-13
Exercise Horizontal .....	4-13
Exercise Vertical .....	4-13
Exercise Extension .....	4-14
Exercise Gripper .....	4-14
Pick/Place All .....	4-14
Rpt Calibrations .....	4-15
Bin SysTest .....	4-16
Bin/Drive SysTest .....	4-16
Random SysTest .....	4-16
Random Bin SysTest .....	4-16
Random Bin/Drive SysTest .....	4-17
Status Menu .....	4-18
Actuator Status .....	4-19
Report Statistics .....	4-19
Reset Statistics .....	4-19
SysTest Info .....	4-19
System Info .....	4-20
Error Description .....	4-20
Display Serial# .....	4-20
Move Actuators Menu .....	4-21
Self Test All .....	4-22
Home All .....	4-22
Horizontal Axis .....	4-23
Vertical Axis .....	4-24
Extension Axis .....	4-25
Gripper .....	4-26
Drive Door .....	4-27
Load Port .....	4-28
Unload Tape .....	4-29

Move Cartridges .....	4-30
Picking a Cartridge.....	4-31
Placing a Cartridge.....	4-31
Reading the Bar Code Label of a Cartridge.....	4-32
Align/Calibrate Menu .....	4-33
Calibrate .....	4-34
Library SCSI ID .....	4-35
Report Lib. SCSI ID.....	4-35
Tape Drive SCSI ID.....	4-36
Reset Drive .....	4-36
Report Drive.....	4-37
Bin Position.....	4-37
Drive Position.....	4-39
Load Port Position.....	4-40
Config Menu .....	4-41
Configure System .....	4-42
Report System .....	4-43
Init Inventory .....	4-43
Init Non-Vol RAM.....	4-43
Recovery .....	4-44
Exabyte .....	4-44
No Bar Code .....	4-44
Clean Tape .....	4-44
Enable Clean Tape.....	4-45
Disable Clean Tape.....	4-45
Report Clean Tape.....	4-45
Initialize Clean Data.....	4-45
Flash Download.....	4-45

## **Glossary**

## **Index**





# List of Figures

Figure 1: Rear Panel .....	2-5
Figure 2: DSP Main Menu Screen .....	2-7
Figure 3: Main Menu Screen .....	3-4
Figure 4: Pull-Down Menus .....	3-5
Figure 5: Sub-Menus and Pop-Up Windows .....	3-6
Figure 6: Return Status Windows .....	3-7
Figure 7: Command Status Window .....	3-8
Figure 8: Bin/Tape Drive Numbering Convention .....	3-10
Figure 9: Main Menu .....	4-4
Figure 10: DSP Structure .....	4-5
Figure 11: User Test Menu .....	4-6
Figure 12: System Tests Menu .....	4-12
Figure 13: Status Menu .....	4-18
Figure 14: Move Actuators Menu .....	4-21
Figure 15: Align/Calibrate Menu .....	4-33
Figure 16: Configuration Menu .....	4-41
Figure 17: Flash Download .....	4-46



# List of Tables

Table 1:	Related Documentation . . . . .	1-4
Table 2:	TAPELIB Directory . . . . .	2-3
Table 3:	Start-Up Configuration Examples . . . . .	2-7
Table 4:	Function and Control Keys . . . . .	3-9
Table 5:	Horizontal Axis Sub-Menu Functions . . . . .	4-23
Table 6:	Vertical Axis Sub-Menu Functions . . . . .	4-24
Table 7:	Extension Axis Sub-Menu Functions . . . . .	4-25
Table 8:	Gripper Sub-Menu Functions . . . . .	4-26
Table 9:	Drive Door Sub-Menu Functions . . . . .	4-27
Table 10:	Load Port Sub-Menu Functions . . . . .	4-28
Table 11:	Move Cartridges Sub-Menu Functions . . . . .	4-30
Table 12:	Calibrate Sub-Menu Functions . . . . .	4-34
Table 13:	Bin Position Sub-Menu Functions . . . . .	4-38
Table 14:	Drive Position Sub-Menu Functions . . . . .	4-39
Table 15:	Load Port Position Sub-Menu Functions . . . . .	4-40
Table 16:	TL81X/TL894 Configuration Matrix . . . . .	4-42



# ***Introduction***

# **1**

Purpose ..... 1-3  
Conventions Used in this Guide ..... 1-3  
Related Documentation. .... 1-4



## Purpose

This document provides instructions on preparing the TL810, TL812, or TL894 library for diagnostics, and on using the diagnostic software for the purpose of testing and/or troubleshooting the library. The document was written for Field Service Engineers (FSEs), and is divided into the following sections:

- Chapter 1, “Introduction,” describes the purpose of this manual, provides a list of its contents and a list of related documentation.
- Chapter 2, “Preparing for Diagnostic Procedures,” contains procedures for installing the diagnostic software into the diagnostic Personal Computer (PC), modifying your “AUTOEXEC.BAT” file, connecting the PC to the library and starting/exiting the diagnostic program.
- Chapter 3, “Menu Overview and Window Descriptions,” contains definitions of the menu structure and of the function and control keys used in the diagnostic software program.
- Chapter 4, “Diagnostic Functions and Procedures,” provides detailed function descriptions and instructions on how to access and perform the functions.

## Conventions Used in this Guide



**WARNING**

*When the warning icon accompanies text, it indicates that a potential hazard to your personal safety exists and is included to help prevent injuries.*



**CAUTION**

*When the caution icon accompanies text, it indicates that a potential hazard to equipment or data exists and is included to help prevent damage.*

## Related Documentation

Table 1 lists all the manuals associated with the TL810, TL812, and TL894 Automated Tape Libraries. To obtain further information and/or copies of documentation on these products, contact:

U.S. Software Supply Business  
Digital Equipment Corporation  
10 Cotton Road  
Nashua, New Hampshire 03063-1260

The part number of each document will be required at the time of order.

---

Table 1: Related Documentation

Document Number	Document Title	Document Description
EK-TL810-OG	TL81X/TL894 Operator's Guide	This guide describes the operator accessible components of the library and provides both operating and troubleshooting procedures.
EK-TL810-IG	TL81X/TL894 Facilities Planning & Installation Guide	This guide describes facilities requirements and installation procedures for the library.
EK-TL810-SV	TL81X/TL894 Field Service Manual	This document contains fault isolation, removal/replacement and periodic maintenance procedures.
EK-TL810-SG	TL81X/TL894 Software Interface Guide	This guide is for software engineers and programmers developing applications that control the libraries.
EK-OTZ87-OM (For TL810 Library)	TZ87 Series Cartridge Tape Subsystem Owner's Manual	This document describes the TZ87 tape drive and provides operating instructions and troubleshooting procedures.
EK-TZ88X-OM (For TL812 Library)	TZ88 Series Cartridge Tape Subsystem Owner's Manual	This document describes the TZ88 tape drive and provides operating instructions and troubleshooting procedures.
EK-TZ89N-UG (For TL894 Library)	TZ89 DLT™ Series Tape Drive User's Guide	This document describes the TZ89 tape drive and provides operating instructions and troubleshooting procedures.



# *Preparing for Diagnostic Procedures*

# 2

Chapter Overview .....	2-3
Installing the Diagnostic Software Program .....	2-3
Modifying the AUTOEXEC.BAT File .....	2-4
Connecting the Diagnostic PC to the Library .....	2-4
Starting the Diagnostic Software .....	2-6
Modifying the LIB.BAT File .....	2-8
Using On-line Help .....	2-8
On-line Error Messages .....	2-9
Exiting the Diagnostic Software .....	2-9



## Chapter Overview

This section contains procedures for installing the Diagnostic Software Program (DSP) into the diagnostic PC, modifying your AUTOEXEC.BAT file, connecting the PC to the library and starting and exiting the program. It also contains a brief discussion of on-line help and error messages.

## Installing the Diagnostic Software Program

To install the DSP, use the procedure below.

**Note** *The DSP requires approximately 380K of hard disk space.*

1. After the diagnostic PC is on and has booted up, insert the DSP diskette into the floppy disk drive; i.e., drive A:.
2. At the "C:\>" prompt, type: a:\install <ENTER>.

**Note** *The INSTALL program creates a directory called TAPELIB on the C: drive and all files described in Table 2 are copied into that directory.*

Table 2: TAPELIB  
Directory

File	Description
README.DOC	This file contains the most up-to-date information about the product, installation instructions and detailed distribution disk contents. To view README.DOC, at the "C:\TAPELIB>" prompt, type: type readme.doc  more<ENTER>
LIB.BAT	Invokes the TAPELIB diagnostic software program.
TAPELIB.EXE	This is the executable file.
TAPELIB.HLP	This is the on-line help file.
TAPELIB.MSG	This is the on-line error message data file.
TAPELIB.NDX	This is the on-line error message index file.
INSTALL.BAT	This is the installation batch file.
PP.TST	This is a pre-defined test script.
PP1.TST	This is a pre-defined test script.
PP2.TST	This is a pre-defined test script.

## Modifying the AUTOEXEC.BAT File

If you want to execute the DSP from any directory on your PC, incorporate the following into the AUTOEXEC.BAT file and then reset your PC.

```
path=c:\TAPELIB;%path%<ENTER>
```


## Connecting the Diagnostic PC to the Library

The DSP interfaces to the library at the DIAG port (RS-232 serial link). It runs from PC communications port #1 (COM1) as the default or from COM2 if the "/c2" switch is set when invoking the diagnostics. (See "Starting the Diagnostic Software" below.)


To connect the diagnostic PC to the library, use the procedure below with Figure 1.

1. Verify that the library front door and load port door are closed.
2. At the rear of the library, connect the RS-232 cable (provided in the accessories kit) to the port marked DIAG.

Figure 1: Rear Panel



## Starting the Diagnostic Software

 **CAUTION** *The DSP is intended to be used for troubleshooting and testing of the library by trained Field Service Engineers. Using the DSP as a demonstration tool may result in damage to the hardware.*

To execute the DSP, use the procedure below with Table 3.

**Note** *Enter one blank space between the executable file name and each parameter. The DSP is not case sensitive.*

1. If applicable, apply power to the library as follows:
  - Verify that the front door and load port are closed, all outer skins are attached, and the rear panel RS-232 diagnostic port connection is secured.
  - At the rear panel, set the power switch to the “|” (on) position.
  - After several seconds, verify that control panel status display area (SDA) shows System On-line.

**Note** *System On-line is only displayed if the library “Power-Up State” is configured for “On-Line.” Otherwise, System Off-line (standby) is displayed in the SDA. (Refer to “Defining the Library Power-Up State” in Chapter 3 of the TL81X/TL894 Operator’s Guide.)*

2. Take the library off-line as follows:
  - With the library power applied and the SDA showing System On-line, press the control panel STANDBY switch.
  - Verify that System Off-line is displayed in the SDA.
3. At the PC “C:\>” prompt, type: `tapelib /b9600 /m /d /cx<ENTER>`, where:
  - `/b` serial port baud rate. This must be set at 9600 baud rate when interfacing with the TL810, TL812, or TL894 library. The default is 2400 baud rate.
  - `/m` indicates a monochrome display. If this variable is omitted, the software assumes a color monitor is being used.
  - `/d` enables the software to capture messages to/from the diagnostic COM port. Messages are logged in the file CAPTURE.TXT in the DSP home directory.
  - `/cx` if specified, uses the COM port “X” (1 or 2) for communication to the host. Supported ports are COM1 and COM2. The default is COM1.
4. After several seconds, verify that the Main Menu Screen (Figure 2) is displayed.

Table 3: Start-Up  
Configuration Examples

Command	Monitor Type	Debug?	Port Used
tapelib /b9600	color	no	COM1
tapelib /b9600 /d	color	yes	COM1
tapelib /b9600 /m	monochrome	no	COM1
tapelib /b9600 /m /d	monochrome	yes	COM1
tapelib /b9600 /c2	color	no	COM2

Figure 2: DSP Main Menu  
Screen



## Modifying the LIB.BAT File

If you plan to use TAPELIB.EXE with the same configuration options every time, you can modify the LIB.BAT file using a text editor. The default LIB.BAT file includes the following commands:

```
@echo off
c:
cd \tapelib
tapelib /1 /2 /3
echo on
```

where /1, /2, and /3 are configuration options described in “Starting the Diagnostic Software” on page 2-6. You can modify these options to reflect your specific configuration.

As an example, if you plan to use the DSP to control a library from a monochrome laptop PC through COM port 2, modify the batch file as shown below:

```
@echo off
c:
cd \tapelib
tapelib /b9600 /m /c2
echo on
```

When you have finished editing the LIB.BAT file, it is recommended you save the file under a new file name, e.g., TL810.BAT if you have the TL810, TL812.BAT if you have the TL812, or TL894.BAT if you have the TL894 library. In order to execute the modified file, at the “C:>” prompt, type: TL810<ENTER>, TL812<ENTER>, or TL894<ENTER>.

## Using On-line Help

The on-line help file, TAPELIB.HLP, can be viewed at any time when running the software by pressing the <F1> function key. The help file explains how to use the software and describes special features. (Entering <Shift> <F1> gives a more detailed description of the function in question.)

**Note** *If you wish, you can modify this file to include additional information by using a text editor. However, no line can be longer than 70 characters (a tab is equivalent to four character spaces) and the total file size must be under 5K bytes.*



## On-line Error Messages

The DSP automatically displays an error code description whenever an error is received from the component being diagnosed. These error descriptions are contained in the error message data file called TAPELIB.MSG. An index file, TAPELIB.NDX, is included to provide pointers to each error code description.

## Exiting the Diagnostic Software

To exit the DSP, use the procedure below.

1. At the Main Screen, press <ESC>.
2. At the "Y/N" (Yes/No) prompt, type Y and press <ENTER> to exit the DSP.
3. Remove the RS-232 cable from the rear panel DIAG port and return the library to the on-line state.



# ***Menu Overview and Window Descriptions***

# **3**

Chapter Overview .....	3-3
Menu Structure .....	3-3
Main Menu Screen .....	3-4
Pull-Down Menus .....	3-5
Sub-Menus and Pop-Up Windows .....	3-6
Return Status Windows .....	3-7
Command Status Window .....	3-8
Function and Control Keys .....	3-9
Location of Bins and Tape Drives .....	3-10



## Chapter Overview

This section describes the structure of the Diagnostic Software Program (DSP) and discusses each of the windows. It also discusses the function of the control keys used in the DSP.

## Menu Structure

The diagnostic software program is divided into three parts:

- Main Menu Screen
- Return Status Window
- Command Status Window

The windows are opened differently; however, all windows may be closed by pressing <ESC>.

**Note** *Some tests must be stopped by pressing <END> or <CTRL><END> before the window can be exited.*

**Note** *The DSP is designed to test the TL810, TL812, TL894, and other libraries. When the diagnostic PC is connected to a library and started, only those DSP menu options that are applicable to the connected library are displayed. If more than one library model is tested using the DSP, then you must completely exit and restart the program after the diagnostic PC has been connected to the new library.*

**Note** *As you progress through this manual, those options that are displayed in the menu, but not currently supported by the TL810, TL812, or TL894 are noted.*

## Main Menu Screen

The Main Menu Screen (Figure 3) is displayed several seconds after executing the “tapelib /b9600” command. The top of the screen is the Information Line containing the:

- Current Date (mm/dd/yy)
- Elapsed Time (hhh:mm:ss) of a specific test
- Real-Time (hh:mm:ss)

Below the Information Line, the TAPE LIBRARY DIAGNOSTIC Main Menu bar is displayed showing the six main categories of diagnostic functions, which are:

- User Test
- System
- Status
- Move Actuators
- Align/Calibrate
- Config

The Status Line at the bottom of the screen provides a brief description of the menu, sub-menu or command that is highlighted (selected).

---

Figure 3: Main Menu Screen



## Pull-Down Menus


The diagnostic categories, and many of the sub-functions, are accessed through pull-down menus. You can select any diagnostic category on the Main Menu bar by using the left-arrow (←) and right-arrow (→) keys. When selected, the category title is highlighted. To access the highlighted function, press the <ENTER> key and the pull-down menu is displayed listing the available options. Refer to Figure 4.

You can use the up-arrow (↑) and down-arrow (↓) keys to navigate through the pull-down or you can highlight the desired option by using the keyboard to enter the letter that is located to the right of the option. Once you highlight the desired option, press <ENTER> to execute it or access another menu (sub-menu).

**Note** *In some cases, the letter to the right of each option may be duplicated. The second or third occurrence of the letter may be accessed by entering the letter two or three times as needed.*

Press <ESC> to exit any diagnostic menu.

Figure 4: Pull-Down Menus



## Sub-Menus and Pop-Up Windows


A “>” (greater than symbol) preceding the letter to the right of an option (Figure 4 on page 3-5) indicates that a sub-menu or a pop-up window is available. Sub-menus provide further options, and pop-up windows typically request additional information that is necessary for executing a particular function.

If a sub-menu is displayed (as shown in Figure 5), select the appropriate option using the ↑/↓ keys or the keyboard. Then press <ENTER> to execute the function.

If a pop-up window is displayed, enter the requested information and then press <ENTER> to execute the option.

Press <ESC> to exit any sub-menu or pop-up window.

Figure 5: Sub-Menus and Pop-Up Windows





## Return Status Windows

The Return Status Window displays detailed information concerning a function that you have selected. The example in Figure 6 shows a RETURN STATUS window for the REPORT STATISTICS command.

Press <ESC> to exit any Return Status Window.

Figure 6: Return Status Windows

```
Date: 02/20/97                               Elapsed Time: 000:00:00 Time: 15:33:13
----- TAPE LIBRARY DIAGNOSTIC -----
User Test  System  Status  Move Actuators  Align/Calibrate  Config
-----
Response For REPORT STATISTICS ->
RETURN STATUS: GOOD
On Time:           3652179 sec      Command Time:      754851 sec
Pick Bin Count:    987           Place Bin Count:   961
Pick Drive Count:  396           Place Drive Count: 411
Horizontal Move Ct: 275634       Vertical Move Count: 162329
Extension Move Count: 420689   Gripper Move Count: 86953
Extension Force Ct: 691           Drive Place Retry: 0
Partial Grip Count: 0
LoadPort Pick Ct: 17           LoadPort Place Ct: 20
Drive Pick Retry:  0           Horizontal Retry:  0
Vertical Retry:    0           Extension Retry:   0
Gripper Retry:     0           Load Retry:        0
Barcode Scan Retry: 32492       Horizontal Correct: 0 steps
Vertical Correct:  0 steps
Drive Handle Retry: 0
1 Command(s) Completed, 0 timeout, Elapsed Time 0:00:00
Press <ESC> key to return .....
Ready For Next Command
Report Components Movement Counters
```

## Command Status Window

The Command Status Window (shown in Figure 7) displays the communications between the DSP and the library. For each command sequence, the Command Status Window lists the command names and the number of commands executed as well as the elapsed time.

This window is often partially hidden by pull-down menus or pop-up windows. To view the full window, press the <HOME> key. Then you can use the <PageUp>, <PageDown> and/or the ↑/↓ keys to view the portions of the window that have already scrolled off the screen.

Figure 7: Command Status Window

```
Date: 05/12/95                               Elapsed Time: 000:01:19 Time: 07:16:45
----- TAPE LIBRARY DIAGNOSTIC -----
User Test  System  Status  Move Actuators  Align/Calibrate  Config

Response = OK : 4.4684 11.8392 3.2472 CLOSED
Sending 1st command again
[4]Command Issued=REPORT ACTUATOR
Waiting For Response ...
Response = OK : 4.4684 11.8392 3.2472 CLOSED
Sending 1st command again
[5]Command Issued=REPORT ACTUATOR
Waiting For Response ...
Response = OK : 4.4684 11.8392 3.2472 CLOSED
Sending 1st command again
[6]Command Issued=REPORT ACTUATOR
Waiting For Response ...
GET ERROR: USER CANCEL OPERATION
Sending ABORT command ...
Response = OK : 4.4684 11.8392 3.2472 CLOSED
Ready For Next Command
Display Component Status and Information
```

TA40020a

## Function and Control Keys

Table 4 lists the function and control keys used in the DSP.


Table 4: Function and Control Keys

Key(s)	Function	Description
<F1> or <Shift><F1>	Help or Extended Help	Displays the help file. Use the <PageUp> and <PageDown> and/or the ↑/↓ keys for navigation. Press <ESC> key to exit.
<F2>	View an Error Description	Displays the expanded error description for the last error returned. Press the <ESC> key to exit the error file.
<F3>	View the Test Command File	Displays a TEST command file stored on disk. This key is only valid for the user-defined tests listed in the lower section of the User Tests Menu. Press the <ESC> key to exit.
<ENTER> or <RETURN>	Make a Selection	Selects a menu option, picks a specific parameter for a command or toggles (select/deselect) a configuration item.
<HOME>	Show the Command Status Window	Displays the Command Status Window. Use the <PageUp>, <PageDown> and/or the ↑/↓ keys to display information not currently in the window. Press the <ESC> key to restore the original window and resume operation.
<END>	Terminate Loop Mode	Loop Mode causes the software to send a command (or a series of commands defined in a test routine) continuously. Upon receiving the <END> key, the software waits for the current loop to complete, then terminates the command sequence.
<CTRL><END>	Abort Command	Aborts the current executing command. The software waits for the response of the most recent command, then terminates the command sequence and returns to the menu selection. Terminates Loop Mode or Test Mode automatically.
<ALT><C>	Start the Capture Mode	Starts the capture mode by defining commands for test routines. Select the commands by pressing the <ENTER> key at the desired menu option. The maximum number of commands that can be captured in a test file is 256. The maximum number of user-defined test routines is 15.
<ALT><E>	End the Capture Mode	Terminates the capture mode. The command sequence file that you created is saved on disk under the name that you specified with a file extension of ".TST." If a file already exists with that name, you have the option to append or overwrite the existing file. The new test routine is added to the User Test menu.
↑ and ↓ ← and →	Menu Navigation	Up-Arrow and Down-Arrow Keys Left-Arrow and Right-Arrow Keys

## Location of Bins and Tape Drives

Figure 8 is a view from the left side of the library with the left cosmetic panel removed. This figure depicts the numbering convention for the library's storage bins, load port bins, and tape drives. This numbering convention is used in the diagnostic software.

Figure 8: Bin/Tape Drive Numbering Convention



TA00053c

# ***Diagnostic Functions and Procedures*** **4**

Chapter Overview .....	4-3
Main Menu .....	4-4
User Tests Menu .....	4-6
Loop Mode .....	4-7
Track Mode .....	4-8
User Input Command .....	4-9
PP.TST .....	4-10
PP1.TST .....	4-10
PP2.TST .....	4-10
User-Defined Tests .....	4-11
Running a User Defined Test .....	4-11
System Tests Menu .....	4-12
Loop Mode .....	4-13
Exercise Horizontal .....	4-13
Exercise Vertical .....	4-13
Exercise Extension .....	4-14
Exercise Gripper .....	4-14
Pick/Place All .....	4-14
Rpt Calibrations .....	4-15
Bin SysTest .....	4-16
Bin/Drive SysTest .....	4-16
Random SysTest .....	4-16
Random Bin SysTest .....	4-16
Random Bin/Drive SysTest .....	4-17
Status Menu .....	4-18
Actuator Status .....	4-19
Report Statistics .....	4-19
Reset Statistics .....	4-19
SysTest Info .....	4-19
System Info .....	4-20

Error Description . . . . .	4-20
Display Serial# . . . . .	4-20
Move Actuators Menu . . . . .	4-21
Self Test All . . . . .	4-22
Home All . . . . .	4-22
Horizontal Axis . . . . .	4-23
Vertical Axis . . . . .	4-24
Extension Axis . . . . .	4-25
Gripper . . . . .	4-26
Drive Door . . . . .	4-27
Load Port . . . . .	4-28
Unload Tape . . . . .	4-29
Move Cartridges . . . . .	4-30
Picking a Cartridge . . . . .	4-31
Placing a Cartridge . . . . .	4-31
Reading the Bar Code Label of a Cartridge . . . . .	4-32
Align/Calibrate Menu . . . . .	4-33
Calibrate . . . . .	4-34
Library SCSI ID . . . . .	4-35
Report Lib. SCSI ID . . . . .	4-35
Tape Drive SCSI ID . . . . .	4-36
Reset Drive . . . . .	4-36
Report Drive . . . . .	4-37
Bin Position . . . . .	4-37
Drive Position . . . . .	4-39
Load Port Position . . . . .	4-40
Config Menu . . . . .	4-41
Configure System . . . . .	4-42
Report System . . . . .	4-43
Init Inventory . . . . .	4-43
Init Non-Vol RAM . . . . .	4-43
Recovery . . . . .	4-44
Exabyte . . . . .	4-44
No Bar Code . . . . .	4-44
Clean Tape . . . . .	4-44
Enable Clean Tape . . . . .	4-45
Disable Clean Tape . . . . .	4-45
Report Clean Tape . . . . .	4-45
Initialize Clean Data . . . . .	4-45
Flash Download . . . . .	4-45

## Chapter Overview

This chapter provides detailed instructions for using each of the diagnostic functions. Each section includes a description of the options that can be selected and additional features or rules that apply specifically to that option.

The options in this chapter are arranged in the order in which they appear in the Main Menu Screen, from left to right.

**Note** *This chapter is written under the assumption that the DSP is running, and that the user is starting at the Main Menu Screen. See Chapter 2, "Preparing for Diagnostic Procedures," before attempting to execute any procedure below.*

## Main Menu

The Main Menu screen contains six categories of diagnostic functions. Use the left-arrow (←) and right-arrow (→) to highlight an option. Press <ENTER> to select the highlighted option and a pull-down menu appears listing the available functions.

Figure 9: Main Menu






Figure 10: DSP Structure

### Main Menu

User Test	System	Status	Move Actuators	Align/Calibrate	Configuration
Loop Mode	Loop Mode	Actuator Status	Self Test All	Calibrate	Configure System
Track Mode	Exercise Horizontal	Report Statistics	Home All	Library SCSI ID	Report System
User Input Cmd	Exercise Vertical	Reset Statistics	Horizontal Axis	Report Lib SCSI ID	Init Inventory
PP.TST	Exercise Extension	SysTest Info	Vertical Axis	Drive SCSI ID	Init Non- Vol RAM
PP1.TST	Exercise Gripper	System Info	Extension Axis	Reset Drive	Recovery
PP2.TST	Pick/Place All	Error Description	Gripper	Report Drive	Auto Inventory
	Rpt Calibrations*	Display Serial#	Drive Door	Bin Position	Exabyte
	Bin SysTest		Load Port	Drive Position	No Bar Code
	Bin/Drive SysTest		Unload Tape	Load Port Position	Clean Tape
	Random SysTest		Move Cartridges		Flash Download
	Random Bin SysTest				
	Random Bin/Drive SysTest				


Note: Asterisk (\*) Indicates that Command is Not Currently Supported

## User Tests Menu

The User Tests Menu (refer to Figure 11) allows you to enable/disable the Loop Mode, log the Command Status Window messages to a designated disk file through Track Mode, and display your own user-defined test scripts.

Once you create a user-defined test script, the file name is displayed in the User Tests Menu window below the User Input Cmd line.

Figure 11: User Test Menu



## Loop Mode

When selected, this option repeats commands or sequences of commands continuously. When active, the Loop Mode option (in the pull-down menu) is prefaced with ">>" and LOOP MODE flashes on and off in the top-center of the screen.

Commands running under this mode are terminated by pressing <END>.

**Note** *When <END> is received, the software waits for the completion of the current command or cycle, then terminates the function and returns to the menu.*

To enable the Loop Mode:

1. Highlight User Test and press <ENTER>.
2. Highlight Loop Mode and press <ENTER> to enable the option.
3. LOOP MODE will flash on and off in the top left-center of the screen.

To disable the Loop Mode:

1. With LOOP MODE flashing on and off in the top-center of the screen, highlight User Test and press <ENTER>.
2. Highlight Loop Mode and press <ENTER> to disable the option.
3. LOOP MODE will no longer flash in the top-center of the screen.

## Track Mode

Track Mode provides the capability to log all messages scrolled in the Command Status Window to a disk file defined by you.

To enable the Track Mode:

1. Highlight User Test and press <ENTER>.
2. Highlight Track Mode and press <ENTER> to enable the option. A pop-up window is displayed.
3. At the "Enter Track File Name:" prompt, type in a file name and press <ENTER> to define the disk file and enable the tracking mode.

**Note** *The file name is limited to eight alphanumeric characters, i.e., the standard alphabet (upper and lower case) and the numerals 0 through 9. No other characters are valid in defining a file name.*

**Note** *If you do not enter a file name when requested, the default file name is "TAPELIB."*

4. Verify that TRACK is displayed on the top left-center of the screen.
5. Make any selection from the Diagnostic Software menus and all information that is scrolled on the screen will also be written to the disk file identified in step 3 above.
6. Example: Turn TRACK mode on, (steps 1 through 4). Then select RPT CALIBRATIONS from the SYSTEM menu. The library bin calibration values will be displayed *and* saved to the track file that was identified in step 3.

To disable the Track Mode:

1. Highlight User Test and press <ENTER>.
2. Highlight Track Mode and press <ENTER> to disable the option.
3. Verify that TRACK is no longer displayed on the top left-center of the screen.

The message sequence will be saved on disk in a file named "filename.TRK," where "filename" is the file name you specified above. The file is stored in the same directory with the diagnostic software program.

## User Input Command

This option is a development tool that allows commands to be entered as an ASCII string of characters. It is not expected to be used during normal field service functions. When selected, a password must be entered before the function executes.

To utilize the User Input Command:

1. Highlight User Test and press <ENTER>.
2. Highlight User Input Cmd and press <ENTER> to enable the option. A pop-up window is displayed.
3. At the "Enter Password:" prompt, type in an authorized password and press <ENTER>. A pop-up window is displayed.
4. At the "Enter Command:" line, type in a single line of text representing the function that you want performed, i.e., SELFTEST ALL. This command represents the following menu selection:
  - Move Actuators Menu: Self Test All
5. Press <ENTER> and the command is executed.

## PP.TST

This test picks and places cartridges from and to the drives and storage bins, exercising all major components of the system in the process.

 **CAUTION** *Do not run PP.TST if the customer is sensitive to the position of the tape cartridges within the library. This test moves cartridges but does not return them to their original locations.*

**Note** *Before running this option, there must be cartridges in the top and bottom bins of each section of the Fixed Storage Array (FSA), i.e., storage bins 0, 7, 8, 15, 16, 23, 24, 31, 32, 39, 40, and 47. All other storage bins must be empty. Each of the four (4) drives must be unloaded and ready to accept a tape. The gripper must also be free. The library must have a current inventory of the cartridges.*

To run PP.TST:

1. Highlight User Test and press <ENTER>.
2. Highlight PP.TST and press <ENTER> to run the test.

<END> will stop the test at the end of the current loop. The test may then be restarted without moving cartridges. A loop takes approximately 15 minutes to complete.

<CNTL><END> will abort the test immediately. If the test is aborted, then the cartridges must be moved to satisfy the initial conditions described above before restarting the test.

**Note** *It is recommended that you run PP.TST as an overall test after servicing the library. This test can also be used, in conjunction with the Loop Mode, as a demonstration of library operation.*

### PP1.TST

PP1.TST is identical to PP.TST except that the tapes are also moved to and from the load port.

### PP2.TST

PP2.TST is similar to PP1.TST but is designed to run on a library with only 2 tape drives and 28 cartridge slots. Start with tape cartridges in slots 7, 8, 15, 16, and 23. Run an INVENTORY process before starting the test.

## User-Defined Tests

The selections at the bottom of the User Tests Menu reflect the diagnostic routines that you create. Create diagnostic routines by capturing one or more commands and saving the commands to a disk file.

To capture commands, do the following:

1. Press <ALT> <C> to enter the User Defined Test function. A pop-up window is displayed.
2. At the "Enter Command File Name:" prompt, type in a file name and press <ENTER>.

**Note** *The file name is limited to eight alphanumeric characters, i.e., the standard alphabet (upper and lower case) and the numerals 0 through 9. No other characters are valid in defining a file name.*

**Note** *If the file name you select already exists, you may choose to either append to it, or overwrite it.*

3. Use the navigation arrows to highlight a test that you want to run and then press <ENTER> to execute and capture the command.
4. Repeat Step 3 for all additional commands.
5. Press <ALT> <E> to end the capture mode.

The command sequence will be saved on disk in a file named "filename.TST," where "filename" is the file name you specified above. All files with the .TST extension will be automatically added to the User Tests Menu and are selectable in the same manner as other options. The file is stored in the same directory with the diagnostic software program.


### Running a User Defined Test

1. Highlight User Test and press <ENTER>.
2. Highlight the test that you want to run and press <ENTER> to execute it.

## System Tests Menu

The System Tests Menu (refer to Figure 12) provides high level command options that exercise entire hardware components as well as test routines that run all library actuators.

Figure 12: System Tests Menu





## Loop Mode

See “Loop Mode” on page 4-7 for a detailed description of this option. The Loop Mode option is also included in this menu for ease of accessibility.

## Exercise Horizontal

This test homes the horizontal axis and moves it to two additional positions. You can use it to verify the proper operation of the horizontal actuator and of the horizontal home, limit, and confirmation sensors.

To exercise the horizontal axis:

1. Highlight System and press <ENTER>.
2. Highlight Exercise Horizontal and press <ENTER>.

## Exercise Vertical

This test homes the vertical axis and moves it to two additional positions. You can use it to verify the proper operation of the vertical actuator and of the vertical home and confirmation sensors.

To exercise the vertical axis:

1. Highlight System and press <ENTER>.
2. Highlight Exercise Vertical and press <ENTER>.

## Exercise Extension

Exercise Extension homes the extension axis and moves it two additional positions. You can use this test to verify the proper operation of the extension actuator, and the extension home sensor.

To exercise the extension axis:

1. Highlight System and press <ENTER>.
2. Highlight Exercise Extension and press <ENTER>.

## Exercise Gripper

This option closes and opens the gripper. Use it to verify the proper operation of the gripper actuator and gripper open and close sensors.

To exercise the gripper:

1. Highlight System and press <ENTER>.
2. Highlight Exercise Gripper and press <ENTER>.

## Pick/Place All

This test picks a cartridge from each of the storage bins and moves it to a new storage bin location, exercising major components of the system in the process.

When the test routine starts, it picks the cartridge from storage bin #31 and moves it to bin #0. Then, it picks a cartridge from bin #14 and moves it to bin #31. This process continues until all cartridges have been picked and moved to a new bin location. The test then repeats this loop endlessly.



### **CAUTION**

***Do not run Pick/Place All if the customer is sensitive to the position of the tape cartridges within the library. This test moves cartridges but does not return them to their original locations.***

### **Note**

***Before running this option, ensure that all bin locations of the FSA contain a cartridge except storage bin #0. The gripper must also be free. The library must have a current inventory of the cartridges.***

To remove the cartridge from storage bin #0 and free the gripper, do the following:

1. Use the Pick from Bin option (see “Move Cartridges”) to remove the cartridge at storage bin #0.

2. Remove the tape from the gripper by either using the Place into Load Port option to place the cartridge into the load port, or by using the Place into Drive option to place the cartridge into a tape drive.

To run Pick/Place All:

1. Highlight System and press <ENTER>.
2. Highlight Pick/Place All and press <ENTER> to run the test. A pop-up "WARNING!" window is displayed.
3. Enter Y to continue the test or N to return to the previous menu and then press <ENTER>.

The best way to stop the test is to press <END>. This will stop the test at the end of the present loop. The test may then be restarted without moving cartridges. A loop takes approximately 10 minutes to complete.

If the test is aborted, then the cartridges must be moved to satisfy the initial conditions described above before restarting the test.

**Note** *It is recommended that you run Pick/Place All as an overall test after servicing the library. This test can also be used as a demonstration of library operation.*


## Rpt Calibrations


This option reports the calibration positions in the system.

To use this option:

1. Highlight System and press <ENTER>.
2. Highlight Rpt Calibrations and press <ENTER>.

**Note** *The next five built-in tests move tapes between bins and/or drives. Each test uses the library's inventory to determine where the tapes are in the system. The tapes do not need to be in any particular orientation, however, there must be at least one empty bin (or drive if they are being used) in the system. If the system inventory is unknown, then the tests will automatically inventory the system.*

 **CAUTION** *The following tests do not distinguish between cleaning and non-cleaning tapes. So if the test is accessing the drives then no cleaning tapes should be in the system.*

 **CAUTION** *Do not run these tests if the customer is sensitive to the position of the tape cartridges within the library. These tests move cartridges but do not return them to their original locations.*

## Bin SysTest

This command will invoke the sequential system test which picks from and places to all bins. This test picks the next bin with a tape and places it into the next available bin in sequence starting from bin 0.

## Bin/Drive SysTest

This command will invoke the sequential system test which picks from each bin and places to a drive, then picks from the drive and places to each bin. When the drive has completed unloading a tape, it is picked from the drive and placed in the next available bin.

## Random SysTest

This command will invoke the system test that picks from and places to both bins and drives. This test finds the next tape from a random location and moves it to the next available drive. If no drives are available then the tape is placed into the next random empty bin. When the drive has completed unloading a tape, it is picked from the drive and placed in the next random empty bin.

## Random Bin SysTest

This command will invoke the random system test that moves tapes between bins only. This test finds the next tape from a random location, and moves it to the next random empty bin.

## Random Bin/Drive SysTest


This command will invoke the random system test which moves tapes between bins and drives only. This test differs from Random SysTest in that it does not move tapes between bins only. This test finds the next tape from a random location, if a drive is available this tape is moved to that drive. If no drives are available, then the system will not perform any moves until a tape is unloaded. When the drive has completed unloading a tape, it is picked from the drive and placed in the next random empty bin.

**Note** *The test results are stored in the NVRAM and can be retrieved any time after the test has been started, whether or not the system has been power cycled. The results are not reset until the next time the test is run. (See Report SysTest Info command for more information).*

## Status Menu


The Status Menu (refer to Figure 13) reports actuator status, statistical information, and system configuration information.

Figure 13: Status Menu



## Actuator Status

Actuator Status reports (in a Return Status Window) the position of each of the four actuators (horizontal, vertical, extension, gripper) in the library. You can use this option to test for proper operation and tracking of each actuator.

 **CAUTION** *Perform a “Self Test All” and “Home All” before selecting “Actuator Status.” If you do not perform these functions, you may receive erroneous status information.*

To display the status of the actuators:

1. Highlight Status and press <ENTER>.
2. Highlight Actuator Status and press <ENTER>. The Return Status Window shows the position of every actuator in the library, pauses for four seconds, then updates the display with the current changes in the position of each actuator location. Press <END> to terminate the report.

## Report Statistics

This option displays a screen of statistical information that is stored in the non-volatile RAM on the library robotic controller. The information returned includes the total power-on hours (POH) for the library, the command time, the numbers of actuations for each of the axes, the numbers of picks and places into bins and drives, and the number and type of retries performed by the library to continue its operation.

To display the library statistics:

1. Highlight Status and press <ENTER>.
2. Select Report Statistics and press <ENTER>. The Return Status Window displays the statistics.

## Reset Statistics

This option resets the statistics table. It is a development tool and is not expected to be used for normal field service functions. When selected, the password must be entered before the function is executed.

## SysTest Info

This command will report pick/place information related to the last System Built-In Test.

## System Info

System Info reports the model number, current firmware revision and configuration of the library.

To display the system information for the library:

1. Highlight Status and press <ENTER>.
2. Select System Info and press <ENTER> to display the information in a Return Status Window.

## Error Description

This feature displays the description of the SCSI error code that you enter.

## Display Serial#

This menu selection will prompt the user to input a serial number then display it on the top line of the screen. This feature is most useful when more than one TAPELIB software is running on the same machine and the serial number is used to identify which library is under the software control.

Through this command, the user can enter the serial number of the library. This information is displayed next to the date on the Information Line.

To display the serial number:


1. Highlight Status and press <ENTER>.
2. Select Display Serial# and press <ENTER>. A pop-up window is displayed.
3. Enter the serial number of the library and press <ENTER>.



## Move Actuators Menu

The Move Actuators Menu (refer to Figure 14) provides you with the capability to test the library actuators and the tape drive insert/release handle (drive door) actuators, unload cartridges from the tape drives, move individual cartridges within the library, and read the bar code labels of individual cartridges.

Figure 14: Move Actuators Menu



## Self Test All

Self Test All sends a short electrical pulse to the extension axis, gripper, and drive door motors and then reads the encoder or sensor data associated with each motor. This operation is used to verify that these motors and their associated encoder or sensors respond as instructed.

To self test the motors in the system:

1. Highlight Move Actuators and press <ENTER>.
2. Highlight Self Test All and press <ENTER>.

## Home All

Home All returns all actuators to their home position.

To home all actuators:

1. Highlight Move Actuators and press <ENTER>.
2. Highlight Home All and press <ENTER>.

## Horizontal Axis

This option tests individual movements of the horizontal axis.

Table 5: Horizontal Axis  
Sub-Menu Functions

Option	Description
Self Test	Sends a short pulse to the horizontal drive motor and then reads the encoder information which comes back to verify that both the motor and encoder are working properly.
Home	Returns the horizontal axis to its home position.
Move To Bin	Moves the horizontal axis directly in front of a bin location (0-47) that you specify via a pop-up window.
Move To Drive	Moves the horizontal axis directly in front of the drive (0-3) that you specify via a pop-up window.
Move To Load Port	Moves the horizontal axis directly in front of the load port bin (0-3) that you specify via a pop-up window.
Move To Position	Moves the horizontal axis to a position relative to the home location. Enter a number (in the pop-up window) to specify the position. The position is specified in inches. A positive number moves the axis toward the rear of the library. A negative number moves the axis toward the front.

To actuate the horizontal axis:

1. Highlight Move Actuators and press <ENTER>.
2. Highlight Horizontal Axis and press <ENTER>.
3. Highlight the desired test and press <ENTER>. For a "Move to..." option, a pop-up window is displayed asking you to enter one of the following based on your selection:
  - Storage Bin: (0 to 47):
  - Drive Number: (0 to 3):
  - Load Port Bin: (0 to 3):
  - Position: (-1.600 to 20.250)

Enter the appropriate information and press <ENTER>.

## Vertical Axis

This option tests individual movements of the vertical axis.

Table 6: Vertical Axis  
Sub-Menu Functions

Option	Description
Self Test	Sends a short pulse to the vertical drive motor and then reads the encoder information which comes back to verify that both the motor and encoder are working properly.
Home	Returns the vertical axis to its home position.
Move To Drive	Moves the vertical axis directly in front of the drive (0-3) that you specify via a pop-up window.
Move To Position	Moves the vertical axis to a position relative to the home location. Enter a number (in the pop-up window) to specify the position. The position is specified in inches. A positive number moves the axis toward the top of the library. A negative number moves the axis toward the bottom.
Move To Bin	Moves the vertical axis directly in front of a bin location (0-15) that you specify via a pop-up window.
Move To Load Port	Moves the vertical axis directly in front of the load port bin (0-3) that you specify via a pop-up window.

To actuate the vertical axis:

1. Highlight Move Actuators and press <ENTER>.
2. Highlight Vertical Axis and press <ENTER>.
3. Highlight the desired test and press <ENTER>. For a "Move to..." option, a pop-up window is displayed asking you to enter one of the following based on your selection:
  - Drive Number: (0 to 3):
  - Position: (-1.800 to 25.300):
  - Bin# For Face: (0 to 15):
  - Load Port Bin: (0 to 3):

Enter the appropriate information and press <ENTER>.

## Extension Axis

Extension Axis tests individual movements of the extension axis.


Table 7: Extension Axis  
Sub-Menu Functions

Option	Description
Self Test	Actuates the extension drive motor and then reads the returned encoder, home sensor, home sensor interrupt, and current feedback information to verify that the motor, encoder, and other sensors are working properly.
Home	Returns the extension axis to its home position.
Move To Drive	Extension Axis Move To Drive is currently not supported.
Move To Load Port	Moves the extension axis directly in front of the load port bin (0-3) that you specify via a pop-up window.
Move To Position	Moves the extension axis to a position relative to the home location. Enter a number (in the pop-up window) to specify the position. The position is specified in inches. A positive number moves the axis toward the storage bins. A negative number moves the axis away from the storage bins.

To actuate the extension axis:

1. Highlight Move Actuators and press <ENTER>.
2. Highlight Extension Axis and press <ENTER>.
3. Highlight the desired test and press <ENTER>. For a “Move to...” option, a pop-up window is displayed asking you to enter one of the following based on your selection:
  - Drive Number: (0 to 3):
  - Load Port Bin: (0 to 3):
  - Position: (-0.400 to 5.000):

Enter the appropriate information and press <ENTER>.

 **CAUTION** *Before moving the extension axis to its furthest position (5.000), make sure that there are no obstructions in either the vertical or horizontal axis.*

## Gripper

This option tests individual movements of the gripper assembly.

---

Table 8: Gripper  
Sub-Menu Functions

Option	Description
Self Test	Opens and closes the gripper jaw to verify proper functioning of the motor and the gripper sensors.
Home	Returns the gripper to its home position; i.e., closes the gripper jaw.
Open	Opens the gripper jaw.
Close	Closes the gripper jaw.

To actuate the gripper:

1. Highlight Move Actuators and press <ENTER>.
2. Highlight Gripper and press <ENTER>.
3. Highlight the desired test and press <ENTER>.

## Drive Door

This option tests the stepper motors which control the tape drive insert/release handle (drive door).

---

Table 9: Drive Door  
Sub-Menu Functions

Option	Description
Self Test	Opens and closes the drive door to verify proper functioning of the stepper motor and sensor operation.
Home	Moves the drive door to the home position, i.e., closes the drive door.
Open	Opens the drive door to the raised position.
Close	Closes the drive door to the lowered position.

To actuate a tape drive door:

1. Highlight Move Actuators and press <ENTER>.
2. Highlight Drive Door and press <ENTER>. A pop-up window is displayed.
3. At the "Drive Number (0-3):" prompt enter the drive number and press <ENTER>.
4. Highlight the desired test and press <ENTER>.

## Load Port

This option allows you to pick and place cartridges from and to the load port bins.

---

Table 10: Load Port  
Sub-Menu Functions

Option	Description
Pick	This option allows you to pick a cartridge from a load port bin (0-3) that you specify via a pop-up window.
Place	This option allows you to place a cartridge into a load port bin (0-3) that you specify via a pop-up window.

To pick (place) cartridges from (to) the load port bins:

1. Highlight Move Actuators and press <ENTER>.
2. Highlight Load Port and press <ENTER>.
3. Highlight the desired Pick or Place test and press <ENTER>. A pop-up window is displayed. At the "Load Port Bin: (0 to 3):" prompt, enter the number of the bin that you want to pick (place) from (to) and press <ENTER>.



## Unload Tape

This option performs the same function as the TZ87, TZ88, or TZ89 tape drive control panel Unload switch on the tape drive (0-3) that you specify via a pop-up window. This option rewinds the cartridge to the beginning-of-tape. You may then eject the cartridge by actuating the drive door or pick the cartridge from the drive.

To unload a cartridge from the drive:

1. Highlight Move Actuators and press <ENTER>.
2. Highlight Unload Tape and press <ENTER>. A pop-up window is displayed.
3. At the "Drive Number: (0 to 3):" prompt, enter the number of the drive containing the cartridge to be rewound and press <ENTER>.

**Note** *When you execute this command, the tape will completely rewind. Depending on the tape position, it will take 10 to 120 seconds before the tape drive Operate Handle indicator lights.*

**Note** *If you want to manually eject the tape, wait two seconds after the Operate Handle indicator is on solid, then place your hand within and inch of the drive throat (to prevent the tape from ejecting too far which can cause a tape leader disconnect failure) and raise the tape drive handle. The tape will be ejected from the drive.*

## Move Cartridges

This option allows you to pick (place) cartridges from (to) storage and load port bins and tape drives. You can also use this test to read a bar code label from a cartridge in a specific location.

Before running this test, the library must have a current inventory of the cartridges. The gripper must be free before picking a cartridge from a bin or drive, and it must be gripping a cartridge before placing a cartridge into a bin or drive.

---

Table 11: Move Cartridges Sub-Menu Functions

Option	Description
Pick From Bin	This option allows you to pick a cartridge from a storage bin (0-47) that you specify via a pop-up window.
Pick From Load Port	This option allows you to pick a cartridge from a load port bin (0-3) that you specify via a pop-up window.
Pick From Drive	This option allows you to pick a cartridge from a tape drive (0-3) that you specify via a pop-up window.
Place Into Bin	This option allows you to place a cartridge into a storage bin (0-47) that you specify via a pop-up window.
Place Into Load Port	This option allows you to place a cartridge into a load port bin (0-3) that you specify via a pop-up window.
Place Into Drive	This option allows you to place a cartridge into a tape drive (0-3) that you specify via a pop-up window.
Bar Code - Bin	Reads the bar code of a cartridge located in a storage bin (0-47) that you specify via a pop-up window.
Bar Code - Drive	Reads the bar code of a cartridge located in a tape drive (0-3) that you specify via a pop-up window.
Bar Code - Load Port	Reads the bar code of a cartridge located in a load port bin (0-3) that you specify via a pop-up window.

## Picking a Cartridge

1. Highlight Move Actuators and press <ENTER>.
2. Highlight Move Cartridges and press <ENTER>.
3. Highlight Pick From Bin, Pick From Load Port, or Pick From Drive and press <ENTER>.

**Note** *There must be a cartridge in the source bin or drive that you select.*

4. For any selection, a pop-up window is displayed asking you to enter one of the following based on your selection in Step 3:
  - Storage Bin: (0 to 47):
  - Load Port Bin: (0 to 3):
  - Drive Number: (0 to 3):
5. Enter the appropriate information and press <ENTER>.

## Placing a Cartridge

1. Highlight Move Actuators and press <ENTER>.
2. Highlight Move Cartridges and press <ENTER>.
3. Highlight Place Into Bin, Place Into Load Port, or Place Into Drive and press <ENTER>.

**Note** *The destination bin or drive that you select must be empty.*

4. For any selection, a pop-up window is displayed asking you to enter one of the following based on your selection in Step 3:
  - Storage Bin: (0 to 47):
  - Load Port Bin: (0 to 3):
  - Drive Number: (0 to 3):
5. Enter the appropriate information and press <ENTER>.

## Reading the Bar Code Label of a Cartridge

1. Highlight Move Actuators and press <ENTER>.
2. Highlight Move Cartridges and press <ENTER>.
3. Highlight Bar Code - Bin, Bar Code - Drive, or Bar Code - Load Port and press <ENTER>.


**Note** *There must be a cartridge in the bin or drive that you select.*

4. For any selection, a pop-up window is displayed asking you to enter one of the following based on your selection in Step 3:
  - Storage Bin: (0 to 47):
  - Drive Number: (0 to 3):
  - Load Port Bin: (0 to 3):
5. Enter the appropriate information and press <ENTER>.
6. The bar code information is displayed in the Return Status Window.

## Align/Calibrate Menu

Calibration is the process of setting the horizontal, vertical, and extension location values for each bin location and each tape drive location within the library. The calibration values are stored in non-volatile RAM (NVRAM). Use the Align/Calibrate Menu (refer to Figure 15) to perform an automatic calibration on all bin and tape drive locations in the library, or to calibrate the storage bins, load port bins and drives individually. This menu also includes the option for setting and changing the SCSI addresses of the library and drives.

Figure 15: Align/Calibrate Menu



## Calibrate

This option allows you to calibrate the entire library automatically. [or calibrate the storage bins, load port bins, and tape drives individually.]

---

Table 12: Calibrate  
Sub-Menu Functions

Option	Description
All	Selecting this option calibrates the entire library.
Bin	Selecting this option calibrates the storage bins only.
Drive	Selecting this option calibrates the tape drives only.
Load Port	Selecting this option calibrates the load port bins only.

To auto-calibrate the library:

1. Highlight Align/Calibrate and press <ENTER>.
2. Highlight Calibrate and press <ENTER>.
3. Highlight the desired option and press <ENTER>.

## Library SCSI ID

This option allows you to set the SCSI ID (0-7) of the library. To perform this command.

To set the SCSI ID of the library:

1. Highlight Align/Calibrate and press <ENTER>.
2. Highlight Library SCSI ID and press <ENTER>. A pop-up window is displayed.
3. At the "SCSI Id: (0 to 7):" prompt, enter the number representing the library SCSI ID and press <ENTER>.

**Note** *After changing the SCSI address of the library, the host controller must issue a "SCSI Bus Reset" in order for the new SCSI ID to be set, or the library must be powered off and on again in order to reset the SCSI ID.*

## Report Lib. SCSI ID

When this option is selected, it returns the SCSI ID (0-7) in the Command Status Window.

To display the SCSI ID of the library:

1. Highlight Align/Calibrate and press <ENTER>.
2. Highlight Report Lib. SCSI ID and press <ENTER>.
3. The SCSI ID information is displayed in the Return Status Window.

## Tape Drive SCSI ID

This option allows you to set the SCSI ID (0-7 for libraries with TZ87N or TZ88N drives, and 0-15 for libraries with TZ89N drives) of each tape drive in the library. To set or change the SCSI ID of a drive:

1. Highlight Align/Calibrate and press <ENTER>.
2. Highlight Drive SCSI ID and press <ENTER>.
3. At the "Drive Number: (0 to 3):" prompt, enter the drive number and press <ENTER>.
4. At the "SCSI Id: (0 to 15):" prompt, enter the drive SCSI ID and press <ENTER>.

**Note** *The Reset Drive command must be performed for the new drive SCSI IDs to be set. Alternately, the host controller must issue a "SCSI Bus Reset" in order for the new SCSI IDs to be set, or the library must be powered off and on again in order to reset the SCSI ID. It is recommended that the Report Drive command be performed after the drives have been reset to verify that the SCSI IDs are set or changed as desired.*

## Reset Drive

The drive must be reset after you use the "Drive SCSI ID" command above. This command takes approximately 10 seconds to complete.

To reset a drive's SCSI ID:

1. Highlight Align/Calibrate and press <ENTER>.
2. Highlight Reset Drive and press <ENTER>.
3. At the "Drive Number: (0 to 3):" prompt, enter the drive number and press <ENTER>.



## Report Drive

Report Drive displays the configuration of each drive. The information that is reported includes the drive model, the drive and controller microcode revisions, the drive SCSI ID, and other information about the drive state.

To display the configuration of a drive:

1. Highlight Align/Calibrate and press <ENTER>.
2. Highlight Report Drive and press <ENTER>.
3. At the "Drive Number: (0 to 3):" prompt, enter the drive number and press <ENTER>. The data for the selected drive will be returned in a Return Status Window.

## Bin Position

Bin Position provides the capability to report or change the horizontal, vertical, and extension location values for each storage bin in the library.



*Changing the calibration values can result in degraded operation of the library. This option should only be used by trained FSEs.*

The storage bins are divided into six packs. Each pack is comprised of eight storage bin locations, which are numbered 0-7, 8-15, 16-23, 24-31, 32-39, and 40-47.

It is not possible to change any of the location values of one storage bin independently of all the other storage bins. Each bin location has the same horizontal and extension value as all other storage bins in a pack. Each bin location has a fixed vertical value relative to all other bin locations in that pack. When any storage bin location is changed, the values for all storage bin locations in that pack will be changed accordingly.

Table 13: Bin Position  
 Sub-Menu Functions

Option	Description
Current Vertical Pos	Updates the vertical location value for the specified bin with the “current” physical location of the vertical axis. When this option is highlighted, a “WARNING!” pop-up window is displayed. Enter Y and press <ENTER> to clear the warning. When cleared, enter the desired storage bin number and press <ENTER>.
Input Vertical Pos	Updates the vertical calibration value for the specified bin. Enter the desired storage bin number and the desired vertical calibration value.
Report Vertical Pos	Displays the current vertical calibration value for a specified bin. Enter the desired bin number, and the current vertical calibration value for that bin is displayed.
Current Extension Pos	Saves the current physical location of the extension axis as the calibration value for that storage bin.
Input Extension Pos	Updates the extension calibration value for the specified bin. Enter the desired storage bin number and the extension calibration value.
Report Extension Pos	Displays the current extension calibration value for a specified bin.
All-Current Hz. Pos	Updates the horizontal location values for all bins in the same column as the specified bin with the “current” physical location of the horizontal axis. The horizontal location values for bins in the other two columns are also updated so that the horizontal distance between the bins in adjacent columns is fixed at 4.600 inches.
All-Input Hz. Pos	Updates the horizontal calibration value for all bins in the same column as the specified bin. The horizontal location values in the other two columns are also updated so that the horizontal distance between the columns is fixed at 4.600 inches.
All-Report Hz. Pos	Displays the current horizontal calibration value for a specified bin. This command performs the same function as Pack-Report Hz. Pos
Pack-Current Hz. Pos	Updates the horizontal location values for all bins in the same pack as the specified bin with the “current” physical location of the horizontal axis. The horizontal location values for bins in the other packs remain unchanged.
Pack-Input Hz. Pos	Updates the horizontal calibration value for all bins in the same pack as the specified bin. The horizontal location values for bins in the other packs remain unchanged.
Pack-Report Hz. Pos	Displays the current horizontal calibration value for a specified bin. This command performs the same function as All-Report Hz. Pos

## Drive Position

Drive Position provides the capability to report or change the horizontal, vertical, and extension location values for each of the four tape drives in the library.

Table 14: Drive Position  
 Sub-Menu Functions

Option	Description
Current Vertical Pos	Current Vertical Pos updates the vertical location value for the specified drive with the "current" physical location of the vertical axis. When this option is highlighted, a "WARNING!" pop-up window is displayed. Enter Y and press <ENTER> to clear the warning. When cleared, enter the desired drive number and press <ENTER>.
Input Vertical Pos	Input Vertical Pos updates the vertical calibration value for the specified drive. Enter the desired drive number and the desired vertical calibration value.
Report Vertical Pos	Report Vertical Pos displays the current vertical calibration value for a specified drive. Enter the desired drive number, and the current vertical calibration value for that drive is displayed.
Current Extension Pos	Current Extension Pos saves the current physical location of the extension axis as the calibration value for that drive.
Input Extension Pos	Input Extension Pos updates the extension calibration value for the specified drive. Enter the desired drive number and the desired extension calibration value.
Report Extension Pos	Report Extension Pos displays the current extension calibration value for a specified drive.
Current Horiz. Pos	Current Horiz. Pos updates the horizontal location value for the selected drive with the "current" physical location of the horizontal axis.
Input Horiz. Pos	Input Horiz. Pos updates the horizontal calibration value for the selected drive with the input value.
Report Horiz. Pos	Report Horiz. Pos displays the current horizontal calibration value for a specified drive.

## Load Port Position

Load Port Position provides the capability to report or change the horizontal, vertical, and extension location values for the four load port bins in the library.

---

Table 15: Load Port Position Sub-Menu Functions


Option	Description
Current Vertical Pos	Current Vertical Pos updates the vertical location value for the specified load port bin with the “current” physical location of the vertical axis. When this option is highlighted, a “WARNING!” pop-up window is displayed. Enter Y and press <ENTER> to clear the warning. When cleared, enter the desired load port bin number and press <ENTER>.
Input Vertical Pos	Input Vertical Pos updates the vertical calibration value for the specified load port bin. Enter the desired load port bin number and the desired vertical calibration value.
Report Vertical Pos	Report Vertical Pos displays the current vertical calibration value for a specified load port bin. Enter the desired load port bin number, and the current vertical calibration value for that load port bin is displayed.
Current Extension Pos	Current Extension Pos saves the current physical location of the extension axis as the calibration value for that load port bin.
Input Extension Pos	Input Extension Pos updates the extension calibration value for the specified load port bin. Enter the desired load port bin number and the desired extension calibration value.
Report Extension Pos	Report Extension Pos displays the current extension calibration value for a specified load port bin.
Current Horiz. Pos	Current Horiz. Pos updates the horizontal location value for the selected load port bin with the “current” physical location of the horizontal axis.
Input Horiz. Pos	Input Horiz. Pos updates the horizontal calibration value for the selected load port bin with the input value.
Report Horiz. Pos	Report Horiz. Pos displays the current horizontal calibration value for a specified load port bin.

## Config Menu

The Config Menu (refer to Figure 16) provides the capability to:

- Set or display the overall library configuration
- Initialize an inventory sequence and NVRAM
- Enable/disable recovery and auto-recovery options
- Perform an automatic inventory
- Disable the bar code scanner
- Enable/disable the tape cleaning feature
- Perform a flash download

Figure 16: Configuration Menu



Select an item by either using the  $\uparrow$  and  $\downarrow$  keys to scroll through the options or by entering the key letter located to the right of the option. Once the option is highlighted, press  $\langle$ ENTER $\rangle$  to execute the selection.

## Configure System

This option allows you to configure your library. The program prompts you to enter the model number, number of bins, etc.

To configure the library:

1. Highlight Config and press <ENTER>.
2. Highlight Configure System and press <ENTER>. A pop-up window is displayed.
3. From the list of available Model Numbers, select the appropriate model number and press <ENTER>. Refer to Table 16 below for the appropriate information for the desired library configuration and Inquiry Data response.

---

Table 16: TL81X/TL894  
Configuration Matrix

Library Model Number	Inquiry Data	Configuration Model Number
TL810-XX	TL810 (C) DEC	6210040
TL812-XX	TL810 (C) DEC	6210040
TL812-XX	TL812 (C) DEC	6210060
TL894-XX	TL810 (C) DEC	6210040
TL894-XX	TL894 (C) DEC	6210080

**Note** *To configure the library as 6210060 or 6210080, it is necessary to have Version 3.04 or later of the Diagnostic Software Package. Also, the 6210060 and 6210080 library configuration options are not supported by library firmware revision 1.20 or earlier revisions.*

4. Enter 48 as the number of bins and press <ENTER>.
5. Enter the number of drives in the library and press <ENTER>.

**Note** *If fewer than four (4) drives are used in the library, then the drives must be located in the top drive positions, starting with Drive 0. For example, if only three (3) drives are available to be used in the library, then those three drives must be located at the Drive 0, Drive 1, and Drive 2 positions. The bottom drive position (Drive 3 position) will be unused.*

6. Enter the desired SCSI ID of the library and press <ENTER>.

## Report System

Report System displays the current library configuration, including model number, number of bins, number of drives, and the library SCSI ID.

To display the current library configuration:

1. Highlight Config and press <ENTER>.
2. Highlight Report System and press <ENTER>.
3. The information is displayed in a Return Status Window.

## Init Inventory

Initialize Inventory starts a cartridge inventory sequence that scans the cartridges in the storage bins, the load port bins, and the tape drives, and then records the location and identity of all bar code labeled cartridges. If all bins in the library are filled with bar code labeled cartridges, the entire inventory sequence takes approximately three (3) minutes.

To initialize the inventory of the cartridges in the library:

1. Highlight Config and press <ENTER>.
2. Highlight Init Inventory and press <ENTER>.

## Init Non-Vol RAM

Use this option to initialize or reset Non-Vol RAM.

**Note** *The calibration values are kept in Non-Vol RAM on the robotic controller board. If a new robotic controller board is installed in the library, it is recommended that Non-Vol RAM be initialized before performing the calibration procedures.*

To initialize the Non-Vol RAM:

1. Highlight Config and press <ENTER>.
2. Highlight Init Non-Vol RAM and press <ENTER>. A pop-up window is displayed.
3. At the prompt, enter: Y and press <ENTER>.

## Recovery

Use this option to enable/disable recovery. When recovery is enabled, the library will attempt to recover from internal anomalies to complete a command sent from the diagnostic PC (or host).

**Note** *The enable/disable recovery switch should remain enabled except when trouble shooting a problem.*

To enable recovery:

1. Highlight Config and press <ENTER>.
2. Highlight Recovery and press <ENTER>.
3. Highlight Enable and press <ENTER>.

## Exabyte

Use this option to enable the system to emulate an Exabyte Command Set. To emulate an Exabyte Command Set:

1. Highlight Config and press <ENTER>.
2. Highlight Exabyte and press <ENTER>.
3. Highlight Enable and press <ENTER>.

## No Bar Code

If your cartridges do not have bar codes, use this option to provide the system with this information in order to deactivate the bar code scanner and speed up the inventory process.

To tell the system that your cartridges do not have bar codes:

1. Highlight Config and press <ENTER>.
2. Highlight No Bar Code and press <ENTER>.
3. Highlight Enable and press <ENTER>.

## Clean Tape

Use this option to enable, disable, and report on, the auto cleaning function. This option also allows you to initialize auto-cleaning default values.

The sub-options under this option are described below.



## Enable Clean Tape

Use this sub-option to enable auto-cleaning.

**Note** *Enabling or disabling auto-cleaning through the diagnostic software is temporary. When library power is cycled, the auto-cleaning mode will revert back to the last state selected by the host controller via the "Mode Select" command. Libraries are shipped from the factory with auto-cleaning disabled.*

## Disable Clean Tape

Use this sub-option to disable auto-cleaning.

## Report Clean Tape

This sub-option provides information indicating whether cleaning is enabled or disabled. It also provides the status of each drive, i.e., whether cleaning is needed or not, and shows the bin location and number of uses for each cleaning cartridge in the library.

## Initialize Clean Data

Use this sub-option to initialize auto-cleaning default values after installation of the support hardware and before enabling the auto-clean option.

## Flash Download

The Flash Download option allows you to download a new version of library robotics firmware. The new version remains active in the system until a another new version of firmware is flash downloaded.

To use the Flash Download option, do the following:

**Note** *The hex file for downloading (ex: S6211250.HEX) must be copied into the same directory as "TAPELIB."*




*Do not attempt Flash Download when running diagnostics from a Windows (3.1/95/NT) environment (or from a DOS window with Windows still running). Shut down Windows and run the Diagnostic Software Program from a DOS environment. Because of timing issues, attempts to Flash Download with Windows running may fail and leave the library inoperable.*

1. Press the control panel STANDBY button and verify that System Off-Line is displayed in the SDA.
2. In the Diagnostic Software highlight Config and press <ENTER>.
3. Highlight Flash Download and press <ENTER>.

4. Select the appropriate firmware option from the Flash Download sub-menu and press <ENTER>. (A "WARNING" pop-up window is displayed.)
5. At the Y/N (Yes/No) prompt, enter <Y><ENTER> to clear the warning. This will start downloading the selected HEX file to initialize your firmware.
6. Flash download takes 10 to 15 minutes to complete. Figure 17 shows the screen after flash download has completed.

Figure 17: Flash Download



7. When flash download has completed, cycle power on the library.
8. Perform a Calibrate All process from the Align/Calibrate menu.
9. Test the library for proper operation.

**Note** *When a failure occurs during Flash Download there will not be a valid executable application program in the flash memory. The diagnostic software will restart in simulation mode, but you can still perform a Flash Download in this mode. When the simulation mode menu is displayed, select the correct configuration options and proceed with the flash download as normal.*

# Glossary

TL810 library	The automated storage and retrieval component of a tape library system used for storing and handling DLT™ cartridges. This library utilizes the TZ87 DLT™ tape drives.
TL812 library	The automated storage and retrieval component of a tape library system used for storing and handling DLT™ cartridges. This library utilizes the TZ88 DLT™ tape drives.
TL894 library	The automated storage and retrieval component of a tape library system used for storing and handling DLT™ cartridges. This library utilizes the TZ89 DLT™ tape drives.
actuators	Robotic components that move cartridges, including the gripper, extension axis, vertical axis, and horizontal axis.
automated tape library	A robotic storage and retrieval system for DLT™ cartridges.
bar code label	The identification label on DLT™ cartridges.
bar code scanner	Electronic device that reads the cartridge bar code labels.
calibration	The process of identifying the vertical and horizontal position of storage locations within the library.
control panel	The panel on the front of the library that contains the Status Display Area, as well as indicators and control switches.
DLT™	Digital Linear Tape
EIA/TIA-574	A serial communications cabling and protocol standard for nine-pin connectors, sometimes referred to as RS-232.
extension axis assembly	Mounted onto the vertical axis, the extension axis assembly consists of the gripper assembly and the lateral axis on which the gripper assembly is mounted.
extension axis belt	The drive belt connecting the extension motor/gearbox to the gripper.
FCC Class A	Standard established by the U.S. Federal Communications Commission governing electromagnetic emissions.
FSE	Field Service Engineer
gripper assembly	The assembly that mounts on the extension axis and grips cartridges; referred to as the gripper.

horizontal belt	The drive belt connecting the horizontal motor to the horizontal axis assembly.
host	Host Computer
host computer	The computer that issues SCSI commands to control the library robotics.
LCD	Liquid Crystal Display
Load Port	The component of the library that allows cartridges to be loaded and unloaded.
MSBF	Mean Swaps Between Failures
MTBF	Mean Time Between Failures
MTTR	Mean Time To Repair
NVRAM	Non-Volatile RAM
on-line	Ready for communications with a host.
PC	Personal Computer
pick	The act of removing a cartridge from one location in preparation for placing it in another location.
place	The act of placing a cartridge in a location after it has been picked from another location.
PROM	Programmable Read-Only Memory
RAM	Random Access Memory
rear panel	The panel that contains the power switch and connectors for attaching external cabling to the library.
SCSI	Small Computer System Interface communications standard for attaching peripheral equipment to computers.
SDA	Status Display Area
tape drive	The mechanism that reads and writes data from and to a tape.
UL	Underwriters Laboratories
vertical belt	The drive belt connecting the vertical motor to the vertical axis assembly.
vertical carriage assembly	The crossbar and linear bearings mounted on the vertical rails and all components mounted on the crossbar.
ZIF connector	Zero Insertion Force connector

# Index

## A

- align/calibrate menu 4-33
  - calibrate library 4-34
  - drive position 4-39
  - load port bin position 4-40
  - report drive status 4-37
  - reporting library SCSI ID 4-35
  - resetting drive SCSI ID 4-36
  - setting drive SCSI ID 4-36
  - setting library SCSI ID 4-35
  - storage bin position 4-37
- auto-cleaning
  - disabling 4-45
  - enabling 4-45
- autoexec.bat 2-4

## B

- bin position, storage 4-37
  - current position 4-38
  - input position 4-38
  - numbering 3-10
  - report position 4-38

## C

- command status window 3-8
- config menu 4-41
  - configure system 4-42
  - disable clean tape 4-45
  - enable clean tape 4-45
  - enable recover 4-44
  - init inventory 4-43
  - initialize clean data 4-45
  - initialize non-vol RAM 4-43
  - report clean tape 4-45
  - report system configuration 4-43
- configure system 4-42
  - library SCSI ID 4-42
  - model number 4-42
  - number of drives 4-42
  - number of storage bins 4-42
- conventions 1-3

## D

- DIAG port 2-4
- diagnostic PC 2-4
- diagnostic software
  - disk space requirements 2-3
  - installation 2-3
  - starting 2-6
  - stopping 2-9
- documentation, reference 1-4
- drive door
  - close 4-27
  - home 4-27
  - open 4-27
  - self-test 4-27
- drive position 4-39
  - current position 4-39
  - input position 4-39
  - numbering 3-10
  - report position 4-39

## E

- error messages 2-9
- extension axis
  - exercise 4-14
  - home 4-25
  - move to drive 4-25
  - move to load port bin 4-25
  - move to position 4-25
  - self-test 4-25

## F

- flash download 4-45
- function and control keys 3-9

## G

- gripper
  - close 4-26
  - exercise 4-14
  - home 4-26
  - open 4-26

self-test 4-26

## H

help 2-8

horizontal axis

exercise 4-13

home 4-23

move to drive 4-23

move to load port bin 4-23

move to position 4-23

move to storage bin 4-23

self-test 4-23

## I

INSTALL.BAT 2-3

installation, diagnostic software 2-3

## L

load port

pick cartridge from 4-28

place cartridge to 4-28

load port bin position 4-40

current position 4-40

input position 4-40

numbering 3-10

report position 4-40

## M

main menu 4-4-4-5

main menu screen 3-4

model number 4-42

move actuators menu 4-21

drive door 4-27

extension axis 4-25

gripper 4-26

home all 4-22

horizontal axis 4-23

load port 4-28

move cartridges 4-30

self test all 4-22

unload tape 4-29

vertical axis 4-24

move cartridges

picking a cartridge 4-30, 4-31

placing a cartridge 4-30, 4-31

reading a bar code label 4-30, 4-32

## N

numbering

load port bins 3-10

storage bins 3-10

tape drives 3-10

## O

on-line error messages 2-9

on-line help 2-8

## P

pop-up windows 3-6

PP.TST 4-10

pull-down menus 3-5

## R

README.DOC 2-3

return status window 3-7

## S

SCSI ID

reporting drive 4-37

reporting library 4-35

resetting drive 4-36

setting drive 4-36

setting library 4-35

status menu

actuator status 4-19

display serial number 4-20

report statistics 4-19

reset statistics 4-19

system info 4-20

sub-menus 3-6  
system tests menu 4-12

- exercise extension 4-14
- exercise gripper 4-14
- exercise horizontal 4-13
- exercise vertical 4-13
- loop mode 4-13
- pick/place all 4-14

## T

TAPELIB directory 2-3  
TAPELIB.BAT 2-3  
TAPELIB.EXE 2-3  
TAPELIB.HLP 2-3  
TAPELIB.MSG 2-3  
TAPELIB.NDX 2-3

## U

user tests menu 4-6

- loop mode 4-7
- pick and place test 4-10
- PP.TST 4-10
- track mode 4-8
- user input command 4-9
- user-defined tests 4-11

## V

vertical axis

- exercise 4-13
- home 4-24
- move to drive 4-24
- move to load port bin 4-24
- move to position 4-24
- move to storage bin 4-24
- self-test 4-24

