

Distributed Routing Software

Quick Reference Guide

Part Number: AA-R7QAA-TE

December 1997

This manual provides quick reference information about installing, configuring, and operating the Distributed Routing Software system software.

Revision/Update Information: This is a new manual.
Software Version: Distributed Routing Software V3.0

**Digital Equipment Corporation
Maynard, Massachusetts**

Digital Equipment Corporation makes no representations that the use of its products in the manner described in this publication will not infringe on existing or future patent rights, nor do the descriptions contained in this publication imply the granting of licenses to make, use, or sell equipment or software in accordance with the description.

Possession, use, or copying of the software described in this publication is authorized only pursuant to a valid written license from DIGITAL or an authorized sublicensor.

© DIGITAL Equipment Corporation 1997
All Rights Reserved.
Printed in U.S.A.

The following are trademarks of DIGITAL Equipment Corporation: DEC, DECnet, DECswitch, DIGITAL, OpenVMS, PATHWORKS, RouteAbout, ThinWire, VAX, VAXcluster, VMS, VT, and the DIGITAL logo.

The following are third-party trademarks:

Apollo is a registered trademark of Apollo Computer, Inc., a subsidiary of Hewlett-Packard Company.

AppleTalk, EtherTalk, and LocalTalk are registered trademarks of Apple Computer, Inc.

Banyan and Vines are registered trademarks of Banyan Systems, Inc.

BSD is a trademark of the University of California, Berkeley, CA.

IBM is a registered trademark of International Business Machines Corporation.

Intel is a registered trademark of Intel Corporation.

Lotus Notes is a registered trademark of Lotus Development Corporation.

MS-DOS and Windows 95 are registered trademarks, and Windows NT is a trademark of Microsoft Corporation.

NetBIOS is a trademark of Micro Computer Systems, Inc.

NetWare and Novell are registered trademarks of Novell, Inc.

Proteon, ProNET, and TokenVIEW are registered trademarks of Proteon, Inc.

UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Ltd.

All other trademarks and registered trademarks are the property of their respective holders.

This manual was produced by DIGITAL Information Design.

Contents

Finding What You Need	vii
Accessing the CONFIG Process	viii
Accessing the CGWCON Process	viii
AppleTalk Phase 1	1
AppleTalk Phase 1 Configuration Commands	2
AppleTalk Phase 1 Console Commands	3
Further Configuration Considerations	3
AppleTalk Phase 2	5
AppleTalk Phase 2 Configuration Commands	6
AppleTalk Phase 2 Console Commands	8
Further Configuration Considerations	8
Border Gateway Protocol 4 (BGP4)	9
BGP4 Configuration Commands	10
BGP4 Console Commands	11
Dial Circuits	13
Dial Circuit Configuration Commands	14
Frame Relay	15
Frame Relay Configuration Commands	17
Frame Relay Console Commands	19
Frame Relay SVC Configuration Commands	20
Frame Relay LAPF Configuration Commands	21
IP	23
IP Configuration Commands	24
IP Console Commands	28

IPX	29
IPX Configuration Commands	31
IPX Console Commands	33
ISDN	35
ISDN Configuration Commands	36
ISDN Console Commands	37
PRI Line Configuration Commands	38
PRI Line Console Commands	38
OSI/DNA V	39
OSI/DNA V Configuration Commands	41
OSI/DNA V Console Commands	43
Protocol Independent Multicast (PIM)	45
PIM Configuration Commands	46
PIM Console Commands	47
Point-to-Point Protocol (PPP)	49
PPP Interface Configuration Commands	50
PPP Interface Console Commands	52
PPP Multilink Link Circuit Configuration Commands	54
Multilink PPP Link Circuit Console Commands	54
SDLC Relay	55
SDLC Relay Protocol Configuration Commands	56
SDLC Relay Protocol Console Commands	57
SDLC Relay Interface Configuration Commands	57
SNMP	59
SNMP Configuration Commands	60
SNMP Console Commands	61
V.25 bis	63
V.25 bis Configuration Commands	64
V.25 bis Console Commands	64
WAN-Restoral and WAN-Reroute	65
WAN-Restoral and WAN-Reroute Configuration Commands	67
WAN-Restoral and WAN-Reroute Console Commands	68

X.25	69
X.25 Interface Configuration Commands	70
X.25 Interface Console Commands	75
X.25-LLC2	77
X.25-LLC2 Pseudo-Interface Configuration Commands	78
X.25-LLC2 Pseudo-Interface Console Commands	82
X.25 Switching Feature	83
X.25 Switching Feature Configuration Commands	84
X.25 Switching Feature Console Commands	85

Finding What You Need

This book

THIS is a quick reference guide to configuring and monitoring the main routing protocols and interfaces available with DIGITAL Distributed Routing Software.

The protocols and interfaces are in alphabetical order, from AppleTalk to X.25.

For each protocol or interface, we give you:

- A flowchart which shows the basic configuration procedure for that protocol or interface. Depending on your network, you will probably need to do more configuration than is shown here.
- A summary of the configuration commands.
- A summary of the console commands.

Overleaf, there is a summary of how to access the CONFIG and CGWCON processes, for configuration and console tasks.

The protocols and interfaces

AppleTalk Phase 1

AppleTalk Phase 2

Border Gateway Protocol 4 (BGP4)

Dial Circuits

Frame Relay

IP

IPX

ISDN

OSI/DNA V

Protocol Independent Multicast (PIM)

Point-to-Point Protocol (PPP)

SDLC Relay

SNMP

V.25 bis

WAN-Restoral and WAN-Reroute

X.25

X.25-LLC2

X.25 Switching Feature

Accessing the CONFIG Process

1 After the router boots, the console displays the OPCON prompt (*). Enter **status** to display the process ID (pid) of CONFIG, which is usually 6.

2 Enter **talk** and the pid (6) for CONFIG. This displays the following information:

```
* t 6
Gateway user configuration
Config>
```

If the Config> prompt does not appear, press RETURN again. You can now enter the configuration commands.

3 When you are done entering the configuration commands, do the following to make the new configuration active:

a Press **Ctrl/P** after the prompt:

```
Config> ^P
*
```

b Enter **restart** after the OPCON prompt (*).

c Respond **yes** to the following prompt:

```
Are you sure you want to restart the gateway?
```

The new configuration is loaded when the console displays the following information:

```
Copyright 1995-1996 Digital Equipment Corp.
```

```
MOS Operator Control
```

```
*
```

Accessing the CGWCON Process

Use the CGWCON process (also known as GWCON) to monitor protocols, network interfaces, and system messages. You cannot access the CGWCON process if the router is in configuration-only mode (the prompt is Config only>). To display the CGWCON prompt (+):

1 After the router boots, the console displays the OPCON prompt (*). Enter **status** to display the process ID (pid) of CGWCON.

2 Enter **talk** and the pid for CGWCON (usually 5). This displays the CGWCON prompt (+). You can now enter the monitoring commands.

```
* t 5
CGW Operator Console
+
```

3 To return to the * prompt, press **Ctrl/P**.

AppleTalk Phase 1

Access the Appletalk Phase 1 configuration process from the Config> prompt.
Syntax: **p apl**
All commands are now entered from the APL config> prompt.

Enable Appletalk Phase 1.
Syntax: **en a**

Enable interfaces running AppleTalk Phase 1.
Syntax: **e i interface#**

Enable checksumming.
Syntax: **en c**

Set the AppleTalk network numbers (entered separately for each network).
Syntax: **s ne interface# AppleTalk-net#**

Set node addresses (entered separately for each network).
Syntax: **s no interface# node#**

Set AppleTalk zone names (entered separately for each network).
Syntax: **s z interface# name**

Set routing table size.
Syntax: **s nn #-of-networks**

Configure any other protocols for your router by returning to the Config> prompt. If all protocols are configured, do the following:

1. Enter **exit** at the APL config> prompt.
2. Press **Ctrl/P** to display the OPCON prompt (*).
3. Enter **restart** and respond **yes** to the prompt.

AppleTalk Phase 1 Configuration Commands

Enter the following configuration commands at the APL config> prompt. To list the configuration commands and their options, enter a ?.

After you have configured all of the protocols, enter **restart** at the OPCON prompt (*), and respond **yes** after the following prompt:

Are you sure you want to restart the router?

disable

apl

Disables the AppleTalk Phase 1 protocol as a whole.

checksum

Disables checksumming on packets that the specified interface generates.

interface *interface#*

Disables AppleTalk Phase 1 on the specified interface.

takedown

Prevents ZIP takedown and bringup packets from affecting the routers network numbers and zone names. This is the default for security reasons.

enable

apl

Enables the AppleTalk Phase 1 packet forwarder.

checksum

Enables checksumming on packets that the specified interface generates.

interface *interface#*

Enables AppleTalk Phase 1 on the specified interface.

takedown

Allows any node to use ZIP takedown and bringup packets to change the routers network numbers and zone names.

list

Displays the current AppleTalk Phase 1 configuration.

set

ddp-header *long interface#*

Specifies long DDP headers for packets sent on that interface number. This is the default, and is recommended by Apple.

ddp-header *short interface#*

Specifies short DDP headers for packets sent on that interface number. Use this only for compatibility with software that does not support long DDP headers.

net-number *interface# AppleTalk Phase 1-net#*

Assigns an AppleTalk Phase 1 network number to the associated directly connected network.

node-number *interface# node#*

Specifies the number of the interface. This is optional. The default is autoconfigure.

nnets#

Specifies the size of the AppleTalk Phase 1 routing table.

zone *interface# name*

Specifies the zone name to be seeded on this network.

exit

Returns to the previous prompt level.

AppleTalk Phase 1 Console Commands

Enter these commands after the APL> prompt.

To list the AppleTalk Phase 1 console commands and their options, enter a ? after the APL> prompt.

counters

Displays the number of packet overflows on each network that sends and receives AppleTalk Phase 1 packets.

dump

Displays the routing table information about the interfaces on the router that forwards AppleTalk Phase 1 packets.

- *dest net*
The destination network number in decimal.
- *cost*
The number of route hops to this destination network.
- *state*
The state of the entry in the routing table.

- *next hop*
The next hop for packets going to networks that are not directly connected. For directly connected networks, this is node number 0.
- *source*
The originating network type for that routing table entry. *APL* indicates an AppleTalkPhase 1 network. *AP2* indicates an AppleTalk Phase II.
- *zone*
Specifies the name for that network. The zone name is enclosed in double quotes in case there are embedded spaces or nonprinting characters.

interface

Displays the addresses of all the interfaces in the router on which AppleTalk Phase 1 is enabled.

exit

Returns to the previous prompt level

Further Configuration Considerations

To allow Phase1 hosts to transparently communicate with Phase 2 hosts, you must enter the AppleTalk Phase 2 configuration process on the router running AP2 and enable the AppleTalk Phase 1/2 translation function via that router's AP2 **enable translation** configuration command.

In addition to providing the gateway translation function, this router now acts as both a Phase1 and Phase 2 router on whatever interfaces these protocols are configured. Routing information is passed between Phase 1 and Phase 2 networks by the gateway resulting in a (logically) single internet.

For more information on the **enable translation** command and AppleTalk Phase 2, refer to the chapter "Configuring AppleTalk Phase 1" in the *Routing Protocols User's Guide*.

AppleTalk Phase 2

Access the AppleTalk Phase 2 configuration process from the Config> prompt.

Syntax: **p ap2**

All commands are now entered from the AP2 config> prompt.

Enable AppleTalk Phase 2.

Syntax: **en a**

Enable interfaces running AppleTalk Phase 2.

Syntax: **e i interface#**

Enable the newtwork range for seed routers (entered separately for each network).

Syntax: **s net interface# start# end#**

Set the starting node number (entered separately for each network).

Syntax: **s no interface# node#**

Add AppleTalk zone names (entered separately for each network).

Syntax: **a z interface# name**

Enable AppleTalk Phase 1/2 gateway translation for interoperability with Phase 1 networks (if necessary).

Syntax: **en t**

Configure any other protocols for your router by returning to the Config> prompt. If all protocols are configured, do the following:

1. Enter **exit** at the AP2 config> prompt.
2. Press **Ctrl/P** to display the OPCON prompt (*).
3. Enter **restart** and respond **yes** to the prompt.

AppleTalk Phase 2 Configuration Commands

Enter the following configuration commands at the AP2 config> prompt. To list the configuration commands and their options, enter a ?.

After you have configured all of the protocols, enter **restart** at the OPCON prompt (*), and respond **yes** after the following prompt:

Are you sure you want to restart the router?

add

defaultzone *interface# zonenumber*

Adds the zone name to the interface zone list as the default for the interface.

ip-tunnel-address *address* DEC

Adds an IP tunnel endpoint at *address* (*n.n.n.n*, each *n* a decimal integer). DEC specifies encapsulation.

nfilter in *interface# first-network# last-network#*

Adds a network filter to the input of the interface. The network range must match that of the interface.

nfilter out *interface# first-network# last-network#*

Adds a network filter to the output of the interface. The network range must match that of the interface.

zfilter in *interface# zonenumber*

Adds a zone name filter to the input of the interface.

zfilter out *interface# zonenumber*

Adds a zone name filter to the output of the interface.

zone *interface# zonenumber*

Adds the zone name to the interface zone list.

delete

interface *interface#*

Deletes the AppleTalk 2 interface.

ip-tunnel-address *address*

Deletes the IP-tunnel endpoint at *address*.

nfilter in *interface# first-network# last-network#*

Deletes a network filter from the input of the interface.

nfilter out *interface# first-network# last-network#*

Deletes a network filter from the output of the interface.

zfilter in *interface# zonenumber*

Deletes a zone name filter from the input of the interface.

zfilter out *interface# zonenumber*

Deletes a zone name filter from the output of the interface.

zone *interface# zonenumber*

Deletes a zone name from the interface zone list.

disable

ap2

Disables the AppleTalk Phase 2 packet forwarder as a whole.

checksum

Disables checksumming on packets that the specified interface generates.

interface *interface#*

Disables AppleTalk Phase 2 functions on the specified interface.

ip-tunnel

Disables IP tunneling.

split-horizon-routing *interface#*

Disables split horizon routing on the specified interface.

translation

Disables the translation process that allows Phase 2 hosts to transparently communicate with Phase 1 hosts.

nfilter in *interface#*

Disables, but does not delete, the input network filters on this interface.

nfilter out *interface#*

Disables, but does not delete, the output network filters on this interface.

zfilter in *interface# zonename*

Disables, but does not delete, the input zone filters on this interface.

zfilter out *interface# zonename*

Disables, but does not delete, the output zone filters on this interface.

enable

ap2

Enables the AppleTalk Phase 2 packet forwarder as a whole.

checksum

Enables checksumming on packets that the specified interface generates.

interface *interface#*

Enables AppleTalk Phase 2 functions on the specified interface.

ip-tunnel

Enables IP tunneling.

split-horizon-routing *interface#*

Enables split horizon routing on the specified interface.

translation

Enables the translation process that allows Phase 2 hosts to transparently communicate with Phase 1 hosts.

nfilter in *interface# inclusive/exclusive*

Enables network input filters and controls how the filter is applied to the interface. Inclusive forwards matches. Exclusive drops matches.

nfilter out *interface# inclusive/exclusive*

Enables network output filters and controls how the filter is applied to the interface. Inclusive forwards matches. Exclusive drops matches.

zfilter in *interface# zonename inclusive/exclusive*

Enables and controls how the zone input filter is applied to the interface. Inclusive forwards matches. Exclusive drops matches.

zfilter out *interface# zonename inclusive/exclusive*

Enables and controls how the zone output filter is applied to the interface. Inclusive forwards matches. Exclusive drops matches.

list

Displays the current AppleTalk Phase 2 configuration.

- *AP2 globally*
Indicates whether AppleTalk Phase 2 is globally enabled or disabled.
- *AP2 IP tunnek*
Indicates whether AppleTalk Phase 2 IP tunnel is globally enabled or disabled.
- *checksumming*
Indicates whether checksum is enabled or disabled.
- *translation gateway*
Indicates whether the AppleTalk Phase 1/Phase2 translation is globally enabled or disabled.
- *configured interfaces*
Lists each interface number and its associated net range, node number, and zone and multi-zone names, as well as the default zone. The zone name is enclosed in double quotes in case there are embedded spaces or nonprinting characters.

set

netrange *interface# start# end#*

Assigns the network range in seed routers.

node *interface# node#*

Specifies short DDP headers for packets sent on that interface number. Use this only for compatibility with software that does not support long DDP headers.

exit

Returns to the previous prompt level.

AppleTalk Phase 2 Console Commands

Enter these commands after the AP2> prompt.

To list the AppleTalk Phase 2 console commands and their options, enter a ? after the AP2> prompt.

counters

Displays the number of packet overflows on each network (interface) that sends and receives AppleTalk Phase 2 packets.

dump

Displays the routing table information about the interfaces on the router that forwards AppleTalk Phase 2 packets.

- *dest net*
Specifies the destination network number in decimal.
- *cost*
Specifies the number of router hops to this destination network.

- *state*
Specifies the state of the entry in the routing table.
- *next hop*
Specifies the next hop for packets going to networks that are not directly connected. For directly connected networks, this is node number 0.
- *zone(s)*
Specifies the user-assigned name for that network. The zonename(s) is enclosed in double quotes in case there are embedded spaces or nonprinting characters.

interface

Displays the addresses of all the interfaces in the router on which AppleTalk Phase 2 is enabled.

exit

Returns to the previous prompt level.

Further Configuration Considerations

To allow Phase 1 hosts to transparently communicate with Phase 2 hosts, you must enter the AppleTalk Phase 2 configuration process on the router running AP2 and enable the AppleTalk Phase 1/2 translation function via that router's AP2 **enable translation** configuration command.

In addition to providing the gateway translation function, this router now acts as both a Phase 1 and Phase 2 router on whatever interfaces these protocols are configured. Routing information is passed between Phase 1 and Phase 2 networks by the gateway resulting in a (logically) single internet.

For more information on the enable translation command and AppleTalk Phase 2, refer to the chapter "Configuring and Monitoring AppleTalk Phase 2" in the *Routing Protocols User's Guide*.



Border Gateway Protocol 4 (BGP4)

Access the BGP configuration module from the Config> prompt.

Syntax:

p bgp

All commands are now entered from the BGP Config> prompt.

Enable BGP speaker:

Syntax:

en bgp
AS [0]? **125**
TCP segment size [1024]?

The AS number identifies the speaker's autonomous system. The TCP segment size represents the maximum segment size BGP uses for passive TCP connections.

Define BGP neighbors. Neighbors either have a direct connection to the speaker, or have an indirect connection within the speaker's AS.

Syntax:

add neighbor 192.18.32.12

Adding a neighbor automatically enables it, causing the speaker to send the neighbor a connection request.

Define the policies. This implementation of BGP4 supports **originate**, **send**, and **receive** policy commands.

When you are finished configuring the router, restart it as described in this section to load the new configuration.

BGP4 Configuration Commands

Enter these commands at the BGP Config> prompt.
Enter ? to list available commands or their options.

add

aggregate *network-prefix network-mask*

Causes the BGP speaker to aggregate a block of addresses and advertise a single address to its neighbors.

neighbor

Defines a BGP neighbor. An external neighbor must be on the same network as the speaker.

no-receive AS number

Excludes updates from a specified AS.

originate-policy...

Adds an originate-policy definition.

receive-policy...

Adds a receive-policy definition.

send-policy...

Adds a send-policy definition.

change

aggregate...

Changes information associated with the current aggregate.

neighbor...

Changes information associated with a neighbor router.

originate-policy...

Changes an existing originate-policy definition.

receive-policy...

Changes an existing receive-policy definition.

send-policy...

Changes an existing send-policy definition.

delete

aggregate index number

Deletes an aggregate.

neighbor network address

Deletes a BGP neighbor.

no-receive AS number

Deletes the no-receive policy associated with a specified AS.

originate-policy index number

Deletes an originate-policy.

receive-policy index number

Deletes a receive-policy.

send-policy index number

Deletes a send-policy.

disable *BGP speaker or neighbor*

Disables a previously enabled BGP speaker or neighbor.

enable *BGP speaker or neighbor*

Disables a BGP speaker or neighbor.

list

aggregate

Lists all aggregated records defined with the **add aggregate** command.

all

Lists the BGP neighbors, policies, aggregated routes, and no-receive-AS records in the current configuration.

BGP speaker

Lists information on the BGP speaker.

neighbor

Lists information on BGP neighbors.

no-receive

Lists information on no-receive-AS definitions.

originate-policy

Lists information on originate policies.

send-policy

Lists information on send policies.

receive-policy

Lists information on receive policies.

exit

Returns to the Config> prompt.

BGP4 Console Commands

Enter these commands at the BGP> prompt. Enter ? to list available commands or their options.

destinations *network-address*

advertised-to *network-address*

Dump information on routes advertised to a specified network address.

received-from *network-address*

Dump information on routes received from a specified network address.

neighbors *internet-address*

Displays information on all active neighbors, or a specified BGP neighbor.

paths

Displays the path descriptors stored in the path descriptions database.

sizes

Displays the number of entries stored in various databases.

exit

Returns to the Config> prompt.

Border Gateway Protocol 4 (BGP4)

Configuring the Router

Enter configuration commands at the Config> prompt. To access the Config> prompt:

```
*talk 6
Gateway user configuration
Config>
```

If the Config> prompt does not appear, press **Return** again.

To enter BGP4 configuration commands, display the BGP config> prompt:

```
Config>protocol bgp
BGP Config>
```

To return to the * prompt, press **Ctrl/P**.

Restarting the Router

When you are done configuring the router, restart it to load the new configuration. Enter **restart** at the * prompt and respond **yes** to the prompt:
Are you sure you want to restart the gateway?

When the new configuration is finished loading, the terminal displays the * prompt.

Monitoring the Router

To enter monitoring commands, display the GWCON prompt (+):

```
*talk 5

CGW Operator Console
+protocol bgp
BGP>
```

To return to the * prompt, press **Ctrl/P**.



Dial Circuits

Configure the ISDN or V.25bis network interface that will be mapped to this circuit.

At the Config> prompt, add a dial circuit.
Syntax: **a dev dial-circuit**

Enter the circuit configuration process.
Syntax: **net dial-circuit-interface#**

Map the dial circuit to an ISDN or V.25 bis interface.
Syntax: **set net interface#**

Set address name of remote router. The name must match one of the ISDN or V.25 bis address names that you added.
Syntax: **set destination address-name**

Configure the dial circuit for inbound or outbound calls or both. For WAN-Restoral, set one end of the link for inbound calls only, and set the other end of the link for outbound calls only.
Syntax: **set calls inbound or outbound or both**

Specify a timeout for the dial circuit. For WAN-Restoral or leased lines, set to zero. For dial-on-demand applications, set to a value other than zero.
Syntax: **set idle #-of-seconds**

Configure optional parameters described in this section. Then configure any other protocols for your router by returning to the Config> prompt. If all protocols are configured, do the following:

1. Enter **exit** at the Circuit Config> prompt.
2. Press **Ctrl/P** to display the OPCON prompt (*).
3. Enter **restart** and respond **yes** to the prompt.

Dial Circuit Configuration Commands

Enter these commands at the Circuit Config> prompt.
Enter ? to list available commands or their options.

delete

inbound destination

Removes the **inbound destination** and the **any_inbound** settings from the dial circuit configuration.

encapsulator

Displays the configuration prompt for the link-layer protocol running on the dial circuit.
V.25 *bis* dial circuits support PPP, PPP-FR, Multilink PPP/PPP-FR and PSL datalinks
ISDN dial circuits support these protocols plus X.25 and Frame Relay.

list

Displays the current dial circuit configuration.

profile-list

Displays the telesaving profiles that have been configured on the router

blocking *profile-name*

Displays the named call-blocking profile, or all call-blocking profiles.

call-back *profile-name*

Displays the named call-back profile, or all call-back profiles.

initial-minimum-timer *profile-name*

Displays the named initial-minimum-timer profile, or all initial-minimum-timer profiles.

set

any_inbound

Specifies that inbound calls that do not identify themselves be mapped to this circuit.

blocking *profile-name*

Specifies the call-blocking profile which this dial circuit is to use.

call-back *profile-name*

Specifies the call-back profile which this dial circuit is to use.

calls *outbound* or *inbound* or *both*

Sets up dial circuit to initiate outbound calls only, accept inbound calls only, or both initiate and accept calls. Default is both.

destination *address-name*

Required for the dial circuit to operate.
Specifies the network dial address of the remote router to which this dial circuit will connect.

inbound-destination *address-name*

Enter this address name if the dial circuit is set up for inbound calls or both inbound and outbound calls, and if the remote router's local address is different from the address this router would use to call that remote router.

idle *#-of-seconds*

If there is no traffic over the circuit for this length of time, the dial circuit hangs up. For WAN-Restoral or dedicated (leased line) circuits, set to zero. Default is 60. Range is 0 to 65535.

initial-minimum-timer *profile-name*

Specifies the initial-minimum-timer profile which this dial circuit is to use.

net *#-of-ISDN-for V.25-bis-jinterface*

Sets number of the ISDN or V.25 *bis* interface to which you want to map this circuit.

selftest-delay *#-of-milliseconds*

Delays the time between establishing the call and sending the initial packet. Default is 150. Range is 0 to 65535.

send_line_id *yes* or *no*


Specifies whether proprietary local ID messages are sent. Default is no.

exit


Returns to the Config> prompt.



Frame Relay



Frame Relay



LKG-10564-97V

Frame Relay Configuration Commands

Enter these commands at the FR config> prompt
Enter ? to list available commands or their options.

add

permanent-virtual-circuit

Adds PVCs in the range 16 to 1007. The maximum number is approximately 64, but the actual number supported by the interface is affected by the configured size of the receive buffer on the interface.

protocol-address

Adds statically configured destination protocol addresses to the FR interface.

change permanent-virtual-circuit

Modifies a PVC that was added with the **add permanent-virtual-circuit** command.

disable

cir-monitor

Disables the circuit monitoring feature that enforces the transmission rate, which was configured using **add permanent-virtual-circuit**.

congestion-monitor

Disables the varying of a circuit's information rate in response to congestion.

dn-length-field

Disables the feature which includes a length field in DECnet packets.

lmi

Disables all management activity.

multicast-emulation

Disables multicast emulation on each active PVC.

orphan-circuits

Prohibits the use of nonconfigured circuits at the interface.

protocol-broadcast

Prohibits protocols such as RIP from functioning over the FR interface.

enable

cir-monitor

Enables the circuit monitoring feature that enforces the transmission rate configured using **add permanent-virtual-circuit**.

congestion-monitor

In response to congestion, allows a circuit's information rate to vary between a minimum of 0.25 times the CIR and a maximum of the line speed.

dn-length-field

Enables the length field to be included in DECnet packets.

lmi

Enables all management activity.

multicast-emulation

Enables multicast emulation on each PVC when a protocol multicast is forwarded.

orphan-circuits

Enables the use at the interface of all nonconfigured circuits.

protocol-broadcast

Allows protocols like RIP to function over the FR interface.

lapf

Displays the FR SVC Config> prompt for configuring Frame Relay SVCs.

list

all

Includes the output of:

list hdlc

list lmi

list permanent-virtual-circuits

list protocol-addresses

hdlc

Displays frame relay HDLC configuration.

Frame Relay

lmi

Displays logical management and related configuration information about the FR interface.

permanent-virtual-circuits

Displays all the configured PVCs on the FR interface.

protocol-address

Displays all the statically configured protocol address circuit mappings at the FR interface.

remove

permanent-virtual-circuit

Deletes any configured PVC in the range of 16 to 1007.

protocol-address

Deletes any statically configured protocol address.

set

encoding *type*

Sets the transmission encoding scheme for the interface to NRZ or NRZI.

frame-size *size*

Sets the size of the network layer portion of frames transmitted and received on the data link.

idle *state*

Sets the data-link state to either Flag or Mark.

line-speed *rate*

Sets data transfer rate to match the speed of the connected modem.

lmi-type *management type*

Sets management mode to Rev1, ANSI, or CCITT.

n1-parameter *count*

Sets the number of t1 time intervals that expire before the FR interface queries management for complete PVC status.

n2-parameter *max#*

Sets the number of errors that can occur in the management window monitored by the n3-parameter before the interface resets.

n3-parameter *max#*

Configures the number of monitored management events for measuring the n2-parameter.

p1-parameter *max#*

Configures the maximum number of PVCs supported by the FR interface.

t1-parameter *time*

Configures the interval (in seconds) that the FR interface takes to perform a sequence number exchange with FR management.

transmit-delay

Allows the insertion of a delay between each transmitted HDLC frame.

svc

Displays the FR SVC Config> prompt for configuring Frame Relay SVCs.

exit

Returns to the previous prompt level.

Frame Relay Console Commands

To list the frame Relay console commands and their options, enter a ? at the FR> prompt.

clear

Removes all statistics from the FR interface.

disable

cir-monitor

Disables CIR monitoring.

congestion-monitor

Disables congestion monitoring.

svc destination-name

Disables active SVCs. Changes made are not saved across a reboot.

enable

cir-monitor

Enables CIR monitoring.

congestion-monitor

Enables congestion monitoring.

svc destination-name

Enables SVCs which have been disabled or have failed. Changes made are not saved across a reboot.

list

call-control

Displays statistical information about SVC call controls.

circuit pvc#

Displays detailed information for the specified PVC.

lapf

Displays statistics relevant to the lower layer protocol LAPF.

lmi

Displays statistics relevant to the logical management on the FR interface.

permanent-virtual-circuits

Displays information for all configured PVCs on the FR interface.

svcs

Displays general link layer statistics and configuration information for all active SVCs on this interface.

all

Displays circuit, management, and PVC statistics on the FR interface.

set circuit

Assigns values to a PVC for the committed information rate (CIR), committed burst rate, and excess burst rate.

exit

Returns to the previous prompt level.

Frame Relay

Frame Relay SVC Configuration Commands

Enter these commands at the FR SVC Config> prompt
Enter ? to list available commands or their options.

add

svc

Adds a frame relay SVC and configures timers and parameters.

protocol-address

Adds statically configured destination protocol addresses to the SVC.

change svc

Modifies an SVC that was added with the **add svc** command.

delete

local-address

Deletes the local address defined using the **set local-address** command.

disable

interface

Disables all frame relay SVC activity on this interface.

svc *destination-name*

Disables the named frame relay SVC.

enable

interface

Enables frame relay SVC activity on this interface.

svc *destination-name*

Enables the named frame relay SVC.

list

all

Displays the entire Frame Relay SVC configuration.

local-address

Displays Frame Relay SVC local address configuration.

maintenance-mode

Displays status of SVC maintenance mode, enabled or disabled.

state

Displays status of Frame Relay SVC activity on this interface, enabled or disabled.

svc

Displays configuration of all SVCs on this interface.

timers

Displays Frame Relay SVC timer configuration.

remove

svc

Deletes an SVC that was added with the **add svc** command.

protocol-address

Deletes any statically configured protocol address.

set

local-address

Configures Frame Relay SVC local addresses.

maintenance-mode

Sets status of SVC maintenance mode to enabled or disabled.

timers

Configures Frame Relay SVC timers.

exit

Returns to the previous prompt level.

Frame Relay LAPF Configuration Commands

Enter these commands at the FR LAPF Config> prompt Enter ? to list available commands or their options.

list

all

Displays the entire Frame Relay LAPF configuration.

frame-size

Displays maximum frame size that can be sent on an LAPF link.

retransmission-count

Displays the number of times a frame will be retransmitted before the link is considered to be down.

timers

Displays Frame Relay LAPF timer configuration.

window-size

Displays the LAPF window size.

set

frame-size

Configures maximum frame size that can be sent on an LAPF link.

retransmission-count

Specifies the number of times a frame will be retransmitted before the link is considered to be down.

timers


Configures the Frame Relay LAPF timers.

window-size

Configures the LAPF window size.

exit

Returns to the previous prompt level.



LKG-10546-97V

IP Configuration Commands

Enter the following configuration commands at the IP config> prompt. To list the configuration commands and their options, enter a ?.

After you have configured all of the protocols, enter restart at the OPCON prompt (*), and respond yes after the following prompt:

Are you sure you want to restart the router?

add

accept-rip-route

Allows an interface to accept a particular RIP route when input filtering is enabled.

access-control

Adds an access control entry to the end of the access control list.

address

Assigns an IP address to the specified interface.

bootp-server

Adds a BootP server to the network configuration.

broadcast-forwarder udp

Adds a broadcast forwarding server for a specified UDP on a specified network interface.

egp-as-info

Defines the type of EGP routing exchange that takes place when communicating with another autonomous system (AS).

egp-neighbor

Adds an EGP neighbor to the router's IP configuration.

filter

Designates a range of IP destinations to be filtered.

input-interchange

Adds an IP network to the list of routes that, when received from an AS, are readvertised via OSPF and RIP.

output-interchange

Adds an IP network that will be advertised via EGP.

packet-filter

Adds one or more packet filters and the corresponding access controls.

route

Adds a static route.

change

address

Changes an interface's address mask.

egp-as-info

Modifies the interchange flag associated with a neighboring AS.

egp-neighbor

Modifies the configured the EGP-neighbor's AS membership.

filter

Changes the mask associated with a range of filtered destinations.

input-interchange

Modifies the cost with which an EGP-learned network is imported into the IGP's (OSPF and RIP).

output-interchange

Modifies the cost advertised by EGP for a given network.

route

Modifies either the designated subnet mask, the next hop, or the hop cost.

delete

accept-rip-route

When input filtering is enabled, it prohibits an interface from receiving a particular network through the RIP protocol.

access-control

Removes an access control record.

address

Removes an IP interface address.

bootp-server

Removes a BootP server from the configuration.

broadcast-forwarder udp

Removes a specified broadcast forwarding server.

default network/subnet-gateway

Removes either the default network gateway or the default subnet gateway.

egp-as-info

Removes the route exchange information that pertains to the neighboring AS.

egp-neighbor

Removes an EGP neighbor.

filter

Stops the router from filtering a range of IP destinations.

input-interchange

Stops importing an EGP-learned route into the IGP.

output-interchange

Stops advertising a network through EGP.

packet-filter

Deletes one or more packet filters and the corresponding access controls.

route

Removes a static route.

triggered-rip

Deletes triggered RIP from the specified interface.

disablearp-subnet-routing

Turns off proxy ARP.

bootp-forwarding

Turns off BootP packet forwarding.

broadcast-forwarding

Turns off broadcast forwarding to a server for a specified UDP on a specified interface.

directed-broadcast

Disables the forwarding of IP packets whose destination is a nonlocal broadcast address.

egp

Turns off EGP.

egp-readvertising

Prevents the router from readvertising EGP-learned information via EGP.

override default

Prevents a received RIP default route from being installed in the routing table.

override static-routes

Prevents received RIP routes from overriding configured static routes.

per-packet-multipath

Turns off the per-packet-multipath feature. Causes IP to use a single path to a destination subnet.

receiving rip

Prevents RIP packets from being received on the interface.

receiving dynamic nets

Turns on input filtering of network routes received by RIP on the interface.

receiving dynamic subnets

Turns on input filtering of subnet routes received by RIP on the interface.

rfc925-routing

Prevents router from responding to ARP requests for off-net destinations.

rip

Turns off RIP.

sending default-routes

Prevents the router from advertising a default route in RIP updates.

sending net-routes

Prevents the router from sending network-level routes in RIP updates.

sending poisoned-reverse-routes

Prevents the router from advertising a certain set of network routes in RIP updates.

IP

sending subnet-routes

Prevents the router from advertising subnet routes in RIP updates.

sending static-routes

Prevents the router from advertising static routes in RIP updates.

enable

arp-subnet-routing

Turns on Proxy ARP.

bootp-forwarding

Turns on BootP packet forwarding.

broadcast-forwarding udp

Turns on broadcast forwarding to a server for a specified UDP on a specified interface.

directed-broadcast

Enables the forwarding of IP packets whose destination is a nonlocal broadcast address.

egp

Turns on EGP.

egp-readvertise

Allows the router to readvertise EGP-learned information via EGP.

override default

Allows the RIP default route to be installed as the router's default route.

override static

Allows RIP information to override configured static routes.

per-packet-multipath

Enables multipath on a per-packet basis.

receiving rip

Allows the router to receive RIP updates.

receiving dynamic nets

Allows all network routes to be received by the RIP protocol on the interface.

receiving dynamic subnets

Allows all subnet level routes to be received by the RIP protocol on the interface.

rfc925-routing

Tells the router to respond to ARP requests for off-net destinations.

rip

Turns on RIP.

sending default-routes

Allows the router to advertise a default route in RIP updates.

sending net-routes

Allows the router to advertise a network route in RIP updates.

sending poisoned-reverse-routes

Allows the router to advertise a certain set of network routes in RIP updates.

sending subnet-routes

Allows the router to advertise subnet routes in RIP updates.

sending static-routes

Allows the router to advertise static routes in RIP updates.

list

all

Displays the entire IP configuration.

access-controls

Displays the configured access control mode and the list of configured access control records.

adresses

Displays the IP internet addresses of the router.

bootp

Displays the BOOTP relay agent configuration of the router.

broadcast-forwarding

Displays broadcast forwarding configuration.

egp-as-info

Displays the routing interchange configured for each neighboring AS.

egp-neighbors

Displays the configured initial EGP neighbors.

filters

Displays a list of all the IP networks/subnets that are being filtered.

input-interchange

Displays the network interchanges that, when learned through EGP, will be imported into the IGP (OSPF and RIP).

output-interchange

Displays the set of routes that will be advertised to the AS neighbor by EGP.

packet-filter

Displays the configured packet filters.

protocols

Displays the state of the IP routing protocols (OSPF, RIP, and EGP).

rip-routes-accept

Displays the set of routes that will be accepted when RIP input filtering is enabled.

routes

Displays the list of static routes.

sizes

Displays the configured size of the routing table.

tags

Displays the tags that will be associated with RIP information learned on the interface.

triggered-rip

Displays the triggered RIP options, timers, and maximum retransmission limits for response and polling messages.

move

Changes the order of the access control records.

set**access-control**

Turns access control on or off.

broadcast address

Specifies the format of the IP broadcast used when the router send broadcasts.

cache-size

Sets the size of the routing cache.

default network-gateway

Configures a static default route.

default subnet-gateway

Configures a static subnet default route.

egp-system-number

Configures the router's autonomous system number, which is used when running the EGP protocol.

internal-IP-address

Configures the internal IP address that belongs to the router as a whole.

ip-host-only-default network-gateway-ip-host-only

Configures the route to a gateway router when operating in ip-host-only mode.

ip-host-only-default subnet-gateway-ip-host-only

Configures the route to a subnet gateway router when operating in ip-host-only mode.

originate-rip-default

Configures the conditions under which the router originates a RIP default route, and the cost that will be used when originating the default.

reassembly-size size

Configures the maximum size for a reassembled packet.

router-id

Sets the address used by the router when sourcing IP traffic.

routing table-size

Sets the size of the routing table.

tags

Sets the tags that will be associated with RIP information learned on the interface.

IP

triggered-rip

Sets the triggered RIP options, timers, and maximum retransmission limits for response and polling messages.

update

packet-filter

Accesses the packet filter update prompt which lets you modify packet filters created with the **add packet-filter** command.

exit

Returns to the previous prompt level.

IP Console Commands

Enter these commands after the IP> prompt.

To list the IP console commands and their options, enter a ? after the IP> prompt.

access controls

Displays a list of configured access control records.

cache

Displays the routing cache.

counters

Displays IP forwarding statistics.

dump routing tables

Displays the routing table.

egp-neighbors

Displays the current EGP state and the interchange flag of each of the router's EGP neighbors.

egp-routes

Displays the routes that are being sent to and received from an EGP neighbor.

interface addresses

Displays the router's IP interface addresses.

packet-filter *filter-name*

Displays packet filter configuration and status.

ping *interface-address*

Lets the router send ICMP echo requests to a given destination. You can use this command for troubleshooting.

route *ip-destination*

Displays the route to a given IP destination (if one exists).

sizes

Displays the configured sizes of specific IP parameters.

static routes

Displays the list of configured static routes and filter entries.

traceroute *interface-address*


Displays the entire hop-by-hop path to a given destination.

triggered-rip


Displays the triggered RIP status and counters for all triggered RIP interfaces.

exit

Returns to the GWCON (+) prompt.



IPX



LKG-10548-97V

IPX Configuration Commands

Enter the following configuration commands at the IPX config> prompt.

To list the configuration commands and their options, enter a ?

After you have configured all of the protocols, enter **restart** at the OPCON prompt (*), and respond **yes** to the following prompt

Are you sure you want to restart the router?

add

access-control *type dest-net dest-host dest-socket-range src-net src-host src-socket-range*

Adds the access control feature. Determines whether IPX packets are dropped or forwarded.

filter *hops service-type service-name*

Adds IPX filtering. Prevents NetWare bindery overflows on large networks by letting you determine the reasonable number of hops for a given service.

ip-tunnel-address *ip-address*

Constructs the IPX IP address peer list. Assigns IP unicast or multicast address one at a time to form the list.

delete

access-control *line#*

Deletes the access control feature for the desired line number.

filter *hops service-type service-name*

Removes IPX filtering.

ip-tunnel-address *ip-address*

Deletes an IP address from the IP peer list.

disable

interface *interface#*

Disables specific interfaces from sending IPX packets.

ip-tunnel

Disables IPX on the IP network.

ipx

Disables all interfaces from sending IPX packets.

ipxwan *interface#*

Prevents IPX from functioning over an interface supporting the Point-to-Point Protocol (PPP).

keepalive *interface#*

Prevents the router from sending IPX packets over specific interfaces.

netbios *interface#*

Prevents the router from filtering NetBIOS packets on the specified interface.

reply-to-get-nearest-server

Prevents the router from responding to GET NEAREST SERVER requests from workstations that are attempting to locate a server.

enable

interface *interface#*

Enables specific interfaces to send IPX packets.

ip-tunnel

Enables IPX on the IP network.

ipx

Allows the router to send IPX packets over all enabled interfaces.

ipxwan

Allows the router to send IPX packets over configured PPP interfaces.

keepalive *interface# timeout*

Allows the router to respond to keepalive packets on the interface specified by *interface#* for the number of minutes specified in *timeout*.

IPX

netbios *interface#*

Allows the router to filter NetBIOS packets on the specified interface.

reply-to-get-nearest-server

Lets the router respond to GET NEAREST SERVER requests from workstations that are attempting to locate a server.

frame

Specifies the packet format for IPX interfaces.

ethernet-format interface#

Selects the Ethernet encapsulation format:

ethernet_II
ethernet_8022
ethernet_8023(default)
ethernet_SNAP

FDDI interface#

Selects the FDDI encapsulation format.

FDDI_SNAP interface#

Selects the FDDI encapsulation format. FDDI_SNAP is the default.

token-ring-format interface#

Selects the Token-Ring encapsulation format:

token-ring_MSB (default)
token-ring_LSB
token-ring_SNAP_MSB
token-ring_SNAP_LSB

list

Displays the current IPX configuration.

move

access-control *line# line#*

Changes the line numbers for the access controls. After you move the lines, they are immediately re-numbered to reflect the new order.

set

access-control *toggle*

Turns access controls on or off. Enter **on** or **off** as the *toggle* value.

filter *toggle*

Turns the IPX SAP filter on or off. Enter **on** or **off** as the *toggle* value.

host-number *host#*

Specifies that each IPX router with serial line support must have a unique host number. This is required because the serial lines do not have hardware node addresses from which to build a host number. The host number is a 12-digit hexadecimal number.

ip-tunnel-net-number *host# ipx-net#*

Assigns a network number to the associated IP tunnel. The interface number is decimal and the net number is hexadecimal.

ipxwan *interface timeout retry-timer #*

Sets up an interface to support the routing of IPX traffic over a WAN interface supporting the Point-to-Point Protocol (PPP). The command also sets up the connection timer and the retry timer.

local-cache-size

Specifies the size of the local cache routing table. The range is 1– 10000. The default size is 64.

maximum alternate-routes-per-destination

Specifies the number of alternate routes that you want to assign to a give destination network. The range is 1– 64. The default value is 3.

maximum networks

Specifies the size of IPX's RIP routing table. This reflects the number of networks in the internet on which IPX operates. There is no maximum size limit; however, it is possible for the router to run out of memory. The default is 32.

maximum services

Specifies the size of IPX's SAP service table. This reflects the number of services (such as file servers or SNA gateways) on the internet on which IPX operates. There is no maximum size limit. The default is 32.

maximum total-alternate-route-entries

Specifies the actual number of entries available for alternate routes.

name

Assigns a symbolic name. The name can be between 1 and 47 characters in length and can contain the characters "A" through "Z".

net-number *host# ipx-net#*

Assigns an IPX network number to the associated directly connected network. Every IPX interface must have a unique network number. The only exception is that serial lines can be assigned network numbers of zero. (Serial lines without network numbers do not pass IPX NetBIOS emulation packets.) The interface number is decimal and the net number is hexadecimal.

node-id *primary-net#*

Assigns a primary network number. The node-id is the primary network number for the router and must be assigned before the exchange of IPXWAN packets can begin.

remote-cache *size*

Specifies the size of the remote cache routing table. The range is 1– 10000. The default size is 64.

rip-interval *delay*

Specifies the delay in minutes between complete RIP updates given on an interface. The range is 1 through 1440. The default is 1.

rip-ip-tunnel-update-interval *interface# delay#*

Specifies the time delay in minutes between transmissions of complete RIP updates through an IP tunnel on an interface.

sap-interval *delay*

Specifies the delay in minutes between complete SAP updates given on an interface. The range is 1 through 1440. The default is 1.

sap-ip-tunnel-update-interval *interface# delay#*

Specifies the delay in minutes between complete SAP updates given on an interface. The range is 1 through 1440. The default is 1.

exit

Returns to the previous prompt level.

IPX Console Commands

Enter these commands at the IPX> prompt.

To list the IPX console commands and their options, enter a ? after the IPX> prompt.

access controls

Lists the status of IPX access controls, the IPX access control statements, and a count of how many times each control statement has been followed.

cache

Displays the contents of the IPX routing cache.

configuration

Lists the network numbers of all the router interfaces on which the IPX protocol is enabled.

counters

Displays the number of routing errors and packet overflows that have occurred.

disable *interface#*

Interactively disables specific IPX interfaces from sending IPX packets over the specified interface.

dump routing tables

Displays the contents of the current IPX RIP network routing tables.

enable *network#*

Returns to the GWCON (+) prompt.

Interactively enables IPX on an interface. To enable IPX, the interface must be up (that is, has passed the self-test).

IPX

filters

Lists the current filters and the states of these filters.

ipxwan

Lists the current configuration information for IPX running over a WAN interface via the Point-to-Point Protocol (PPP).

detailed interface#

Lists the current configuration information for IPX running over the specified interface.

summary

Lists the current configuration information for IPX running over all WAN interfaces.

shutdown

Performs an orderly shutdown of IPX functions on all router interfaces.

sizes

Lists the current size and contents of the local node and remote network caches.

slist

Displays the contents of the current IPX SAP routing tables. This command is similar to the NetWare **slist** command.

exit

Returns to the GWCON (+) prompt.

Add ISDN addresses. Include address name (description of address), network dial address (telephone number), and network subdial address (telephone extension).

Syntax: **add isdn-address** *address-name*
network-dial-address subdial-address

Access the ISDN configuration process from the Config> prompt.

Syntax: **net isdn-interface#**

Set address name of the local port. Must match one of the ISDN addresses.

Syntax: **set local** *address-name*

Specify switch-variant to which this ISDN interface is connected.

Syntax: **set switch-variant** *value*

If your service provider supports directory numbers, set the directory number of the local port. Enter the network dial address (telephone number) of the ISDN address that you entered using **set local-address-name**.


Syntax: **set dn0** *network-dial-address*

Set the signalling terminal endpoint identifier (TEI).

Syntax: **set tei** *auto* or *value*

Set the framesize greater than or equal to the framesize of the datalink protocol.

Syntax: **set ppp** *value*



LKG-10549-97V

ISDN Configuration Commands

Enter these commands at the ISDN config> prompt.
Enter ? to list available commands or their options.

add

accounting-entry *address-name*

If your ISDN service provides accounting information, you can track telephone charges for specific network addresses. You can add up to eight entries. Must match ISDN address names.

enable

ps1

Enables Power Source 1 (PS1) detection. If your ISDN switch supplies PS1, enable PS1.

disable

ps1

Disables PS1 detection.

line

Accesses the Primary Rate ISDN (PRI) Line configuration prompt PRI Line Config>.

list

Displays the current ISDN configuration.

remove

accounting-entry

Removes accounting entries you set using **add accounting-entry**.

set

dn0 *network-dial-address*

Applies only if your service provider supports directory numbers. Enter the network dial address of the local port. Must match the network dial address (telephone number) of the ISDN address you entered using the **set local-address-name** command.

dn1 *network-dial-address*

Some service providers support a second directory number (**dn1**).

framesize *1024 or 2048 or 4096*

Size of the network layer portion of frames on the ISDN interface. Must be greater than or equal to the frame size of the data-link protocol (PSL or PPP) running on the link. The default is 2048.

local-address-name *address-name*

Network address name of the local ISDN interface. Must match one of the ISDN address names.

multipoint-selection *on or off*

Applies only to switch variant 5ESS. Default is *off* (point-to-point operation). Specifying *on* selects multipoint operation.

retries-call-address *value*

Maximum number of calls the router attempts to a nonresponding address during the **timeout-call-address** period. The range is 0 to 10. The default is 2.

If you set the switch-variant to INS64, you cannot change **retries-call-address**. It is fixed at 2.

service-profile-id *value*

Sets the service profile identifier (SPID) for a specified B-channel. The SPID value is ignored if the switch variant is not DMS100, NI1, or 5ESS multipoint.

switch-variant *variant-id*

Model of the switch to which this ISDN interface is connected. Basic Rate ISDN (BRI) supports NET3 (*default*), INS64, 5ESS, DMS100, VN3, NI1 or AUSTEL. Primary Rate ISDN supports NET5 (*default*), INS1500, 4ESS, 5ESS, DMS100, NI2 or AUSTEL.

tei *auto or value*

Signalling terminal endpoint identifier (TEI) for the ISDN interface. Must match the signalling TEI of your ISDN switch. The range is 0 to 63 or Auto. The default is Auto.

`timeout-call-address` *#-of-seconds*

When the router reaches **retries-call-address**, it does not make further calls to that address until this time has expired. The default is 180 seconds. The range is 0 to 65535 seconds. Zero causes the router to retry until the call is established.

If you set the switch-variant to INS64, you cannot change **timeout-call-address**. It is fixed at 180 seconds.

exit

Returns to the Config> prompt.

ISDN Console Commands

Enter these commands at the ISDN> prompt. Enter ? to list available commands or their options.

accounting

Displays accrued telephone charges for all Dial circuits on the current interface.

all-accounting

Displays accrued telephone charges for all Dial circuits on all ISDN interfaces.

calls

Lists the number of completed and attempted connections made for each dial circuit mapped to this interface since the last time statistics were reset on the router.

circuits

Shows the status of dial circuits.

line

Accesses the Primary Rate ISDN (PRI) Line console prompt PRI Line>.

parameters

Displays the current ISDN configuration.

statistics

Displays the current state of the link and the dial circuit and displays the firmware revision. Also shows statistics on what was transmitted and received on the interface.

exit

Returns to the GWCON (+) prompt.

ISDN

PRI Line Configuration Commands

Enter these commands at the PRI Line Config> prompt. Enter ? to list available commands or their options.

list

Displays the current Primary Rate ISDN line speed (E1 or T1) and configuration.

set

clocking internal *or* external

Specifies the source of the transmit clock. The default is external.

encoding format

Specifies the encoding format to be used. On an E1 line the format may be AMI, JBZS, or HDB3 (*default*). On a T1 line the format may be AMI, JBZS, or B8ZS3 (*default*).

framing format

Specify the zero code suppression format to use. On an E1 line the format may be E1-DF, E1-DF-CRC, E1-MF, or E1-MF-CRC (*default*). On a T1 line the format may be T1-SF or T1-ESF (*default*).

exit

Returns to the ISDN Config> prompt.

PRI Line Console Commands

Enter these commands at the PRI Line> prompt. Enter ? to list available commands or their options.

parameters

Displays the current Primary Rate ISDN line speed and configuration.

statistics

all

Displays the current error and alarm statistics for this PRI interface.

alarms


Displays the status of the alarm indicators.


errors

Displays the status of the error counters.

exit

Returns to the ISDN> prompt.





OSI/DNA V Configuration Commands

Enter the following configuration commands at the OSI config> prompt. To list the configuration commands and their options, enter a ?

After you have configured all the protocols, enter **restart** at the OPCON prompt (*), and respond **yes** to the prompt:

Are you sure you want to restart the router?

add

alias *alias segment offset*

Adds an ASCII string that designates a particular address or system ID.

area *area-address*

Adds additional area addresses that the node supports.

filter *filter-name circuit-name dte-address userdata priority*

Adds parameters to determine acceptance of incoming X.25 calls on a routing circuit (static incoming circuit or DA circuit).

permitted-neighbor *entry-name system-id verifier*

Adds a system ID (permitted neighbor) and its verifier password for system level security.

prefix-address ...

Adds static routes to destinations external to the IS-IS domain. Parameter prompts depend on subnet type.

receive-password *type password1 password2*

Adds an ASCII character string (8 characters maximum) that authenticates all incoming packets.

routing-circuit *interface# circuit-name*

[static | da] [in | out]

Adds a communication channel for X.25 SVCs (*static-in*, *static-out* or *DA*). Additional parameters depend on type and direction.

summary-address *address mask default-metric*

Adds a summary address for abbreviating IP routing information at Level 2.

template *template-name circuit DTE-address userdata compression*

Adds a template for making outgoing X.25 static-out or X.25 DA circuits.

change

filter *name dte-address userdata*

Modifies an incoming X.25 call filter.

permitted-neighbor *entry-name system-id verifier*

Modifies a permitted neighbor and its verifier password.

prefix-address ...

Modifies a static route.

routing-circuit *circuit-name ...*

Modifies the configuration of an X.25 routing circuit.

summary-address *address mask default-metric*

Modifies an IP summary address.

template *template-name circuit DTE-address userdata compression*

Modifies an outgoing X.25 call template.

clear

receive-password *type*

Erases all configured receive-passwords.

sram

Erases the OSI configuration from SRAM.

transmit-password *type*

Erases the configured transmit-password.

delete

adjacency *interface# area-address system-id*

Removes statically configured ES adjacency.

alias *alias-name*

Removes a configured alias.

area *address*

Removes the specified configured area address.

OSI/DNA V

filter *filter-name*

Removes a configured incoming X.25 filter.

permitted-neighbor *entry-name*

Removes a permitted neighbor and its verifier password.

prefix-address *interface# address-prefix*

Removes a configured prefix-address.

routing-circuit *circuit-name*

Removes a configured routing circuit.

subnet *interface#*

Removes a configured subnet from the specified interface.

summary-address *address*

Removes the specified statically configured IP summary address.

template *template-name*

Removes a configured outgoing X.25 call template.

virtual-circuit *interface# dte-address*

Removes a configured X.25 or Frame Relay virtual circuit.

disable

integrated-isis

Disables Integrated IS-IS. Disables capability to route IP traffic in addition to OSI traffic using OSI IS-IS Routing.

osi

Disables the OSI protocol running on the router.

routing-circuit *routing-circuit-name*

Disables the specified routing circuit.

subnet *interface#*

Disables the subnet on the specified interface.

enable

integrated-isis

Enables Integrated IS-IS to use a single routing protocol for routing both OSI and IP packets.

osi

Enables the OSI protocol running on the router.

routing-circuit *routing-circuit-name*

Enables the specified routing circuit.

subnet *interface#*

Enables the subnet on the specified interface.

list

adjacencies

Displays all statically configured ES adjacencies.

algorithm

Displays the routing algorithm when running the DNA V protocol.

alias

Displays the configured aliases and their corresponding address segments.

filter

Displays the defined filters for incoming X.25 routing circuits

globals

Displays a summary of the OSI configuration.

integrated-isis

Displays Integrated IS-IS configuration parameter settings.

permitted-neighbor

Displays the permitted neighbors and their verifier passwords.

phaseivpfx

Displays the configured DNA IV address prefix.

prefix-addresses

Displays all the SNPAs for statically configured routes.

routing-circuit [detailed | summary]

Displays a summary of all routing circuits or details of each circuit.

subnets [detailed | summary] *interface#*

Displays either a summary or detailed report for the specified interface.

summary-addresses

Displays all statically configured IP summary address entries.

template

Displays a list of all the defined templates for outgoing X.25 routing circuits.

timers

Displays the OSI/DNA V timer configuration.

virtual-circuit

Displays all configured X.25 or Frame Relay virtual circuits.

set**adjacency** *interface# area-address system-id MAC-address*

Adds or changes an ES adjacency.

algorithm *level-1-algorithm level-2-algorithm*

This is a DNA V command that selects the routing algorithm, link-state or distance-vector.

globals ...

Configures the global parameters required by the OSI protocol.

network-entity-title *area-address system-id*

Configures the router's NET.

phaseivpfx *local-prefix*

Configures the prefix-address of an attached DNA IV network.

subnet *interface# subnet-type ...*

Adds or changes a subnet. Additional parameters depend on subnet type.

switches [on | off] [on | off] [on | off]

Turns OSI options (ES-IS checksum, ES-IS init, and authentication) on or off.

timers ...

Configures the OSI timers, excluding any circuit timers.

transmit-password *type password1 password2*

Sets or changes a transmit password.

virtual-circuit *interface# dte-address ...*

Configures an X.25 or Frame Relay virtual circuit.

exit

Returns to the previous prompt level.

OSI/DNA V Console Commands

Enter these commands after the OSI> prompt.

To list the OSI/DNA V console commands and their options, enter a ? after the OSI> prompt.

addresses

Displays the router's NET and area addresses.

change metric

Modifies the cost of a circuit.

clnp-stats

Displays OSI CLNP information.

designated-router

Displays the designated router for the LAN subnets that are actively running IS-IS.

dnav-info

Displays the Level 1 and Level 2 routing algorithm currently running on the router.

es-adjacencies

Displays all ES adjacencies.

es-is-stats

Displays the statistics for the ES-IS protocol.

OSI/DNA V

is-adjacencies

Displays all IS adjacencies.

is-is-stats

Displays information associated with the IS-IS protocol.

l1-routes

Displays all L1 routes in the L1 database.

l2-routes

Displays all L2 routes in the L2 database.

l1-summary

Displays a summary of the L1 link state database.

l2-summary

Displays a summary of the L2 link state database.

l1-update

Displays a LSP for the specified L1 IS.

l2-update

Displays a LSP for the specified L2 IS.

route

Displays the next hop of a packet.

send

Encodes an echo request message in the CLNP packet to the specified destination NSAP.

show routing circuit

Displays the state of routing circuits for the specified interface.

subnets

Displays information on all operational subnets.

toggle

Enables or disables the NSAP alias display function.

traceroute

Tracks the path an OSI packet takes to a destination.

virtual-circuits


Displays information on all X.25 virtual circuits.

exit

Returns to the previous prompt level.



Protocol Independent Multicast (PIM)



Protocol Independent Multicast (PIM)

PIM Configuration Commands

Enter the following configuration commands at the PIM Config> prompt. To list the configuration commands and their options, enter a ?

After you have configured all the protocols, enter **restart** at the OPCON prompt (*), and respond **yes** to the prompt:

Are you sure you want to restart the router?

delete

group *group-address mask*

Removes the specified group entry from the group configuration table (Sparse Mode only).

interface *ip-address*

Removes the specified interface from the PIM interface configuration table.

disable

pim

Disables PIM protocol globally at system startup.

enable

pim *#-of-groups #-of-SPTs #-of-OIFs*

Enables PIM protocol globally at system startup, and reserves memory for routing tables.

join *group-address*

Sets permanent group membership for the router at system startup.

leave *group-address*

Removes permanent group membership previously configured using the **join** command.

list

all

Displays all information related to PIM options and parameters.

set

group *group-address mask RP1 RP2 RP3 RP4*

Maps a list of Rendezvous Point routers to a multicast group (Sparse Mode only).

interface *ip-address ...*

Identifies the specified interface for use by PIM and configures threshold timers and polling intervals.

pim ...

Sets global timers and thresholds and enables SPT switchover for Sparse Mode PIM. Sets (S,G) entry timeout for Dense Mode and Sparse Mode PIM.

exit

Returns to the Config> prompt.

PIM Console Commands

Enter these commands after the PIM> prompt.

To list the PIM console commands and their options, enter a ? at the PIM> prompt.

dump *source group*

Displays a summary of the (S,G) entries in the PIM routing table or a detailed listing of a selected (S,G) entry.

interface *ip-address* or *interface#*

Displays a summary listing of all PIM interfaces or a detailed listing of a selected interface.

join *group-address*

Sets group membership for the router. Used for testing purposes only. For example, use this command to set group membership at several routers, then use the **ping** command to verify the multicast group.

leave *group-address*

Removes group membership for the router previously requested using the **join** command. Used for testing purposes only.

mgroups

Displays the group membership for this router.

neighbor

Displays a summary of the neighboring PIM routers.

ping *destination-address*

Lets the router send ICMP echo requests to a given destination. You can use this command to ping a multicast group for troubleshooting.

routes

Displays the IP routing table. This command is equivalent to the IP console **dump** command.

stat

Displays static memory usage, data throughput, and error rates.

traceroute *destination-address*

Displays the entire hop-by-hop path to a given destination.

exit

Returns to the CGWCON prompt (+).

Point-to-Point Protocol (PPP)

Access the Config> prompt.
Syntax: **t 6**

Set data-link on chosen serial interface to PPP.
Syntax: **s d ppp intfc#**

Enter the PPP configuration process.
Syntax: **net PPPintfc#**
All commands are now entered at the PPP Config> prompt.

Set PPP protocol parameters.
Syntax: **s option**

Configure any other protocols for your router by returning to the Config> prompt. If all protocols are configured, do the following:

1. Enter **exit** at the PPP config> prompt.
2. Press **Ctrl/P** to display the OPCON prompt (*).
3. Enter **restart** and respond **yes** to the prompt.

Refer to the *Network Interfaces Operations Guide* chapter on PPP for details of how to configure:

- Multilink PPP bundles
- Multilink PPP over Frame Relay
- Multilink PPP over ISDN
- PPP over Frame Relay PVCs
- PPP over Frame Relay SVCs
- PPP over Frame Relay over ISDN

Use the set command, as required, to change the default values of:

- HDLC parameters
- LCP options and parameters
- IPCP options
- BNCP options
- MP options
- PAP and CHAP parameters and options
- Compression and NCP parameters

PPP Interface Configuration Commands

Enter the following configuration commands at the PPP Config> prompt. To list the configuration commands and their options, enter a ?.

After you have configured all the protocols, enter restart at the OPCON prompt (*), and respond **yes** to the prompt

Are you sure you want to restart the router?

delete

chap

Deletes remote CHAP identifiers and passwords.

pap

Deletes local PAP identifiers and passwords.

link circuit#

Access the Link Circuit Config> prompt, or list link details if no *circuit#* is specified. This command is available only when configuring Multilink PPP Bundle (MPB) devices.

list

all

Lists all PPP options and parameters.

authentication

Lists the authentication protocol parameters and options (CHAP and PAP).

bncp

Lists Bridging Network control protocol options and parameters.

ccp

Lists the Compression Control Protocol options and parameters.

fixed

Lists the fixed links in a MP Bundle. This command is available only when configuring MPB devices.

frame-relay

Lists the frame relay parameters associated with a PPP-FR (PVC) pseudo interface. This command is available only when configuring PPP-FR or MPPP-FR devices.

hdlc

Lists the HDLC protocol options and parameters.

ipcp

Lists the Internet Protocol control protocol options and parameters.

lcp

Lists the Link Control Protocol options and parameters.

mp

Lists the Multilink Protocol and Bandwidth on Demand (BoD) options. This command is available only when configuring MPB devices.

parameters

Lists network control protocol options and parameters.

profile-list

Lists telesaving profiles configured on the router. This command is available only when configuring MPB devices.

profile-list

blocking profile-name or all

Lists the call blocking telesaving profiles which have been configured on the router. This command is available only when configuring MPB devices.

call-back profile-name or all

Lists the call back telesaving profiles which have been configured on the router. This command is available only when configuring MPB devices.

initial-minimum-timer *profile-name* or all

Lists the initial minimum timer telesaving profiles which have been configured on the router. This command is available only when configuring MPB devices.

set

authentication

Sets the authentication protocol parameters and options (CHAP and PAP).

bncp

Sets Bridging Network control protocol Tinygram compression yes or no.

ccp *options* or *parameters*

Sets the Compression Control Protocol options and parameters.

fixed add

Sets the fixed links in a MP Bundle. This command is available only when configuring MPB devices.

fixed delete

Removes a fixed link from a MP Bundle. This command is available only when configuring MPB devices.

frame-relay

Creates a frame relay PVC and associates it with a (M)PPP-FR pseudo interface. This command is available only when configuring PPP-FR or MPPP-FR devices.

hdlc encoding *nrz* or *nrzi*

Sets to NRZ or NRZI.

hdlc frame-size *size*

Sets maximum frame size, in bytes, that can be received over the data-link, in the range 576 to 4088.

hdlc idle *flag* or *mark*

Sets data-link idle state to either Flag or Mark.

hdlc speed *value*

Sets the reported clock speed, in bits per second. Used by SNMP to indicate the modem speed.

hdlc transmit-delay *# of microseconds*

Sets period of time to elapse between the transmission of each frame.

ipcp

Enables and configures all Internet Protocol control protocol options for the link, including IP compression, sending and requesting IP address.

lcp *options* or *parameters*

Sets the Link Control Protocol options and parameters.

mp

Sets the Multilink Protocol and Bandwidth on Demand (BoD) options. This command is available only when configuring MPB devices.

parameters

Sets network control protocol parameters including retry timer, configuration tries, NAK tries, and Terminate tries.

blocking

Specifies the call blocking telesaving profile for a Multilink PPP dial (link) circuit to use. This command is available only when configuring MPB devices.

call-back

Specifies the call back telesaving profile for a Multilink PPP dial (link) circuit to use. This command is available only when configuring MPB devices.

initial-minimum-timer

Specifies the initial minimum timer telesaving profile for a Multilink PPP dial (link) circuit to use. This command is available only when configuring MPB devices.

exit

Returns to the Config> prompt.

Point-to-Point Protocol (PPP)

PPP Interface Console Commands

Enter these commands after the PPP> prompt.

To list the PPP console commands and their options, enter a ? at the PPP> prompt

clear

Clears all statistics from point-to-point interfaces.

link circuit#

Accesses the MP Link> prompt, or list link details if no *circuit#* is specified. This command is available only when monitoring Multilink PPP Bundle (MPB) devices.

list

all

Displays all information and counters related to the point-to-point interface and the PPP options and parameters.

ap2

Lists the number of AppleTalk Phase 2 packets, bytes, and protocol-reject packets transmitted and received over the current point-to-point interface.

atcp

Lists the number of ATCP packets, bytes in octets, and protocol-reject packets transmitted and received over the current point-to-point interface.

bncp

Lists the number of BNCP packets, bytes in octets, and protocol-reject packets transmitted and received over the current point-to-point interface.

bod

Lists Bandwidth on Demand statistics. This command is available only when monitoring MPB devices or MP fixed links.

ccp

Lists the number of CCP packets, bytes in octets, protocol reset requests, acknowledgements and reject packets, and the recent compression ratios transmitted and received over the current point-to-point interface.

chap

Lists the number of CHAP packets, bytes in octets, and authentication request, acknowledgement, and reject packets transmitted and received over the current point-to-point interface.

compression

Lists the number of compressed packets, bytes in octets, compressed octets, incompressible packets, discarded packets, and protocol-reject packets transmitted and received over the current point-to-point interface.

control control protocol

Lists information and counters related to the specified control protocol: LCP, PAP, CHAP IPCP, DNCP, IPXCP, BNCP, ATCP, OSICP, CCP, MP.

dn

Lists the number of DECnet packets, bytes in octets, and protocol-reject packets transmitted and received over the current point-to-point interface.

dncp

Lists the number of DECnet control protocol packets, bytes in octets, and protocol-reject packets transmitted and received over the current point-to-point interface.

errors

Displays all error conditions tracked by the PPP software.

fixed

Lists the fixed links in an MP Bundle. This command is available only when monitoring MPB devices.

frame-relay

Lists the frame relay parameters associated with a PPP-FR pseudo interface.

ip

Lists the number of IP packets, bytes in octets, and protocol-reject packets transmitted and received over the current point-to-point interface.

ipcp

Lists the number of IPCP packets, bytes in octets, and protocol-reject packets transmitted and received over the current point-to-point interface.

ipx

Lists the number of IPX packets, bytes in octets, and protocol-reject packets transmitted and received over the current point-to-point interface.

ipxcp

Lists the number of IPXCP packets, bytes in octets, and protocol-reject packets transmitted and received over the current point-to-point interface.

lcp

Lists all of the Link Control Protocol statistics.

mp

Lists the number of Multilink Protocol packets, bytes in octets, and protocol-reject packets transmitted and received over the current point-to-point interface.

osi

Lists the number of OSI packets, bytes in octets, and protocol-reject packets transmitted and received over the current point-to-point interface.

osicp

Lists the number of OSICP packets, bytes in octets, and protocol-reject packets transmitted and received over the current point-to-point interface.

pap

Lists the number of PAP packets, bytes in octets, and authentication request, acknowledgement, and reject packets transmitted and received over the current point-to-point interface.

exit

Returns to the CGWCON prompt (+)

Point-to-Point Protocol (PPP)

PPP Multilink Link Circuit Configuration Commands

Enter the following configuration commands at the MP Link Config> prompt. To list the configuration commands and their options, enter a ?.

After you have configured all the parameters, return to the PPP Config> prompt using the exit command.

delete

inbound-destination

Deletes inbound call settings from the link circuit configuration.

list

Displays the current link circuit configuration.

set

any_inbound

Specifies that inbound calls that do not match any other link circuit are mapped to this circuit and accepted as inbound calls.

calls *outbound or inbound or both (default)*

Restricts the link circuit to making outbound calls only, accepting inbound calls only or both initiating and accepting calls.

destination *address-name*

Network dial address of the remote station.

inbound *local-address-name*

Network dial address of the local station.

net *interface#*

Specifies the number of the network interface to map the link circuit to. The interface may be V.25 *bis*, ISDN, Frame Relay dial circuit (SVC), or Frame Relay over ISDN.

selftest-delay *#milliseconds*

Set the time interval to wait after the call is established before the first packet is sent.

send_line_id *yes or no*

Specifies whether the proprietary local id messages are sent. Select **yes** for V.25 *bis* circuits.

exit

Returns to the PPP Config> prompt.

Multilink PPP Link Circuit Console Commands

Enter these commands after the MP Link> prompt.

To list the MP Link console commands and their options, enter a ? at the MP Link> prompt.

list

The list commands and options are the same as the PPP console list command. The listing displays the current state of these options on the selected Multilink PPP Link circuit.

exit

Returns to the PPP> prompt .

SDLC Relay

Set the serial line interface data-link to SRLY.
Syntax: **set data-link srlly** *interface#*

Define data communications parameters at the SRLY # Config> prompt, where # is the interface number specified with the **network** command. To reach this prompt, enter the network command followed by the appropriate interface number at the Config> prompt.
Syntax: **network** *interface#*

Enter all configuration commands from the SDLC Config> prompt. Access this prompt from the Config> prompt.
Syntax: **protocol sdlc**

Assign a number to a group of associated primary or secondary ports. The default is 1.
Syntax: **add group** *group#*

Add a local port. Ensure that there is no IP address configured for the interface you select. The interface you select must have a data-link type of SRLY.
Syntax: **add local-port**

Add a remote port. The IP address of the remote port is that of the cooperating SDLC Relay router.
Syntax: **add remote-port**

Repeat these steps for the second SDLC Relay router. Provide the address of the first router when prompted for the IP address of the remote port.

Configure any other protocols for your router by returning to the Config> prompt. If all protocols are configured, do the following:

1. Enter **exit** at the SDLC Config> prompt.
2. Press **Ctrl/P** to display the OPCON prompt (*).
3. Enter **restart** and respond **yes** to the prompt.

SDLC Relay Protocol Configuration Commands

Enter these commands at the SDLC Config> prompt. The end of this section tells you how to display this prompt. Enter ? to list available commands or their options.

It is important to note the following about the roles of local and remote ports:

- You need a port for both primary and secondary in each group (the local port takes one role and the remote port takes the opposite role)
- On the participating neighbor router, the port role designations are logically reversed on neighbor routers. For example, if router A has a local primary and a remote secondary, then its neighbor router B has a local secondary and a remote primary.

add

`group group#`

Assigns a number to a group of primary or secondary ports added to the router.

`local-port group# interface# primary-or-secondary`

Identifies the interface that you are using for the local port.

`remote-port group# IP address primary-or-secondary`

Identifies the IP address of the port directly connected to the serial line on the remote router.

delete

`group group#`

Removes a group of SDLC Relay configured ports.

`local-port interface#`

Removes the local port for the specified interface.

`remote-port group# primary-or-secondary`

Removes the remote port for the specified group.

disable

`group group#`

Suppresses the transfer of SDLC Relay frames to or from a specific group.

`port interface# primary-or-secondary`

Suppresses the transfer of SDLC Relay frames to or from a specific port.

enable

`group group#`

Allows the transfer of SDLC Relay frames to or from a specific group.

`port interface# primary-or-secondary`

Allows the transfer of SDLC Relay frames to or from a specific port.

list

`all`

Displays the configuration for all groups, and includes:

- group number
- port status
- interface number
- packets forwarded and discarded
- remote IP address

`group group#`

Displays the configuration of the specified group, and includes:

- group number
- port status
- interface number
- packets forwarded and discarded
- remote IP address

exit

Returns to the Config> prompt.

SDLC Relay Protocol Console Commands

Enter these commands at the SDLC> prompt. The end of this section tells you how to display this prompt. Enter ? to list available commands or their options.

clear-port-statistics

Clears port statistics gathered since the last time the router was restarted or statistics were cleared.

disable

group *group#*

Suppresses the transfer of SDLC Relay frames to or from a specific group.

port *interface# primary-or-secondary*

Suppresses the transfer of SDLC Relay frames to or from a specific local port.

enable

group *group#*

Allows the transfer of SDLC Relay frames to or from a specific group.

port *interface# primary-or-secondary*

Allows the transfer of SDLC relay frames to or from a specific local port.

list

all

Displays the configuration for the local ports including the group number, port status, device number, packets forwarded and discarded, and the IP address.

group *group#*

Displays the configuration of the specified group including group number, port status, device number, packets forwarded and discarded, and IP address.

exit

Returns to the console prompt (+).

SDLC Relay Interface Configuration Commands

Enter these commands at the SRLY # config> prompt. The end of this section tells you how to display this prompt. Enter ? to list available commands or their options.

list

Displays the serial line interface configuration.

set

encoding *nrz or nrzi*

Sets to NRZ or NRZI.

frame-size *size*

Sets maximum frame size, in bytes, that can be received over the data link, in the range 576 to 4088.

idle *flag or mark*

Sets data link idle state to either Flag or Mark.

transmit-delay *# of microseconds*

Sets period of time to elapse between the transmission of each frame.

exit

Returns to the Config> prompt.

Configuring SDLC Relay on the Router

Enter configuration commands at the Config> prompt. To access the Config> prompt:

```
*talk 6  
Config>
```

If the Config> prompt does not appear, press **Return** again.

To enter SDLC Relay configuration commands, display the SDLC config> prompt as shown:

```
Config>protocol sdlc  
SDLC Relay protocol user configuration  
SDLC config>
```

Define communications parameters at the SRLY # config> prompt, where # is the interface number specified with the **network** command. To reach this prompt, set a network interface to data-link SRLY and enter the **network** command followed by the appropriate interface number. For example:

```
Config>set data-link srlly 2  
Config>network 2  
SDLC relay interface user configuration  
SRLY 2 config>
```

To return to the * prompt at any time, press **Ctrl/P**.

Restarting the Router

When you are done configuring the router, restart it to load the new configuration. Enter **restart** at the * prompt and respond **yes** to the following prompt:


```
Are you sure you want to restart the gateway? (Yes or No):
```

When the new configuration is finished loading, the terminal displays the * prompt.

Monitoring the Router

Enter monitoring commands at the console prompt. To enter SRLY protocol monitoring commands, display the SDLC> prompt as shown:

```
*talk 5  
  
+protocol sdlc  
SDLC>
```



LKG-10557-97V

SNMP Configuration Commands

Enter these configuration commands after the SNMP config> prompt. To list the configuration commands and their options, enter a ?.

Be aware that, with the exceptions of the **disable**, **enable**, and **set trap_port** commands, you do not need to restart the router for the SNMP configuration commands to take effect.

add

address *community-name net-addr*

Adds a network address to an existing community. You must supply the name of the community and the network address (in the standard *a.b.c.d.* notation).

community *community-name*

Adds a name to the list of SNMP communities currently configured in the router.

sub_tree

Adds a portion of the MIB to a view or creates a new view. The default is the entire MIB. Be aware that you must assign a view to one or more communities with the **set community view** command for it to take effect.

delete

address *community-name net-addr*

Deletes an address from a community. You must supply the name of the community and the network address (in the standard *a.b.c.d.* notation).

community *community-name*

Deletes a name from the list of SNMP communities currently configured in the router.

sub_tree *object-id*

Removes a MIB or portion of the MIB from a view.

disable

snmp

Disables the SNMP protocol on the router.

trap *trap-type community-name*

Disables specified traps or all traps on the router.

Note: It is necessary to restart the router for this command to take effect.

enable

snmp

Enables the SNMP protocol on the router.

trap *trap-type community-name*

Enables specified traps or all traps on the router.

Note: It is necessary to restart the router for this command to take effect.

list

all

Displays the current configuration of specified SNMP communities for access modes, traps, network address, and views.

community *option*

Displays the current configuration of a specified SNMP community. Options are *access*, *traps*, *address*, and *view*. The default option is *access*.

views

Displays the current view for a specified SNMP community.

set

community access *community-name option*

Assigns one of three access types to a community. Options are *read_trap*, *write_read_trap*, and *trap_only*. You must supply the name of the community.

community view *community-name option*

Assigns a MIB view to a named community. Options are *all* and *view*. The default option is *all*.

trap_port *udpport#*

Allows you to specify a User Datagram Protocol (UDP) port number to send traps to the trap port. The default is the standard UDP port (default # 162).

Note: You must restart the router for this command modification to take effect.

exit

Returns to the previous prompt level.

SNMP Console Commands

Enter these commands after the SNMP> prompt. To list the SNMP console commands and their options, enter a ? after the SNMP> prompt.

list**all**

Displays the current configuration of SNMP communities, authentication types, access modes, traps, and network addresses.

community *option*

Displays the current configuration of a specified SNMP community. Options are *access*, *traps*, *address*, and *view*. The default option is *access*.

views


Displays the current view for a specified SNMP community.

statistics

Displays the statistics about the number of defined variables and the size of the MIB. The statistics can change only when the load or hardware configuration changes.

exit

Returns to the previous prompt level.



V.25 bis Configuration Commands

Enter the following configuration commands at the V.25bis Config> prompt. To list the configuration commands and their options, enter a ?.

After you have configured all of the protocols, enter **restart** at the OPCON prompt (*), and respond **yes** to the prompt:

Are you sure you want to restart the router?

list

Displays the current V.25 bis configuration.

set

command-delay-timeout # of milliseconds

Maximum amount of time the router waits for the modem to respond to DTR with CTS. If the modem does not respond by the end of this delay, the router initiates or answers the call. Default is 0, which causes the router to wait for a CTS signal before it issues commands. Range is 0–65535.

connect-timeout # of seconds

Number of seconds allowed for a call to be established. Default is 60. Range is 0–65535.

dial-mode

Specifies the dialing mode to use: **V25BIS-DIAL** (default) or **DTR-DIAL**. Use DTR-DIAL if your modem does not support V.25 bis automatic dialing.

disconnect-timeout # of seconds

Maximum amount of time after dropping a signal (CTS, DSR, or RI) that the router waits for the modem to respond before it initiates further calls. Default is 2. Range is 0–65535.

local-address address name

Network address name of the local port.

retries-no-answer # of calls

Limits number of successive calls to an address that is inaccessible or that refuses those calls. Default is 1. Range is 0–10.

timeout-no-answer # of seconds

After the router reaches the maximum number of RETRIES-NO-ANSWER to a nonresponding address, it does not make any further calls to that address until this time has expired. This timeout period begins when the router attempts the first call to an address. Default is 0. Range is 0–65535.

exit

Returns to the Config> prompt.

V.25 bis Console Commands

Enter these commands from the V.25bis> prompt. To list the V.25 bis console commands and their options, enter a ? at the V.25bis> prompt.

calls

Lists the number of completed and attempted connections made for each dial circuit mapped to this interface since the last time statistics were reset on the router.

circuits

Shows the status of all dial circuits mapped to this V.25 bis interface.

parameters

Displays the current V.25 bis serial line configuration.


statistics

Displays the current statistics for this V.25 bis interface.

exit


Returns to the GWCON (+) prompt.

WAN-Restoral and WAN-Reroute



LKG-10559-97V

WAN-Restoral and WAN-Reroute



LKG-10560-97V

WAN-Restoral and WAN-Reroute Configuration Commands

Enter the following configuration commands at the WRS Config> prompt. To list the configuration commands and their options, enter a ?.

After you have configured all of the protocols, enter **restart** at the OPCON prompt (*), and respond **yes** to the prompt

Are you sure you want to restart the router?

add

alternate-circuit *alternate-interface#*
primary-interface#

Maps an alternate interface to a primary interface for WAN reroute.

secondary-circuit *secondary-interface#*
primary-interface#

Maps a secondary interface to a primary interface for WAN restoral.

disable

alternate-circuit *alternate-interface#*

Disables WAN reroute for the primary interface that is mapped to this alternate interface.

secondary-circuit *secondary-interface#*

Disables WAN restoral for the primary interface that is mapped to this secondary interface.

wrs

Globally disables WAN restoral or WAN reroute on this router.

enable

alternate-circuit *alternate-interface#*

Enables WAN reroute for the primary interface that is mapped to this alternate interface.

secondary-circuit *secondary-interface#*

Enables WAN restoral for the primary interface that is mapped to this secondary interface.

wrs

Globally enables WAN restoral or WAN reroute on this router.

list

Shows WAN restoral and WAN reroute configuration and status on this router. Lists each primary-to-secondary interface mapping and whether or not WAN restoral is enabled for those interfaces. Lists each primary-to-alternate interface mapping and whether or not WAN reroute is enabled for those interfaces.

remove

alternate-circuit *alternate-interface#*

Removes mapping of the alternate interface to the primary interface for WAN reroute.

secondary-circuit *secondary-interface#*

Removes mapping of the secondary interface to the primary interface for WAN restoral.

set

Sets stabilization intervals for use by WAN reroute.

default first-stabilization *interval*

Sets the interval that will be used as a default value for the first-stabilization time.

default stabilization *interval*

Sets the interval that will be used as a default value for the subsequent stabilization time.

first-stabilization *interval*

Sets the interval that will be used for the first stabilization time.

stabilization *interval*

Sets the interval that will be used for the subsequent stabilization time.

exit

Returns to the Config> prompt.

WAN-Restoral and WAN-Reroute Console Commands

Enter these commands from the WRS> prompt. To list the WAN-restoral console commands and their options, enter a ? at the WRS> prompt. Use the WAN-restoral console to monitor WAN restoral and WAN reroute configurations.

clear

Clears the statistics displayed by the **list** commands. Does not clear the "Most recent restoral period" statistics.

disable

alternate-circuit *alternate-interface#*

Disables the rerouting of the primary interface that is mapped to this alternate interface until the next restart, reload, or **enable alternate** command if both interfaces were previously configured and bound together in a WAN reroute configuration.

secondary-circuit *secondary-interface#*

Disables the restoral of the primary interface that is mapped to this secondary interface until the next restart, reload, or **enable secondary** command if both interfaces were previously configured and bound together in a WAN restoral configuration.

wrs

Disables WAN restoral or WAN reroute on the router until the next restart, reload, or **enable wrs** command.

enable

alternate-circuit *alternate-interface#*

Enables the rerouting of the primary interface. WAN reroute remains enabled only until the next time you restart the router or until you issue the **disable** command.

secondary-circuit *secondary-interface#*

Enables the restoral of the primary interface. WAN restoral remains enabled only until the next time you restart the router or until you issue the **disable** command.

wrs

Globally enables WAN restoral or WAN reroute on this router.

list

alternate-circuit *alternate-interface#*

Lists statistics for the selected alternate circuit.

circuit

Provides statistics for all alternate and secondary dial circuits and their associated primary interfaces.

secondary-circuit *secondary-interface#*

Lists statistics for the selected secondary circuit.

status

Lists status information for individual alternate and secondary circuits and their associated primary interfaces.

set

Sets stabilization intervals for use by WAN reroute.

default first-stabilization *interval*

Sets the interval that will be used as a default value for the first-stabilization time.

default stabilization *interval*

Sets the interval that will be used as a default value for the subsequent stabilization time.

first-stabilization *interval*

Sets the interval that will be used for the first stabilization time.

stabilization *interval*

Sets the interval that will be used for the subsequent stabilization time.

exit

Returns to the GWCON (+) prompt.

Access the X.25 configuration process from the Config> prompt.
 Syntax: **network** *intfc#*
 All commands are now entered from the X.25 config> prompt.


Set the router's local X.25 address.
 Syntax: **set addr** *x.25-node-addr*

Specify the frame and packet levels as either DCE or DTE.
 Default is DTE. DCE is usually only for test setups.
 Syntax: **set equ** *DCE* or *DTE*

Define the lowest and highest two-way SVC channel numbers.
 Syntax:
set svc low-two *channel#* [Default is 0]
set svc high-two *channel#* [Default is 64]

Define the lowest and highest PVC channel numbers. Default is 0.
 Syntax:
set pvc low *channel#*
set pvc high *channel#*

Add protocol type.
 Syntax:
add prot *prot-type window-size def-pkt-siz max-pkt-size
 idle-time maxSVCs*



Add protocol address.
 Syntax:
add address *prot-type prot-addr
 x.25-node-addr*

Configure any other protocols for your router by returning to the Config> prompt. If all protocols are configured, do the following:

1. Enter **exit** at the X.25 config> prompt.
2. Press **Ctrl/P** to display the OPCON prompt (*).
3. Enter **restart** and respond **yes** to the prompt.

X.25 Interface Configuration Commands

Enter the following configuration commands at the X.25 Config> prompt. To list the configuration commands and their options, enter a ?.

After you have configured all of the protocols, enter **restart** at the OPCON prompt (*), and respond **yes** to the prompt

Are you sure you want to restart the router?

add

address *prot-type prot-addr x.25-node-addr*
Adds a public data network (PDN) X.25 address translation for a protocol supported in the router's configuration and specifies whether compression is to be used on calls to this address.

htf-address *prot-type DDN-host-table-addr*
Adds a Defense Data Network (DDN) X.25 address translation.

protocol *prot-type window-size def-pkt-size max-pkt-size idle-time max-svcs*
Adds a supported protocol to the configuration.

pvc *prot-type pkt-channel# x.25-dest-addr window-size pkt-size*
Adds a PVC definition to the configuration.

change

address *prot-type prot-addr x.25-node-addr*
Modifies a PDN X.25 node address translation for a protocol supported in the router's configuration and specifies whether compression is to be used on calls to this address.

htf-address *prot-type DDN-host-table-addr*
Modifies a DDN X.25 address translation.

protocol *prot-type window-size def-pkt-size max-pkt-size idle-time max-svcs*
Modifies a supported protocol in the router's configuration.

pvc *prot-type pkt-channel# x.25-dest-addr window-size pkt-size*

Modifies a PVC definition in the router's configuration.

delete

address *prot-type prot-addr*
Removes a PDN or DDN X.25 address.

protocol *prot-type*
Removes a protocol configuration definition.

pvc *prot-type x.25-dest-addr*
Removes a PVC definition.

disable

compression
Disables Stac-LZS data compression over the X.25 interface.

ddn-address-translations
Disables DDN host table format addresses from being converted dynamically to X.121 call addresses.

interface-resets
Disables the router from initiating packet layer restarts and frame link establishments.

incoming-calls-barred
Specifies that the router will accept incoming calls (certification purposes).

outgoing-calls-barred
Specifies that the router will allow outgoing calls.

enable

compression
Enables Stac-LZS data compression over the X.25 interface.

ddn-address-translations
Allows DDN host table format addresses to be converted dynamically to X.121 call addresses.

interface-resets

Allows the router to initiate packet layer restarts and frame link establishments.

incoming-calls-barred

Specifies that the router will not accept incoming calls.

outgoing-calls-barred

Specifies that the router will not allow outgoing calls.

listaddresses

Displays all X.25 address translations.

all

Displays all the X.25 addresses, National Personality parameters, all defined protocols and their values, and all defined PVCs.

detailed

Displays the value of all the default parameters that the **national set** command modifies.

protocols

Displays all the defined protocol configurations.

pvc

Displays all defined PVCs.

summary

Displays all the values established by the **set** and **enable** commands.

national disableaccept-reverse-charges

Does not allow accepting of reverse charges during call establishment.

ccitt

Disables the CCITT convention for timer retries.

clear-w/diag

Does not allow the clear request packets to include the diagnostic field.

flow-control-negotiation

Disables the negotiation of frame's packet and window size during call setup of SVCs.

frame-ext-seq-mode

Disables the frame layer from using extended sequence numbers 0 to 127. The frame layer then uses 0 to 7.

multi-link-addresses

Sets the frame level back to addresses A (03) and B (01).

osi-84

Disables the CCITT OSI facilities defined by the 1984 standard.

osi-88

Disables the CCITT OSI facilities defined by the 1988 standard.

packet-ext-seq-mode

Disables the packet layer from using extended sequence numbers 0 to 127. The packet layer then uses 0 to 7.

packet-layer-restarts

Disables the packet layer from sending a restart packet when the router restarts.

request-reverse-charges

Disables requesting of reverse charges on all outgoing calls.

reset-w/diag

Disables the reset request packet from including the diagnostic field.

restart-w/diag

Disables the restart request packet from including the diagnostic field.

suppress-calling-addresses

Allows the router to insert the source address in call packets.

suppress-idle-frame-rr

Allows the router to send an idle receiver ready in frame layer frames.

suppress-non-zero-cause

Enables the packets layer cause fields.

throughput-class-negotiation

Disables the negotiation of throughput class during call setup of SVCs.

national enableaccept-reverse-charges

Accepts reverse charges during call establishment.

ccitt

Specifies the use of the CCITT convention, rather than the ISO convention for timer retries.

clear-w/diag

Allows clear request packets to include the diagnostic field.

flow-control-negotiation

Enables the negotiation of frame's packet and window size during call setup of SVCs.

frame-ext-seq-mode

Specifies the frame layer to use extended sequence numbers 0 to 127.

multi-link-addresses

Sets the frame level addresses to C (0F) and D (07), rather than A (03) and B (01).

osi-84

Enables the CCITT OSI facilities defined by the 1984 standard.

osi-88

Enables the CCITT OSI facilities defined by the 1988 standard.

packet-ext-seq-mode

Specifies the packet layer to use extended sequence numbers 0 to 127.

packet-layer-restarts

Allows the packet layer to send a restart packet when the router restarts.

request-reverse-charges

Allows the router to request reverse charges on all outgoing calls.

reset-w/diag

Allows the reset request packet to include the diagnostic field.

restart-w/diag

Allows the restart request packet to include the diagnostic field.

suppress-calling-addresses

Inhibits the inclusion of source addresses in call packets.

suppress-idle-frame-rr

Suppresses the sending of idle receiver ready in frame layer frames.

suppress-non-zero-cause

Suppresses the packet layer cause fields.

throughput-class-negotiation

Allows the negotiation of throughput class during call setup of SVCs.

national restoreall

Restores all the default values to the National Personality configuration.

accept-reverse-charges

Restores the accept-reverse-charges feature for calls during call establishment.

call-req

Restores the default value of 10 second intervals permitted before clearing an unaccepted call.

ccitt

Restores CCITT convention feature.

clear-req retries timer

Restores the default value for the number of clear requests transmissions (*retries*) and the number of 10 second intervals (*timer*) to wait before retransmission.

clear-w/diag

Restores the default feature that allows the inclusion of the diagnostic field in clear request packets.

disconnect-procedure passive or active

Restores the default type of disconnect procedure, passive or active.

dp-timer

Restores the default value the number of milliseconds that the frame level remains in the disconnected state.

flow-control-negotiation

Restores the router's capability to negotiate packet size and window size.

frame-ext-seq-mode

Restores the default for the frame layer sequence numbering modulus.

frame-window-size

Restores the default size of the frame window.

multi-link-addresses

Restores the default values (A+B) for frame layer addressing.

network-type *CCITT* or *DDN*

Restores the default window.

n2-timeouts

Restores the default value for the number of times the T1 timer can expire before a state change.

osi-84

Restores the default value for CCITT OSI facilities as defined by the 1984 standard.

osi-88

Restores the default value for CCITT OSI facilities as defined by the 1988 standard.

packet-size *default-size* *max-size* *window-size*

Restores the default value for the packet layer parameters mentioned above.

packet-ext-seq-mode

Restores the default value for the packet layer sequence numbering modulus.

packet-layer-restarts

Restores the default value for the packet layer transmission of a restart packet when the router restarts.

request-reverse-charges

Restores the default value for reverse charges requests for all outgoing calls.

reset *retries timer*

Restores the default value for the number of reset request transmissions, and the time between transmissions.

reset-w/diag

Restores the inclusion of diagnostic fields in reset request packet.

restart *retries timer*

Restores the default value for the number of restart request transmissions and the timeout value between each restart.

standard-version

Restores the default OSI facilities settings. Options are 1980, 1984, and 1988.

suppress-calling-address

Restores the inclusion of source addresses in call packets.

suppress-idle-frame-rr

Restores the transmission of idle receiver ready frame layer frames.

suppress-non-zero-cause

Restores the inclusion of the packet layer's cause fields.

throughput-class-negotiation

Restores the enabling of throughput negotiation.

t1-timer

Restores the default value for the frame retransmission time in seconds.

t2-timer

Restores the default value for the maximum number of seconds before acknowledging the receipt of an I-frame.

national setcall-req

Specifies the number of 10 second intervals permitted before clearing an unaccepted call.

clear-req *retries timer*

Specifies the maximum number of clear request re-transmissions and the timeout interval between each of them.

X.25

disconnect-procedure *passive* or *active*

Specifies the type of disconnect procedure when disconnecting, passive or active.

dp-timer

Specifies the number milliseconds that the frame level remains in a disconnect state.

frame-window-size

Specifies the number of frames that can be outstanding before acknowledgment.

idle-frame-timer

Specifies the delay before an idle frame is sent to refresh the interface. It is a multiple of T1.

network-type *CCITT DDN*

Specifies the type of network being supported, CCITT or DDN.

n2-timeouts

Specifies the number of times the T1 timer can expire before a state change.

packet-size *default-size max-size window-size*

Specifies the size of the packet and window used for negotiation.

reset *retries timer*

Specifies the number of reset request re-transmissions and the timeout value between each re-transmission.

restart *retries timer*

Specifies the number of restart request re-transmissions and the timeout value between each re-transmission.

standard-version

Determines some of the standard default settings. Options are 1980, 1984, and 1988.

t1-timer

Specifies the frame re-transmit time in seconds.

t2-timer

Specifies the maximum number of seconds before acknowledging the received I-frame. Must be less than T1 and should be greater than 0.

set

address *x.25-node-addr*

Sets the local X.25 interface address.

calls-out

Specifies the maximum number of SVCs for this link.

compression-disable-threshold *value*

Specifies the number of incompressible bytes that can be transmitted before compression is dynamically disabled.

dial-type *point-to-point* or *proprietary*

Sets the dial circuit type if this device is an X.25 Dial Circuit over an ISDN interface.

default-window-size

Specifies the window size for the packet level. Note that the window is assumed if no window-size facility is present in the Call Setup Packet.

equipment-type *DCE DTE*

Specifies whether the frame and packet levels act as DCE or DTE.

hft *addr x.25-node-addr*

Sets the local X.25 address translation.

inter-frame-delay *value*

Sets the minimum number of flags transmitted between frames.

max-retry *value*

Sets the maximum number (*value*) of reset request transmissions permitted before the call is cleared.

minimum-compression-message-size *value*

Sets the minimum size of a routing packet which will be compressed for calls with no compression dictionary assigned.

mtu *value*

Sets the maximum transmission unit (MTU) size in bytes.

national personality *GTE-Telenet DDN*

Sets the 28 default parameters for either *GTE-Telenet* or *DDN*.

pvc *low*

Defines the lowest PVC channel number.

pvc high

Defines the highest PVC channel number.

speed value

Defines the line speed of this interface.

svc low-inbound

Defines the lowest inbound SVC channel number.

svc low-two-way

Defines the lowest two-way SVC channel number.

svc low-outbound

Defines the lowest outbound SVC channel number.

svc high-inbound

Defines the highest inbound SVC channel number.

svc high-two-way

Defines the highest two-way SVC channel number.

svc high-outbound

Defines the highest outbound SVC channel number.

throughput-class inbound or outbound bit-rate

Defines the default bit rate between 75 bps and 48,000 bps for an inbound or outbound logical channel.

vc-idle

Defines the number of seconds that an SVC can be idle before it is cleared.

exit

Returns to the previous prompt level.

X.25 Interface Console Commands

Enter these commands from the X.25> prompt. To list the X.25 console commands and their options, enter a ? at the X.25> prompt.

list**pvc**

Displays the configured PVCs.

svcs

Displays the active SVCs.

parameters**all**

Displays the parameters for packet, frame, and physical levels.

frame

Displays the parameters for the frame level.

packet

Displays the parameters for the packet level.

physical

Displays the parameters for the physical level.

statistics**all**

Displays the statistics for the packet, frame, and physical levels.

compression

Displays the statistics for data compression.

frame

Displays the statistics for the packet level.

packet


Displays the statistics for the packet level.

physical

Displays the statistics for the physical level.

exit

Returns to the previous prompt level.



X.25-LLC2 Pseudo-Interface Configuration Commands

Enter the following configuration commands at the X.25-LLC2 config> prompt. To list the configuration commands and their options, enter a ?.

After you have configured all of the protocols, enter **restart** at the OPCON prompt (*), and respond **yes** to the prompt

Are you sure you want to restart the router?

add

address *prot-type prot-addr x.25-node-addr*
Adds a public data network (PDN) X.25 address translation for a protocol supported in the router's configuration.

protocol *prot-type window-size def-pkt-size max-pkt-size idle-time max-svcs*
Adds a supported protocol to the configuration.

change

address *prot-type prot-addr x.25-node-addr*
Modifies a PDN X.25 node address translation for a protocol supported in the router's configuration.

protocol *prot-type window-size def-pkt-size max-pkt-size idle-time max-svcs*
Modifies a supported protocol in the router's configuration.

delete

address *prot-type prot-addr*
Removes an X.25 address translation.

protocol *prot-type*
Removes a protocol configuration definition.

disable

interface-resets
Disables the router from initiating packet layer restarts (certification purposes).

incoming-calls-barred
Specifies that the router will accept incoming calls.

outgoing-calls-barred
Specifies that the router will allow outgoing calls.

enable

interface-resets
Allows the router to initiate packet layer restarts and frame link establishments.

incoming-calls-barred
Specifies that the router will not accept incoming calls.

outgoing-calls-barred
Specifies that the router will not allow outgoing calls.

list

addresses
Displays all X.25 address translations.

all
Displays all the X.25 addresses, National Personality parameters, and all defined protocols and their values.

detailed
Displays the value of all the default parameters that the **national set** command modifies.

protocols
Displays all the defined protocol configurations.

summary
Displays all the values established by the **set** and **enable** commands.

national disable

accept-reverse-charges
Does not allow accepting of reverse charges during call establishment.

ccitt

Disables the CCITT convention for timer retries.

clear-w/diag

Does not allow the clear request packets to include the diagnostic field.

flow-control-negotiation

Disables the negotiation of packet and window size during call setup of SVCs.

osi-84

Disables the CCITT OSI facilities defined by the 1984 standard.

osi-88

Disables the CCITT OSI facilities defined by the 1988 standard.

packet-ext-seq-mode

Disables the packet layer from using extended sequence numbers 0 to 127. The packet layer then uses 0 to 7.

packet-layer-restarts

Disables the packet layer from sending a restart packet when the router restarts.

request-reverse-charges

Disables requesting of reverse charges on all outgoing calls.

reset-w/diag

Disables the reset request packet from including the diagnostic field.

restart-w/diag

Disables the restart request packet from including the diagnostic field.

suppress-calling-addresses

Allows the router to insert the source address in call packets.

suppress-non-zero-cause

Enables the packets layer cause fields.

throughput-class-negotiation

Disables the negotiation of throughput class during call set up of SVCs.

national enableaccept-reverse-charges

Accepts reverse charges during call establishment.

ccitt

Specifies the use of the CCITT convention, rather than the ISO convention for timer retries.

clear-w/diag

Allows clear request packets to include the diagnostic field.

flow-control-negotiation

Enables the negotiation of packet and window size during call setup of SVCs.

osi-84

Enables the CCITT OSI facilities defined by the 1984 standard.

osi-88

Enables the CCITT OSI facilities defined by the 1988 standard.

packet-ext-seq-mode

Specifies the packet layer to use extended sequence numbers 0 to 127.

packet-layer-restarts

Allows the packet layer to send a restart packet when the router restarts.

request-reverse-charges

Allows the router to request reverse charges on all outgoing calls.

reset-w/diag

Allows the reset request packet to include the diagnostic field.

restart-w/diag

Allows the restart request packet to include the diagnostic field.

suppress-calling-addresses

Inhibits the inclusion of source addresses in call packets.

suppress-non-zero-cause

Suppresses the packet layer cause fields.

X.25-LLC2

throughput-class-negotiation

Allows the negotiation of throughput class during call set up of SVCs.

national restore

all

Restores all the default values to the National Personality configuration.

accept-reverse-charges

Restores the accept-reverse-charges feature for calls during call establishment.

call-req

Restores the default value of 10 second intervals permitted before clearing an unaccepted call.

ccitt

Restores CCITT convention feature.

clear-req *retries timer*

Restores the default value for the number of clear requests transmissions (*retries*) and the number of 10 second intervals (*timer*) to wait before retransmission.

clear-w/diag

Restores the default feature that allows the inclusion of the diagnostic field in clear request packets.

flow-control-negotiation

Restores the router's capability to negotiate packet size and window size.

osi-84

Restores the default value for CCITT OSI facilities as defined by the 1984 standard.

osi-88

Restores the default value for CCITT OSI facilities as defined by the 1988 standard.

packet-size *default-size max-size window-size*

Restores the default value for the packet layer parameters mentioned above.

packet-ext-seq-mode

Restores the default value for the packet layer sequence numbering modulus.

packet-layer-restarts

Restores the default value for the packet layer transmission of a restart packet when the router restarts.

request-reverse-charges

Restores the default value for reverse charges requests for all outgoing calls.

reset *retries timer*

Restores the default value for the number of reset request transmissions, and the time between transmissions.

reset-w/diag

Restores the inclusion of diagnostic fields in reset request packet.

restart *retries timer*

Restores the default value for the number of restart request transmissions and the timeout value between each restart.

standard-version

Restores the default OSI facilities settings. Options are 1980, 1984, and 1988.

suppress-calling-address

Restores the inclusion of source addresses in call packets.

suppress-non-zero-cause

Restores the inclusion of the packet layer's cause fields.

throughput-class-negotiation

Restores the enabling of throughput negotiation.

national set

call-req

Specifies the number of 10 second intervals permitted before clearing an unaccepted call.

clear-req *retries timer*

Specifies the maximum number of clear request re-transmissions and the timeout interval between each of them.

packet-size *default-size max-size window-size*

Specifies the size of the packet and window used for negotiation.

reset *retries timer*

Specifies the number of reset request re-transmissions and the timeout value between each re-transmission.

restart *retries timer*

Specifies the number of restart request re-transmissions and the timeout value between each re-transmission.

standard-version

Determines some of the standard default settings. Options are 1980, 1984, and 1988.

setaddress *x.25-node-addr*

Sets the local X.25 interface address.

calls-out

Specifies the maximum number of SVCs for this link.

default-window-size

Specifies the window size for the packet level. Note that the window is assumed if no window-size facility is present in the Call Setup Packet.

dsap *sap*

Sets the destination SAP for LLC2. The default value 7E (hexadecimal) is the ISO standard SAP for X.25.

equipment-type *DCE DTE*

Specifies whether the frame and packet levels act as DCE or DTE.

mtu *value*

Sets the maximum transmission unit (MTU) size in bytes.

speed *value*

Defines the line speed of this interface.

ssap *sap*

Sets the source SAP for LLC2. The default value 7E (hexadecimal) is the ISO standard SAP for X.25.

svc low-inbound

Defines the lowest inbound SVC channel number.

svc low-two-way

Defines the lowest two-way SVC channel number.

svc low-outbound

Defines the lowest outbound SVC channel number.

svc high-inbound

Defines the highest inbound SVC channel number.

svc high-two-way

Defines the highest two-way SVC channel number.

svc high-outbound

Defines the highest outbound SVC channel number.

throughput-class *inbound or outbound bit-rate*

Defines the default bit rate between 75 bps and 48,000 bps for an inbound or outbound logical channel.

yc-idle

Defines the number of seconds that an SVC can be idle before it is cleared.

exit

Returns to the previous prompt level.

X.25-LLC2 Pseudo-Interface Console Commands

Enter these commands from the X.25-LLC2> prompt.
To list the X.25-LLC2 console commands and their options, enter a ? at the X.25-LLC2> prompt.

list

svcs

Displays the active SVCs.

parameters

all

Displays the parameters for packet, frame, and physical levels.

frame

Displays the associated LAN interface number and the local and remote MAC addresses.

packet

Displays the parameters for the packet level.

statistics

all

Displays the statistics for the packet, frame, and physical levels.

frame

Displays the statistics for the frame level.
Only I-frames are counted.


packet

Displays the statistics for the packet level.

exit

Returns to the previous prompt level.

X.25 Switching Feature



LKG-10563-97V

X.25 Switching Feature

X.25 Switching Feature Configuration Commands

Enter the following configuration commands at the X.25S Config> prompt. To list the configuration commands and their options, enter a ?.

After you have configured all of the protocols, enter **restart** at the OPCON prompt (*), and respond **yes** to the prompt

Are you sure you want to restart the router?

add

client

Defines new client profiles and associates incoming call filters. Incoming X.25 calls matching an associated filter are switched to the client's destination address.

filter

Defines new filter with a profile for incoming calls.

change

client

Modifies client profiles.

filter

Modifies incoming call filters.

delete

client

Removes client profiles.

filter

Removes incoming call filters.

disable

client

Disables client profiles. When a client is disabled, incoming calls matching an associated filter are blocked.

filter

Disables incoming call filters. Incoming calls are not matched against disabled filters.

x25-switching

Globally disables X.25 Switching on the router.

enable

client

Enables client profiles.

filter

Enables incoming call filters.

x25-switching

Globally enables X.25 Switching on the router.

list

client

Displays the current configuration options and status of all defined clients.

filter

Displays the current configuration options and status of all defined filters.

set

x25-switching

Sets routing priority of the implicit filters that are used to handle routing calls, and the maximum number of X.25 circuits that can be switched at any one time.

show

client

Displays the current configuration options and status of the named client.

filter

Displays the current configuration options and status of the named filter.

x25-switching

Displays the current configuration options and status of X.25 Switching.

exit

Returns to the Config> prompt.

X.25 Switching Feature Console Commands

Enter these commands from the X.25S> prompt. To list the X.25 Switching console commands and their options, enter a ? at the X.25S> prompt.

disable**client**

Disables client profiles. When a client is disabled, incoming calls matching an associated filter are blocked.

filter

Disables incoming call filters. Incoming calls are not matched against disabled filters.

x25-switching

Globally disables X.25 Switching on the router.

enable**client**

Enables client profiles.

filter

Enables incoming call filters.

x25-switching

Globally enables X.25 Switching on the router.

list**client**

Displays the current configuration options and status of all defined clients.

filter

Displays the current configuration options and status of all filters that have been associated with clients.

set**x25-switching**

Sets routing priority of the implicit filters that are used to handle routing calls, and the maximum number of X.25 circuits that can be switched at any one time.

show**client**

Displays the current configuration options and status of the named client.

filter

Displays the current configuration options and status of the named filter.

x25-switching

Displays the current configuration options and status of X.25 Switching.

exit

Returns to the CGWCON prompt (+).

