

# **VSI OpenVMS Version 8.4-1H1 Installation and Upgrade Manual**



# VSI OpenVMS Version 8.4-1H1 Installation and Upgrade Manual:



Software Version: VSI OpenVMS Version 8.4-1H1 for HP Integrity Servers

Publication date 5-May-2015 - Release Version 1.0

Copyright © 2015 VMS Software, Inc., (VSI), Bolton Massachusetts, USA

## Legal Notice

Confidential computer software. Valid license from VSI required for possession, use or copying. Consistent with FAR 12.211 and 12.212, Commercial Computer Software, Computer Software Documentation, and Technical Data for Commercial Items are licensed to the U.S. Government under vendor's standard commercial license.

The information contained herein is subject to change without notice. The only warranties for VSI products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. VSI shall not be liable for technical or editorial errors or omissions contained herein.

HP, HP Integrity, HP Alpha, Proliant and Superdome are trademarks or registered trademarks of Hewlett Packard Development Company, L.P.

Intel, Itanium and IA64 are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Java, the coffee cup logo, and all Java based marks are trademarks or registered trademarks of Oracle Corporation in the United States or other countries.

Kerberos is a trademark of the Massachusetts Institute of Technology.

Microsoft, Windows, Windows-NT and Microsoft XP are U.S. registered trademarks of Microsoft Corporation. Microsoft Vista is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.

UNIX is a registered trademark of The Open Group.

The VSI OpenVMS documentation set is available on DVD.

# Table of Contents

Preface .....	viii
About VSI and this document .....	viii
A Proud Heritage .....	viii
What's in a Name? .....	viii
New and Changed Information in this Edition .....	ix
Software Licensing and Rebranding .....	ix
I. Before Installing or Upgrading .....	1
1. Getting Started .....	4
Obtaining the Distribution Image .....	4
System Preparation .....	6
Device Naming. Device-Naming Conventions .....	7
Determine your Environment .....	8
2. Before Non-Cluster Installation .....	9
Before Installation Checklist. Before Non-Clustered Installation .....	9
Boot Methods. Distribution Media Boot Methods .....	9
Console Prep. Preparing the Console .....	10
MP Console .....	11
Graphics Console .....	11
Console Selection. Selecting a Primary and Secondary Console .....	12
Selecting a Console on Legacy HP Integrity servers .....	13
ACPI Config. Checking the ACPI Configuration (Cell-Based Servers) .....	16
Target Disk. Selecting your Target Disk .....	17
Network Details. Determining your Network Requirements .....	17
License PAKs. Product Licensing Keys .....	17
3. Before Non-Cluster Upgrade .....	19
Before Non-Clustered Upgrade .....	19
Related Documents. Documentation References .....	19
Upgrade Cautions. Notes, Cautions, and Restrictions .....	20
Upgrade Paths .....	20
Update License Requirements .....	20
Components You Choose Not to Install .....	20
Licenses and Layered Products .....	21
Software That Must Be Manually Removed .....	21
Deconfigure Software. Software That Must be Deconfigured .....	21
Preventing Archived Files from Being Deleted .....	21
Upgrade Disk Prep. Preparing the System Disk for Upgrade .....	22
Checking the Directory Structure and Preserving Your Security Protections .....	22
Checking the SYSCOMMON Directories .....	22
Purging Duplicate Files from the System Disk .....	23
Examining the System Disk .....	23
Checking the Size of the System Disk .....	23
Returning Authorization and AGEN\$INCLUDE Files to the System Disk .....	24
Verifying System Parameters .....	25
Autogen Feedback. Ensuring a Recent FEEDBACK.DAT File .....	26
Shadow Environment. Shadowing Environment .....	27
Setting the Boot Device .....	28
Creating a Nonshadowed Target Disk .....	28
Upgrade Backup. Backing Up the System Disk .....	28
Finish Upgrade Prep. Finishing the <i>Before Upgrade</i> Tasks .....	29
4. Before Clustered System Installation .....	31
Before Clustered Installation Tasks .....	31
Cluster Documents. Cluster Documentation References .....	31
Cluster Matrix. Mixed Version and Architecture Cluster Systems .....	31
Single Architecture Cluster Support .....	32

VSI OpenVMS Version 8.4-1H1  
Installation and Upgrade Manual

Mixed Arch Matrix. Mixed Architecture Cluster Support .....	32
Required Cluster Info. Required OpenVMS Cluster Information .....	33
Dismount Cluster Disk. Dismounting the Target System Disk in the Cluster .....	34
Finishing the <i>Before Cluster Install</i> Tasks .....	34
5. Before Clustered System Upgrade .....	35
Before Clustered Upgrade Tasks .....	35
Cluster Upgrade Documents. Cluster Documentation to Review .....	35
Cluster Upgrade Matrix. Mixed-Version Support in a Cluster .....	35
Upgrade Types. Types of Upgrades .....	36
CONCURRENT Upgrade .....	36
ROLLING Upgrade .....	37
Finishing the <i>Before Cluster Upgrade</i> Tasks .....	39
II. During Installation or Upgrade .....	40
6. INSTALLATION Procedure .....	42
Booting the VSI OpenVMS Distribution Media .....	42
Booting a Local DVD. Booting from a Local DVD Drive .....	42
Booting via Network. Booting from a Network InfoServer Utility .....	43
Performing the INSTALLATION .....	43
Responding to Installation Prompts .....	43
Using the VSI OpenVMS Installation Menu .....	44
OPTION 1: Upgrade, install or reconfigure OpenVMS .....	45
OPTION 2: Display layered products that this procedure can install .....	48
OPTION 3: Install or upgrade layered products .....	49
OPTION 4: Show installed products .....	51
OPTION 5: Reconfigure installed products .....	52
OPTION 6: Remove installed products .....	53
OPTION 7: Find, Install or Undo Patches; Show or Delete recovery data .....	55
OPTION 8: Execute DCL Commands and Procedures .....	56
OPTION 9: Shut down this system .....	56
STEP-BY-STEP Installation Example .....	56
Next Steps .....	76
7. UPGRADE Procedure .....	77
Performing the UPGRADE .....	77
Upgrading the System Using Option 1 of the Installation Menu .....	77
Selecting INITIALIZE or PRESERVE .....	77
Specifying the Target Disk .....	78
Selecting Reinstallation and Reconfiguration Options .....	78
Checking for Recovery Data .....	80
Specifying the Volume Label .....	81
Specifying the On-Disk Structure Level .....	81
Create and Validate Boot Options .....	83
Warning About Removal of the DECRAM Command .....	84
Setting OpenVMS Cluster Membership Information .....	84
License Rebranding .....	84
Updating Time Zone Information .....	84
Upgrading Windowing, Networking, and Related Products .....	85
Completing the Upgrade .....	86
Selecting Descriptive Help Text .....	86
Removing Older Versions of ENCRYPT .....	87
Secure Delivery Validation .....	87
Selecting Product Component Options .....	87
Component and Product Installation Confirmation Messages .....	89
Upgrade Creates and Validates Boot Options .....	90
Upgrade Completed .....	91
Shutting Down the System .....	92
III. After Installing or Upgrading .....	93
8. After Installing or Upgrading OpenVMS .....	96
After Installation or Upgrade Tasks .....	96

VSI OpenVMS Version 8.4-1H1  
Installation and Upgrade Manual

Booting the newly installed VSI OpenVMS System Disk .....	98
Logging In to the SYSTEM Account .....	99
Logging In from a Character-Cell Terminal .....	99
Logging In from a Workstation .....	100
Running Autogen. Running AUTOGEN .....	100
Autogen. Running AUTOGEN to Tune the System .....	101
Rebooting After AUTOGEN .....	102
Joining an OpenVMS Cluster .....	103
System Disk Backup. Backing Up Your System Disk .....	104
Registering Licenses. Registering Your Licenses .....	105
Shadow Parameters. Set System Parameters for Volume Shadowing (Optional) .....	106
Forming a Shadow Set. Forming the Shadow Set .....	107
Customizing the System (New Installations, Some Upgrades) .....	108
Network Proxy Files. Creating Network Proxy Authorization Files .....	109
Queue Manager. Setting Up the Queue Manager and Default Queues .....	109
Configuring DECnet. Configuring DECnet .....	110
Configuring TCPIP. Configuring TCP/IP Services for OpenVMS .....	111
Configuring Additional Software. Installing and Configuring Third-Party Networking Software .....	111
Multihead Display. Configuring a Multihead System (Optional) .....	111
Configuring CDSA. Initializing CDSA (Optional) .....	112
Configuring Availability Manager. Configuring the Availability Manager Base Software (Optional) .....	113
Configuring Kerberos. Configuring Kerberos (Optional) .....	113
Configuring SSL. Configuring SSL for OpenVMS (Optional) .....	114
Configuring WBEM Services. Configuring WBEM Services for OpenVMS (Optional) .....	115
Configuring WBEM Services for OpenVMS (Where Not Configured Previously) .....	116
Configuring WBEM Services for OpenVMS (Where Configured Previously) .....	117
Configuring WBEM Providers. Configuring WBEM Providers for OpenVMS (Optional) .....	119
Configuring TDC. Configuring and Running the Performance Data Collector Base Software (Optional) .....	122
User Privileges and Quotas .....	122
Startup File .....	123
Compatibility with Prior Releases .....	123
Running TDC_RT .....	124
Installation in OpenVMS Clusters .....	124
Configuring Management Station. Configuring the OpenVMS Management Station (Optional) .....	124
Configuring a Welcome Message. Creating a System-Specific Login Welcome Message (Optional) .....	125
Configuring COM Files. Examining Your Command Procedures (Upgrades Only) .....	125
Add or Remove SYSTEM files. Adding and Removing Operating System Files (Optional) .....	126
Compressing Libraries. Compressing the System Libraries (Optional; Not Recommended) .....	128
Installing Patches. Installing Patches (Optional but Recommended) .....	128
Installing Layered Products. Installing and Configuring Layered Products .....	129
Alternative Procedure .....	130
Creating Print Queues. Creating Print Queues .....	131
Starting Layered Products. Updating SYSTARTUP_VMS.COM to Start Layered Products and Print Queues .....	131
Creating Accounts. Creating Accounts (New Installations, Some Upgrades) .....	132
Running UETP. Testing the System with UETP (Optional) .....	132

Backup after Customization. Backing Up the Customized System Disk and Initiating System Backups .....	132
Reforming a Shadow Set. Reforming the Shadow Set as Final Postupgrade Backup .....	132
Rebooting Cluster Members. Rebooting Cluster Members (Upgrades Only) .....	133
Modifying System Parameters. Modifying System Parameters .....	133
General Notes About Modifying System Parameters .....	133
Modifying System Parameters After an Upgrade .....	133
IV. Boot Methods and Tools .....	135
9. OpenVMS, Hardware and Boot Operations .....	137
Configuration and Management Utilities .....	137
Overview of Utilities and Console Options .....	137
Configuration and Management Utilities on Cell-Based Servers .....	140
Using the Delete or Backspace Key .....	140
EFI Usage Overview .....	140
General Notes About Using EFI .....	141
Enabling or Disabling Hyper-Threading on Dual-Core Processors .....	144
Configuring and Managing OpenVMS Booting .....	144
Boot Options. Setting Boot Options for Your System Disk .....	145
Writing a New Boot Block .....	150
Booting Operations .....	151
Overview of Booting on a Cell-Based Server .....	152
Alternate Method of Booting the DVD with EFI .....	154
Booting the VSI OpenVMS OE DVD from the InfoServer .....	156
Booting from a Fibre Channel Device .....	156
Booting Manually from the Local System Disk .....	156
Performing a Conversational (Interactive) Boot .....	157
Booting with Minimum Startup .....	158
Booting with the XDelta Utility (XDELTA) .....	159
Booting from a Different Root Directory .....	159
Emergency Booting .....	159
Booting with Default System Parameters .....	160
Booting Without Startup and Login Procedures .....	161
Booting Without a User Authorization File .....	162
Halt and Shutdown Procedures .....	163
Halting a Server to Recover from Hangs and Crashes .....	163
Shutting Down the System .....	164
Troubleshooting Procedures .....	165
If the System Does Not Boot .....	165
Detecting and Responding to System Problems .....	166
Network Booting. Setting Up and Performing Network Booting .....	166
InfoServer Client Setup. Setting Up Your System as an InfoServer Client .....	168
Determining the Local Network I/O Card to Be Used .....	168
Adding the Network Boot Option to the EFI Boot Manager .....	169
Verifying the Network I/O Device Is Bootable by EFI .....	171
InfoServer Server Setup. Setting Up the InfoServer Server .....	172
InfoServer BOOTP Setup. Setting Up the BOOTP Boot Server and TFTP Server ....	175
InfoServer Booting. Booting OpenVMS from the InfoServer .....	179
InfoServer Troubleshooting. Troubleshooting InfoServer Boot Problems .....	183
Setting Up and Booting Fibre Channel Storage Devices .....	184
Checking the Firmware Version .....	184
Obtaining the IPF Offline Diagnostics and Utilities .....	185
Configuring and Booting FC Boot Device .....	186
Configuring Additional Nodes to Boot into a Cluster Using a Shared Disk ....	188
A. Backing Up and Restoring the System Disk .....	189
Reasons for Backing Up the System Disk .....	189
Suggested Procedures .....	189
OpenVMS Cluster Caution .....	190

VSI OpenVMS Version 8.4-1H1  
Installation and Upgrade Manual

Backing Up the System Disk .....	190
Getting Started .....	190
Mounting Devices .....	191
Performing the System Disk Backup .....	191
Changing the Disk Volume Cluster Size .....	191
Logging Out, Shutting Down, and Rebooting .....	191
Restoring the System Disk .....	192
Getting Started .....	192
Mounting Devices .....	192
Performing the System Disk Restore .....	193
Logging Out, Shutting Down, and Rebooting .....	193
Alternative Backup and Restore Procedure (Minimum OpenVMS Environment) .....	193
Preparing an Alternate System Disk .....	194
Using the Alternate System Disk .....	195
B. Removing the OpenVMS Operating System .....	197
C. Alternative Ways to Initialize the System Disk .....	199
Alternative Method of Initialization .....	199
Removing the Diagnostic Partition File .....	200
Index .....	201

# Preface



## About VSI and this document

This document explains how to install, or upgrade to, VSI OpenVMS Version 8.4-1H1 for HP Integrity Servers. *Please note that VSI OpenVMS Version 8.4-1H1 does not support HP Alpha systems.*

Also described are the prerequisites for installing or upgrading your software plus the required and optional tasks you can perform after completing the software installation or upgrade.

VMS Software, Inc., (VSI) is an independent software company licensed by Hewlett-Packard Development Company, L.P. to develop and support the OpenVMS operating system. As such, VSI does not produce computer hardware. In an effort to remain focused on *software* installation, this manual attempts to describe procedures in a manner that is compatible with industry standard console interfaces, such as EFI (Extensible Firmware Interface). HP Integrity servers use the EFI console, so with only minor variations among system models, users should have little trouble relating the information and examples to their systems.

Users of this manual are expected to obtain and reference as needed, any additional documentation specific to their hardware. Users are expected to know how to identify the various devices involved in their installation and be familiar with the console commands that are available on their system.

## A Proud Heritage

Users familiar with our product have known it as simply "VMS" ever since its inception in the mid 1970's by DEC (Digital Equipment Corporation). VMS stands for "Virtual Memory System", which is a revolutionary technological innovation of that period. The original "VAX" (Virtual Address eXtension) architecture was a predominant 32-bit architecture for nearly a decade until it was superseded by the high-performance Alpha 64-bit architecture in the late 1990's. In the first decade of this century, VMS was ported to the Intel Itanium (IA64) architecture where it runs today on the full lineup of HP Integrity servers.

Over the years, VMS has seen its owner and its name change several times, yet it continues to enjoy a dedicated global customer base. VMS and VMS Clusters are well known for their high availability, unparalleled security (virus-free, "Cool and Unhackable" {quote from DEFCON}) and scalability. For these reasons and more, VMS has found its way into some of the world's most demanding corporate, government and military applications.

With the formation of VMS Software Inc., we intend to build on our proud heritage and bring the virtues of this great operating system to a wider customer base, including a future port to the Intel x86 architecture. Considering the state of our world today, surely a mature, virus-free, totally secure, user-friendly, high-performance operating system has a place among businesses of all sizes.

## What's in a Name?

VMS has brandished a few marketing prefixes and suffixes during its evolution. Version 8.4-1H1 is the release where product development passes from Hewlett-Packard to VMS Software Inc. The full product name from Hewlett-Packard is: *HP OpenVMS Version 8.4-1H1 for Integrity Servers*. As you might imagine, this does not make for a readable document when the product name is referenced hundreds of times!

To distinguish the VMS Software Inc. product, we shall refer to it throughout this document as *VSI OpenVMS* and its predecessor as *HP OpenVMS*. If specific versions need to be referenced, a version

number will appear. Lacking a specific version reference, readers should note that we are referring to the current release version *8.4-1H1*. Future product naming is a topic for the future...

At this time, VSI is not currently licensed to develop or support the HP Alpha architecture, therefore we do not typically distinguish among architectures in this manual. However, in certain sections of this manual, we discuss compatibility among versions and therefore, we will identify *HP Alpha* where necessary.

## New and Changed Information in this Edition

The following information is new or revised for VSI OpenVMS Version 8.4-1H1:

- With this release, the VSI and HP Operating Environment (OE) names have changed. VSI and HP support two OE's:
  - The *Base Operating Environment*, containing the essential components required by all customers, including the OS, several layered products, networking options, languages, etc.
  - The *High Availability Operating Environment*, containing the Base Operating Environment plus additional components to support mission critical computing requirements, including VMS Clustering, Volume Shadowing, Reliable Transaction Router, etc.

For more information, see the *VSI OpenVMS Version 8.4-1H1 Software Product Description (SPD)*.

- Re-branding is ongoing and evident everywhere from documentation to licensing and the operating system itself. This is an iterative process that will take some time to sort out. Although VMS Software Inc. is an independent entity, our products remain closely tied to Hewlett Packard, therefore you will see a lot of both brands, VSI and HP. This is particularly evident in documentation and licensing.

## Software Licensing and Rebranding

The *Software Product Description (SPD)* mentioned in the previous section, contains a wealth of information related to products and licenses. Refer to the SPD for official licensing details.

Much work has gone into branding and licensing now that VSI owns ongoing development of OpenVMS. We have rebranded licenses for VSI OpenVMS to list "VSI" as the license *Producer* for the OS and the layered products VSI supports. If existing customers are *updating* to the VSI OpenVMS, their existing HP branded licenses will continue to work after the upgrade. New installations of the OS and VSI supported layered products will receive VSI branded licenses. We are working closely with HP to assure a smooth transition, regardless of where these product are purchased.

When you perform an *upgrade* from HP OpenVMS to VSI OpenVMS, the PCSI installed product database, excluding any HP patch entries, will be re-branded. This occurs one time only and is required to assure consistency for license management functions.

The example below, shows what you will see during upgrade re-branding.

The target disk contains a Hewlett-Packard (HP) branded OPENVMS platform. The Platform, the Operating System, and all System Integrated Products must be rebranded as VMS Software, Inc. (VSI), and all Layered Products must have their dependencies updated from HP to VSI.

```
----- Rebranding started -----  
Identifying System Integrated Products...  
Identifying additional Layered Products and Patches...  
Creating PDFs for VSI System Integrated Products...
```

## Preface

Identifying Layered Products now available from VSI...  
Extracting PDFs for Layered Products and Patches from PCSI Database...  
Determining interdependence of Layered Products and Patches...  
Converting PDFs for all Layered Products and Patches to VSI dependence...  
Saving and then removing the existing PCSI database...  
Creating the new PCSI database by registering the OPENVMS Platform...  
Registering all remaining Layered Products and Patches...  
Ensuring validity of the resulting PCSI database...

----- Rebranding finished -----

Rebranding successfully completed. A BACKUP save set  
of the original PCSI database has been created in:  
\$1\$DGA2105:[000000]SAVED\_PCSI\_DATABASE.BCK

This will be deleted after the upgrade is complete.

Continuing the upgrade...

The following products have been installed:

VSI I64VMS CDSA V2.4-322A	Layered Product
VSI I64VMS DECNET_PLUS V8.4-A	Layered Product
VSI I64VMS DWMOTIF V1.7-A	Layered Product
VSI I64VMS DWMOTIF_SUPPORT E8.4-1H1	Layered Product
VSI I64VMS HPBINARYCHECKER V1.1-A	Layered Product
VSI I64VMS KERBEROS V3.2-256	Layered Product
VSI I64VMS OPENVMS E8.4-1H1	Platform (product suite)
VSI I64VMS SSL V1.4-496	Layered Product
VSI I64VMS TCPIP V5.7-13ECO4	Layered Product
VSI I64VMS VMS E8.4-1H1	Operating System
VSI I64VMS WBEMCIM V2.99-B100614	Layered Product
VSI I64VMS WBEMPROVIDERS V2.2-3A	Layered Product

The following products have been removed:

HP I64VMS VMS84I_PCSI V4.0	Patch (maintenance update)
HP I64VMS VMS84I_UPDATE V10.0	Patch (maintenance update)
VSI I64VMS AVAIL_MAN_BASE V8.4	Layered Product
VSI I64VMS CDSA V2.4-322	Layered Product
VSI I64VMS DECNET_PLUS V8.4	Layered Product
VSI I64VMS DWMOTIF V1.7	Layered Product
VSI I64VMS DWMOTIF_SUPPORT V8.4	Layered Product
VSI I64VMS HPBINARYCHECKER V1.1	Layered Product
VSI I64VMS KERBEROS V3.1-152	Layered Product
VSI I64VMS OPENVMS V8.4	Platform (product suite)
VSI I64VMS SSL V1.4-334	Layered Product
VSI I64VMS TCPIP V5.7-13	Layered Product
VSI I64VMS TDC_RT V2.3-20	Layered Product
VSI I64VMS VMS V8.4	Operating System
VSI I64VMS WBEMCIM V2.96-A100211	Layered Product
VSI I64VMS WBEMPROVIDERS V2.0-4	Layered Product

### Note

You may notice that the VSI brand appears in the names of removed products. This is only a side-effect of the way the re-branding works. These were HP branded products.

# Part I. Before Installing or Upgrading

We anticipate that the typical user of this document will be following along with an actual installation as it progresses. Readers will require some preliminary information based on their computing environment then, as they proceed, quick-references to specific steps. After the basic installation, additional details are required to customize their installation.

With this scenario in mind, this document is structured in this same order, using four parts:

- **PART I - Before Installing or Upgrading.**

Readers are encouraged to review information pertaining to their computing environment with regards to type of installation or upgrade and clustered or non-clustered configuration.

- **PART II - During Installation or Upgrade.**

After review of the preliminary details, the reader should begin the activity and follow along with the sections pertaining to the *Installation Menu*.

- **PART III - After Installing or Upgrading.**

Following the installation or upgrade, the reader should refer to these post-installation details pertaining to their specific computing environment.

- **PART IV - Booting.**

This part describes the variety of boot methods, boot options, boot flags and boot related tools.

The various appendices contain additional information that may be relevant to specific computing environments.

Once you have been through the process a few times, this document becomes less important, but it should remain useful as a reference and checklist.

Throughout this manual, examples are taken from installations performed on HP Integrity servers. The reader may be required to identify minor command differences based on their specific system model.

## Note

There are several system management utilities offered by HP to assist with provisioning, partitioning, and installation of operating systems on HP hardware. It is beyond the scope of this manual to describe these vendor-specific programs. If you are interested in using these programs and procedures, you are encouraged to refer to specific documentation provided by HP. You may wish to obtain a copy of the *HP OpenVMS V8.4 Installation Manual* if you intend to continue using these HP-specific programs for your installation as that information will not be repeated here.

# Table of Contents

1. Getting Started .....	4
Obtaining the Distribution Image .....	4
System Preparation .....	6
Device Naming. Device-Naming Conventions .....	7
Determine your Environment .....	8
2. Before Non-Cluster Installation .....	9
Before Installation Checklist. Before Non-Clustered Installation .....	9
Boot Methods. Distribution Media Boot Methods .....	9
Console Prep. Preparing the Console .....	10
MP Console .....	11
Graphics Console .....	11
Console Selection. Selecting a Primary and Secondary Console .....	12
Selecting a Console on Legacy HP Integrity servers .....	13
ACPI Config. Checking the ACPI Configuration (Cell-Based Servers) .....	16
Target Disk. Selecting your Target Disk .....	17
Network Details. Determining your Network Requirements .....	17
License PAKs. Product Licensing Keys .....	17
3. Before Non-Cluster Upgrade .....	19
Before Non-Clustered Upgrade .....	19
Related Documents. Documentation References .....	19
Upgrade Cautions. Notes, Cautions, and Restrictions .....	20
Upgrade Paths .....	20
Update License Requirements .....	20
Components You Choose Not to Install .....	20
Licenses and Layered Products .....	21
Software That Must Be Manually Removed .....	21
Deconfigure Software. Software That Must be Deconfigured .....	21
Preventing Archived Files from Being Deleted .....	21
Upgrade Disk Prep. Preparing the System Disk for Upgrade .....	22
Checking the Directory Structure and Preserving Your Security Protections .....	22
Checking the SYSCOMMON Directories .....	22
Purging Duplicate Files from the System Disk .....	23
Examining the System Disk .....	23
Checking the Size of the System Disk .....	23
Returning Authorization and AGEN\$INCLUDE Files to the System Disk .....	24
Verifying System Parameters .....	25
Autogen Feedback. Ensuring a Recent FEEDBACK.DAT File .....	26
Shadow Environment. Shadowing Environment .....	27
Setting the Boot Device .....	28
Creating a Nonshadowed Target Disk .....	28
Upgrade Backup. Backing Up the System Disk .....	28
Finish Upgrade Prep. Finishing the <i>Before Upgrade</i> Tasks .....	29
4. Before Clustered System Installation .....	31
Before Clustered Installation Tasks .....	31
Cluster Documents. Cluster Documentation References .....	31
Cluster Matrix. Mixed Version and Architecture Cluster Systems .....	31
Single Architecture Cluster Support .....	32
Mixed Arch Matrix. Mixed Architecture Cluster Support .....	32
Required Cluster Info. Required OpenVMS Cluster Information .....	33
Dismount Cluster Disk. Dismounting the Target System Disk in the Cluster .....	34
Finishing the <i>Before Cluster Install</i> Tasks .....	34
5. Before Clustered System Upgrade .....	35
Before Clustered Upgrade Tasks .....	35
Cluster Upgrade Documents. Cluster Documentation to Review .....	35
Cluster Upgrade Matrix. Mixed-Version Support in a Cluster .....	35

## Before Installing or Upgrading

Upgrade Types. Types of Upgrades .....	36
CONCURRENT Upgrade .....	36
ROLLING Upgrade .....	37
Finishing the <i>Before Cluster Upgrade</i> Tasks .....	39

# Chapter 1. Getting Started

## Obtaining the Distribution Image

If you purchased OpenVMS from Hewlett-Packard, follow their recommended procedures for obtaining your distribution image. You may benefit from reviewing the rest of this section.

If you purchased an official VSI OpenVMS distribution DVD, proceed with the next section: *System Preparation*.

If you purchased OpenVMS from VMS Software Inc. and would prefer to download the distribution image via internet, you will need to select a local disk to place the image on and then prepare it as a bootable installation disk.

The following procedure demonstrates one way to acquire the image and prepare your installation disk. At sites that do not allow ftp access, you will need to use whatever methods are approved by your site for accessing the disk image, or request a physical DVD kit.

### Example 1.1. Downloading the Distribution Image from VSI

1. As a VSI customer, you should have received information regarding setting up a customer account. Contact your VSI sales representative if you have not received this information.
2. Visit **www.vmssoftware.com** and log into your customer account using the provided username and password. Select the appropriate menu item for downloading images.
3. Review the End User License Agreement (EULA). You will be asked to enter identification details and to accept the terms of the EULA.
4. Click on the button to download VSI OpenVMS V8.4-1H1 to your local system. The actual downloaded file will be named similar to: *OpenVMS V8.4-1H1 ISO.ZIP*. This is quite a large file, so plan accordingly.
5. Using the same procedure, download copies of the *Cover Letter*, *Software Product Description*, and *Installation Manual*.
6. If you do not have a copy of *UNZIP* for OpenVMS, download a copy of the **UNZIP-2.EXE** for your local system.
7. If you intend to install layered products, download the *Layered Products* disk image zip file also.
8. Be sure to have any license keys (PAKS) required for your installation. You can install licenses later, but it is generally easier to do so during the installation or upgrade.
9. Once the downloads have completed, you can log out of your customer account.
10. You now have two options:
  - a. Burn a DVD using the ISO image contained in the zip file (and another for layered products).
  - b. Use the ISO image as a Virtual Device to install from a local VMS disk.
11. **DVD Method:**
  - a. Choose a system having a DVD reader/writer and related utilities.
  - b. Transfer the zip file/s (and if needed, the UNZIP utility) to that system. If you use ftp, be sure to use the BINARY or IMAGE qualifier.

Install the UNZIP utility if needed. We recommend putting it in SYSSUPDATE.

## Getting Started

Define a symbol: **\$ UNZIP := \$SYSSUPDATE:UNZIP-2.EXE**  
To get help: **\$ UNZIP -h**  
Typical command: **\$ UNZIP -V zipfilename -d ddcu:[directory]**

- c. UNZIP the downloads into their local IMG files.
- d. Using your burner utility, burn the IMG file onto a DVD.
- e. Proceed with the installation or upgrade.

### Caution

IMPORTANT: Now that you have created a bootable DVD, the remaining instructions that describe the initial os loader DVD boot path: **fsn:\efi\boot\bootia64.efi** should apply to your installation process.

Once the image has been installed, your normal os loader boot path will be: **fsn:\efi\vms\vms\_loader.efi**

### 12.Virtual Disk Method:

- a. Transfer the zip file/s (and if needed, the UNZIP utility) to the local system that is hosting the target installation disk. If you use ftp, be sure to specify the BINARY or IMAGE qualifier.
- b. UNZIP the downloads into their local IMG files.
- c. Start the LD (logical disk) utility if needed. The command: **\$ SHOW DEV LD** will determine if the utility is running. To start the utility, enter: **\$ @SYSSSTARTUP:LD\$STARTUP**
- d. Use LD to create a virtual disk whose content is the IMG file.

**\$ LD CONNECT file.IMG** where *file* is the name of your kit image file.

**%LD-I-UNIT, Allocated device is LDA1**

Mount the device:

**\$ MOUNT/OVER=ID LDA1**

**%MOUNT-I-MOUNTED, label mounted on \_LDA1:**

If installing the Operating System (not layered products), prepare a destination disk:

**\$ MOUNT/FOREIGN/OVER=ID ddcu**

**%MOUNT-I-MOUNTED, label mounted on \_destdevice**

Move the installation kit to the destination device:

**\$ BACKUP/IMAGE LDA1: destdevice:/INIT**

**\$ DISMOUNT destdevice**

**\$ MOUNT/OVER=ID destdevice**

Ensure that the boot device is available:

**\$ @SYSSMANAGER:BOOT\_OPTIONS**

Select "B" to assign boot devices

Select "I" to add a new boot device 5

or, if there is already an entry for this device, either delete and recreate it, or select "5" to review and validate the entry.

Select "E" to exit

If you are using the Virtual Disk methods for installing layered products, you can access the product kits directly from the Virtual Disk via: **\$ DIR LDA0:[README]**

When you are done with the Virtual Disk, dismount it and disconnect via:

**\$ DISMOUNT LDA0**  
**\$ LD DISCONNECT LDA0**

You may choose to delete the zip and img files.

### Caution

IMPORTANT: Now that you have created a bootable hard drive, the remaining instructions that describe the initial os loader DVD boot path: **fsn:\efi\boot\bootia64.efi** no longer apply to your installation process.

Instead, your normal os loader boot path will be: **fsn:\efi\vms\vms\_loader.efi**. Keep this in mind as you continue.

13. You may now continue with System Preparation.

## System Preparation

It is convenient to set up a work area nearby your system as you will need to insert and remove the distribution media for the operating system and layered products and you may need to gather additional system details. Plan on spending approximately 1 hour for the basic installation; more for layered products.

Next you need to have access to the system console. Depending on your system, this may require installing a serial communication cable (null-modem cable) between your system's console port and a portable laptop computer or other suitable device capable of acting as a terminal or terminal-emulator (PuTTY, Kermit, Hyperterm, etc.). Directly connecting a physical terminal (ie. VT220 etc.) is also an option, but most people will prefer the convenience of having online access to documentation and other information on a laptop computer.

More advanced systems are likely to have remote management ports and management processors that provide for console access. You may need to set up and enable network access methods, such as TCP/IP and Telnet or SSH to access these systems. *As always, refer to your system documentation.*

You will need to be familiar with your computer system and console command environment. Specifically, you must be able to identify the physical location and logical name of the DVD drive that will contain the distribution media or an *InfoServer*-enabled system that serves the DVD, and the target drive where the installation will occur. Systems that do not have a built-in DVD reader may require temporary installation of a portable USB-DVD drive. There are numerous subtle console command variations among system models, so be sure to become comfortable with your console environment before proceeding.

HP Integrity servers take advantage of an industry standard console interface known as *EFI (Extensible Firmware Interface)*. This manual provides examples of EFI commands using general syntax which may have minor variations among system models. You should be able to figure out any of these minor variations easily enough based on the command verb and descriptions provided.

It is recommended that you record the installation procedure. A transcript is helpful if a problem occurs during installation. If you are using terminal emulation software, set the software to log the session. Otherwise, set up your system to record the installation procedure on either a hardcopy terminal or a printer attached to the console terminal.

In general, your system should be running the latest revision of firmware. Contact your hardware vendor if you need to verify or update firmware revisions. System Firmware is no longer provided on the operating system distribution media.

To determine the installed firmware version on servers supporting the EFI console, you can use the following command at the EFI Shell prompt:

```
Shell> info fw
```

As installation begins, the procedure will present a simple text script and menus of installation options. After answering the various prompts, you will shutdown and reboot the system. Aside from setting up the boot command details (optional boot flags, device names, etc.), very little additional console commands are required.

Various boot options can be configured during installation or while the operating system is running by using the OpenVMS Boot Manager procedure: SYSS\$MANAGER:BOOT\_OPTIONS.COM, as explained in: “Setting Boot Options for Your System Disk”. This utility is easier to use than issuing individual EFI commands, and it allows you to configure the most pertinent options for your system. In addition, the installation and upgrade procedure can assist you in establishing and validating boot options for your system disk.

**Of course you will want to read the release notes!**

## Device-Naming Conventions

Various console operations will ask for a *device name* for the source drive and one for the target drive. When specifying those device names, note the following naming conventions:

- When the source drive is a local DVD drive, the device name is similar to the following:

DQA0 (IDE drive) or DNA0 (USB drive)

For a device name, such as DQA0:, note the following conventions:

- *DQ* is the device code.
  - *A* is the device controller designation.
  - *0* is the unit number of the device.
- When the target drive is a local disk, the device name is similar to the following:

DKA0:

- When the source drive is a virtual DVD drive served by the InfoServer, the device name is similar to the following:

DAD1:

- On systems configured in certain OpenVMS Cluster or HSx environments, the device naming convention is similar to the following:

DUA20.14.0.2.0

The values you specify identify components such as the boot device, controller, unit number of the boot device, HSx controller node number, and channel numbers. Because these values vary depending on your specific hardware configuration, see the owner, operator, and technical service manuals that came with your computer for detailed information.

Within the EFI console environment, file system oriented devices will be assigned sequential names such as *fs0*, *fs1*, etc. Refer to your hardware documentation if you cannot identify the target device.

# Determine your Environment

Prior to starting your installation or upgrade, refer to the following sections for details specific to your system environment, then proceed to PART-II to begin your installation or upgrade.

---

<b>IF YOU ARE...</b>	<b>THEN REVIEW:</b>
INSTALLING in a non-clustered environment	<i>“Before Non-Cluster Installation”</i>
UPGRADING in a non-clustered environment	<i>“Before Non-Cluster Upgrade”</i>
INSTALLING in an OpenVMS Cluster environment	<i>“Before Clustered System Installation”</i>
UPGRADING in an OpenVMS Cluster environment	<i>“Before Clustered System Upgrade”</i>
BACKING UP or RESTORING your system	<i>“Backing Up and Restoring the System Disk”.</i>

---

# Chapter 2. Before Non-Cluster Installation

This chapter contains information to review and steps to perform before installing VSI OpenVMS in a non-clustered environment.

If you purchased a system with the operating system preinstalled, then most of the information in this chapter does not apply. The first time you power up a preinstalled system, you are prompted to enter only the information necessary to customize your installation. See the documentation provided with your system.

## Note

Before you install the VSI OpenVMS operating system, ensure that your system firmware is up to date.

## Before Non-Clustered Installation

Use the checklist below to ensure that you perform all necessary preinstallation tasks.

**Table 2.1. Before Installation Checklist**

TASK	SECTION
• Determine how to boot the distribution media.	Section Boot Methods
• Prepare your console.	Section Console Prep
• Set the ACPI Configuration (Cell-based servers).	Section ACPI Config
• Select your target system disk.	Section Target Disk
• Determine your network requirements.	Section Network Details
• Gather Product Authorization Key (PAK) licenses.	Section License PAKs
• Begin the installation.	PART-II

Click on the Section links in the above table to go to specific sections, or just skim through the remainder of this chapter in sequence before proceeding to PART-II.

## Distribution Media Boot Methods

Determine how you wish to boot the VSI OpenVMS distribution media. Once you have decided and have reviewed the relevant sections, return to the “Before Non-Clustered Installation”.

You can boot the distribution media in any of the following ways. Detailed instructions on each method are provided in corresponding sections to follow.

- From your local DVD drive (“Booting from a Local DVD Drive”)
- From a DVD drive served over the network by the OpenVMS InfoServer utility (“Booting from a Network InfoServer Utility”)
- From an image on a PC running Microsoft Windows™ in a network, accessed through the HP SIM interface (Not described here).
- From an image on a PC running Microsoft Windows™ in a network, using virtual media (vMedia) through a browser connected to your HP Integrity servers iLO 2 MP port (Not described here).

## Note

The latter two options can be used for entry-class HP Integrity servers that support such means (you can use these options when a local DVD drive is not available on your HP Integrity server). Refer to the HP documentation for these utilities.

# Preparing the Console

Before booting your OpenVMS distribution media, make sure your console is configured correctly. Once your console has been configured, return to the “Before Non-Clustered Installation”.

**If you are already using the system console, you can disregard the remainder of this section and return to the “Before Non-Clustered Installation”.**

If your machine has OpenVMS preinstalled, your console selection has been made by the factory, but you can change this if you like. If you have changed your system configuration, or if you are installing OpenVMS on a new (uninstalled) machine, or if you are reinstalling OpenVMS using the INITIALIZE option (removing all prior software and data files on the system disk), you might need to select the correct console, otherwise OpenVMS might use an unexpected console device, causing your system to appear to be hung; or with output sent to the wrong location.

On power-up, firmware displays information to the Primary and Secondary console devices. If you do not see the EFI Boot Manager displayed shortly after powering up, your console device is probably not selected as a Primary or Secondary device; you will need to connect your console terminal cable to the appropriate device. When booting OpenVMS, if you do not see OpenVMS console output and the system appears to be hung, your console terminal device might be connected to a Secondary console device instead of the Primary console device.

Decide which console to use and review the following section pertaining to your choice. OpenVMS can use one of the following types of consoles:

- **System Serial Port**
- **MP (or iLO MP) Serial Port**

The MP interface is only visible to OpenVMS if the MP Serial Port is selected as the Primary console.

- **MP (or iLO MP) Network Port**

The MP, being an independent processor itself, offer a Network Port and thus supports remote access to the console using Telnet or SSH connection.

- **Graphics (VGA) device**

Graphics console support allows you to use a Monitor, USB keyboard and mouse connected directly to the server. Certain older (legacy) servers, such as the rx2600, do not support a graphics console because they lack the required firmware capabilities. Other servers lack an integral VGA device, in which case a graphics option card is required for VGA console support.

The MP port is typically used by the OpenVMS operating system on HP Integrity servers. Connect a serial cable or network cable depending on which MP port you intend to use.

If using the serial port, you must connect a VT100–capable terminal or terminal emulator. On servers that do not have an MP port, the console serial port is enabled (generally located on the back of the server).

With the exception of some older server models, the firmware provides a text menu-based interface. The firmware also identifies console interfaces as “Primary”, “Secondary” and “Not Configured.” The Primary console is the console enabled for interacting with the operating system. Although the

firmware can interact with multiple console devices, OpenVMS uses only one of these devices as its console and requires that one device be selected.

You select one device to serve as the Primary console, as explained in “Selecting a Primary and Secondary Console” where more details are also given about the Primary, Secondary, and Not Configured console selections.

## MP Console

You can use the MP to establish remote console access, such as through the TELNET utility provided with TCP/IP Services for OpenVMS. Alternatively, you can access the MP console interface through the Internet using a browser.

If you intend to set up LAN or remote access for the MP console, you must initially use the serial port for console operations when you set up the machine for the first time. (See your hardware documentation for instructions on setting LAN or remote access for the MP console interface.)

On systems which support iLO-MP, OpenVMS enables the Integrated Console which provides a virtual keyboard, video and mouse (vKVM) to operate from a remote iLO browser window. The Integrated Console functionality allows both pre-boot (EFI), OpenVMS boot, and runtime (both text console and DECwindows) display and interaction from from the iLO browser window.

## Graphics Console

Most HP Integrity servers support multiple VGA graphics options. A graphics option consists of a graphics card and a graphics display interface (monitor). When multiple graphics devices are present, you can select only one device for use as a console device. The other graphics devices must be set to Not Configured (NC).

When DECwindows is used on a system booted using the VGA as the OpenVMS console, DECwindows selects the VGA console as the default screen. When enabling multihead DECwindows graphics operation, the VGA console defaults to screen 0. If no VGA device is configured as a console, DECwindows selects a default screen based on the HP Integrity server model and device bus ordering.

By default, the maximum resolution of the graphics display in DECwindows is 1024x768. This is a restriction of the iLO-MP firmware. To use the Integrated Console, the system must be set up with VGA as the primary console. Both the local keyboard, video and mouse can be used in addition to (or at the same time) with the remote iLO Integrated Console. Performance of DECwindows graphics using the iLO Integrated Console will vary depending on the speed of the LAN, and in general is only recommended for doing occasional system management functions that do not require performance sensitive graphics.

Note the following restrictions:

- OpenVMS supports up to four add-on graphics devices plus any built-in graphics, depending on the server model and available slots. The firmware available on some servers might limit which devices can be used as a VGA console device. For information about your specific configuration's platform and graphics configuration rules, see your hardware documentation .
- For correct operation of the VGA console, OpenVMS requires that at least one other non-VGA device be configured as the Secondary console.
- XDELTA (low-level system debugger) is not available when using the VGA console.
- Conversational (interactive) boot (SYSBOOT>) is not supported with the VGA console. To change SYSGEN parameters, use SYSGEN from OpenVMS, or boot OpenVMS from a non-VGA console.
- When using a VGA console and installing from a USB DVD drive with the keyboard plugged into a USB hub, the keyboard might not be operational initially. To enable keyboard operation, simply unplug the hub and plug it back in.

## Selecting a Primary and Secondary Console

On HP Integrity servers other than the rx2600, console devices can be configured as one of the following:

- **PRIMARY CONSOLE**—The device enabled as a console for the firmware interface and used as the OpenVMS console (OPA0). If a VGA device is selected as the Primary console, at least one serial device path must be set as a Secondary console in order to use the VGA device to boot OpenVMS.
- **SECONDARY CONSOLE**—A device enabled as a console for the firmware but not used as the OpenVMS console during or after booting. The device is configured as a normal serial port device. If you specify an MP port as the Secondary console, it will not be visible to OpenVMS. The MP port is visible to OpenVMS only when selected as a Primary console. If multiple serial ports are available as a console on your HP Integrity servers and you select one for a Secondary console, do not use that console for transmission of binary data.
- **NOT CONFIGURED**—A device that is not enabled as a console for the firmware or operating system.

Your system can be booted from any Primary or Secondary console but OpenVMS output displays only on the Primary console.

Select a console in one of two ways:

- Using the EFI Boot Manager, as described in “Using the EFI Boot Manager to Select the OpenVMS Console”
- Using the EFI shell, as described in “Using the EFI Shell to Select the OpenVMS Console”

## Using the EFI Boot Manager to Select the OpenVMS Console

### Note

The (slightly fuzzy) examples in the following two subsections show how to select a VGA device for the OpenVMS console.

To select the device for your OpenVMS console using the EFI Boot Manager, follow these steps.

1. From the EFI Boot Manager screen, use the up or down arrow key to select the Boot Configuration menu and press **Enter**:
2. From the Boot Configuration menu, select the Console Configuration menu and press **Enter**:
3. If the Console Configuration menu shows that your preferred device is already configured as the Primary console, you need not continue; otherwise, select the device that you want as the OpenVMS Primary console. In the following screen, the VGA device is selected:
4. Enter **P** to configure the selected device as the Primary console. You then see the selected device as the Primary console:
5. Press the **Esc** key to return to the previous menu. When prompted whether to save changes to NVRAM, enter **Y**:
6. When prompted whether to reset the system, enter **Y** to make the changes take effect:

## Using the EFI Shell to Select the OpenVMS Console

To select the device for your OpenVMS console using the EFI shell, follow these steps:

1. At the EFI Shell prompt, enter the **conconfig** command to view the index number for the available console devices, as in the following example (the column titled “Primary” displays how the device is configured (P for Primary, S for Secondary, NC for Not Configured)):

```
Shell>conconfig
CONSOLE CONFIGURATION
```

Index	Primary	Type	Device Path
1	P	Serial	Acpi (PNP0501,0)
2	S	Serial	Acpi (HWP0002,700)/Pci (1 1)
3	S	VGA	Acpi (HWP0002,700)/Pci (2 0)

2. If your preferred device is already configured as the Primary console, you need not continue. If your preferred device is not currently configured as the Primary console, enter the **conconfig** command in the following format:

```
conconfig index primary
```

where *index* is the index number of the device preferred for the OpenVMS console. In the following example, the VGA device is selected as the Primary console, and the resulting display reflects the configuration change:

```
Shell>conconfig 3 primary
CONSOLE CONFIGURATION
```

Index	Primary	Type	Device Path
1	S	Serial	Acpi (PNP0501,0)
2	S	Serial	Acpi (HWP0002,700)/Pci (1 1)
3	P	VGA	Acpi (HWP0002,700)/Pci (2 0)

3. Enter the reset command to make the changes active, as in the following example:

```
Shell>reset
```

Once your console has been configured, return to the “Before Non-Clustered Installation”.

## Selecting a Console on Legacy HP Integrity servers

This section describes how to select a console on rx2600 HP Integrity servers or other servers with outdated firmware. On such servers, you must configure a Console Input, Console Output, and Console Error Device for your OpenVMS console. There is no concept of the Primary console that automatically configures these devices. In addition, on such servers OpenVMS does not support graphics consoles.

### Note

The following instructions assume that OpenVMS is not installed on your server and that boot options are not defined.

1. **Decide what console you want to use.**

2. **Power on the system. If using an MP serial port, log in to the MP and access EFI.**

If you are setting the system serial port as your system console, go to the next step now.

If you are setting the MP serial port as your system console and you have just powered on your server, the MP console interface prompts you to log in. (By default, both user name and password are set to Admin. For security purposes, change the password immediately. See your hardware documentation.)

**Note**

To see the MP login user name and password prompts, you might need to press **Enter** one or more times on your console keyboard. If this does not work, try pressing **Ctrl/B**.

If you see only the MP password prompt, press **Enter** to get to the MP login prompt.

If you see a message similar to the following, another user has the console (only one user can write to the console, although multiple users can view it).

```
[Read only - use Ctrl-Ecf for console write access]
```

To gain control of the console from the other user, press **Ctrl/E**, release the key combination, and then immediately type the letters **cf**. Alternatively, you can have the other user log off.

When the MP> prompt is displayed, move to the EFI interface by entering the **co** (console mode) command. If the power or initialization sequence has not completed, wait until the menu reappears, at which point reenter the **co** command to get to the EFI Boot Manager menu.

At the EFI Boot Manager menu, select the EFI Shell interface.

On HP Integrity servers without nPartitions, the **co** command brings you directly to the EFI Boot Manager screen. If you do not enter a command before the EFI countdown timer expires (typically 10 seconds), the EFI Shell prompt is displayed. When the operating system is running, the **co** command brings you to the console port of the operating system (OPA0).

On cell-based servers, unless you are using a single-partition user account, the **co** command first brings you to a console menu that lists the available nPartitions. Select the appropriate nPartition to access the EFI Boot Manager console for that nPartition. The following example shows a console menu (menus and displays such as this might vary from system to system):

```
Partitions available:
```

```

#      Name
---  ----
1)    MIA1
2)    MIA2
3)    TESTING
4)    LAN
5)    AMYS
6)    ACCNTS
Q)    Quit
```

```
Please select partition number:
```

If the **co** command results in a screen that is unexpected or difficult to interpret, pressing **Enter** might help. If you are at an EFI submenu instead of the main menu, navigate to the main menu by exiting from the submenu and any subsequent submenus until you return to the EFI main menu.

3. **Access the EFI Boot Configuration menu.** The EFI Boot Manager screen includes a boot menu. The default menu option is highlighted, as shown in the following example:

## Note

The appearance of EFI Boot Manager screens and menus differs from version to version of the firmware.

```

Boot Menu

EFI Shell [Built-in]
Internal Bootable DVD
-----
Boot Configuration
System Configuration
Security Configuration

```

From the EFI boot menu, select the Boot Configuration option (or Boot Option Maintenance Menu). To move to an option, use the up or down arrow key. (With some terminal emulators, you might have to use the letter v to scroll down or the caret (^) to scroll up.) Press **Enter** to toggle the selection. If you do not select an option within the countdown period, EFI moves to the default option—the EFI Shell in the boot menu example, in which case the EFI Shell prompt is displayed.

Exit the EFI Shell to return to the Boot Configuration menu. If lines from the preceding screen linger and obscure the EFI Shell prompt, press **Enter** to bring the EFI Shell prompt into view.

4. **Configure the Console Input, Console Output, and Console Error Devices.** Select the Console Configuration option from the Boot Configuration menu to list the console input, console output, and console error device options. Some versions of EFI list the three console device options directly in the Boot Option Maintenance Menu. Configure each console option one at a time, as follows:

## Note

OpenVMS requires that the input, output, and error console all must point to the same serial-line console device. New systems might be shipped with multiple devices selected for each of the console types, so make sure only one device is selected for each. If you see an error message that mentions multiple device-path instances for the console input or output device, perform the following steps to select a single console only.

On rx2600 HP Integrity servers and certain other servers with firmware that is not up to date, OpenVMS might not boot using a USB keyboard or a VGA graphics display device. The system might boot with these devices but does not display any indication that the system is booting. You might receive a warning when the system begins to boot. You might also see other errors in later stages of the boot. Additionally, you might lose output that you normally see during booting.

- a. **Select the console input device.** EFI displays a list of devices (device paths) available for console input. Select only one device from this list, and deselect any unused devices. The following is a sample list of devices, annotated with explanatory text below the list. This example shows the devices for an entry-class HP Integrity server.

### System Serial Port

These four lines indicate any of the valid devices that you can define for the console using the system serial port. Any line that has the notation UART but not the notation PCI is one of the system serial ports. Notice that the lines are almost identical except for the text following the VenMsg portion indicating the terminal emulation protocol such as

VT100. Thus, each of the four entries is the same device with different emulation protocols.

**MP Console**

These four lines appear only on systems that have an MP port. Any lines that include both UART and PCI are MP serial port devices. As with the serial port devices, these four lines refer to the same device with different emulation protocols.

**VGA Device**

This is the graphic console device. Do not select this. OpenVMS does not support VGA graphics as a console output device for booting on rx2600 and older servers.

Select a device using the protocol appropriate for your terminal emulator (in most cases, VT100+ is the best choice). Select only one device line. OpenVMS does not operate if more than one device is selected.

- b. **Save your settings to NVRAM.**
  - c. **Select the console output device.** Repeat steps a and b to configure the console output device. Select the same device you selected for the console input device.
  - d. **Select the console error device.** Repeat steps a and b to configure the console error device (also referred to as the standard error device). Select the same device you selected for the console input and output devices.
5. **Perform a cold reset if required.** Your system might require a cold reset. Newer versions of EFI do not require a cold reset. For more information, see your hardware documentation.

## Note

Whenever new console devices are added to a system, or the NVRAM on a system is cleared, review your console selections. When you change serial devices, you must also make changes to the input, output, and error console device options to ensure proper operation.

Once your console has been configured, return to the “Before Non-Clustered Installation”.

# Checking the ACPI Configuration (Cell-Based Servers)

## Caution

To boot your operating system on an **HP cell-based server (Superdome servers, or midrange servers such as rx8620 and rx7620)**, the ACPI configuration must be set correctly.

The ACPI configuration value determines, among other things, the EFI Path format used when referencing devices. If your OpenVMS operating system was factory installed, the ACPI configuration is set correctly. If the nPartition on which you want to boot your OpenVMS system had previously been running a non-VMS operating system, then enter the following command at the EFI Shell prompt to set the partition:

```
EFI> acpiconfig default
```

To make this new value take effect, you must reset the nPartition by using the EFI Shell **reset** command:

```
EFI> reset
```

If the ACPI configuration value is not set properly, when the operating system boots, it fails with bugcheck code INCONSTATE.

To display the current configuration value, enter the **acpiconfig** command with no arguments:

```
EFI> acpiconfig  
Acpiconfig settings: default
```

Once your ACPI Configuration has been set, return to the “Before Non-Clustered Installation”.

## Selecting your Target Disk

Identify the target disk for your installation or upgrade and locate the logical name of the disk from your EFI console.

You will need to identify both the EFI logical name (**fx**) and the eventual OpenVMS device name (i.e. **DKA100**). Refer to “Device-Naming Conventions” for help with device naming conventions.

### Note

If you are installing a new copy of OpenVMS, you can select the INITIALIZE option from the Installation Menu to initialize the target disk, or if you prefer, you can initialize the disk prior to its use. Note that you cannot install OpenVMS in a disk partition shared with another type of operating system.

Once your target disk has been identified, return to the “Before Non-Clustered Installation”.

## Determining your Network Requirements

During installation, you will need to decide whether you want to use TCP/IP Services for OpenVMS, DECnet Phase IV, DECnet Plus for OpenVMS (DECnet over IP), or a combination of these products. It is common to configure network adapters for both TCP/IP and DECnet, although DECnet Plus allows you to use the DECnet protocols over IP.

These network products are licensed as part of the base operating environment and as such, they do not require separate licenses.

Any of the network products can be installed after the base OS installation, but it is often easier to install them along with the base OS. To do this, you will need to gather details for your network addresses (IP Address and Mask and/or DECnet Address) and if using DECnet, a DECnet SCS Node Name. Consult with your network administrator to determine these details.

You should also determine which network adapters in your system that you wish to assign. These will be assigned with OpenVMS device names, i.e. EWA0, etc. Again, these details can be configured after the base OS installation if you prefer.

Determine what, if any, TCP/IP Services you wish to enable or disable, such as Telnet, SSH, routing etc.

Once your network requirements are known, return to the “Before Non-Clustered Installation”.

## Product Licensing Keys

During the installation, you will be prompted to enter Product Authorization Keys (Licenses) for the base operating environment and any layered products that are not already included in the base OS.

A PAK is represented as a text structure containing a series of named fields and unique values that were generated by VSI (or HP). During installation or upgrade you will be asked to enter the PAK for

## Before Non-Cluster Installation

the Base Operating Environment and then for any layered products that you are installing. You have the option of deferring PAK entry until after the installation and entering them using the OpenVMS LICENSE utility. If you choose to enter your PAKs, you can either type the values of each requested field, or cut-and-paste the values into the console (assuming your console connection supports this action (i.e. Terminal Emulators do).

Below is an example of a typical PAK:

```
$ LICENSE REGISTER OPENVMS-I64-BOE -  
/ISSUER=VSI -  
/AUTHORIZATION=AUTHORITY-2-I64-123456 -  
/PRODUCER=VSI -  
/UNITS=0 -  
/TERMINATION_DATE=31-OCT-2015  
/OPTIONS=( IA64 ) -  
/CHECKSUM=X-XXXX-XXXX-XXXX-XXXX
```

**This concludes the Before Installation Tasks.**

Gather any PAKs you intend to register, then return to the “Before Non-Clustered Installation”.

# Chapter 3. Before Non-Cluster Upgrade

This chapter contains information to review and steps to perform before upgrading an existing system in a non-cluster environment.

## Before Non-Clustered Upgrade

Use the checklist below to ensure that you perform all necessary tasks prior to upgrading your system.

**Table 3.1. Before Non-Clustered Upgrade Checklist**

TASK	SECTION
• Review relevant documentation.	Section Related Documents
• Review notes and restrictions about the following:	Section Upgrade Cautions
• Upgrade paths to VSI OpenVMS Version 8.4-1H1	
• Update license requirements	
• Components you choose not to install	
• Upgrade issues after the system disk directory structure has been changed	
• Licenses and possible reinstallation requirements for layered products	
• Save files that you do not want deleted by the upgrade procedure.	Section Deconfigure Software upgrade procedure.
• Prepare the system disk.	Section Upgrade Disk Prep
• Ensure that you have a recent FEEDBACK.DAT file.	Section Autogen Feedback
• Perform required actions before upgrading in a volume shadowing environment.	Section Shadow Environment
• Back up the current system disk.	Section Upgrade Backup
• Shut down the current system to begin upgrade.	Section Finish Upgrade Prep

## Documentation References

In addition to reviewing the information in this chapter, you might need to refer to the following sources of information as well.

- *Cover Letter for VSI OpenVMS Version 8.4-1H1*
- Software Product Descriptions included with your distribution kit
- *VSI OpenVMS Version 8.4-1H1 Release Notes*
- *VSI OpenVMS Version 8.4-1H1 New Features and Documentation Overview*
- *OpenVMS System Manager's Manual, Volume 2: Tuning, Monitoring, and Complex Systems* (specifically, the chapter entitled “Managing System Parameters”), for information about using AUTOGEN, modifying the system parameters file (MODPARAMS.DAT), and related operations
- *OpenVMS System Management Utilities Reference Manual*, for information about using system management utilities such as SYSMAN and ANALYZE/DISK\_STRUCTURE

- *OpenVMS Guide to System Security*, for information about reestablishing your security environment after the upgrade

## Notes, Cautions, and Restrictions

This section provides important information that can affect the success of your upgrade. Review the cautions, restrictions, and notes carefully before you begin the upgrade.

### Upgrade Paths

You can upgrade directly to VSI OpenVMS Version 8.4-1H1 from only the following versions of HP OpenVMS:

- HP OpenVMS Version 8.4U900
- HP OpenVMS Version 8.4U1000

If you are running versions prior to these, you must incrementally upgrade to one of these versions before upgrading to VSI OpenVMS 8.4-1H1, or you can choose to perform a complete installation rather than an upgrade.

#### Important

Additional upgrade paths may be qualified over time.

### Update License Requirements

#### Important

Before upgrading to VSI OpenVMS Version 8.4-1H1, you must register the appropriate OE license on your system using the OpenVMS LICENSE utility.

VSI software licenses grant the right to use the current version of a product or any previous version of the product at the time of purchase.

#### Note

When you initially purchase the OpenVMS software and license, VSI (or HP) provides a Product Authorization Key (PAK) that is required to enable the License Management Facility (LMF) to register the license and to validate and authorize subsequent use of the product. A PAK does not provide license or new version rights. For more information about licensing and the License Management Facility, see the *OpenVMS License Management Utility Manual*.

#### Note

As mentioned in the preface of this manual (“Software Licensing and Rebranding”), the first time you install or upgrade your system to VSI OpenVMS 8.4-1H1 your existing product license database entries will be re-branded to list VSI as the Producer. This change affects only the license names (to avoid confusion in the License Management Facility) and does not alter the terms of existing licenses or the behavior of the existing products.

If you need an Update License, please contact your VSI Sales representative <info@vmssoftware.com>.

### Components You Choose Not to Install

If you choose not to install optional OpenVMS networking software (DECnet or TCP/IP) or the DECwindows/Motif GUI during the upgrade, the upgrade procedure removes these products from the system disk.

## Note

Unless you have specific reasons to do otherwise, VSI recommends that you accept the defaults and install all VSI OpenVMS options. VSI OpenVMS and layered products have various dependencies on many of these options. Even if you think you do not need certain options, some VSI OpenVMS or layered product operations might not work correctly if other VSI OpenVMS options are not installed.

Note that the availability of certain options depends on the OE you have purchased. For more information, see the *VSI OpenVMS Software Product Description* (SPD V8.4-1H1).

## Licenses and Layered Products

The upgrade procedure is designed so that you do not need to reinstall most layered products after the upgrade. However, you might need to reinstall certain layered products because of product-specific installation procedures.

The upgrade procedure leaves your OpenVMS license and layered product licenses intact. You do not need to reinstall these licenses after you upgrade.

## Software That Must Be Manually Removed

Before upgrading, if you are currently using DECram or TDC V2.0, these products must be removed manually; otherwise, the upgrade might fail. For other information about software that might need to be removed manually, see the *VSI OpenVMS Version 8.4-1H1 Release Notes*.

## Software That Must be Deconfigured

Before upgrading, if you are using or have configured WBEM Providers for OpenVMS, you must manually deconfigure WBEM Providers by entering the following command:

```
$ @SYS$COMMON:[WBEMPROVIDERS]WBEMPROVIDERS$DECONFIGURE.COM
```

## Preventing Archived Files from Being Deleted

By default, the upgrade procedure deletes files that were archived as *filename.type\_OLD* by OpenVMS remedial kits. If you do not want these files deleted, you can rename them before you perform the upgrade. Alternatively, you can have the upgrade procedure save them by responding to the prompts, as described below.

- When the installation procedure asks whether you want the defaults for all options, answer NO. (This script is shown in the example in “Selecting Product Component Options”.) Step through the options and answer NO to the option for deleting files archived by remedial kits. This action saves all such files.
- Before beginning the upgrade, rename any *\_OLD* files that you want to save. Files that you do not rename are deleted.

Note that the upgrade does not delete all files with a file extension ending in *\_OLD*. Rather, it deletes only those *\_OLD* files that were archived by OpenVMS remedial kits.

## Note

OpenVMS patches save these *\_OLD* files in *VMSS\$REMEDIAL\_OLD\_FILES.TXT* in the *SYS \$UPDATE* directory. All files listed in this file are supposed to have *\_OLD* appended to their names; however, some patch kits add the files without this extension. If the upgrade procedure detects files without *\_OLD* appended, it displays a message similar to the following:

```
%UPGRADE-I-FIXUP, appending _OLD to file names in
PCSI$DESTINATION:[SYSUPD] VMS$REMEDIAL_OLD_FILES.TXT
[SYSUPD]VMSKITBLD.DAT
[SYSHLP]XFC$SDA.HLP
[SYS$LDR]SYSTEM_SYNCHRONIZATION.EXE-OLD
[SYS$LDR]SYS$XFCACHE.DSF
[SYS$LDR]SHELL9K.EXE_STB
[000000]HP-I64VMS-VMS-V0820-1-2.PCSI$DESCRIPTION
```

## Preparing the System Disk for Upgrade

The following tasks are required to prepare the system disk for the upgrade.

- Check the directory structure and preserve security protections
- Check the SYSCOMMON directories
- Purge duplicate files from the system disk
- Examine the system disk
- Check the size of the system disk
- Return Authorization and AGEN\$INCLUDE files to the system disk
- Verify System Parameters

## Checking the Directory Structure and Preserving Your Security Protections

If you changed the directory structure on your system disk, the upgrade procedure does not work correctly. Restore your system disk to a standard directory structure before you attempt an upgrade.

The OpenVMS upgrade procedure provides new files and directories in the directory [VMS \$COMMON...]. If you have any special protections and access control lists (ACLs), you need to reapply them to reestablish the security environment you currently have. For more information about creating and maintaining a secure environment, see the *OpenVMS Guide to System Security* manual.

## Checking the SYSCOMMON Directories

For the upgrade to be successful, the SYSCOMMON directories in all system roots must be aliases (or hard links) for the VMSS\$COMMON directory. To check whether this is the case, enter the following commands if you are booted from the system disk that you are upgrading, and compare the displayed file identifiers to ensure that they are all the same:

```
$ DIRECTORY/FILE_ID/NOHEADING/NOTRAILING SYS$SYSDEVICE:[000000]VMS$COMMON.DIR
$ DIRECTORY/FILE_ID/NOHEADING/NOTRAILING SYS$SYSDEVICE:[SYS*]SYSCOMMON.DIR
```

If you did not boot from the system disk that you are upgrading, mount the disk to be upgraded and specify the actual device name in the command. For example, if the system disk to be upgraded is mounted on DKA100, you would use commands similar to the following:

```
$ DIRECTORY/FILE_ID/NOHEADING/NOTRAILING DKA100:[000000]VMS$COMMON.DIR
$ DIRECTORY/FILE_ID/NOHEADING/NOTRAILING DKA100:[SYS*]SYSCOMMON.DIR
```

Output from the first command should list a single file. Output from the second command should list one file for each system root on the disk. Check whether the file ID is the same for all of the listed files and take action as follows:

- If all the file IDs are the same, continue with the procedure described in the next section.
- If all the file IDs are not the same, this system disk does not have the directory structure that OpenVMS requires, and the upgrade will not succeed. For assistance on resolving this, contact your software support representative.

## Purging Duplicate Files from the System Disk

To free up disk space and file headers, purge the system disk of certain large files. VSI recommends that you enter the following commands, as shown:

```
$ PURGE/LOG/BEFORE=TODAY SYS$SYSDEVICE:[000000...]*.LOG
$ PURGE/LOG SYS$SYSTEM:PAGEFILE*.SYS
$ PURGE/LOG SYS$SYSTEM:SWAPFILE*.SYS
$ PURGE/LOG SYS$SYSTEM:SYSDUMP.DMP
```

Check the system disk for application and system dump files by entering the following command:

```
$DIRECTORY/SIZE/DATE SYS$SYSDEVICE:[000000...]*.DMP
```

If any .DMP files are found, use your discretion and delete them. Unless these files are important for a current problem investigation, they are unlikely to be applicable after the new version upgrade and they may consume a significant amount of disk space.

## Examining the System Disk

Examine and repair if necessary, the system disk using the `ANALYZE/DISK_STRUCTURE` command. (See the *OpenVMS System Management Utilities Reference Manual: A-L* for more information about this command.) Use the following procedure:

1. Analyze the system disk for inconsistencies and errors in the file structure by entering the following command:

```
$ ANALYZE/DISK_STRUCTURE SYS$SYSDEVICE
```

Ignore the following message:

```
%ANALDISK-I-OPENQUOTA, error opening QUOTA.SYS
```

2. If you find any other errors on the system disk, repair the errors by entering the following command:

```
$ ANALYZE/DISK_STRUCTURE/REPAIR SYS$SYSDEVICE
```

Repeat steps 1 and 2 until no errors (other than the one shown in step 1) are returned.

## Checking the Size of the System Disk

It is difficult to determine in advance how many blocks of disk space you need for the upgrade. It depends on how many files you have on the target disk already and on how many components you select during the upgrade procedure. However, the following information will help:

- The *maximum* amount of disk space you need is approximately 18,000,000 blocks, but your system might use substantially less.
- After you select the components you want installed on the system for the upgrade, the upgrade procedure calculates whether you have enough disk space, displaying the number of available blocks and the number required for the upgrade. If the procedure determines that your disk does not have enough space to perform the upgrade, it displays a message to alert you and allows you to terminate the upgrade so you can create more disk space and try the upgrade again.

### Note

If the files on your system disk are badly fragmented, you might not be able to complete an upgrade, even when the amount of disk space appears to be sufficient. VSI recommends that you back up and restore the system disk prior to upgrading. Restoring the system disk from

an image backup defragments the disk. For information about backing up and restoring your system disk, see “*Backing Up and Restoring the System Disk*”.

To see how much space you have on the system disk, enter the following command:

```
$ SHOW DEVICE SYS$SYSDEVICE
```

## Returning Authorization and AGEN\$INCLUDE Files to the System Disk

If you place authorization and AGEN\$INCLUDE files on disks other than the system disk, the upgrade procedure will not find these files. This is because the other disks are not mounted during the upgrade. In addition, the logical names you set up to point to these files are not defined during the upgrade. The following sections explain how to make these files available to the upgrade procedure.

### Authorization Files

OpenVMS allows you to relocate certain system files (mostly authorization files) off the system disk. You do this by copying the files to another location and then defining logical names as documented in the file SYSS\$MANAGER:SYLOGICALS.TEMPLATE. The logical names are defined in SYSS\$STARTUP:SYLOGICALS.COM.

When you boot your system from the OpenVMS operating system media, the logical names pointing to these files are not defined, and the disks where they are located are not mounted. Because of this, the upgrade cannot access the relocated files, possibly resulting in an incorrect or incomplete upgrade. The upgrade might finish without error, but the files might not be in place as expected.

Before upgrading your system, check the definitions of these logical names on your system. (If a file has not been relocated, the corresponding logical name might not be defined. This is acceptable.)

If any logical name points to a location or file name other than the location and file name listed in “Logical Names for Relocated Authorization Files”, return the file to the default location and file name.

To prevent the system from referencing the files located off the system disk, either delete the associated logical name (using the DCL command DEASSIGN/SYSTEM/EXEC), or shut down the operating system and reboot from the operating system media.

After the upgrade and before booting the operating system, you can move these files back to their original locations off the system disk, using the DCL option (8) from the OpenVMS operating system menu.

### Note

Some files listed in “Logical Names for Relocated Authorization Files”, such as SYSS\$SYSTEM:VMS\$PASSWORD\_HISTORY.DATA and SYSS\$LIBRARY:VMS\$PASSWORD\_POLICY.EXE, might not exist on your system, depending on certain configuration settings. For information about these files, see the *OpenVMS Guide to System Security* manual.

**Table 3.2. Logical Names for Relocated Authorization Files**

LOGICAL NAME	LOCATION AND FILE NAME
LAN\$NODE_DATABASE	SYSS\$SYSTEM:LAN\$NODE_DATABASE.DAT
LMF\$LICENSE	SYSS\$SYSTEM:LMF\$LICENSE.LDB
NETNODE_REMOTE	SYSS\$SYSTEM:NETNODE_REMOTE.DAT
NETNODE_UPDATE	SYSS\$MANAGER:NETNODE_UPDATE.COM
NETOBJECT	SYSS\$SYSTEM:NETOBJECT.DAT

LOGICAL NAME	LOCATION AND FILE NAME
NETPROXY	SYSS\$SYSTEM:NETPROXY.DAT
NET\$PROXY	SYSS\$SYSTEM:NET\$PROXY.DAT
RIGHTSLIST	SYSS\$SYSTEM:RIGHTSLIST.DAT
SYSUAF	SYSS\$SYSTEM:SYSUAF.DAT
SYSUAFALT	SYSS\$SYSTEM:SYSUAFALT.DAT
SYSALF	SYSS\$SYSTEM:SYSALF.DAT
VMSMAIL_PROFILE	SYSS\$SYSTEM:VMSMAIL_PROFILE.DATA
VM\$AUDIT_SERVER	SYSS\$MANAGER:VM\$AUDIT_SERVER.DAT
VM\$OBJECTS	SYSS\$SYSTEM:VM\$OBJECTS.DAT
VMS\$PASSWORD_DICTIONARY	SYSS\$LIBRARY:VM\$PASSWORD_DICTIONARY.DATA
VM\$PASSWORD_HISTORY	SYSS\$SYSTEM:VM\$PASSWORD_HISTORY.DATA
VM\$PASSWORD_POLICY	SYSS\$LIBRARY:VM\$PASSWORD_POLICY.EXE

## AGEN\$INCLUDE Files

If you use the AGEN\$INCLUDE feature in SYSS\$SYSTEM:MODPARAMS.DAT to include files containing additional parameter settings, and the files that are being included are not on the system disk, then do the following before upgrading:

1. Move the files to the system disk.
2. Update the AGEN\$INCLUDE entries to reflect the new locations of these files. For these entries, do not use logical names that you defined in SYSS\$STARTUP:SYLOGICALS.COM or elsewhere for your normal startup procedure. When you boot the system from the OpenVMS operating system media for an upgrade, your normal startup procedure is not run, and so these logical names are not defined for the upgrade. In addition, when you first boot the upgraded system, a special startup procedure is used.

After the upgrade is complete, you can move these included files back to their original locations. If you do so, remember to re-set the AGEN\$INCLUDE entries in SYSS\$SYSTEM:MODPARAMS.DAT.

## Verifying System Parameters

Verify (and modify if necessary) system parameters. (For information about verifying and modifying system parameters, see the *OpenVMS System Manager's Manual, Volume 2: Tuning, Monitoring, and Complex Systems* .)

During an upgrade, AUTOGEN initially generates parameter values based on parameter defaults. However, during the GETDATA phase, AUTOGEN modifies parameter values based on entries stored in SYSS\$SYSTEM:MODPARAMS.DAT. In addition, AUTOGEN analyzes feedback information stored in the AGEN\$FEEDBACK.DAT file and, if the data is valid, adjusts any related parameter values accordingly. (AUTOGEN considers data as valid if the system has been up at least for 24 hours and the feedback is no more than 30 days old.)

### Important

Any system parameters that you modified and *did not* enter in the SYSS\$SYSTEM:MODPARAMS.DAT file are lost during the upgrade.

To retain these parameters, enter their names and the values that you have in use for them in SYSS\$SYSTEM:MODPARAMS.DAT. When AUTOGEN runs after the upgrade, it uses the entered values.

For example, if the current value of GBLPAGES is 30000, and you modified GBLPAGES by 128 pages above the default, add the following line to SYSS\$SYSTEM:MODPARAMS.DAT:

```
MIN_GBLPAGES=30128 !Increased by 128 by PLM for product z 12/12/04
```

AUTOGEN compares the computed value of GBLPAGES with this MIN\_ value (30128). If the computed value is less than the specified MIN\_ value, AUTOGEN increases the value of GBLPAGES to the MIN\_ value. Each time AUTOGEN runs, it makes the same comparison and adjusts the value of GBLPAGES, but never below the minimum indicated by MIN\_GBLPAGES.

## Important

If you modify system parameters, note the following:

- In general, you should allow AUTOGEN to calculate system parameters. You can hardcode values (such as GBLPAGES=*value*), but doing so overrides AUTOGEN and might not allow it to set an optimal value based on observed usage.
- Whenever possible, use MIN\_ *parameter* values (such as MIN\_GBLPAGES) to set the minimum value that can be set for a parameter by AUTOGEN. AUTOGEN increases the value if necessary. It also adjusts related parameters, unless they are hardcoded, in which case information is provided in the AGEN\$PARAMS.REPORT file. Use MAX\_ *parameter* values to set a maximum value when you need to limit a parameter to a known maximum value.
- Enter numeric values as integers, without commas (for example, 10000). Enter alphabetic characters in lowercase or uppercase.
- VSI recommends that you include comments in the MODPARAMS.DAT file indicating who changed the value, when it was done, and why it was done. An exclamation point serves as a comment starter and can appear anywhere on a line. The following is an example illustrating the modifications recommended in the preceding bulleted items:

```
! the following changes made by K.Olsen on 9/20/78
!
SWAPFILE=0                ! don't re-size the SWAPFILE on AUTOGEN runs
MIN_gblsections=750       ! required for DECwindows MOTIF
MIN_NPAGEDYN=2750000      ! set npagedyn to a min of 2.75 million
```

For more information about using AUTOGEN as recommended, see “Running AUTOGEN”.

If your system was upgraded previously, a new SYSS\$SYSTEM:MODPARAMS.DAT file was created then. This file has comments and possibly duplicated entries that were created during that upgrade. If you upgrade again, SYSS\$SYSTEM:MODPARAMS.DAT can become unnecessarily large and potentially confusing. VSI recommends that you edit and reorganize SYSS\$SYSTEM:MODPARAMS.DAT before you upgrade again.

## Note

On a cluster system disk, the MODPARAMS.DAT file should exist in SYSS\$SYSROOT:[SYSEXE] for each root. You must edit MODPARAMS.DAT as necessary for each root.

# Ensuring a Recent FEEDBACK.DAT File

Before upgrading your system, VSI recommends that you have a recent AGEN\$FEEDBACK.DAT file. This file is in SYSS\$SPECIFIC:[SYSEXE] (that is, in [SYSx.SYSEXE], where *x* is the root; for example, SYS0 or SYS1). In OpenVMS Cluster systems, this file should exist in each node's SYSS\$SPECIFIC directory. When the system (or each system in a cluster) is rebooted after the upgrade,

AUTOGEN runs. If a recent AGEN\$FEEDBACK.DAT file is available, it is used. The data in this file helps AUTOGEN set system parameters for your specific applications and workload.

## Note

If you do not have a current AGEN\$FEEDBACK.DAT file, AUTOGEN might calculate system parameters that do not reflect your system's requirements. In that case, multiple cycles of running AUTOGEN and rebooting might be necessary before all layered products can be started. In some cases, successful startup can require additional entries in MODPARAMS.DAT. This should not be necessary if a current AGEN\$FEEDBACK.DAT file is available.

If you do not have the AGEN\$FEEDBACK.DAT file on your system, VSI recommends that you create a current AGEN\$FEEDBACK.DAT file during a time when your system is running under a typical workload. To ensure the greatest data reliability, the system should be running for more than 24 hours but less than 30 days. Enter the following command:

```
$ RUN SYS$SYSTEM:AGEN$FEEDBACK.EXE
```

This runs very quickly and should not affect the performance of your system while it executes.

You can also specify the SAVE\_FEEDBACK option when you execute the system shutdown procedure; however, the data captured might not fully reflect the typical workload on your system.

## Important

If you start AUTOGEN without specifying the execution-mode parameter (FEEDBACK, NOFEEDBACK, or CHECK\_FEEDBACK), AUTOGEN uses the feedback information in its calculations. However, if the feedback information reflects system up time of less than 24 hours, or if the feedback information is more than 30 days old, AUTOGEN includes warnings in the AGEN\$PARAMS.REPORT file to alert you to potential problems with the feedback data. If you wrongly assume the feedback is valid, the parameter settings might vary significantly from your expectations.

If you specify FEEDBACK (or NOFEEDBACK), AUTOGEN uses (or does not use) the feedback regardless of the data's reliability. AUTOGEN proceeds through the SETPARAMS phase (if you specified SETPARAMS, SHUTDOWN, or REBOOT as the end phase) and sets system parameters to the values it computed.

If you specify CHECK\_FEEDBACK, AUTOGEN checks the validity of the feedback data. If AUTOGEN determines the feedback is suspect, then AUTOGEN ignores the feedback when computing parameter values. It stops at the TESTFILES phase and issues a warning in the report that parameters have not been changed. You must read the report and decide whether the calculated values are acceptable. You can either use them (by running the AUTOGEN SETPARAMS phase) or rerun AUTOGEN with valid feedback data.

# Shadowing Environment

Because you cannot upgrade the operating system on a shadowed system disk (the upgrade will fail), you need to disable shadowing of the system disk and perform other operations before you can upgrade the operating system.

There are several methods for creating a nonshadowed target disk. This section describes how to change one of your *existing* shadowed system disks in a multiple-member shadow set to a nonshadowed disk that you can use as your target disk for the upgrade.

If you have a larger configuration with disks that you can access physically, you might want to use a copy of the system disk as your target disk. *Volume Shadowing for OpenVMS* describes two methods you can use to create this copy (using volume shadowing commands or BACKUP commands) and how to disable volume shadowing.

## Setting the Boot Device

Be sure your system is set to boot by default from the disk you intend to upgrade.

VSI recommends using the OpenVMS Boot Manager utility (SYS\$MANAGER:BOOT\_OPTIONS.COM) to add shadowed system disks in a multiple-member shadow set to the EFI boot device list and dump device list. Be sure to add all members to both lists. For more information about setting boot options and using this utility, see “Setting Boot Options for Your System Disk”.

## Creating a Nonshadowed Target Disk

Perform the steps described in this section to change one of your existing shadowed system disks to a nonshadowed disk.

### Warning

If you simply use a MOUNT/OVERRIDE=SHADOW\_MEMBERSHIP command to mount the volume to be upgraded, volume shadowing can overwrite the newly upgraded disk with information from a prior volume that has not been upgraded.

1. Shut down all systems booted from the shadowed system disk.
2. Perform a conversational (interactive) boot (see “Performing a Conversational (Interactive) Boot”) on the system disk you have chosen for your target disk. Enter the following command at the EFI Shell prompt, where *fsn*: is the device associated with the system disk (such as fs1:):

```
Shell> fsn:\efi\vms\vms_loader.efi -flags 0,1
```

3. At the SYSBOOT> prompt, enter the following command to disable volume shadowing of the system disk:

```
SYSBOOT> SET SHADOW_SYS_DISK 0
```

4. Enter the CONTINUE command to resume the boot procedure. For example:

```
SYSBOOT> CONTINUE
```

5. After the boot completes, go to “Finishing the *Before Upgrade* Tasks”.

You now have a nonshadowed system disk that you can use for the upgrade.

## Backing Up the System Disk

### Caution

VSI strongly recommends that you make a backup copy of the system disk and, if your configuration allows it, upgrade the backup copy. Then, if there are problems, you still have a working system disk.

VSI OpenVMS Engineering has encountered cases where recovery from a failed upgrade has been difficult, expensive, or impossible because no backup of the preupgrade system disk was available. Various hardware or software failures or a power failure can make a partially upgraded system disk unusable. A backup copy might be the only route to recovery. The minimal time required to make a backup is a very wise investment.

To back up the system disk, follow these steps:

1. Shut down the system.

2. Boot the operating system distribution media, following the instructions in “Distribution Media Boot Methods”
3. Select Option 8 of the menu to enter the DCL environment.
4. Mount the system device and the target device on which you will make the backup copy. (If you are backing up to tape, skip to the next step.) For example, if your system disk is on DKA0: and the target device is on DKA100:, you might use the following commands. The /OVERRIDE qualifier used in this example allows you to mount the system disk without entering its volume label. The /FOREIGN qualifier is required for the target disk when you use the BACKUP /IMAGE command.

```
$$$ MOUNT /OVERRIDE=IDENTIFICATION DKA0:
$$$ MOUNT /FOREIGN DKA100:
```

5. To back up the system disk to a magnetic tape, enter the following commands, where MTA0: is the magnetic tape drive and *label* is the volume label. Note that the BACKUP command automatically mounts the tape and begins the backup to it.

```
$$$ INITIALIZE MTA0: label
$$$ MOUNT /OVERRIDE=IDENTIFICATION DKA0:
$$$ BACKUP /IMAGE /LOG DKA0: MTA0:label.BCK
```

6. To back up to a device other than a magnetic tape drive, enter the BACKUP command. For example, if your system disk is on DKA0: and your target disk is on DKA100:, use the following command (the colons are required):

```
$$$ BACKUP /IMAGE /LOG DKA0: DKA100:
```

The /IMAGE qualifier causes the Backup utility to produce a functionally equivalent copy of the system disk, which is also bootable. The /LOG qualifier causes the procedure to display the specification of each save set file being processed. To compare the backed up files to the source files, use the /VERIFY qualifier. If any discrepancies are detected, the Backup utility displays an error message indicating the discrepancies.

7. Log out from the DCL environment.
8. Shut down the system by selecting Option 9 on the menu.

For more complete information about backup operations, including a description of an alternative method that does not require booting from the operating system media, see “*Backing Up and Restoring the System Disk*”. For more information about the Backup utility, see the *OpenVMS System Management Utilities Reference Manual: A-L*.

## Finishing the *Before Upgrade* Tasks

Shutdown the system as follows, depending on whether you are upgrading in a non-clustered or OpenVMS Cluster environment:

IF UPGRADING A...	THEN...
CLUSTER SYSTEM	1. Go to the next chapter, “ <i>Before Clustered System Upgrade</i> ” to prepare for a cluster system upgrade.
NON-CLUSTERED SYSTEM	1. Log in to the SYSTEM account. 2. Enter the command:
	\$ @SYS\$SYSTEM:SHUTDOWN

## Before Non-Cluster Upgrade

---

<b>IF UPGRADING A...</b>	<b>THEN...</b>
--------------------------	----------------

---

3. When asked whether an automatic system reboot should be performed, enter N (NO).
  4. Review the checklist (“Before Non-Clustered Upgrade”) at the beginning of this chapter to verify that you have performed the necessary tasks.
  5. Go to PART-II to begin the upgrade procedure.
-

# Chapter 4. Before Clustered System Installation

This chapter contains information to review and steps to perform before installing VSI OpenVMS in an OpenVMS Cluster environment.

## Before Clustered Installation Tasks

Use the checklist below to ensure that you perform all necessary tasks prior to installing your system in an OpenVMS Cluster environment.

**Table 4.1. Before Clustered Installation Checklist**

TASK	SECTION
• Review relevant OpenVMS operating system and OpenVMS Cluster documentation.	Section Cluster Documents
• Familiarize yourself with mixed-version, mixed-architecture, and migration support in OpenVMS Cluster systems.	Section Cluster Matrix
• Have information ready to provide at the system prompt during an installation.	Section Required Cluster Info
• Make sure the target system disk is not mounted elsewhere in the cluster.	Section Dismount Cluster Disk
• Begin the installation.	PART-II

## Cluster Documentation References

Before you install the operating system in an OpenVMS Cluster environment, review any relevant OpenVMS Cluster information contained in the following documents.

- *Cover Letter for VSI OpenVMS Version 8.4-1H1*
- Software Product Descriptions included with your distribution kit
- *VSI OpenVMS Version 8.4-1H1 Release Notes*
- *VSI OpenVMS Version 8.4-1H1 New Features and Documentation Overview*
- *HP and VSI OpenVMS Cluster Systems*
- *Guidelines for OpenVMS Cluster Configurations*

Be sure to consult your network or system manager as well.

## Mixed Version and Architecture Cluster Systems

VSI and HP provide support for specific configurations of mixed-version and mixed-architecture (HP Alpha/HP Integrity) OpenVMS Cluster systems. These support options include: *Warranted Support* and *Migration Support*.

Warranted Support means that the installation has been fully qualified and the specified versions can coexist in an OpenVMS Cluster and the support contract will address all problems identified by customers using this configuration.

Migration Support means that the versions have been qualified for use together in configurations that are migrating in a staged fashion to a newer version of OpenVMS. Problem reports submitted against these configurations will be answered by support. However, in exceptional cases, support may request that you move to a Warranted configuration as part of the problem resolution. Migration Support helps customers move to Warranted OpenVMS Clusters.

## Single Architecture Cluster Support

The following matrix shows the versions of OpenVMS that may coexist and the type of support they qualify for.

**Table 4.2. Single Architecture Cluster Matrix**

	V8.2	V8.2-1	V8.3 and V8.3-1H1	V8.4	V8.4-1H1 and V8.4-1H2
V8.2	Warranted	Warranted	Migration	Migration	Migration
V8.2-1	Warranted	Warranted	Migration	Migration	Migration
V8.3 and V8.3-1H1	Migration	Migration	Warranted	Migration	Migration
V8.4	Migration	Migration	Migration	Warranted	Warranted
V8.4-1H1 and V8.4-1H2	Migration	Migration	Migration	Warranted	Warranted

## Mixed Architecture Cluster Support

The following matrix shows the versions and architectures of OpenVMS that may coexist and the type of support they qualify for.

**Table 4.3. Mixed Architecture Cluster Matrix**

	V7.3-2	V8.2	V8.3	V8.4
V8.2	Warranted	Warranted	Migration	Migration
V8.2-1	Warranted	Warranted	Migration	Migration
V8.3 and V8.3-1H1	Migration	Migration	Warranted	Migration
V8.4	Migration	Migration	Migration	Warranted
V8.4-1H1 and V8.4-1H2	Migration	Migration	Migration	Warranted

### Note

Only two architectures are supported in the same OpenVMS Cluster.

System disks are architecture specific and can be shared only by systems of the same architecture. An HP Alpha and HP Integrity system, or an HP Alpha and VAX system, cannot boot from the same system disk. However, cross-architecture satellite booting is supported between an HP Alpha and VAX system. When you configure an OpenVMS Cluster to take advantage of cross-architecture booting, make sure that at least one system from each architecture is configured with a disk that can be used for installations and upgrades. For more information, see the *Guidelines for OpenVMS Cluster Configurations* and *HP and VSI OpenVMS Cluster Systems*.

# Required OpenVMS Cluster Information

If during the installation you answer YES to the system prompt asking whether your system will be a member of an OpenVMS Cluster, you need to provide the following information after you boot the system disk:

Required Information	Explanation
Type of configuration	Configuration types (CI, DSSI, SCSI, local area, or mixed-interconnect) are distinguished by the interconnect device that the VAX, HP Alpha, or HP Integrity server computers in the OpenVMS Cluster use to communicate with one another. HP Integrity servers do not support CI, DSSI, or MEMORY CHANNEL devices.
DECnet node name and node address	To obtain the DECnet node name and node address for the computer on which you are installing the VSI OpenVMS operating system, consult your network or system manager. If you install DECnet-Plus for OpenVMS (Phase V) software and do not plan to use DECnet Phase IV for OpenVMS addresses, then you do not need to provide this information.
Allocation class value	<p>During the installation procedure, you might be asked for the allocation class value (ALLOCLASS) of the computer on which you are installing the VSI OpenVMS operating system.</p> <p>For example:</p> <pre>Enter a value for <i>this_node</i> ALLOCLASS parameter:</pre> <p>In an OpenVMS Cluster environment, the allocation class value cannot be zero if the node serves DSSI or CI disks to other cluster members, or if volume shadowing will be used on this system or in the cluster. In either case, the ALLOCLASS value must be a number from 1 to 255 and cannot be a number in use by another system in the cluster.</p> <p>After you enter the allocation class value, the installation procedure uses it to automatically set the value of the ALLOCLASS system parameter.</p> <p>VSI recommends that you thoroughly review the chapter on cluster storage devices in the <i>HP and VSI OpenVMS Cluster Systems</i> manual. This manual also includes the rules for specifying allocation class values.</p>
Whether you want a quorum disk	To help you determine whether you need a quorum disk in the cluster, see the <i>HP and VSI OpenVMS Cluster Systems</i> manual.
Location of the page and swap files	On a non-clustered system, the page and swap files are on one or more local disks, but on a clustered system, the files might be on one or more local or clustered disks. See the <i>HP and VSI OpenVMS Cluster Systems</i> manual to help you determine where the page and swap files will be located for the system on which you are installing the VSI OpenVMS operating system software.
Systems that will be a MOP server <sup>a</sup> , disk server, or tape server	If you are going to set up either a local area or a mixed-interconnect cluster, you need to make these determinations.

Required Information	Explanation
Cluster group number and cluster password <sup>b</sup>	<p>If you are going to set up a local area or mixed-interconnect cluster that is LAN-based (Gigabit Ethernet), use the following rules to determine the cluster group number and password:</p> <ul style="list-style-type: none"> <li>• Cluster group number—A number in the range from 1 to 4095 or 61440 to 65535.</li> <li>• Cluster password—Must be from 1 to 31 alphanumeric characters in length and can include dollar signs (\$) and underscores(_).</li> </ul>

<sup>a</sup>Servers that use the Maintenance Operations Protocol (MOP).

<sup>b</sup>Cluster group number and password are required by any cluster nodes that use the local area network for cluster communications. In a cluster that uses mixed interconnects, if any of the interconnects require the cluster number and password, then you must set the cluster number and password for all nodes.

## Dismounting the Target System Disk in the Cluster

Before installing VSI OpenVMS on a target drive in an OpenVMS Cluster, make sure the target system disk is not mounted elsewhere in the cluster. The target system disk must be dismounted clusterwide (except on the system from which the installation is being performed) and must remain so during the installation. For instructions on dismounting cluster disks, see “Types of Upgrades”.

## Finishing the *Before Cluster Install* Tasks

After you have completed all the tasks in this chapter, go to PART-II to begin the installation.

# Chapter 5. Before Clustered System Upgrade

This chapter describes how to prepare to upgrade in an OpenVMS Cluster environment. If you are not upgrading in an OpenVMS Cluster environment, go to Upgrade Procedure.

## Before Clustered Upgrade Tasks

### Note

Be sure you have performed the tasks described in “*Before Non-Cluster Upgrade*” before you upgrade your OpenVMS Cluster system.

Use the checklist below to ensure that you perform all necessary tasks prior to upgrading your system in an OpenVMS Cluster environment.

**Table 5.1. Before Clustered Upgrade Checklist**

TASK	SECTION
• Review relevant OpenVMS Cluster documentation.	Section Cluster Upgrade Documents
• Familiarize yourself with mixed-version, mixed-architecture, and migration support in OpenVMS Cluster systems.	Section Cluster Upgrade Matrix
• Perform the preliminary tasks required for the type of upgrade:	
- CONCURRENT upgrade.	Section Upgrade Types
- ROLLING upgrade.	Section Upgrade Types
• Begin the upgrade.	PART-II

## Cluster Documentation to Review

When you upgrade the operating system in an OpenVMS Cluster environment, be sure you review any relevant OpenVMS Cluster information contained in the following documents.

- *Cover Letter for VSI OpenVMS Version 8.4-1H1*
- Software Product Descriptions included with your distribution kit
- *VSI OpenVMS Version 8.4-1H1 Release Notes*
- *VSI OpenVMS Version 8.4-1H1 New Features and Documentation Overview*
- *HP and VSI OpenVMS Cluster Systems*
- *Guidelines for OpenVMS Cluster Configurations*

Be sure to consult your network or system manager as well.

## Mixed-Version Support in a Cluster

HP and VSI provide two levels of support for mixed-version and mixed-architecture OpenVMS Cluster systems: *Warranted* support and *Migration* support.

For details refer to the “Mixed Version and Architecture Cluster Systems”.

For information about valid upgrade paths, see “Upgrade Paths”.

### Note

VSI OpenVMS Version 8.4-1H1 does not currently require any patch kits to be installed on your system prior to introducing it into an existing OpenVMS Cluster.

Before adding a new system running VSI OpenVMS Version 8.4-1H1 to an existing OpenVMS Cluster configuration, all existing nodes in the cluster must be running compatible versions of VSI OpenVMS or HP OpenVMS. Any node in the cluster that is running an older version of OpenVMS must be upgraded appropriately before you can add a Version 8.4-1H1 node.

Alternatively, any HP Integrity node that needs to be upgraded can be removed temporarily from the cluster and added back after it has been upgraded. This allows you to form a supported cluster immediately, adding nodes back into the cluster as they are upgraded.

### Note

Depending on the number of nodes being added, you might need to adjust the EXPECTED\_VOTES system parameter to reflect the number of voting nodes and any quorum disk votes (if a quorum disk is being used). In addition, for any node being removed from the cluster, you should specify the REMOVE\_NODE option during system shutdown so that the quorum for the remaining nodes is correctly adjusted.

## Types of Upgrades

Two types of cluster upgrades are available: a *CONCURRENT upgrade* and a *ROLLING upgrade*. The type of upgrade you use depends on whether you want to maintain the availability of the cluster during the upgrade and whether you have more than one system disk.

### CONCURRENT Upgrade

During a concurrent upgrade, you must shut down the entire cluster and upgrade each system disk. No one can use the cluster until you upgrade each system disk and reboot each computer. When the cluster reboots, each computer will run the upgraded version of the OpenVMS operating system.

If all systems in the OpenVMS Cluster environment are booted from one system disk, you must perform a concurrent upgrade.

To prepare for a concurrent upgrade, follow these steps:

1. Log in locally to the SYSTEM account.

If you have more than one system disk, make sure that you have performed the preupgrade tasks on each system disk that you are upgrading. Make sure the target system disk is not mounted on any other node in the cluster and remains dismounted during the upgrade. It should be mounted only on the system that is performing the upgrade. Then go to PART-II and perform an upgrade on each system disk. You do not have to reboot the operating system media for each upgrade. You only need to choose option 1 on the menu for each upgrade.

2. Shut down all systems by entering the following command on each system (*satellite nodes* first, then the boot nodes):

```
$ @SYS$SYSTEM:SHUTDOWN
```

3. When the procedure asks whether an automatic system reboot should be performed, enter N (NO).

4. After all satellite nodes have shut down, select the `CLUSTER_SHUTDOWN` option.
5. When the shutdown procedure is finished on all nodes, halt each system by either pressing **Ctrl/P** or **Halt**.
6. If you have only one system disk for your cluster, go to PART-II to begin the upgrade procedure.

After the upgrade is complete, you are instructed to reboot each computer in the OpenVMS Cluster environment before beginning other postupgrade procedures.

## ROLLING Upgrade

A rolling upgrade allows you to have a mixed-version cluster. During a rolling upgrade, you keep some of the computers in the cluster running and available while you upgrade others. You must have more than one system disk. You upgrade each system disk individually, allowing old and new versions of the operating system to run together in the same cluster.

For additional compatibility issues and restrictions information, see the *VSI OpenVMS Version 8.4-1H1 Release Notes*.

The following restrictions apply to rolling upgrades:

- The system being upgraded must not attempt to access any disk that is being accessed by one or more of the remaining OpenVMS Cluster systems.
- The remaining OpenVMS Cluster systems must not attempt to access the target disk of the system being upgraded.

If the target disk being upgraded is locally attached to the system performing the upgrade, then it is not accessible to the remaining OpenVMS Cluster systems. (The OpenVMS system booted from the operating system media does not MSCP serve local disks.) VSI recommends that, whenever possible, you perform the upgrade on a local disk or that you perform a concurrent upgrade.

### Warning

Any attempt to access the target system disk from the remaining OpenVMS Cluster members will corrupt the target disk. Even if the target system disk is mounted only by a remaining cluster member and no file access is performed, the target disk will probably be corrupted. If a disk is corrupted in this way, the only supported recovery is to restore the backup copy of the corrupted disk.

- VSI recommends that all HP Alpha computers in a cluster run the same (preferably the latest) version of the HP OpenVMS Alpha operating system, and that all HP Integrity servers run the same version of the VSI OpenVMS operating system.
- You cannot perform a rolling upgrade if all systems boot from a single system disk. Perform a concurrent upgrade instead.
- The upgrade procedure affects the queuing system as follows:
  - The queuing system is not active on the system you are upgrading; do not attempt to execute a `START/QUEUE/MANAGER` command.
  - You cannot create a queue database on the operating system CD/DVD (because it is not writable).
  - The queue manager process on other nodes in the cluster can continue to run during the upgrade if the queue database is not on the disk being upgraded.

To prepare for a rolling upgrade, follow these steps:

## Before Clustered System Upgrade

1. Log in to any node where the target disk is mounted as a data disk rather than as the system disk. (That disk must be the one on which you already performed the pre-upgrade tasks described in “*Before Non-Cluster Upgrade*”.)
2. Check the votes and make adjustments to maintain the proper quorum so the cluster can continue to operate throughout the upgrade. (*HP and VSI OpenVMS Cluster Systems* describes this procedure in detail.)
3. Use the DCL command **DISMOUNT/CLUSTER** to dismount the data disk. (You can also perform this operation using the SYSMAN utility.)

Note that you can ignore messages from nodes where the specified data disk is being used as the system disk.

4. Verify that the data disk has been dismounted successfully by entering the following commands:

```
$ MCR SYSMAN
SYSMAN> SET ENVIRONMENT/CLUSTER
SYSMAN> DO SHOW DEVICE disk-name
```

Examine the display to be sure the disk is not mounted on any nodes as a data disk. Noting the value listed in the *Trans Count* field can help you make that determination: A value of less than 50 indicates that the disk is mounted as a data disk rather than as the system disk; a much larger value (for example, 300) indicates that the disk most likely is the system disk.

5. If the disk is still mounted on any nodes as a data disk, use the SYSMAN utility to dismount the disk; otherwise, exit the SYSMAN utility.
6. Use the following command to shut down any nodes that boot from the system disk you are upgrading (shut down satellite nodes first):

```
$ @SYS$SYSTEM:SHUTDOWN
```

- a. When the procedure asks whether an automatic system reboot should be performed, enter N (NO).
- b. After all satellite nodes have shut down, select the *REMOVE\_NODE* option.

If a proper quorum is not maintained at any time during the upgrade procedure, the shutdown procedure hangs the cluster. If the cluster hangs during a shutdown, you can use the Interrupt Priority C (IPC) facility to adjust quorum from the system console of a system that is still a cluster member.

From an HP Alpha cluster member, press **Ctrl/P**. The IPC facility displays help information about IPC commands. Enter the commands at the console:

```
$ Ctrl/P
>>> D SIRR C
>>> C
Interrupt Priority C
```

Commands:

C device	Cancel Mount Verification
Q	Adjust Quorum
CTRL-Z	Exit IPC
CTRL-P	Prompt for Crash

```
IPC> Q
IPC> Ctrl/Z
```

From an HP Integrity OpenVMS cluster member, pressing **Ctrl/P** puts the system directly into the IPC facility, which displays help information about IPC commands. To adjust quorum, enter the commands shown in the following example. Note that if systems are booted with XDELTA (low-level system debugger), pressing **Ctrl/P** brings the OpenVMS system into XDELTA. The IPC facility is not available in this case.

```
$ Ctrl/P
Interrupt Priority C
```

Commands:

```
  C device      Cancel Mount Verification
  Q             Adjust Quorum
  CTRL-Z       Exit IPC
  CTRL-P       Prompt for Crash
IPC> Q
IPC> Ctrl/Z
```

You can also adjust quorum using Availability Manager. The method is equivalent to that used by IPC except you do not have to use the console (this assumes the Data Analyzer is running on a system outside the OpenVMS Cluster, which is recommended). For more information, see the “Adjust Quorum” section in the *Availability Manager User’s Guide*, available at:

<http://www.hp.com/products/OpenVMS/availabilitymanager>

After the shutdown procedure is finished on all nodes, go to PART-II to begin the upgrade procedure.

### Caution

During the upgrade it is very important that the system disk being upgraded is accessed **only** by the node on which the upgrade is being performed. If the disk can be accessed from other nodes in the cluster, for example, through an HSC or HSJ device, you *must* ensure that this does not happen. Even if the disk is only mounted and no file access is performed, the disk can still become corrupted.

Ensure that any users who might mount disks know that they must not access the system disk being upgraded. Also make sure that any procedures that might mount the disk do not run during the upgrade. If you have automatic procedures that periodically check and remount disks, it would be wise to disable them during the upgrade.

## Finishing the *Before Cluster Upgrade* Tasks

After you have completed all the tasks in this chapter, go to PART-II to begin the installation.

# Part II. During Installation or Upgrade

This part of the manual covers the actual installation or upgrade process. Use this part to follow along with your activity and to locate any additional details you may require along the way.

Before starting the procedures described in this chapter, be sure to review and perform as necessary, the *BEFORE* installation or upgrade steps listed in “Before Installing or Upgrading” of this manual.

The following sections provide examples of booting the distribution media from DVD and also from an *Infoserver* utility located on another system within your LAN.

Greater details of booting methods and Infoserver setup are located in PART-IV of this manual.

# Table of Contents

6. INSTALLATION Procedure .....	42
Booting the VSI OpenVMS Distribution Media .....	42
Booting a Local DVD. Booting from a Local DVD Drive .....	42
Booting via Network. Booting from a Network InfoServer Utility .....	43
Performing the INSTALLATION .....	43
Responding to Installation Prompts .....	43
Using the VSI OpenVMS Installation Menu .....	44
OPTION 1: Upgrade, install or reconfigure OpenVMS .....	45
OPTION 2: Display layered products that this procedure can install .....	48
OPTION 3: Install or upgrade layered products .....	49
OPTION 4: Show installed products .....	51
OPTION 5: Reconfigure installed products .....	52
OPTION 6: Remove installed products .....	53
OPTION 7: Find, Install or Undo Patches; Show or Delete recovery data .....	55
OPTION 8: Execute DCL Commands and Procedures .....	56
OPTION 9: Shut down this system .....	56
STEP-BY-STEP Installation Example .....	56
Next Steps .....	76
7. UPGRADE Procedure .....	77
Performing the UPGRADE .....	77
Upgrading the System Using Option 1 of the Installation Menu .....	77
Selecting INITIALIZE or PRESERVE .....	77
Specifying the Target Disk .....	78
Selecting Reinstallation and Reconfiguration Options .....	78
Checking for Recovery Data .....	80
Specifying the Volume Label .....	81
Specifying the On-Disk Structure Level .....	81
Create and Validate Boot Options .....	83
Warning About Removal of the DECRAM Command .....	84
Setting OpenVMS Cluster Membership Information .....	84
License Rebranding .....	84
Updating Time Zone Information .....	84
Upgrading Windowing, Networking, and Related Products .....	85
Completing the Upgrade .....	86
Selecting Descriptive Help Text .....	86
Removing Older Versions of ENCRYPT .....	87
Secure Delivery Validation .....	87
Selecting Product Component Options .....	87
Component and Product Installation Confirmation Messages .....	89
Upgrade Creates and Validates Boot Options .....	90
Upgrade Completed .....	91
Shutting Down the System .....	92

# Chapter 6. INSTALLATION Procedure

This chapter explains how to *INSTALL* the OpenVMS operating system from a local DVD drive or via a network Infoserwer.

## Booting the VSI OpenVMS Distribution Media

The VSI OpenVMS Version 8.4-1H1 distribution DVD includes procedures and tools that enable you to install, upgrade and configure the operating system. These tools become available once you boot the distribution media (DVD or Network Infoserwer boot).

### Booting from a Local DVD Drive

Boot the VSI OpenVMS OE DVD from a local DVD drive by performing the steps included in this section. To boot the DVD on a cell-based server, a DVD device must be accessible by the nPartition on which OpenVMS is being installed and console commands must be issued from the console of that nPartition.

1. Make sure your server is powered on. If your system has an attached external device, make sure it is turned on and operational.
2. Insert the DVD into the drive.
3. Cycle power (so the firmware will mount the DVD).
4. From the main EFI boot menu, select the appropriate entry for your DVD from the boot options list. The EFI boot menu is timed; press any key to stop the timeout count.

For some systems, the boot option to select is the *Internal Bootable DVD* option. If that option is not listed in your EFI boot menu, move to the *Boot From a File* menu item and select the *Removable Media Boot* option, if present.

Alternatively (and this method is recommended for cell-based servers), boot the DVD drive from the EFI Shell prompt by entering the command shown in the following example, where *fsn*: corresponds to the servers DVD drive (such as fs0:). If you have navigated to a particular file system, the EFI Shell prompt reflects that file system; for example, if the current file system is fs0:, the EFI Shell prompt is fs0:>.

```
Shell> fsn:\efi\boot\bootia64.efi
```

To determine which device is the bootable DVD drive, examine the list of mapped devices and look for an fs device listing that includes the letters “CDROM”, as in the following line. In this line, *fsn* is the file system associated with the drive, which is usually fs0: (instead of "fsn", you might see something similar to "V8.4-1H1"; instead of Ata, you might see Scsi, depending on the server model):

```
fsn      :      Acpi(HWP0002,400)/Pci(4|1)/Ata(Primary,Master)/  
CDROM(Entry0)
```

You can use the following command to display the mapping of various EFI device names to OpenVMS device names, where *fsn* is the device you want to check (such as fs0:):

```
Shell> fsn:\efi\vms\vms_show dev -fs
```

On most HP Integrity servers, the DVD drive is DQA0: (IDE) or DNA0: (USB). On systems that include a SCSI bus, such as the Superdome server, the DVD drive is DKA0:. For more information about the **vms\_show** command, see the *OpenVMS System Management Utilities Reference Manual*.

**Note**

By default, certain versions of EFI might interpret the **Delete** (or **Backspace**) key differently than do OpenVMS Alpha systems or Microsoft Windows computers. In such cases, press **Ctrl/H** to delete the last character entered. For more information, see “Using the Delete or Backspace Key”.

When the DVD boots properly, the OpenVMS operating system banner is displayed, followed by the operating system Installation Menu. You can now install your operating system onto the target disk. If the methods documented in this section do not succeed in booting the DVD, see “Alternate Method of Booting the DVD with EFI”.

**Note**

When booting OpenVMS from the installation DVD for the first time on any OpenVMS HP Integrity server system with a SAN storage device, you might experience a delay in EFI initialization because the entire SAN is scanned. Depending on the size of the SAN, this delay might range from several seconds to several minutes.

## Booting from a Network InfoServer Utility

To use the InfoServer utility to boot over a network, certain configuration steps are required initially (one time only); see “Setting Up and Performing Network Booting”. The instructions on booting over the network from a virtual DVD are also included in that section.

## Performing the INSTALLATION

After booting the distribution media, you can create an operating system disk by using Option 1 of the Installation Menu.

## Responding to Installation Prompts

At different points during the installation, you must respond to prompts that ask for specific information. This manual and the help text available during the installation procedure tell you how to obtain most of this information and how to make decisions when responding to specific prompts.

To repeat an explanation provided by the installation procedure, type a question mark (?) at the prompt. To change or correct a response made to an earlier question, enter the caret (^) character as many times as needed. Entering this character might take you back more than one question. To return to the main menu, press **Ctrl/Y**, which aborts the installation.

VSI recommends that you review the following summary before you begin the installation so that you understand beforehand the types of information you need to provide.

During the installation, you will be prompted to supply the following information:

- Name of the target drive, and LAN device(if booting via InfoServer).
- Whether you want to INITIALIZE or PRESERVE the target disk(as described in “OPTION 1: Upgrade, install or reconfigure OpenVMS”).
- Volume label for the target disk (or default label).
- Password for the SYSTEM account.
- Whether to form or join a OpenVMS Cluster and, if so, what kind (described in “Required OpenVMS Cluster Information”).
- DECnet node name and address (or values for the system parameters, SCSNODE and SCSSYSTEMID).

## Note

If you install the DECnet-Plus for OpenVMS, but you want to use addresses compatible with DECnet Phase IV software, you still need to provide this information. These settings identify your system by name and number in a DECnet or cluster environment. If you supply a DECnet Phase IV address, the SCSSYSTEMID value will be automatically calculated. This should be coordinated with your network or system manager to avoid use of conflicting addresses.

- Product Authorization Keys (PAKs) for your OpenVMS licenses. To register your licenses, you must enter the information listed on the PAK for each license. You may register your licenses after installing OpenVMS.
- Optional components that you want to install. You can install all components (by default), or you can select components from this list:
  - DECwindows Motif for OpenVMS (G)

If you install this product, you must also include the DECwindows Server Support component. If you are not installing DECwindows as part of the OpenVMS installation now, but you plan to install it later, install the DECwindows Server Support component now.

- OpenVMS Management Station

If you need to create a kit to install the PC component of the *OpenVMS Management Station* software, then you must include the OpenVMS Management Station Software PC files component.

- TCP/IP Services for OpenVMS
- Either DECnet-Plus for OpenVMS or DECnet Phase IV for OpenVMS (but not both)

If you install either DECnet implementation, you must also include the Support for DECnet component. If you are not installing DECnet-Plus or DECnet Phase IV now, but you plan to install one of them later, you should install the Support for the DECnet-Plus or DECnet Phase IV component now. (The same support component applies to both implementations of DECnet.)

For a list of component options included with the OpenVMS operating system, see “Component Options and Suboptions”.

## Using the VSI OpenVMS Installation Menu

Recognizing that most installers will prefer to reference the on-screen Installation Menu, as opposed to a large document, the following sections show the menu as it will appear, with pointers to additional details in case you encounter a step or prompt that is not obvious to you. After you have installed OpenVMS once, you are less likely to require this manual, but we have tried to organize it in a way that it will still provide a useful quick-reference if needed.

The examples provided are from an HP Integrity Server installation using the EFI console environment.

The OpenVMS Installation Menu displays automatically when you boot the operating system from the distribution media. From the Installation Menu, you can choose options to perform specific tasks.

**Readers can skim through the following descriptions, or if preferred, go directly to a step-by-step example in “STEP-BY-STEP Installation Example”**

The following is a sample display of the OpenVMS Installation Menu:

```
*****
You can install or upgrade the OpenVMS operating system
```

## INSTALLATION Procedure

or you can install or upgrade layered products that are included on the OpenVMS distribution media (DVD).

You can also execute DCL commands and procedures to perform "standalone" tasks, such as backing up the system disk.

Please choose one of the following:

- 1) Upgrade, install or reconfigure OpenVMS Version 8.4-1H1
- 2) Display layered products that this procedure can install
- 3) Install or upgrade layered products
- 4) Show installed products
- 5) Reconfigure installed products
- 6) Remove installed products
- 7) Find, Install or Undo patches; Show or Delete recovery data
- 8) Execute DCL commands and procedures
- 9) Shut down this system

Enter CHOICE or ? for help: (1/2/3/4/5/6/7/8/9/?)

The following sections (Option 1 through Option 9) describe each of the main menu options in the order listed. Refer to these sections as needed.

### OPTION 1: Upgrade, install or reconfigure OpenVMS

Select Option 1 on the main Installation Menu to upgrade, install or reconfigure your OpenVMS software. Selecting Option 1 implements a PCSI utility concept called a *platform*.

The VSI OpenVMS platform contains System Integrated Packages (SIP's) that are automatically installed and optional packages for which you will be prompted whether to install. Refer to the Software Product Description for details regarding package versions.

The current platform includes the following packages:

- The VSI OpenVMS **Base Operating Environment**
- Common Data Security Architecture (*CDSA*)
- Common Internet File System (*CIFS*)
- DECnet-Plus (optional)
- DECnet Phase IV (optional)
- DECprint Supervisor (*DCPS*)
- DECram
- DECwindows Motif (optional)
- Distributed Computing Environment Runtime (*DCE*)
- J2SE Development Kit for Java (*JDK*)
- Kerberos Encryption
- NetBeans Suite (Distributed NetBeans and Plug-ins)
- OPC Transport for HP Integrity servers
- OpenVMS Enterprise Directory
- OpenVMS I18N
- OpenVMS Management Station
- Performance Data Collector (*TDC*)
- Secure Sockets Layer (*SSL*)
- TCP/IP Services for OpenVMS
- WEBM/CIM
- WEBM Providers
- Insight Management Agents
- Web Server Suite, including:
  - Secure Web Server
  - Secure Web Browser

## INSTALLATION Procedure

- CSWS\_Java (Tomcat)
- CSWS\_Perl (mod\_Perl)
- CSWS\_PHP (mod\_PHP)
- Perl
- Mozilla Firefox
- Web Services Toolkit, including:
  - ANT (Another Neat Tool)
  - AXIS2
  - SOAP Toolkit (Simple Object Access Protocol)
  - UDDI Client Toolkit
  - Web Services Integration Toolkit (WSIT)
  - XML C++
  - XML Java

If you are installing the **VSI OpenVMS High Availability Operating Environment (HAOE)** you will receive the contents of the base environment listed above, as well as the following packages:

- Availability Manager
- gWLM Agent
- Performance Agent (OVPA)
- Reliable Transaction Router, Back End (RTR)
- RMS Journalling for OpenVMS
- Volume Shadowing for OpenVMS
- VMS Cluster Client
- VMS Cluster Software

Including the optional products in the OpenVMS platform allows you to install or upgrade these products along with the operating system.

When you choose to upgrade the system disk, and the software on the disk is the same version, you are given options to reinstall or to reconfigure the system or reconfigure the OpenVMS platform.

### Caution

Before installing or upgrading VSI OpenVMS on a target drive in an OpenVMS Cluster, make sure the target system disk is not mounted elsewhere in the cluster. The target system disk must be dismounted clusterwide (except on the system from which the installation or upgrade is being performed) and must remain so during the installation or upgrade.

When you select Option 1 on the Installation Menu, the system asks whether you want to preserve or initialize the system disk. The display is similar to the following:

```
There are two choices for Installation/Upgrade:
```

```
INITIALIZE - Removes all software and data files that were  
previously on the target disk and installs VSI OpenVMS.
```

```
PRESERVE -- Installs or upgrades VSI OpenVMS on the target disk  
and retains all other contents of the target disk.
```

```
* Note: You cannot use PRESERVE to install VSI OpenVMS on a disk on  
which any other operating system is installed. This includes  
implementations of OpenVMS for other architectures.
```

```
Do you want to INITIALIZE or to PRESERVE? [PRESERVE]
```

### INITIALIZE Option

When you specify the INITIALIZE option, the following operations take place:

- All software and data files that already exist on the target disk are removed. The software can only be recovered from a backup of the disk, so make sure that you either have a backup or will not need the data again.
- The operating system is installed.

Specify the INITIALIZE option and perform a full installation under any of the following conditions:

- If your computer is new (it has never had any version of any operating system running on it, including factory-installed software).
- If your computer is already running a version of the OpenVMS operating system and you want to overwrite the entire contents of the system disk (the operating system, application software, and any user files on the system disk).
- If you want to keep an existing system disk and install OpenVMS on a different disk.
- If you are running the OpenVMS operating system but cannot upgrade. For example, if you changed the names of system directories on the system disk, the upgrade procedure will not work correctly. Therefore, unless you restore the system disk to its original directory structure, you must reinstall the operating system using the INITIALIZE option.

### Note

During initialization of VSI OpenVMS the installation process creates a *diagnostic partition*, visible only at the console prompt. For more information about this partition and options you can take, see “*Alternative Ways to Initialize the System Disk*”.

## PRESERVE Option

When you specify the PRESERVE option, the following operations take place:

IF ...	THEN ...
The OpenVMS operating system <i>is not</i> already installed on the target disk and no other operating system is installed on the disk	<ul style="list-style-type: none"> <li>• The operating system is <i>installed</i>.</li> <li>• All other contents of the target disk are retained.</li> </ul>
The OpenVMS operating system <i>is</i> installed on the target disk	<p>The operating system is <i>upgraded</i>, as follows:</p> <ul style="list-style-type: none"> <li>• Old operating system files and new files are merged or replaced.</li> <li>• All other contents of the target disk are retained.</li> </ul>

### Note

You cannot install VSI OpenVMS on a disk where another operating system is installed. For example, you cannot take a UNIX disk, select the PRESERVE option, and then install OpenVMS on the disk. The UNIX disk is not structured in the format that OpenVMS requires.

If you intend to choose the PRESERVE option (because there are certain files on the disk that you want to retain), VSI recommends that you first make a backup copy of your system disk. If there is any problem during the installation or upgrade that might affect the integrity of the disk, you will have the backup copy as a safeguard.

If you choose the PRESERVE option with a target disk that already contains the VSI OpenVMS Version 8.4-1H1 software, you are provided with the further option to RECONFIGURE or REINSTALL the OpenVMS operating system:

- RECONFIGURE the operating system if you want to change the options you selected when the operating system was installed.

- REINSTALL the operating system if you think that your system files have become corrupted.

## OPTION 2: Display layered products that this procedure can install

Use Option 2 to display the layered products and patch kits that can be installed. Generally speaking, products that can be installed or upgraded along with the operating system, should be.

### Note

Although Option 2 displays any patch kits available on the distribution media, VSI recommends using Option 7 to display patch kits; Option 7 enables you to specify locations to search in addition to the standard location.

In the following example, WBEMCIM is the file name used in the PCSI kit for the WBEM Services for OpenVMS product. *CIM stands for the Common Information Model, which differentiates the current OpenVMS WBEM product from the original one that is based on the Simple Network Management Protocol (SNMP)*. The version numbers in this example do not necessarily reflect the version numbers of the products actually shipped with VSI OpenVMS Version 8.4-1H1.

The following versions of the OpenVMS operating system, required components and other optional products are available on the VSI OpenVMS distribution media DVD. They can be installed by selecting Option 1:

```
VSI I64VMS OpenVMS Version 8.4-1H1
VSI I64VMS AVAIL_MAN_BASE V8.4-1H1
VSI I64VMS CDSA version V2.4
VSI I64VMS KERBEROS version V3.2
VSI I64VMS SSL V1.4-284
VSI I64VMS TDC_RT version V2.3-20
VSI I64VMS BINARYCHECKER version V1.0
VSI I64VMS WBEMCIM version V2.9-9
VSI I64VMS WBEMPROVIDERS version V2.2-3
VSI I64VMS DWMOTIF version V1.7
VSI I64VMS DECNET_PLUS version V8.4-1H1
VSI I64VMS DECNET_PHASE_IV version V8.4-1H1
VSI I64VMS TCPIP version V5.7
```

The following Layered Product kits are available on the VSI OpenVMS Distribution media (DVD). They can be installed by selecting Option 3. If they are already installed, they can be reconfigured by selecting Option 5, or removed by selecting Option 6.

PRODUCT	KIT TYPE	KIT FORMAT
VSI I64VMS AVAIL_MAN_BASE V8.4-1H1	Full LP	Compressed
VSI I64VMS CDSA V2.3-306	Full LP	Compressed
VSI I64VMS DECNET_PHASE_IV V8.4-1H1	Full LP	Compressed
VSI I64VMS DECNET_PLUS V8.4-1H1	Full LP	Compressed
VSI I64VMS DWMOTIF V1.7	Full LP	Compressed
VSI I64VMS HPBINARYCHECKER V1.0	Full LP	Compressed
VSI I64VMS DWMOTIF_SUPPORT V8.4-1H1	Full LP	Compressed
VSI I64VMS KERBEROS V3.1-152	Full LP	Compressed
VSI I64VMS SSL V1.4-284	Full LP	Compressed
VSI I64VMS TCPIP V5.7	Full LP	Compressed

## INSTALLATION Procedure

VSI I64VMS TDC_RT V2.3-1	Full LP	Compressed
VSI I64VMS WBEMCIM V2.91-A070728	Full LP	Compressed
VSI I64VMS WBEMPROVIDERS V2.0-31	Full LP	Compressed

-----

13 items found

Press Return to continue...

## OPTION 3: Install or upgrade layered products

Use Option 3 on the Installation Menu for normal installations or upgrades of layered products.

### Note

Although Option 3 installs any patch kits available from the VSI OpenVMS distribution media, VSI recommends using Option 7 to install patch kits; Option 7 enables you to install patch kits that are not located in the standard location. In addition, Option 7 saves recovery data; when you use Option 7 to remove patch kits, only kits with recovery data are removed.

You can use Option 1 to install or upgrade the DECwindows graphical user interface and networking products along with the operating system.

When you select Option 3, the PCSI utility allows you to choose whether to install layered products or to register layered products that are on the target disk but are not in the Product Database. If you attempt to reinstall the same version of a product that is already installed, the product is reinstalled. Any patches that were applied to the product are removed. If you want to reconfigure, select the RECONFIGURE (Option 5) on the Installation Menu.

Most of the software kits included on the VSI OpenVMS distribution media are signed using *Secure Delivery*. When you use Option 3 of the Installation Menu, these kits are validated by the PCSI utility. You can install kits created before the secure delivery process was enabled in HP OpenVMS Version 8.3. However, after you install or upgrade to OpenVMS Version 8.3 or later, signed kits that you install subsequently are validated, including any signed kits included on the distribution media.

The DCL command **PRODUCT SHOW HISTORY** displays the validation status of these kits as *unsigned* rather than as a validated kit.

As shown in the following example, you are also prompted for a target disk and asked whether you want brief or detailed descriptions. The procedure presents a list of products and allows you to select any or all of these products. Alternatively, you can exit without installing or upgrading any products.

\*\*\*\*\*

The procedure will ask a series of questions.

() - encloses acceptable answers  
[] - encloses default answers

Type your response and press the <Return> key. Type:

? - to repeat an explanation  
^ - to change prior input (not always possible)  
Ctrl/Y - to exit the installation procedure

Do you want to INSTALL or REGISTER? (INSTALL/REGISTER/?) [INSTALL] **INSTALL**  
\*\*\*\*\*

## INSTALLATION Procedure

If you choose to install or upgrade DECwindows Motif, please note the following:

- o If you did not select the DECwindows server support and workstation files options, DECwindows Motif will not run. You must add these options to use DECwindows Motif.

If you choose to install or upgrade DECnet-Plus or DECnet Phase IV, please note the following:

- o If you did not select the DECnet option, neither version of DECnet will run. You must add this option to use DECnet.

If you want to install a patch kit, please use main menu option 7.

Press Return to continue...

You must enter the device name for the target disk on which the layered product(s) installation will be performed.

Enter device name for target disk: [DKB300] (? for choices) **DKB300**

DKB300: is labeled V84SYS.

The install operation can provide brief or detailed descriptions. In either case, you can request the detailed descriptions by typing "?".

Do you always want detailed descriptions? (Yes/No) [No] **NO**

- |   |                 |
|---|-----------------|
| 1 - VSI I64VMS AVAIL_MAN_BASE V8.4-1H1  | Layered Product |
| 2 - VSI I64VMS CDSA V2.4                | Layered Product |
| 3 - VSI I64VMS DECNET_PHASE_IV V8.4-1H1 | Layered Product |
| 4 - VSI I64VMS DECNET_PLUS V8.4-1H1     | Layered Product |
| 5 - VSI I64VMS DWMOTIF V1.7             | Layered Product |
| 6 - VSI I64VMS DWMOTIF_SUPPORT V8.4-1H1 | Layered Product |
| 7 - VSI I64VMS BINARYCHECKER V1.0       | Layered Product |
| 8 - VSI I64VMS KERBEROS V3.2            | Layered Product |
| 9 - VSI I64VMS SSL V1.4-284             | Layered Product |
| 10 - VSI I64VMS TCPIP V5.7              | Layered Product |
| 11 - VSI I64VMS TDC_RT V2.3-20          | Layered Product |
| 12 - VSI I64VMS WBEMCIM V2.99           | Layered Product |
| 13 - VSI I64VMS WBEMPROVIDERS V2.2-3    | Layered Product |
| 14 - All products listed above          |                 |
| ? - Help                                |                 |
| E - Exit                                |                 |

Choose one or more items from the menu separated by commas: **9**

### Note

When you boot the VSI OpenVMS distribution media and select the option to install layered products, the installation procedure for the selected layered product(s) does not run the *Installation Verification Procedure (IVP)* for layered products. Because the operating system is booted from the distribution media and the layered products are installed on a different device (the target drive), the IVPs cannot execute correctly. However, you can run the IVP for each layered product after you boot the target system (see the layered product installation documents for information about running their IVP).

## OPTION 4: Show installed products

Use Option 4 on the Installation Menu to display a list of products that have been installed on a selected target disk by the PCSI utility. Products that were installed by VMSINSTAL or other installation methods do not appear in this display unless they have been registered in the PCSI utility's product database.

The following is a sample display of the prompts and information that appear when you select Option 4 and WBEM Services for OpenVMS and WBEM Providers for OpenVMS. The version numbers in this example do not necessarily reflect the version numbers of the products actually shipped with VSI OpenVMS Version 8.4-1H1.

You must enter the device name for the system disk for which you want to display installed products.

If you enter an invalid device or one which is not a system disk an error will occur.

(Enter "^" and press Return to return to main menu.)

Enter device name for system disk: [DKB300] (? for choices) **DKB300**  
 %MOUNT-I-MOUNTED, V84SYS mounted on \_DKB300:

The default is an 80-column display that does not include Maintenance (patches) or Referenced by information.

Do you want the full, 132-column display? (Yes/No) [No] **NO**

PRODUCT	KIT TYPE	STATE
VSI I64VMS AVAIL_MAN_BASE V8.4-1H1	Full LP	Installed
VSI I64VMS CDSA V2.3-306	Full LP	Installed
VSI I64VMS DECNET_PLUS V8.4-1H1	Full LP	Installed
VSI I64VMS DWMOTIF V1.7	Full LP	Installed
VSI I64VMS DWMOTIF_SUPPORT V8.4-1H1	Full LP	Installed
VSI I64VMS HPBINARYCHECKER V1.0	Full LP	Installed
VSI I64VMS KERBEROS V3.1-152	Full LP	Installed
VSI I64VMS OpenVMS V8.4-1H1	Platform	Installed
VSI I64VMS TCPIP V5.7	Full LP	Installed
VSI I64VMS VMS V8.4-1H1	Oper System	Installed
VSI I64VMS SSL V1.4-284	Full LP	Installed
VSI I64VMS TDC_RT V2.3-1	Full LP	Installed
VSI I64VMS WBEMCIM V2.91-A070728	Full LP	Installed
VSI I64VMS WBEMPROVIDERS V2.0-31	Full LP	Installed

12 items found

Do you wish to display product history? (Yes/No) [No] **YES**

PRODUCT	KIT TYPE	OPERATION	DATE AND TIME
VSI I64VMS AVAIL_MAN_BASE V8.4-1H1	Full LP	Install	25-JAN-2015 18:04:
VSI I64VMS CDSA V2.3-306	Full LP	Install	25-JAN-2015 18:04:
VSI I64VMS DECNET_PLUS V8.4-1H1	Full LP	Install	25-JAN-2015 18:04:
VSI I64VMS DWMOTIF V1.7	Full LP	Install	25-JAN-2015 18:04:

## INSTALLATION Procedure

VSI I64VMS KERBEROS V3.1-152	Full LP	Install	25-JAN-2015 18:04:
VSI I64VMS OpenVMS V8.4-1H1	Platform	Install	25-JAN-2015 18:04:
VSI I64VMS TCPIP V5.7	Full LP	Install	25-JAN-2015 18:04:
VSI I64VMS VMS V8.4-1H1	Oper System	Install	25-JAN-2015 18:04:
VSI I64VMS SSL V1.4-284	Full LP	Install	25-JAN-2015 18:04:
VSI I64VMS WBEMCIM V2.91-A070728	Full LP	Install	25-JAN-2015 18:04:
VSI I64VMS WBEMPROVIDERS V2.0-31	Full LP	Install	25-JAN-2015 18:04:
VSI I64VMS TDC_RT V2.3-1	Full LP	Install	25-JAN-2015 18:04:
HP I64VMS AVAIL_MAN_BASE V8.3	Full LP	Remove	25-SEP-2009 18:04:
HP I64VMS CDSA V2.2	Full LP	Remove	25-SEP-2009 18:04:
HP I64VMS DECNET_PHASE_IV V8.3	Full LP	Remove	25-SEP-2009 18:04:
HP I64VMS DWMOTIF V1.6	Full LP	Remove	25-SEP-2009 18:04:
HP I64VMS OpenVMS V8.3	Platform	Remove	25-SEP-2009 18:04:
HP I64VMS VMS V8.3	Oper System	Remove	25-SEP-2009 18:04:
HP I64VMS KERBEROS V3	Transition	Remove	25-SEP-2009 18:04:
HP I64VMS KERBEROS V3	Transition	Reg Product	25-SEP-2008 17:20:
HP I64VMS CDSA V2.1	Full LP	Install	27-AUG-2004 21:07:
HP I64VMS DECNET_PHASE_IV V8.2	Full LP	Install	27-AUG-2004 21:07:
HP I64VMS DWMOTIF V1.5	Full LP	Install	27-AUG-2004 21:07:
HP I64VMS OpenVMS V8.3	Platform	Install	27-AUG-2004 21:07:
HP I64VMS TCPIP V5.4-18	Full LP	Install	27-AUG-2004 21:07:
HP I64VMS VMS V8.3	Oper System	Install	27-AUG-2004 21:07:

---

26 items found

Press Return to continue...

### Note

The products listed in the product history vary from system to system, depending on the actual history of the system.

## OPTION 5: Reconfigure installed products

Use Option 5 of the Installation Menu to reconfigure layered products, including the DECwindows graphical user interface and networking products. This allows you to change the product choices you made during a previous installation or upgrade.

You can reconfigure a product only if all of the following conditions are true:

- The product is available for installation while your system is booted from the operating system media. For information about displaying products that are available for installation, see “OPTION 2: Display layered products that this procedure can install” (Option 2 on the Installation Menu).
- The product is installed. For information about displaying installed products, see “OPTION 4: Show installed products” (Option 4 on the Installation Menu).
- The version of the product that is available for installation is the same as the version of the product that is installed.

When you select Option 5 on the Installation Menu, the procedure prompts you for a target disk name and asks whether you want brief or detailed descriptions about the reconfiguration options. The procedure then lists the products you can configure. You can select any or all of these products, or you can exit without reconfiguring products.

The following is a sample display of the prompts and information that might appear when you select Option 5. The version numbers in this example do not necessarily reflect the version numbers of the products actually shipped with VSI OpenVMS Version 8.4-1H1.

## INSTALLATION Procedure

This procedure will ask a series of questions.

- () - encloses acceptable answers
- [] - encloses default answers

Type your response and press the <Return> key. Type:

- ? - to repeat an explanation
- ^ - to change prior input (not always possible)
- Ctrl/Y - to exit the installation procedure

You must enter the device name for the target disk on which the layered product(s) reconfiguration will be performed.

Enter device name for target disk: [DKB300] (? for choices) **DKB300**

DKB300: is labeled V84SYS.

The reconfigure operation can provide brief or detailed descriptions. In either case, you can request the detailed descriptions by typing "?".

Do you always want detailed descriptions? (Yes/No) [No] **NO**

- 1 - VSI I64VMS AVAIL\_MAN\_BASE V8.4-1H1 Layered Product
- 2 - VSI I64VMS CDSA V2.3-306 Layered Product
- 3 - VSI I64VMS DECNET\_PHASE\_IV V8.4-1H1 Layered Product
- 4 - VSI I64VMS DECNET\_PLUS V8.4-1H1 Layered Product
- 5 - VSI I64VMS DWMOTIF V1.7 Layered Product
- 6 - VSI I64VMS DWMOTIF\_SUPPORT V8.4-1H1 Layered Product
- 7 - VSI I64VMS HPBINARYCHECKER V1.0 Layered Product
- 8 - VSI I64VMS KERBEROS V3.1-152 Layered Product
- 9 - VSI I64VMS SSL V1.4-284 Layered Product
- 10 - VSI I64VMS TCPIP V5.7 Layered Product
- 11 - VSI I64VMS TDC\_RT V2.3-1 Layered Product
- 12 - VSI I64VMS WBEMCIM V2.91-A070728 Layered Product
- 13 - VSI I64VMS WBEMPROVIDERS V2.0-31 Layered Product
- 14 - All products listed above
- ? - Help
- E - Exit

Choose one or more items from the menu separated by commas:

## OPTION 6: Remove installed products

Installation Menu Option 6 allows you to remove products that were installed or registered with the PCSI utility. (This option removes complete products. To remove patches, use Option 7, as described in "OPTION 7: Find, Install or Undo Patches; Show or Delete recovery data".)

### Important

Do NOT remove the following system-integrated products (*SIPs*):

- Availability Manager
- CDSA
- Binarychecker

## INSTALLATION Procedure

- Kerberos
- SSL
- TDC\_RT
- WBEM Services for OpenVMS (WBEMCIM)
- WBEM Providers for OpenVMS

These products are tightly bound with the operating system. Attempts to remove any of these products might not work as expected and can create undesirable side effects.

When you select Option 6, you are prompted for a target disk name and whether you want brief or detailed descriptions about the remove options. The procedure then lists the products you can remove. You can select any or all of these products, or you can exit without removing any products.

The following is a sample display of the prompts and information that appear when you select Option 6. The version numbers in this example do not necessarily reflect the version numbers of the products actually shipped with VSI OpenVMS Version 8.4-1H1.

This procedure will ask a series of questions.

- ( ) - encloses acceptable answers
- [ ] - encloses default answers

Type your response and press the <Return> key. Type:

- ? - to repeat an explanation
- ^ - to change prior input (not always possible)
- Ctrl/Y - to exit the installation procedure

You must enter the device name for the target disk on which the layered product(s) removal will be performed.

Enter device name for target disk: [DKB300:] (? for choices) **DKB300**

DKB300: is labeled V84SYS.

The remove operation can provide brief or detailed descriptions. In either case, you can request the detailed descriptions by typing "?".

Do you always want detailed descriptions? (Yes/No) [No] **NO**

- |                                      |                 |
|--------------------------------------|-----------------|
| 1 - HP I64VMS AVAIL_MAN_BASE V8.3    | Layered Product |
| 2 - HP I64VMS CDSA V2.3-306          | Layered Product |
| 3 - HP I64VMS DECNET_PHASE_IV V8.3   | Layered Product |
| 4 - HP I64VMS DECNET_PLUS V8.3       | Layered Product |
| 5 - HP I64VMS DWMOTIF V1.6           | Layered Product |
| 6 - HP I64VMS DWMOTIF_SUPPORT V8.3   | Layered Product |
| 7 - HP I64VMS HPBINARYCHECKER V1.0   | Layered Product |
| 8 - HP I64VMS KERBEROS V3.1-152      | Layered Product |
| 9 - HP I64VMS SSL V1.4-284           | Layered Product |
| 10 - HP I64VMS TCPIP V5.7            | Layered Product |
| 11 - HP I64VMS TDC_RT V2.3-1         | Layered Product |
| 12 - HP I64VMS WBEMCIM V2.91-A070728 | Layered Product |
| 13 - HP I64VMS WBEMPROVIDERS V2.0-31 | Layered Product |
| 13 - All products listed above       |                 |
| ? - Help                             |                 |
| E - Exit                             |                 |

Choose one or more items from the menu separated by commas:

## OPTION 7: Find, Install or Undo Patches; Show or Delete recovery data

Select Option 7 to install or undo patches and to perform related operations. When you select Option 7, the following options submenu appears:

This procedure can perform one of the following operations:

- 1) Install one or more patches
- 2) Undo recent patches for which there is recovery data
- 3) Show recovery data
- 4) Delete recovery data
- 5) Find patch kits

Enter CHOICE or X to return to main menu: (1/2/3/4/5/X)

Note the following about these options:

- When you choose submenu Option 1, the following information is displayed:

NOTE: Some patch kits cannot be correctly installed by this procedure; this includes patch kits for versions of OpenVMS prior to V8.4-1H1. Patches for VSI OpenVMS V8.4-1H1 and later install correctly. For patches to other products, check with the patch kit provider, or install the patch from the running system.

Options 2 through 5 (undo, show, delete, and find) will work correctly for all patch kits.

- When you choose submenu option 1, 2, 3, or 4, you are prompted for the target device on which to perform the operation:

You must enter the device name for the target disk on which the operation will be performed.

Enter device name for target disk: (? for choices) [DKB300]

- When you choose submenu Option 1, you are prompted to choose detailed or brief descriptions, as follows:

The patch operation can provide brief or detailed descriptions. In either case, you can request the detailed descriptions by typing ?.

Do you always want detailed descriptions? (Yes/No) [No]

- For each of the submenu options (1 through 5), you are prompted for the patch kit source. You can specify alternate locations. You can use wildcards when you specify the location. The prompt and introductory information are displayed as follows:

This procedure will look for patch kits in

SYS\$SYSDEVICE:[KITS.\*]

If you want to add an additional location, enter the device and directory specification and press return.

Wildcards are allowed. For example:

```
dka100:[dir1]
dkb0:[dir1,dir2]
dka200:[dir1,*]
dkb300:[dir1...]
```

Enter the single letter "D" to reset the default location.

If you do not want to add an additional location, just press return without entering anything.

Enter additional location, D, or just press Return:

After you provide the necessary information, a PCSI/PRODUCT command automatically performs the operation you requested. If you chose options 1, 2, or 4 from the submenu, the PCSI utility prompts you for additional input and displays additional information.

## OPTION 8: Execute DCL Commands and Procedures

When you select Option 8 of the Installation Menu, you are allowed to access a subset of DCL commands (such as SHOW DEVICE, MOUNT, and BACKUP) to perform specific preinstallation and maintenance operations. Note, however, that this is a restricted DCL environment in that certain DCL commands (such as PRODUCT) and certain utilities (such as VMSINSTAL) do not function as expected because you are booting from read-only or write-locked distribution media, and because a full system startup has not been performed.

A triple dollar sign prompt (\$\$\$) indicates that you are in this restricted DCL environment, as in the following example:

```
$$$ SHOW DEVICE
```

To exit the DCL environment and return to the main menu, enter the LOGOUT command.

## OPTION 9: Shut down this system

When you select Option 9 of the Installation Menu, your system shuts down and you are returned to the console prompt. The system displays a message similar to the following:

```
Shutting down the system

SYSTEM SHUTDOWN COMPLETE

**** Primary HALTED with code HWRPB_HALT$K_REMAIN_HALTED

**** Hit any key to cold reboot ****
P00>>>
```

## STEP-BY-STEP Installation Example

A few seconds after you boot the distribution media DVD, several informational messages will appear, followed by the OpenVMS banner and eventually by the Installation Menu, as shown in the following example:

```
.
.
```

## INSTALLATION Procedure

\*\*\*\*\*  
You can install or upgrade the OpenVMS I64 operating system  
or you can install or upgrade layered products that are included  
on the OpenVMS I64 distribution media (CD/DVD).

You can also execute DCL commands and procedures to perform  
"standalone" tasks, such as backing up the system disk.

Please choose one of the following:

- 1) Upgrade, install or reconfigure OpenVMS I64 Version 8.4-1H1
- 2) Display layered products that this procedure can install
- 3) Install or upgrade layered products
- 4) Show installed products
- 5) Reconfigure installed products
- 6) Remove installed products
- 7) Find, Install or Undo patches; Show or Delete recovery data
- 8) Execute DCL commands and procedures
- 9) Shut down this system

Enter CHOICE or ? for help: (1/2/3/4/5/6/7/8/9/?)

To install OpenVMS, follow these steps:

1. **Select Option 1 on the Menu:** Respond to the menu prompt by entering 1.

Enter CHOICE or ? for help: (1/2/3/4/5/6/7/8/9/?)**1**

The OpenVMS operating system kit might contain patch kits. If it does, information similar to  
the following is displayed:

The following PATCH kits are present on the OpenVMS I64  
distribution media.

PRODUCT	KIT TYPE	KIT FORMAT
DEC I64VMS TCPIP_ECO V5.n-nnn	Patch	Compressed

1 item found

Please consult the OpenVMS I64 Upgrade and Installation Manual,  
the Release Notes, and the Cover Letter to determine if any or  
all of these patches may be required for your system.

If you have not already done so, determine whether you need to install any patches.

\*\*\*\*\*  
This procedure will ask a series of questions.

- ( ) - encloses acceptable answers
- [ ] - encloses default answers

Type your response and press the <Return>key. Type:

- ? - to repeat an explanation
- ^ - to change prior input (not always possible)

## INSTALLATION Procedure

Ctrl/Y - to exit the installation procedure

2. **Create the System Disk:** You can choose to initialize or preserve data on the target disk.

There are two choices for Installation/Upgrade:

INITIALIZE - Removes all software and data files that were previously on the target disk and installs OpenVMS I64.

PRESERVE -- Installs or upgrades OpenVMS I64 on the target disk and retains all other contents of the target disk.

\* NOTE: You cannot use preserve to install OpenVMS I64 on a disk on which any other operating system is installed. This includes implementations of OpenVMS for other architectures.

Do you want to INITIALIZE or to PRESERVE? [PRESERVE] **INITIALIZE**

**Respond to the INITIALIZE or PRESERVE prompt as follows:**

<b>IF ...</b>	<b>THEN ...</b>
Your disk is new	Type INITIALIZE and press <b>Enter</b> .
You want to remove all files from an existing system disk	Type INITIALIZE and press <b>Enter</b> .
You want to retain prior OpenVMS files on an existing disk	Type PRESERVE and press <b>Enter</b> .

### Note

You cannot install OpenVMS on a disk where another operating system is installed. For example, you cannot take a UNIX disk, select the PRESERVE option, and then install OpenVMS on the disk. The UNIX disk is not structured in the format that OpenVMS requires.

During initialization of an OpenVMS target system disk, the installation process creates a diagnostic partition, visible only at the console prompt.

3. **Specify the System Disk (Target Disk):** If you do not know the name of the disk, enter a question mark (?) to list devices on your system. Select the appropriate disk and respond to the prompt. For example:

You must enter the device name for the target disk on which OpenVMS I64 will be installed.

Enter device name for target disk: (? for choices) **DKB400**

If this is the first installation on this system, no default device is indicated, as in this example. A default device name is listed if this is not the first installation (for example, [DKB400] or, for a Fibre Channel disk device, [\$1\$DGA567]).

If you select a device that is not available or that cannot be used for some other reason, you will see a message indicating why the device cannot be used. For example, if you enter MKA500, a tape device, a message similar to the following is displayed:

MKA500 is not a disk device

4. **Specify the Volume Label:** The procedure displays the volume label currently assigned to this device and asks whether you want to keep that label. If you choose not to, you are prompted for

## INSTALLATION Procedure

a new label, as shown in the following example. OpenVMS uses the volume label to identify and reference the disk.

```
DKB400: is now labeled V84SYS.
```

```
Do you want to keep this label? (Yes/No) [Yes] NO
```

```
Enter volume label for target system disk: [I64SYS] I64084
```

You can keep the label already assigned to the disk, accept the default label assigned by the system (I64SYS), or specify a new volume label (limited to 12 characters, A to Z, 0 through 9, the dollar sign (\$), hyphen (-), and underscore (\_).

### Warning

OpenVMS requires that the volume labels for all disks on your system or OpenVMS Cluster have unique labels. If a disk having the same label as the system disk is mounted, various OpenVMS components do not function as intended or a node might crash during boot.

5. **Specify On-Disk Structure Level:** If you enter the volume label for the target disk, you are asked whether you want to initialize the system disk with On-Disk Structure Level 2 (ODS-2) or Level 5 (ODS-5).

```
The target system disk can be initialized with On-Disk Structure Level 2 (ODS-2) or Level 5 (ODS-5). (? for more information)
```

```
OpenVMS I64 systems include WBEM Services for OpenVMS; the WBEM data repository requires an ODS-5 disk. If you choose to initialize the target system disk with ODS-5 the repository can be on the system disk; otherwise you will need to provide an additional ODS-5 disk. (? for more information).
```

```
Do you want to initialize with ODS-2 or ODS-5? (2/5/?)
```

For details about ODS-2 and ODS-5 file systems, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*. A brief summary follows.

### Note

VSI recommends that your system disk be initialized in ODS-5 format, unless you plan to use software that requires ODS-2.

Although WBEM Services for OpenVMS can be installed on an ODS-2 disk, the WBEM Services for OpenVMS data repository requires an ODS-5 disk. A system disk in ODS-5 format can store everything; if you choose to have your disk in ODS-2 format, the procedure asks you to provide an ODS-5 disk for the data repository.

- ODS-2 allows for compatibility with OpenVMS VAX and HP Alpha systems that use ODS-2 disks (as well as HP Integrity Server systems using ODS-2 disks). Choose ODS-2 if you do not need the new features of ODS-5 disks, including the support of applications ported from other operating systems (such as UNIX, Linux, and Microsoft Windows).
- ODS-5 supports file names that are longer, have a wider range of legal characters, and allow for mixed-case file names. This feature permits use of file names similar to those in a Microsoft Windows or UNIX environment.
- ODS-5 supports hard links to files, access dates, and files whose names differ only by case.
- ODS-5 volumes cannot be mounted on any version of OpenVMS prior to HP OpenVMS Version 7.2.

## INSTALLATION Procedure

- Systems running HP OpenVMS VAX Version 7.2 and higher can mount ODS-5 volumes, but cannot create or access files having extended names. (Lowercase file names are seen in uppercase on OpenVMS VAX systems.)

Select ODS-2 or ODS-5 by entering 2 or 5 at the prompt.

6. **Enable Hard Links (ODS-5 Only):** If you select ODS-5, you have the option to enable hard links (if you selected ODS-2, skip to the next step). When you install VSI OpenVMS, the procedure advises you that WBEM Services for OpenVMS does not require hard links, as shown in the following example. Enter YES or NO to indicate your choice.

```
Hard links can be enabled on ODS-5 disks. WBEM Services for OpenVMS
does not require hard links. (? for more information)
```

```
Do you want to enable hard links? (Yes/No/?) YES
```

Both ODS-2 and ODS-5 support aliases, which are additional names for a file or directory. Only ODS-5 supports hard links.

One of the differences with hard links enabled is the way the DCL DELETE command works. With hard links enabled, if you enter the DELETE command to delete a file that has one or more aliases associated with it, the command only deletes the alias by which the file is being accessed. The actual file continues to exist and is accessible by any remaining alias. The file is deleted only when the last remaining alias is deleted.

Without hard links enabled, the DELETE command deletes both the alias by which the file is being accessed and the file itself. Any other aliases remain but the file is no longer accessible because it is no longer present. Thus, the remaining aliases are unusable.

If enabling hard links has any drawbacks, they are minor and probably of concern only in rare circumstances. For example, if disk quotas are in effect, though owners of a file can delete any links to a file in a directory they can access, hard links in other users' directories might cause a file to be retained, and the file size continues to be charged against that owner's disk quota.

In general, be aware that enabling hard links does change the file system's behavior and that applications and management practices should respond accordingly (instead of being alias-specific, for example).

For more information about hard links, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*.

7. **Confirm Target System Disk Choices:** Your target system disk choices are listed and you are asked to confirm that they are correct. In the following example, the choices made were to initialize the disk with ODS-5 and with hard links. The volume label is I64084.

```
You have chosen to install OpenVMS I64 on a new disk.
```

```
The target system disk, DKB400:, will be initialized
with structure level 5 (ODS-5).
```

```
Hard links WILL be enabled.
```

```
It will be labeled I64084.
```

```
Any data currently on the target system disk will be lost.
```

```
Is this OK? (Yes/No) YES
```

```
Initializing and mounting target....
```

```
%EFI-I-VOLINIT, FAT volume DIAGNOSTICS has been initialized
```

Creating page and swap files....

8. **Configure and Validate Boot Options .**

Boot options in the EFI Boot Manager boot option menu can provide a convenient way to boot your system. The installation procedure can automatically create a new boot option (if none exists) or validate existing boot options.

Do you want to create or validate boot options? (Yes/No) [Yes] **YES**

If your newly installed system disk will be booted on this system disk, and if you want the installation procedure to assist you in setting up boot options in the EFI Boot Manager menu, answer YES. The procedure will create and validate a new boot option if one does not exist.

When you answer YES and no boot option exists, the procedure allows you to set OpenVMS boot flags (VMS\_FLAGS), as shown in the following example. Enter the OpenVMS flags (for example, 0,1), or press **Enter** to set no flags (the default). If a boot option exists, you can change boot flags after the installation completes (for information about changing boot flags, see “Setting Boot Options for Your System Disk”).

You can set VMS\_FLAGS or accept the default, 0,0.

Enter the value for VMS\_FLAGS: (n,n) [0,0]

If you do not want the installation procedure to assist you in setting up or validating boot options on the EFI console, answer NO.

VSI recommends that you allow the installation procedure to assist you in setting up and validating boot options.

**Note**

If your newly installed system disk is a Fibre Channel device, VSI recommends that you add it as a boot option in the EFI boot menu. If you do not allow the installation procedure to add the device to the boot menu, you can add it by using the OpenVMS Boot Manager utility (SYS\$MANAGER:BOOT\_OPTIONS.COM) after the installation completes. (To add Fibre Channel devices to the EFI boot menu, use the OpenVMS Boot Manager utility instead of EFI.)

VSI recommends using the OpenVMS Boot Manager utility to add shadowed system disks in a multiple-member shadow set to the EFI boot device list and dump device list. Be sure to add all members to both lists.

For information about the OpenVMS Boot Manager utility, see “Setting Boot Options for Your System Disk”. For more information about configuring and booting Fibre Channel devices, see “Setting Up and Booting Fibre Channel Storage Devices”.

9. **Specify SYSTEM Account Information (Initialized Disks Only):** If you are initializing the target disk, you are prompted for SYSTEM account information. Before you respond to the prompt asking you to enter a password for the SYSTEM account, note the following:

- Passwords must be at least 8 characters in length (but must not exceed 31 characters). Valid characters for the password include A through Z, 0 through 9, the dollar sign (\$), and underscore (\_). Passwords must contain at least one alphabetic character (A through Z). The system converts all characters to uppercase, so the case of characters you enter does not matter.
- Press **Enter** after you enter the password. (The password does not display as you type it.)

## INSTALLATION Procedure

- After you enter the password, the procedure checks to make sure it meets the requirements for a valid password.
- Reenter the password for verification.

The following is a sample display:

```
You must enter a password for the SYSTEM account.
```

```
The password must be a minimum of 8 characters in length, and  
may not exceed 31 characters. It will be checked and verified.  
The system will not accept passwords that can be guessed easily.
```

```
The password will not be displayed as you enter it.
```

```
Password for SYSTEM account:
```

```
Re-enter SYSTEM password for verification:
```

If you reenter the password incorrectly or if the password is too easy for another user to guess, an error message is displayed and you must specify a valid password.

10. **Declare OpenVMS Cluster Membership:** Determine whether your system will be part of an OpenVMS Cluster. The display is similar to the following:

```
Will this system be a member of an OpenVMS Cluster? (Yes/No)
```

Answer YES if the system will be a member of an OpenVMS Cluster. Answering YES, causes SYSSMANAGER:CLUSTER\_CONFIG.COM to run automatically when your newly installed system is first booted. The CLUSTER\_CONFIG procedure asks further questions about the cluster. Your response to this question determines how the VAXCLUSTER system parameter is set. (The VAXCLUSTER system parameter is set for VSI OpenVMS systems.) For more information, see the *Guidelines for OpenVMS Cluster Configurations* manual.

If you answer YES to the cluster question, the display is similar to the following:

```
When your new system is first booted you will be required to answer  
additional questions in order to configure the OpenVMS Cluster.
```

If you answer NO to the cluster question, the system can still be a member of an OpenVMS Cluster. However, in this case you must explicitly configure the node into the cluster after the installation is completed. For more information, see “Joining an OpenVMS Cluster”.

For more information about cluster configuration, see the *HP and VSI OpenVMS Cluster Systems* manual.

11. **Set SCSNODE System Parameter:** The procedure now asks you to specify a value for the first of two system parameters, the SCSNODE parameter. (Step 12 describes the output and prompts for the second system parameter, SCSSYSTEMID.) SCSNODE is a name that can be from one to six letters or numbers; it must include at least one letter. If this system is part of an OpenVMS Cluster, SCSNODE must be unique within the cluster. If you are using DECnet Phase IV for OpenVMS or DECnet-Plus for OpenVMS with DECnet Phase IV addresses, then SCSNODE must be the same as your DECnet node name.

The following is an example of the display and a valid response:

```
For your system to operate properly, you must set two parameters:  
SCSNODE and SCSSYSTEMID.
```

## INSTALLATION Procedure

SCSNODE can be from 1 to 6 letters or numbers. It must contain at least one letter.

If you plan to use DECnet, SCSNODE must be the DECnet Phase IV node name, or the DECnet-Plus (Phase V) node synonym.

If you have multiple OpenVMS systems, the SCSNODE on each system must be unique.

Enter SCSNODE: **I64CSI**

12. **Declare Use of DECnet; Setting SCSSYSTEMID System Parameter:** The next prompt asks whether you plan to use DECnet. It also informs you that the SCSSYSTEMID system parameter is based on the DECnet Phase IV address. SCSSYSTEMID must also be unique within an OpenVMS Cluster.

If you plan to use DECnet, SCSSYSTEMID must be set based on the DECnet Phase IV address.

Do you plan to use DECnet (Yes/No) [YES]: **YES**

If you answer YES, the information about the DECnet Phase IV addresses is displayed along with a prompt for a DECnet Phase IV address. Enter a valid DECnet Phase IV address, as in the following example:

DECnet Phase IV addresses are in the format

DECnet\_area\_number.DECnet\_node\_number

DECnet\_area\_number is a number between 1 and 63.

DECnet\_node\_number is a number between 1 and 1023.

If you plan to use DECnet WITHOUT Phase IV compatible addresses, enter 0.0.

Enter DECnet (Phase IV) Address [1.1]: **63.180**

A display such as the following informs you of the value assigned to SCSSYSTEMID:

SCSSYSTEMID will be set to 64692.

This was calculated as follows:

$(\text{DECnet\_area\_number} * 1024) + \text{DECnet\_node\_number}$

If you are not using DECnet, or if you enter 0.0 as the DECnet Phase IV address, you are prompted to enter a SCSSYSTEMID in the range of 1 to 65535. If this is a *standalone system*, the default of 65534 is acceptable. However, if this system is part of an OpenVMS Cluster, you must enter a SCSSYSTEMID that is unique within the cluster. The following is a sample display:

The system cannot calculate SCSSYSTEMID from an address that is not compatible with DECnet Phase-IV.

You will have to choose a value for SCSSYSTEMID.

If you plan to use LAT software, you may have to add /NODECNET to any CREATE LINK commands in SYS\$MANAGER:LATSYSSTARTUP.COM.

## INSTALLATION Procedure

Please choose a SCSSYSTEMID between 1 and 65535. If you have multiple OpenVMS systems, the SCSSYSTEMID on each system must be unique.

Enter SCSSYSTEMID [65535]: **12345**

13. **Set Local Time Zone:** Now the procedure asks you to configure the local time zone. For local time zone support to work correctly, the installation procedure must set the time zone that accurately describes the location you want to be your default time zone. Usually, this is the time zone in which your system is running. In addition, you may need to set the time differential factor (TDF).

The main time zone menu is displayed. You can select the time zone in either of two ways:

- Select the number in the main time zone menu that best represents the time zone desired. (If multiple time zones exist for the selection you make, you must select the exact time zone from another menu.)
- Use a search option that allows you to bypass the time zone menu and search by name (partial or full).

If you select one of the numbers in the time zone menu, the corresponding time zone is selected. At any prompt, you can enter a question mark (?) for help information.

### Note

An asterisk (\*) next to a number indicates that more than one time zone exists for that selection. If you select such a number, an additional menu displays choices that allow you to select the appropriate time zone. For example, if you choose the United States (US) time zone from the main time zone menu, a second menu displays the specific time zones within the United States.

The following example shows how you would select the Eastern time zone for the United States by using the menu number:

#### Configuring the Local Time Zone

```
TIME ZONE SPECIFICATION -- MAIN Time Zone Menu      "*" indicates a menu

0* GMT
1* AFRICA                17) EST                33) IRAN                49) PORTUGAL
2* AMERICA               18) EST5EDT           34) ISRAEL              50) PRC
3* ANTARCTICA           19* ETC                35) JAMAICA             51) PST8PDT
4* ARCTIC               20* EUROPE            36) JAPAN               52) ROC
5* ASIA                 21) FACTORY           37) KWAJALEIN          53) ROK
6* ATLANTIC             22) GB-EIRE           38) LIBYA               54) SINGAPORE
7* AUSTRALIA           23) GB                 39) MET                 55) TURKEY
8* BRAZIL               24) GMT-0             40* MEXICO              56) UCT
9* CANADA               25) GMT               41* MIDEAST             57) UNIVERSAL
10) CET                 26) GMT0              42) MST                 58* US
11* CHILE               27) GMTPLUS0          43) MST7MDT            59) UTC
12) CST6CDT            28) GREENWICH         44) NAVAJO              60) W-SU
13) CUBA               29) HONGKONG          45) NZ-CHAT            61) WET
14) EET                 30) HST               46) NZ                  62) ZULU
15) EGYPT              31) ICELAND           47* PACIFIC
16) EIRE               32* INDIAN            48) POLAND
```

Press "Return" to redisplay, enter "=" to search or "?" for help, or  
Select the number above that best represents the desired time zone: **58**

## INSTALLATION Procedure

US Time Zone Menu

"\*" indicates a menu

- 0\* RETURN TO MAIN TIME ZONE MENU
- 1) ALASKA                      5) EAST-INDIANA              9) MICHIGAN                  13) SAMOA
- 2) ALEUTIAN                    6) EASTERN                    10) MOUNTAIN
- 3) ARIZONA                     7) HAWAII                     11) PACIFIC-NEW
- 4) CENTRAL                     8) INDIANA-STARKE          12) PACIFIC

Press "Return" to redisplay, enter "=" to search or "?" for help, or  
Select the number above that best represents the desired time zone: **6**

You selected US /EASTERN as your time zone.

Is this correct? (Yes/No) [YES]:

To use the search option instead of menu numbers to select the time zone, enter an equals sign (=) at the menu prompt instead of a number. You can enter one or more words or partial words immediately after the equals string, or you can enter the equals sign alone, in which case you are prompted for the words or partial words of the time zone you want to select. After you enter that information, all matching time zones are displayed, and you can then select the appropriate one.

The following example shows how you would select the Eastern time zone for the United States by using the search option:

Configuring the Local Time Zone

TIME ZONE SPECIFICATION -- MAIN Time Zone Menu

"\*" indicates a menu

- 0\* GMT
- 1\* AFRICA                      17) EST                      33) IRAN                      49) PORTUGAL
- 2\* AMERICA                    18) EST5EDT                34) ISRAEL                    50) PRC
- 3\* ANTARCTICA                19\* ETC                      35) JAMAICA                  51) PST8PDT
- 4\* ARCTIC                      20\* EUROPE                 36) JAPAN                    52) ROC
- 5\* ASIA                        21) FACTORY                37) KWAJALEIN                53) ROK
- 6\* ATLANTIC                    22) GB-EIRE                38) LIBYA                    54) SINGAPORE
- 7\* AUSTRALIA                 23) GB                      39) MET                      55) TURKEY
- 8\* BRAZIL                      24) GMT-0                  40\* MEXICO                  56) UCT
- 9\* CANADA                     25) GMT                    41\* MIDEAST                 57) UNIVERSAL
- 10) CET                        26) GMT0                    42) MST                      58\* US
- 11\* CHILE                      27) GMTPLUS0              43) MST7MDT                59) UTC
- 12) CST6CDT                  28) GREENWICH             44) NAVAJO                   60) W-SU
- 13) CUBA                      29) HONGKONG              45) NZ-CHAT                 61) WET
- 14) EET                        30) HST                     46) NZ                        62) ZULU
- 15) EGYPT                     31) ICELAND                47\* PACIFIC
- 16) EIRE                       32\* INDIAN                 48) POLAND

Press "Return" to redisplay, enter "=" to search or "?" for help, or  
Select the number above that best represents the desired time zone: **=EAST**

Search for Time Zone by Full or Partial Name

"\*" indicates a menu

- 1) BRAZIL / EAST
- 2) CANADA / EAST-SASKATCHEWAN
- 3) CANADA / EASTERN
- 4) CHILE / EASTERISLAND
- 5) MIDEAST / RIYADH87
- 6) MIDEAST / RIYADH88

## INSTALLATION Procedure

- 7) MIDEAST / RIYADH89
- 8) PACIFIC / EASTER
- 9) US / EAST-INDIANA
- 10) US / EASTERN

Press "Return" to redisplay this menu,  
enter "=" to search for a new zone,  
enter "0" to return to the Main Time Zone Menu, enter "?" for help, or  
Select the number above that best represents the desired time zone: **10**

You selected US / EASTERN as your time zone.  
Is this correct? (Yes/No) [YES]:

The procedure prompts you for the TDF.

For more information about local time zone support, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*.

14. **Set Time Differential Factor (TDF):** Here you are prompted to enter the time differential factor (TDF). The TDF is the difference between your system time and Coordinated Universal Time (UTC), which is an international standard (similar to Greenwich Mean Time) for measuring time of day. The procedure supplies a default for TDF, which is generally the correct response. If the time zone you selected supports daylight saving time, you are asked whether daylight saving time is currently in effect. The following example shows TDF information and prompts:

Configuring the Time Differential Factor (TDF)

Default Time Differential Factor for standard time is -5:00.  
Default Time Differential Factor for daylight saving time is -4:00.

The Time Differential Factor (TDF) is the difference between your system time and Coordinated Universal Time (UTC). UTC is similar in most respects to Greenwich Mean Time (GMT).

The TDF is expressed as hours and minutes, and should be entered in the hh:mm format. TDFs for the Americas will be negative (-3:00, -4:00, etc.); TDFs for Europe, Africa, Asia and Australia will be positive (1:00, 2:00, etc.).

This time zone supports daylight saving time.  
Is this time zone currently on daylight saving time? (Yes/No): **YES**

Enter the Time Differential Factor [-4:00]:

NEW SYSTEM TIME DIFFERENTIAL FACTOR = -4:00

Is this correct? [Y]:

For more information about TDF support, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*. Once OpenVMS has been installed and booted from the system disk, you can determine whether your system is set for daylight saving time by using the following DCL command to display the translation for the daylight saving time logical:

```
$ SHOW LOGICAL *TIMEZONE*
"SYS$TIMEZONE_DAYLIGHT_SAVING" = "1"
.
.
.
```

## INSTALLATION Procedure

15. **Register Licenses (Optional at this time):** After setting the TDF, Product Authorization Keys (PAKs) may be entered:

If you have Product Authorization Keys (PAKs) to register, you can register them now.

Do you want to register any Product Authorization Keys? (Yes/No) [Yes]

You can register the PAKs now by responding YES to the prompt, or later by responding NO. You register licenses later by following the directions in "Registering Your Licenses".

To register your licenses now, be sure you have the following before proceeding:

- A copy of the Product Authorization Key (PAK) for each license that you are registering.
- The *OpenVMS License Management Utility Manual*, which contains complete, detailed information about the licensing procedure.

For the OpenVMS operating system, a single Operating Environment (OE) license grants the right to use all the components bundled in the purchased OE. Sufficient PCL (Per Core License) units are required to license all processor cores in a socket.

The OE license must contain PCL units sufficient to activate all licensed sockets in the system or hard partition. (If additional cores are added later to the system or hard partition, each requires additional PCL units.) The License Management utility supports these licensing practices. The OpenVMS Unlimited User License is included with the Base Operating Environment (BOE) and, therefore, is included with the other OEs available. For more information, see the *VSI OpenVMS Software Product Description (SPD)*.

For more information about licensing terms and policies, contact your VSI sales office at <info@vmssoftware.com>

When you answer YES to the prompt to register your licenses now, the installation procedure launches the SYSS\$UPDATE:VMSLICENSE.COM procedure, which displays the following options menu:

VMS License Management Utility Options:

1. REGISTER a Product Authorization Key
  2. AMEND an existing Product Authorization Key
  3. CANCEL an existing Product Authorization Key
  4. LIST Product Authorization Keys
  5. MODIFY an existing Product Authorization Key
  6. DISABLE an existing Product Authorization Key
  7. DELETE an existing Product Authorization Key
  8. COPY an existing Product Authorization Key
  9. MOVE an existing Product Authorization Key
  10. ENABLE an existing Product Authorization Key
  11. SHOW the licenses loaded on this node
  12. SHOW the unit requirements for this node
99. Exit this procedure

Type '?' at any prompt for a description of the information requested. Press Ctrl/Z at any prompt to return to this menu.

Enter one of the above choices [1]

Select the REGISTER option and enter each license key until you have successfully registered all required PAKs. After you register all your licenses, exit the License Management procedure by entering 99 at the prompt.

16. **Install Windowing, Networking, and Related Products:**

You are asked whether you want to install the optional DECwindows GUI (DECwindows Motif for OpenVMS) and networking software (DECnet and TCP/IP) included with OpenVMS. The software that you choose to install (including the required software) is installed along with the OpenVMS operating system. You can change the default values for these products later in the installation procedure.

**Note**

The following display shows what you will see during an OpenVMS installation.

The following products are part of the OpenVMS installation; they will be installed along with the OpenVMS operating system:

- o Availability Manager (base) for OpenVMS I64
- o CDSA for OpenVMS I64
- o KERBEROS for OpenVMS I64
- o SSL for OpenVMS I64
- o Performance Data Collector (base) for OpenVMS I64
- o HP Binary Checker for OpenVMS I64
- o WBEM Services for OpenVMS (WBEMCIM)
- o WBEM Providers for OpenVMS (WBEMPROVIDERS)

You can also install the following optional products along with the OpenVMS operating system:

- o DECwindows Motif for OpenVMS I64
- o DECnet-Plus for OpenVMS I64
- o DECnet Phase IV for OpenVMS I64
- o TCP/IP Services for OpenVMS

If you want to change your selections, you can do so later in the installation by answering "NO" to the following question:

"Do you want the defaults for all options?"

Do you want to install DECwindows Motif for OpenVMS I64 V1.7? (Yes/No) [Ye

If you want to install the OpenVMS graphical user interface and you have the hardware that supports it and the license to use it, answer YES; otherwise, answer NO.

You may install any of the optional software products separately after the OpenVMS installation completes.

**Note**

DECwindows client files are made available through the DWMOTIF\_SUPPORT kit. The OpenVMS installation procedure installs this kit automatically. The DWMOTIF\_SUPPORT kit name is listed during the installation.

The OpenVMS Installation Menu offers the choice to install DECnet-Plus for OpenVMS or DECnet Phase IV for OpenVMS networking software. You cannot have both installed on your

## INSTALLATION Procedure

system at the same time. You can also choose to install neither DECnet product; however, certain products that depend on DECnet might be adversely affected.

If you have installed DECnet-Plus and TCP/IP on your system, you can run DECnet applications over your TCP/IP network. For more information about DECnet over TCP/IP, see the *DECnet-Plus for OpenVMS Network Management* manual.

The software products display is similar to the following:

```
The DECnet-Plus kit is provided with
the OpenVMS operating system kit.  VSI strongly recommends that
DECnet users install DECnet-Plus.  DECnet Phase IV applications are
supported by DECnet-Plus.
```

DECnet Phase IV is also provided as an option.

```
If you install DECnet-Plus and TCP/IP you can run DECnet
applications over a TCP/IP network.  Please see the OpenVMS
Management Guide for information on running DECnet over TCP/IP.
```

```
Do you want to install DECnet-Plus for OpenVMS I64 V8.4-1H1? (Yes/No) [YES]
```

If you answer NO to the DECnet-Plus prompt, you are prompted to install DECnet Phase IV:

```
Do you want to install DECnet Phase IV for OpenVMS I64 V8.4-1H1? (Yes/No) [Y
```

Finally, you are asked whether you want to install TCP/IP Services for OpenVMS:

```
Do you want to install TCP/IP Services for OpenVMS V5.7?
(Yes/No) [Yes] Y
```

17. **Choose Descriptive Help Text (Optional):** After you respond to the prompt for TCP/IP Services for OpenVMS, the final stages of the installation proceed. First, the procedure asks whether you want detailed descriptions:

The installation can provide brief or detailed descriptions.

In either case, you can request the detailed descriptions by typing ?.

```
Do you always want detailed descriptions? (Yes/No) [No]
```

If you answer YES, the procedure displays additional explanatory text with each prompt.

PCSI kits included on the OpenVMS distribution media are signed using Secure Delivery. Each target file includes an associated digital signature file that is used for Secure Delivery validation. This validation involves authenticating the originator (VSI, in this case) and verifying the contents of the target file. (The digital signature file is also referred to as a manifest; it has the same file name as the target file plus `_ESW` appended to the file extension, as in `filename.PCSI$COMPRESSED_ESW`.) When you install OpenVMS from the distribution media, the procedure validates any signed PCSI kits that are being installed. For each kit successfully validated, you see a message similar to the following:

Prior to Version 8.4:

```
Performing product kit validation ...
%PCSI-I-HPCVALPASSED, validation of
DKB400:[KITS.CDSA]HP-I64VMS-CDSA-Vnnnn-nnn-n.PCSI$COMPRESSED;1 succeeded
.
.
.
```

## INSTALLATION Procedure

VSI Version 8.4-1H1 onwards:

```
Performing product kit validation ...
%PCSI-I-VSICVALPASSED, validation of
DKB400:[KITS.BINARYCHECKER]VSI-I64VMS-BINARYCHECKER-Vnnnn-nnn-n.PCSI$COMPRES
.
.
.
```

### Note

Any signed PCSI kits that you install subsequently (including any signed kits on the distribution media) are validated. In addition, the DCL command `PRODUCT SHOW HISTORY` displays the validation status of installed products.

18. **Select Product Component Options (Accept All Defaults or Select Individually):** The procedure displays the following:

```
The following product has been selected:
      VSI I64VMS OpenVMS V8.4-1H1           Platform (product suite)
```

```
Configuration phase starting ...
```

You will be asked to choose options, if any, for each selected product and for any products that need to be installed to satisfy software dependency requirements.

```
VSI I64VMS OpenVMS V8.4-1H1: OpenVMS and related products Platform
```

```
  COPYRIGHT ...
```

```
  VMS Software, Inc.
```

```
Do you want the defaults for all options? [YES]
```

When selecting options, note the following:

- If you want all the default values, press **Enter**.

If you want to select options individually, answer NO. The procedure then prompts you for each option and suboption shown in “Component Options and Suboptions”.

- Review the list of options and compare them with the requirements for your system. If you are selecting components individually, be sure that you include all components necessary to support the needs of your users. Note also that certain components depend on the installation of other components.
- If you are not sure whether you want certain options, request help by entering a question mark (?) at the prompt for that option.
- After you select all the options you want, you can view your selections and make changes (if necessary).
- OpenVMS Management Station software is automatically installed on your OpenVMS system disk when you accept all the default values. If you do not accept the default values, you must select the OpenVMS Management Station component (server and client files) if you plan to use this product.

## INSTALLATION Procedure

- If you decide after the installation to change which options you want installed on your system, you must run the installation procedure again, but this time select the PRESERVE option as described in “PRESERVE Option”.
- After you boot the new system disk and log in, you can obtain information about individual system files by entering HELP SYS\_FILES at the dollar sign prompt (\$).

### Note

Unless you have specific reasons to do otherwise, VSI recommends that you accept the defaults and install all OpenVMS options. OpenVMS and layered products have various dependencies on many of these options. Even if you think you do not need certain options, some OpenVMS or layered product operations might not work correctly if other OpenVMS options are not installed.

Note also that the availability of certain options depends on the OE you have purchased. For more information, see the *Operating Environments for VSI OpenVMS Software Product Description* (SPD 82.34.xx).

If you answer YES to accept the defaults for all options, the procedure displays a message similar to the following, the contents of which depend on the products you chose to install. If you answer NO, you are prompted for each option and suboption.

Availability Manager (base) for OpenVMS I64

CDSA for OpenVMS I64

KERBEROS for OpenVMS I64

SSL for OpenVMS I64

Performance Data Collector for OpenVMS

HP Binary Checker for OpenVMS I64

WBEM Services for OpenVMS (WBEMCIM)

VSI I64VMS WBEMCIM V2.91-A070728: VSI WBEM Services for OpenVMS  
Copying WBEM Services for OpenVMS Release Notes to SYS\$HELP  
....There are post-installation tasks you must complete.

WBEM Providers for OpenVMS (WBEMPROVIDERS)

VSI I64VMS DWMOTIF V1.7: DECwindows Motif

If a Language Variant is installed, refer to the Installation Guide.

19. **Finish Installation onto System Disk – Review and Confirm Options:** When you have answered all the prompts and selected the options you want installed, the procedure displays information about the products you have selected and allows you to review your selections and make changes if necessary, then it installs the product, provides informational messages, and returns you to the original menu.

Do you want to review the options? [NO]

If you answer YES, the selected options and suboptions are displayed. If you answer NO, the installation continues as described with the sample script (beginning with "Execution phase starting ...") that follows.

### Example 6.1. Component Options and Suboptions

```

DECdtm Distributed Transaction Manager
Support for DECnet-Plus or DECnet for OpenVMS
Programming Support
    Debugger Utility
    Image Dump Utility
    Macro libraries
    TLB intermediary form of STARLET

    C Header Files
    VMS text libraries of Ada declarations
RMS Journaling Recovery Utility
System Programming Support
    Delta Debugger
    System Dump Analyzer Utility
    Miscellaneous Symbol Table Files
OpenVMS Management Station Software -- PC files
Utilities
    Phone Utility

    XPG4 Internationalization Utilities
    World Wide PostScript Printing Subsystem
Bliss Require Files
Example Files
Message Facility Files (HELP/MESSAGE)
Translated Image Support
UETP Files
DECwindows Server Support
Delete any obsolete OpenVMS files
Delete files archived by OpenVMS remedial kits
    
```

The component options listed in “Component Options and Suboptions” are included within the OpenVMS Version 8.4-1H1 operating system. Depending on the products you chose to install with the operating system, additional components are included as well. After the selected options and suboptions are displayed, you are prompted as follows:

```
Are you satisfied with these options? [YES]
```

If you answer NO to this question, you are allowed to selectively configure options and suboptions, even if you did not do so previously. When you finish, you are asked again whether you are satisfied with the options you selected. When you answer YES to indicate you are satisfied with the selections, the installation begins installing OpenVMS onto the target disk as shown below:

```
Execution phase starting ...
```

The following products will be installed to destinations:

```

VSI I64VMS AVAIL_MAN_BASE V8.4-1H1  DISK$I64SYS:[VMS$COMMON.]
VSI I64VMS CDSA V2.3-306             DISK$I64SYS:[VMS$COMMON.]
VSI I64VMS DECNET_PLUS V8.4-1H1     DISK$I64SYS:[VMS$COMMON.]
VSI I64VMS DWMOTIF V1.7              DISK$I64SYS:[VMS$COMMON.]
VSI I64VMS DWMOTIF_SUPPORT V8.4-1H1 DISK$I64SYS:[VMS$COMMON.]
VSI I64VMS BINARYCHECKER V1.0        DISK$I64SYS:[VMS$COMMON.]
VSI I64VMS KERBEROS V3.1-152         DISK$I64SYS:[VMS$COMMON.]
VSI I64VMS OpenVMS V8.4-1H1          DISK$I64SYS:[VMS$COMMON.]
VSI I64VMS SSL V1.4-284              DISK$I64SYS:[VMS$COMMON.]
    
```

## INSTALLATION Procedure

```
VSI I64VMS TCPIP V5.7                DISK$I64SYS:[VMS$COMMON.]
VSI I64VMS TDC_RT V2.3-1             DISK$I64SYS:[VMS$COMMON.]
VSI I64VMS VMS V8.4-1H1             DISK$I64SYS:[VMS$COMMON.]
VSI I64VMS WBEMCIM V2.91-A070728    DISK$I64SYS:[VMS$COMMON.]
VSI I64VMS WBEMPROVIDERS V2.0-31    DISK$I64SYS:[VMS$COMMON.]
```

Portion done: 0%..10%..20%..30%..40%..50%..60%..70%..80%..90%

%PCSI-I-PRCOUTPUT, output from subprocess follows ...

% - Execute SYS\$MANAGER:TCPIP\$CONFIG.COM to proceed with configuration of  
% VSI TCP/IP Services for OpenVMS.

%

Portion done: 100%

Depending on the options you selected, certain messages such as the preceding TCP/IP message might be displayed at this point.

20. **Final Installation Confirmation and Information Messages:** The installation continues, displaying the products that have been installed and post-installation tasks that might need to be performed. The version numbers in this example do not necessarily reflect the version numbers of the products actually shipped with OpenVMS Version 8.4-1H1.

The following products have been installed:

```
VSI I64VMS AVAIL_MAN_BASE V8.4-1H1 Layered Product
VSI I64VMS CDSA V2.3-306           Layered Product
VSI I64VMS DECNET_PLUS V8.4-1H1   Layered Product
VSI I64VMS DWMOTIF V1.7           Layered Product
VSI I64VMS DWMOTIF_SUPPORT V8.4-1H1 Layered Product
VSI I64VMS BINARYCHECKER V1.0     Layered Product
VSI I64VMS KERBEROS V3.1-152      Layered Product
VSI I64VMS OpenVMS V8.4-1H1       Platform (product suite)
VSI I64VMS SSL V1.4-284           Layered Product
VSI I64VMS TCPIP V5.7             Layered Product
VSI I64VMS TDC_RT V2.3-1         Layered Product
VSI I64VMS VMS V8.4-1H1          Operating System
VSI I64VMS WBEMCIM V2.91-A070728 Layered Product
VSI I64VMS WBEMPROVIDERS V2.0-31 Layered Product
```

VSI I64VMS OpenVMS V8.4-1H1: OpenVMS and related products Platform

VSI I64VMS KERBEROS V3.1-152

Configure and set up Kerberos

If Kerberos will be run on this system, but has not been used previously, you need to perform the following steps.

- o Run the Kerberos configuration procedure:

```
@SYS$STARTUP:KRB$CONFIGURE.COM
```

- o Add the following line to SYS\$MANAGER:SYSTARTUP\_VMS.COM:

```
$ @SYS$STARTUP:KRB$STARTUP
```

- o Add the following line to SYS\$MANAGER:SYLOGIN.COM:

```
$ @SYS$MANAGER:KRB$SYMBOLS
```

## INSTALLATION Procedure

Press RETURN to continue:

VSI I64VMS SSL V1.4-284: SSL for OpenVMS I64 V1.4 (Based on OpenSSL 0.9.8h)

There are post-installation tasks that you must complete after upgrading from previous SSL versions including verifying startup command procedures and logical names. Refer to SYS\$HELP:SSL014.RELEASE\_NOTES for more information.

VSI I64VMS TDC\_RT V2.3-1: The Performance Data Collector (base) for OpenVMS

Users of this product require the following privileges:  
(CMKRNL,LOG\_IO,WORLD,PHY\_IO,SYSPRV,SYSLCK)

Users of this product require the following process resource limits:  
WSQUO minimum 7000

A read-me file is available in SYS\$COMMON:[TDC]TDC\_README.TXT

Release notes are available in SYS\$COMMON:[TDC]TDC\_RELEASE\_NOTES.TXT

VSI I64VMS TCPIP V5.7 : VSI TCP/IP Services for OpenVMS.

Check the release notes for current status of the product.

21. **Installation Creates and Validates Boot Options** : At this point in an installation, the procedure creates and validates boot options if you chose to have it do so (see Step 8).

- **If you answered NO** in Step 8, the following message is displayed:

If there is an existing boot option that was used to boot this system disk, you may be able to use it. Otherwise, you will have to use the EFI Shell the first time that you boot the newly installed system. After booting, use the OpenVMS Boot Manager to create a Boot Option. To do this log in to a privileged account and execute this command:

```
$ @SYS$MANAGER:BOOT_OPTIONS
```

The procedure then informs you that the installation is complete and prompts you to press **Return (Enter)** to continue, at which point it returns you to the OpenVMS main menu. You can select Option 8 ("Execute DCL commands and procedures") on the OpenVMS Installation Menu and enter the command at the DCL triple dollar sign prompt (\$\$\$) to start the OpenVMS Boot Manager utility.

- **If you answered YES** in step 8, the installation procedure determines whether a boot entry already exists for the system disk (in this example, DKB400):

- **If an entry is found**, a message similar to the following is displayed:

The EFI Boot Manager menu includes the following boot option(s) for DKB400:

```
EFI Boot Options list:      Timeout = 0 secs.
```

```
-----  
01. DKB400 PCI(0|20|1|0) Scsi(Pun1,Lun0) "OpenVMS on DKB400: PKA0.1"
```

## INSTALLATION Procedure

-----  
1 entries found.

In this example, one boot option is found. If multiple entries are found and if they are all SCSI devices, the following message appears and then the installation is complete:

Please use the OpenVMS Boot Manager to ensure that you have a valid boot option for the system you have just installed.

When one entry is found, or when multiple Fibre Channel entries are found, the procedure validates the boot options, as in the following example, in which the found entry fails to boot and is then fixed and validated:

Validate EFI Boot Options list:      Timeout = 0 secs.

-----  
1 OpenVMS on DKB400: PKA0.1  
   DKB400 PCI(0|20|1|0) Scsi(Pun1,Lun0)  
   efi\$bcfg: Option Failed. Fixing Boot Entry automatically.  
  
efi\$bcfg: Entry 1 Boot0001 removed.  
efi\$bcfg: DKB400 PCI(0|20|1|0) Scsi(Pun1,Lun0) (Boot0001) Option  
successfully added  
-----

1 entries validated.

- **If no existing entry is found**, a boot option is created and the procedure displays the validation text, as in the following example:

efi\$bcfg: DKB400: (Boot0003) Option successfully added

The Boot Option is called OpenVMS on DKB400;;  
it is the first entry in the Boot Options menu, and is  
configured (by default) to boot from SYS0.

VMS\_FLAGS are set to -fl 0,30000

22. **Installation Completes and Returns to OpenVMS Menu:** The installation procedure is now complete. The procedure displays information about the special startup procedure that runs when the newly installed system is first booted. It then prompts you to press **Return (Enter)** to continue. After you do so, you are returned to the OpenVMS operating system menu. The following is a sample display:

The installation is now complete.

When the newly installed system is first booted, a special startup procedure will be run. This procedure will:

- o Configure the system for standalone or OpenVMS Cluster operation.
- o Run AUTOGEN to set system parameters.
- o Reboot the system with the newly set parameters.

You may shut down now or continue with other operations.

Process I64VMS\_INSTALL logged out at 12-MAR-2015 14:45:49.54

Press Return to continue...

\*\*\*\*\*

## INSTALLATION Procedure

You can install or upgrade the OpenVMS I64 operating system or you can install or upgrade layered products that are included on the OpenVMS I64 distribution media (CD/DVD).

You can also execute DCL commands and procedures to perform "standalone" tasks, such as backing up the system disk.

Please choose one of the following:

- 1) Upgrade, install or reconfigure OpenVMS I64 Version 8.4-1H1
- 2) Display layered products that this procedure can install
- 3) Install or upgrade layered products
- 4) Show installed products
- 5) Reconfigure installed products
- 6) Remove installed products
- 7) Find, Install or Undo patches; Show or Delete recovery data
- 8) Execute DCL commands and procedures
- 9) Shut down this system

Enter CHOICE or ? for help: (1/2/3/4/5/6/7/8/9/?)

23. **Shut Down the System:** Unless you want to perform other operations prior to booting the new system disk, choose the shutdown Option 9 on the OpenVMS main menu to shut down the operating system, as shown in the following example. If you want to install layered products that have not been installed yet, VSI recommends doing so during the postinstallation phase, as described in "After Installation or Upgrade Tasks".

```
Enter CHOICE or ? for help: (1/2/3/4/5/6/7/8/9/?) 9
      Shutting down the system
```

```
SYSTEM SHUTDOWN COMPLETE
```

After you complete the installation and shut down the system, you can boot your new operating system disk. Make sure you remove the DVD from the drive before booting the system disk.

## Next Steps

When you boot OpenVMS from a newly created system disk, a special startup procedure runs that does the following:

- Gives you the opportunity to configure the system for standalone or OpenVMS Cluster operation (see "Joining an OpenVMS Cluster").
- Runs AUTOGEN to evaluate your hardware configuration, estimate typical workloads, and set system parameters (see "Running AUTOGEN").
- Reboots your system with the new parameters (see "Rebooting After AUTOGEN").

After the system is rebooted with the new parameters, you can log into your SYSTEM account, as explained in "Logging In to the SYSTEM Account". If you did not allow the installation procedure to create a boot option for your system disk, you can set up such an option now, as explained in "Configuring and Managing OpenVMS Booting". *OpenVMS, Hardware and Boot Operations* includes additional information regarding setting up and booting your system.

**This completes the basic installation. Next, we recommend that you review the information in the AFTER INSTALLATION part of this manual: PART-III.**

# Chapter 7. UPGRADE Procedure

This chapter explains how to *UPGRADE* the OpenVMS operating system and includes information about reinstalling or reconfiguring your system.

**NOTE:** refer to “Booting the VSI OpenVMS Distribution Media” if you need instruction on booting, then return to this section.

Note also that some of the descriptions for **UPGRADE** steps that are common with the **INSTALLATION** procedure have been abbreviated in this chapter and you may be referred to the **INSTALLATION** chapter for details.

## Performing the UPGRADE

The following sections describe how to upgrade OpenVMS from the distribution media.

### Upgrading the System Using Option 1 of the Installation Menu

A few seconds after you boot the VSI OpenVMS OE DVD, several informational messages followed by the OpenVMS banner and eventually the Installation and Upgrade Menu appears.

To upgrade the OpenVMS operating system, choose Option (1) on the menu:

```
.
.
.
*****
You can install or upgrade the OpenVMS I64 operating system
or you can install or upgrade layered products that are included
on the OpenVMS I64 distribution media (CD/DVD).

You can also execute DCL commands and procedures to perform
"standalone" tasks, such as backing up the system disk.

Please choose one of the following:

1) Upgrade, install or reconfigure OpenVMS I64 Version 8.4-1H1
2) Display layered products that this procedure can install
3) Install or upgrade layered products
4) Show installed products
5) Reconfigure installed products
6) Remove installed products
7) Find, Install or Undo patches; Show or Delete recovery data
8) Execute DCL commands and procedures
9) Shut down this system

Enter CHOICE or ? for help: (1/2/3/4/5/6/7/8/9/? ) 1
```

### Selecting INITIALIZE or PRESERVE

The procedure displays the following information and prompts:

```
*****
```

## UPGRADE Procedure

This procedure will ask a series of questions.

() - encloses acceptable answers  
[] - encloses default answers

Type your response and press the <Return>key. Type:

? - to repeat an explanation  
^ - to change prior input (not always possible)  
Ctrl/Y - to exit the installation procedure

There are two choices for installation/upgrade:

Initialize - removes all software and data files that were previously on the target disk and installs OpenVMS I64.

Preserve -- installs or upgrades OpenVMS I64 on the target disk and retains all other contents of the target disk.

\* NOTE: You cannot use preserve to install OpenVMS I64 on a disk on which any other operating system is installed. This includes implementations of OpenVMS for other architectures.

Do you want to INITIALIZE or to PRESERVE? [PRESERVE])

For an upgrade, enter PRESERVE or press **Enter** (or **Return**) to accept the default (PRESERVE).

## Specifying the Target Disk

Next the procedure asks for the name of the target disk. If you enter a question mark (?), the system displays a list of devices on your system. Select the appropriate disk being upgraded and respond to the prompt:

You must enter the device name for the target disk on which OpenVMS I64 will be installed.

Enter device name for target disk: [DKB300] (? for choices) **DKB400**

If you select a device that is not available or that cannot be used for some other reason, the system displays information indicating why the device cannot be used.

### Caution

If the selected target disk includes .EXE or .COM files installed by a previous upgrade or installation in one or more system-specific root directories in SYS\$COMMON, the upgrade procedure tells you that when you boot from a root that contains any of these files, they are used instead of the files provided by the newer version of OpenVMS. This can make the upgraded system unbootable or cause errors after booting.

Unless a VSI representative has advised you to keep one or more of these files where they are, you must delete, rename, or move these files from the system-specific root directory. The procedure lists the names and locations of these files. Record these if you are not using a hardcopy terminal.

The procedure gives you the option of terminating the upgrade so that you can do what is necessary for these files: Select Option 8 ("Execute DCL commands and procedures") on the OpenVMS main menu and enter the appropriate DCL commands.

## Selecting Reinstallation and Reconfiguration Options

## UPGRADE Procedure

If you are using the VSI OpenVMS Version 8.4-1H1 operating system media and you selected a target disk that already has Version 8.4-1H1 installed, you are presented with several configuration options. A sample display follows.

Version 8.4-1H1 of the OpenVMS operating system is already installed on DKB400:.

Please choose one of the following:

- 1) Reconfigure the OpenVMS platform.
- 2) Reconfigure the OpenVMS operating system.
- 3) Reinstall the OpenVMS operating system.
- 4) Return to the Main Menu (abort the upgrade/installation).

Enter a "?" for more information.

If you enter a question mark (?), the following information is displayed:

- o Reconfigure the OpenVMS platform.

This action will allow you to change your selections of which products you installed along with the OpenVMS operating system installation.

This will NOT change any options in the OpenVMS operating system, nor will it reinstall any operating system files.

- o Reconfigure the OpenVMS operating system.

This action will allow you to change your choices about which options you included for the OpenVMS operating system.

This will NOT change any options for the products you installed along with the OpenVMS operating system installation, nor will it reinstall or upgrade any of them.

- o Reinstall the OpenVMS operating system.

This action will cause ALL operating system files to be replaced. You can also change your choices about which options you included for the OpenVMS operating system.

This will NOT change any options for the products you installed along with the OpenVMS operating system installation, nor will it reinstall or upgrade any of them.

Reinstall will take longer than Reconfigure. Reinstall may be appropriate if you suspect that files in the operating system, or in the windowing and network products have become corrupted.

If you want to reinstall or upgrade any of the products you installed along with the OpenVMS operating system installation, choose "Install or upgrade layered products" (Option 3) from the Installation Menu.

If you want to change your choices about which options you included for any of the products you installed along with the OpenVMS operating system installation, choose "Reconfigure installed products" (Option 5) from the Installation Menu.

## UPGRADE Procedure

Next the menu is redisplayed:

Please choose one of the following:

- 1) Reconfigure the OpenVMS platform.
- 2) Reconfigure the OpenVMS operating system.
- 3) Reinstall the OpenVMS operating system.
- 4) Return to the Main Menu (abort the upgrade/installation).

Enter choice or ? for help: (1/2/3/4/?)

## Checking for Recovery Data

When you specify the /SAVE\_RECOVERY\_DATA qualifier with the PRODUCT INSTALL command, the PCSI utility saves information that can be used for removing patches and mandatory update kits at a later time. The PRODUCT UNDO PATCH command removes the patches and kits.

The upgrade procedure, after entering the PRODUCT INSTALL command, checks the target disk for recovery data that was saved by the PCSI utility during patch installations. If no recovery data is present, the upgrade continues.

If recovery data is present and all the data found applies only to the OpenVMS operating system, the upgrade procedure deletes the data and continues. The data is deleted because it becomes invalid after the upgrade and the disk space freed up might be needed during the upgrade. (The procedure does not display the deletion of the files because earlier patches to OpenVMS are always removed as part of the upgrade.)

If any of the recovery data applies to products other than the OpenVMS operating system, then the upgrade procedure displays a message similar to the following:

```
The target system has recovery data from PRODUCT operations which
  used the /SAVE_RECOVERY_DATA qualifier.  This data must be deleted
  to continue the OpenVMS upgrade.
```

Please examine the following display.

If you wish to delete this data and continue the OpenVMS upgrade, answer YES to the question "Do you want to continue?"

If you do not wish to delete this data, answer NO. A NO answer will preserve the recovery data and abort the OpenVMS upgrade.

The following patch recovery data has been selected:

```
RECOVERY DATA SET 001 created 25-JUL-2014 15:23:39.69
```

```
-----
PATCH                                APPLIED TO
-----
JAK VMS RM1 V1.0                      JAK VMS RMTEST V1.0
-----
```

- \* If you continue, recovery data for the patches listed above will be deleted.
- \* The deletion of recovery data does not affect the installation status of
- \* patches applied to products that are not participating in this operation.
- \* However, continuing with this operation prevents you from uninstalling
- \* these patches at a future time by use of the PRODUCT UNDO PATCH command.

Do you want to continue? [YES]

If you answer YES (the default), the recovery data sets are deleted and the OpenVMS upgrade continues.

```
Deleting RECOVERY DATA SET 001 ...
```

If you answer NO, the recovery data sets are not deleted and the OpenVMS upgrade aborts.

```
Do you want to continue? [YES] NO
%PCSIUI-I-USERABORT, operation terminated by user request
```

```
You chose to retain recovery data on the target system disk.
The OpenVMS upgrade cannot continue.
```

```
Please correct the situation that prevents you from deleting the
recovery data and then retry the upgrade.
```

## Specifying the Volume Label

After you specify the target disk and if applicable, check for recovery data, the procedure informs you of the volume label currently assigned to the target disk and asks whether you want to keep that label. As shown in the following example, if you choose not to keep the label, you are prompted for a new label. The OpenVMS operating system uses the volume label to identify and reference the disk. Make sure the label you use is unique; problems occur if the same label is used by different disk volumes.

```
DKB400: is now labeled I64SYS.
```

```
Do you want to keep this label? (Yes/No) [Yes] NO
```

```
Enter volume label for target system disk: [I64SYS] I64084
```

You can accept the default label assigned by the system or specify a different volume label. (The label name has a limit of 12 characters that can include A to Z, 0 to 9, the dollar sign (\$), hyphen (-), and underscore(\_) characters).

### Warning

OpenVMS requires that the volume labels for all disks on your system or OpenVMS Cluster have unique labels. If a disk that has the same label as the system disk is mounted, various OpenVMS components will not function as intended or a node might crash during boot.

If you change the volume label for a disk in an OpenVMS Cluster, be sure to change the command that mounts the disk on other nodes in the cluster; otherwise, the disk will not mount on those nodes once they are rebooted.

## Specifying the On-Disk Structure Level

If the target disk is currently initialized with On-Disk Structure Level 2 (ODS-2), you have the option to convert the disk to On-Disk Structure Level 5 (ODS-5), as in the following example. If the target disk is currently initialized with ODS-5, the upgrade continues. You are not asked whether to convert the system disk's structure or whether to enable hard links.

### Note

If your disk is initialized with ODS-5 with hard links not enabled. You can enable them after the upgrade by executing the following commands:

```
$ SET VOLUME/VOLUME_CHARACTERISTICS=HARDLINKS SYS$SYSDEVICE
```

## UPGRADE Procedure

**\$ ANALYZE DISK\_STRUCTURE/REPAIR SYS\$SYSDEVICE**

The target system disk is currently at On-Disk Structure Level 2 (ODS-2). It can be converted to On-Disk Structure Level 5 (ODS-5).

OpenVMS I64 systems include WBEM Services for OpenVMS; the WBEM data repository requires an ODS-5 disk. If you choose to convert the target system disk to ODS-5, the repository can be on the system disk; otherwise you will need to provide an additional ODS-5 disk. (? for more information.)

Do you want to convert the target system disk to ODS-5? (Yes/No/?)

If you answer YES, the disk will be converted to ODS-5. The procedure informs you that you can use the BACKUP/CONVERT command to convert ODS-5 disks back to ODS-2 format; for more information, see the *OpenVMS System Management Utilities Reference Manual: A-L*.

### Note

VSI recommends that your system disk be structured in ODS-5 format unless you use software that requires ODS-2. A brief comparison of ODS-2 and ODS-5, including advantages and disadvantages is in "STEP-BY-STEP Installation Example". See also: *OpenVMS System Manager's Manual, Volume 1: Essentials*.

Note also that although WBEM Services for OpenVMS can be installed on an ODS-2 disk, the WBEM Services for OpenVMS data repository requires an ODS-5 disk. A system disk in ODS-5 format can store everything; if you choose to have your disk in ODS-2 format, the procedure asks you to provide an ODS-5 disk for the data repository.

If you choose not to change to ODS-5, the upgrade continues and the target disk is mounted:

Do you want to convert the target system disk to ODS-5? (Yes/No/?) **NO**

...OpenVMS I64 will be upgraded on DKB400:.

If you choose to change to ODS-5, you are given the option to enable hard links. (For more information about hard links, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*.) The upgrade then continues.

Do you want to convert the target system disk to ODS-5? (Yes/No/?) **YES**

DKB400: has been converted to ODS-5.

You can use the BACKUP/CONVERT command to convert ODS-5 disks back to ODS-2 format. For more information, refer to the OpenVMS System Management Utilities Reference Manual.

Hard links can be enabled on ODS-5 disks. WBEM Services for OpenVMS does not require hard links. (? for more information)

(\*\*\*Enabling hard links can take from 5-10 minutes to an hour or more.\*\*\*)

Do you want to enable hard links? (Yes/No/?) **YES**

If you choose to enable hard links, the procedure automatically executes an ANALYZE/DISK\_STRUCTURE/REPAIR operation to correctly set the reference (link) counts. ANALYZE/DISK/REPAIR counts the number of directory entries that reference each file, and sets the link count if it is incorrect. This operation can take from 5 to 10 minutes to an hour or more, depending on the complexity of the system disk configuration, the number of layered products installed, and the number of user files. During the process, messages similar to the following are displayed:

## UPGRADE Procedure

Hard links have been enabled on DKB400:.

The newly enabled hard links are not correct and need to be updated. The Analyze/Disk\_Structure utility will now be run to do this.

This can take from 5 - 10 minutes to an hour or more. It is a normal requirement when hard links are enabled on an existing disk.

```
%ANALDISK-I-COUNT, 1000 hard link updates completed
%ANALDISK-I-COUNT, 2000 hard link updates completed
%ANALDISK-I-COUNT, 3000 hard link updates completed
%ANALDISK-I-COUNT, 4000 hard link updates completed
%ANALDISK-I-COUNT, 5000 hard link updates completed
%ANALDISK-I-COUNT, 6000 hard link updates completed
```

OpenVMS I64 will be upgraded on DKB400:.

## Create and Validate Boot Options

On upgrades, the procedure next asks whether you want to create or validate boot options.

Boot options in the EFI Boot Manager boot option menu can provide a convenient way to boot your system. The installation procedure can automatically create a new boot option (if none exists) or validate existing boot options.

Do you want to create or validate boot options? (Yes/No) [Yes] **YES**

If this is your normal system disk and you want the upgrade procedure to assist you in setting up or validating boot options in the EFI Boot Manager menu, answer YES.

If you answer YES and no boot option exists, the procedure allows you to set OpenVMS boot flags (VMS\_FLAGS), as shown in the following example. Enter the OpenVMS flags (for example, 0,1), or press **Enter** to set no flags (the default). If a boot option exists, you can change boot flags after the upgrade completes (for information about changing boot flags, see “Setting Boot Options for Your System Disk”).

You can set VMS\_FLAGS or accept the default, 0,0.

Enter the value for VMS\_FLAGS: (n,n) [0,0]

### Note

If your newly upgraded system disk is a Fibre Channel device, VSI recommends that you add it as a boot option in the EFI boot menu. If you do not allow the upgrade procedure to add the device to the boot menu, you can add it by using the OpenVMS Boot Manager utility (SYS\$MANAGER:BOOT\_OPTIONS.COM) after the upgrade completes. (To add Fibre Channel devices to the EFI boot menu, you must use this utility instead of EFI.)

VSI recommends using the OpenVMS Boot Manager utility to add shadowed system disks in a multiple-member shadow set to the EFI boot device list and dump device list. Be sure to add all members to both lists.

For information about the OpenVMS Boot Manager utility, see “Setting Boot Options for Your System Disk”. For more information about configuring and booting Fibre Channel devices, see “Setting Up and Booting Fibre Channel Storage Devices”.

## Warning About Removal of the DECRAM Command

When upgrading from versions of OpenVMS prior to 8.3, the procedure displays a message similar to the following that warns you that the DCL command DECRAM is being removed to prevent conflict with the DECRYPT command:

```
The DCL commands ENCRYPT and DECRYPT
are provided as part of OpenVMS.
```

```
Because "DECRYPT" conflicts with the existing command "DECRAM",
this upgrade will remove the DECRAM command.
```

```
If you use the command DECRAM interactively or in command
procedures, please see the release notes for more information.
```

The DECRYPT command (introduced with OpenVMS Version 8.3) overwrites the default definition of DECR, which you might have been using to run DECram. You should update any command procedures that use the DECRAM command so that they use the foreign command style of DCL to run DECram:

```
$ DECRAM == "$MDMANAGER"
```

This change affects only the use of the DCL command; all other aspects of the DECram product remain the same.

## Setting OpenVMS Cluster Membership Information

The procedure now asks whether your system will be part of an OpenVMS Cluster. For example:

```
Will this system be a member of an OpenVMS Cluster? (Yes/No)
```

If you answer YES to this question, the procedure will ask whether your system will use IP for Cluster Communications.

```
Will this system use IP for Cluster Communications ? (Yes/No)
```

If the system being upgraded is member of an existing cluster, answering YES to this question causes the `SYS$MANAGER:CLUSTER_CONFIG.COM` procedure to run automatically when your upgraded system is first booted. However, correct cluster membership information is required by the upgrade procedure. Note that you can run this procedure manually to configure or reconfigure your system as a member of an OpenVMS Cluster. For more information about configuring a member of an OpenVMS Cluster, see the *Guidelines for OpenVMS Cluster Configurations* manual.

## License Rebranding

At this point, if you are upgrading from an *HP OpenVMS* release to a *VSI OpenVMS* release, you will see information pertaining to the re-branding of installed product licenses. This process is required to maintain consistency in the installed product license database. Refer to “Software Licensing and Rebranding” if you would like more information.

## Updating Time Zone Information

For local time zone support to work correctly, the time zone that accurately describes the location you want to be considered as your default time zone must be set. In addition, your system must be configured correctly to use a valid OpenVMS time differential factor (TDF).

If the installation procedure determines that time zone information is incomplete, it prompts you to set the correct default time zone and TDF for your system. For information about setting the time zone information, see “STEP-BY-STEP Installation Example”.

For more information about TDF and local time zone support, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*.

## Upgrading Windowing, Networking, and Related Products

The procedure now presents information about the optional DECwindows GUI (DECwindows Motif for OpenVMS), and networking (DECnet and TCP/IP) products that will be upgraded along with the OpenVMS operating system. As noted by the procedure, you can change the default values for these products later in the installation procedure.

### Note

The following display shows what you might see during an installation.

The following products are part of the OpenVMS installation;  
if necessary they will be installed or upgraded along with the OpenVMS oper

- o Availability Manager (base) for OpenVMS I64
- o CDSA for OpenVMS I64
- o KERBEROS for OpenVMS I64
- o SSL for OpenVMS I64
- o Performance Data Collector (base) for OpenVMS I64
- o HP Binary Checker for OpenVMS I64
- o WBEM Services for OpenVMS (WBEMCIM)
- o WBEM Providers for OpenVMS (WBEMPROVIDERS)

If necessary, the following optional products will also be upgraded along with the OpenVMS operating system:

- o DECwindows Motif for OpenVMS I64
- o DECnet-Plus for OpenVMS I64
- o DECnet Phase IV for OpenVMS I64
- o TCP/IP Services for OpenVMS

If you want to add or delete optional products, you can do so later in the upgrade by answering NO to the following question:

"Do you want the defaults for all product options?"

Availability Manager (base) for OpenVMS I64  
is already installed on your system. An upgrade is not required.

CDSA for OpenVMS I64 ...  
is installed on your system. It will be upgraded.

KERBEROS for OpenVMS I64...  
is installed on your system. It will be upgraded.

SSL for OpenVMS I64...  
is installed on your system. An upgrade is not required.

Performance Data Collector (base) for OpenVMS I64...  
is installed on your system. It will be upgraded.

HP Binary Checker for OpenVMS I64

## UPGRADE Procedure

DECwindows Motif for OpenVMS I64 V1.7  
is installed on your system. An upgrade is not required.

The DECnet-Plus kit is provided with  
the OpenVMS operating system kit. VSI strongly recommends that  
DECnet users install DECnet-Plus. DECnet Phase IV applications are  
supported by DECnet-Plus.

DECnet Phase IV is also provided as an option.

If you install DECnet-Plus and TCP/IP you can run DECnet  
applications over a TCP/IP network. Please see OpenVMS  
Management Guide for information on running DECnet over TCP/IP.

Do you want to install DECnet-Plus for OpenVMS I64 V8.4-1H1? (Yes/No) [Yes]

VSI TCP/IP Services for OpenVMS  
is already installed on your system. An upgrade is not required.

WBEM Services for OpenVMS (WBEMCIM)  
is installed on your system. It will be upgraded.

WBEM Providers for OpenVMS (WBEMPROVIDERS)  
is installed on your system. It will be upgraded.

### Note

DECwindows client files are made available through the DWMOTIF\_SUPPORT kit. The OpenVMS installation procedure installs this kit automatically. The DWMOTIF\_SUPPORT kit name is listed during the installation.

Required versions of some of the windowing and networking products might already be installed on the system. If so, you will see a message to this effect, as seen for most of the products in the previous example. For some of the windowing and networking products, earlier versions might be installed that still work on OpenVMS Version 8.4-1H1. In this case, you will see a message indicating the software is already installed and asking whether you want to install the newer version. You can keep the currently installed version or upgrade to the newer version supplied with OpenVMS Version 8.4-1H1. If you choose to keep the currently installed version, you should verify what level of support for this version is available from HP or VSI.

Some windowing and networking products might have versions installed that do not work with VSI OpenVMS Version 8.4-1H1. In this case, you are not given a choice to upgrade; the software is upgraded automatically.

## Completing the Upgrade

The following sections describe the remaining steps that you need to perform to complete the upgrade.

### Selecting Descriptive Help Text

The procedure next prompts you as follows:

The installation operation can provide brief or detailed descriptions.  
In either case, you can request the detailed descriptions by typing ?.

Do you always want detailed descriptions? (Yes/No) [No]

If you answer YES, the procedure displays additional explanatory text with each prompt.

## Removing Older Versions of ENCRYPT

Encryption for OpenVMS is included with the operating system. If an older version of ENCRYPT (HP I64VMS ENCRYPT) is found on your system, the upgrade procedure removes the product. Confirmation of the removal of the ENCRYPT product is displayed, as in the following example:

```
HP I64VMS ENCRYPT will now be removed.
    This is required because VSI OpenVMS now includes ENCRYPT.

The following product has been selected:
    HP I64VMS ENCRYPT V1.6                Layered Product
The following product will be removed from destination:
    HP I64VMS ENCRYPT V1.6                DISK$I64084:[VMS$COMMON.]

Portion done: 0%...20%...30%...40%...50%...60%...70%...80%...90%...100%

The following product has been removed:
    HP I64VMS ENCRYPT V1.6                Layered Product
```

## Secure Delivery Validation

PCSI kits included on the OpenVMS distribution media are signed using Secure Delivery. Each target file includes an associated digital signature file (also referred to as a manifest) that is used for Secure Delivery validation. This validation involves authenticating the originator and verifying the contents of the target file. The digital signature file has the same file name as the target file plus `_ESW` appended to the file extension, as in `filename.PCSI$COMPRESSED_ESW`.

When you upgrade from the distribution media (and if the re-branding procedure has not already done this), the upgrade procedure validates any PCSI kits that are being installed. For each kit successfully validated, you may see a message similar to the following:

Prior to Version 8.4:

```
Performing product kit validation of signed kits...
%PCSI-I-HPCVALPASSED, validation of
DKB400:[KITS.CDSA]HP-I64VMS-CDSA-Vnnnn-nnn-n.PCSI$COMPRESSED;1 succeeded
.
.
.
```

From Version 8.4-1H1 onwards:

```
Performing product kit validation ...
%PCSI-I-VSICVALPASSED, validation of
DKB400:[KITS.BINARYCHECKER]VSI-I64VMS-BINARYCHECKER-Vnnnn-nnn-n.PCSI$COMPRESSED
.
.
.
```

Signed PCSI kits that are installed subsequent to the initial boot of the OpenVMS DVD (including signed kits on the distribution media) are validated. In addition, the DCL command `PRODUCT SHOW HISTORY` displays the validation status of installed products.

## Selecting Product Component Options

As you begin the upgrade procedure, the procedure asks whether you want all the default values (meaning all the files and subgroups of files for each component included in the operating system). The display is similar to the following:

```
The following product has been selected:
```

## UPGRADE Procedure

VSI I64VMS OpenVMS V8.4-1H1 Platform (product suite)

Configuration phase starting ...

You will be asked to choose options, if any, for each selected product and for any products that may be installed to satisfy software dependency requirements.

VSI I64VMS OpenVMS V8.4-1H1: OpenVMS and related products Platform

COPYRIGHT 1976, 2015 ...

VMS Software, Inc.

Do you want the defaults for all options? [YES]

During an upgrade, the PCSI utility defines default values as the values that you selected when you last installed or upgraded the OpenVMS operating system on your system. Therefore, before you respond to the prompt, note the following:

- If you accept the default values, you receive the same components that you selected when you last installed or upgraded the system (instead of *all* the components currently available) plus any new components that were not in the previous version of the OpenVMS operating system.
- If you want to include or exclude any components differently than you did in the last installation or upgrade, you must answer NO and then respond to the prompts for *each* option, even those that you are not changing.
- If you want to review the current defaults first, answer NO. Then answer YES when the procedure asks whether you want to view the values.

If you review the defaults and are satisfied, answer YES to the prompt asking whether you are satisfied with the values. If you want to make changes, answer NO to that question and then answer YES when the procedure asks whether you want to reenter the values.

When you select component options, also note the following:

- Whether you choose all the default values or select individual files, the procedure allows you to view your selections and make changes.
- If you are not sure whether you want certain component options, you can request help by entering a question mark (?) at the prompt for that component (or group of components).
- You should review the list of options and compare them with the requirements for your procedure. If you are selecting components individually, be sure that you include all components necessary to support the needs of your users. Note also that certain components depend upon the installation of other components.
- OpenVMS Management Station software is installed automatically on your OpenVMS system disk when you accept all the default values. If you do not accept the default values, you must select the OpenVMS Management Station component (server and client files) if you plan to use that product.
- If you decide after the upgrade to change which OpenVMS operating system components you want installed on your system, you must reconfigure the installation as described in “Adding and Removing Operating System Files (Optional)”.
- After you boot the upgraded system disk and log in, you can obtain information about individual system files by entering HELP SYS\_FILES at the dollar sign prompt (\$).

### Note

Unless you have specific reasons to do otherwise, VSI recommends that you accept the defaults and install all OpenVMS options. OpenVMS and layered products have various dependencies on

## UPGRADE Procedure

many of these options. Even if you think you do not need certain options, some OpenVMS or layered product operations might not work correctly if other OpenVMS options are not installed.

If you answer YES to accept the defaults for all options, the procedure displays a message similar to the following, the contents of which depend on the products you chose to install. If you answer NO, the procedure prompts you for each option and suboption.

Availability Manager (base) for OpenVMS I64

CDSA for OpenVMS I64

KERBEROS for OpenVMS I64

SSL for OpenVMS I64

Performance Data Collector (base) for OpenVMS I64

HP Binary Checker for OpenVMS I64

WBEM Services for OpenVMS (WBEMCIM)

WBEM Providers for OpenVMS (WBEMPROVIDERS)

For a list of component options included with VSI OpenVMS Version 8.4-1H1 operating system, see "Component Options and Suboptions".

## Component and Product Installation Confirmation Messages

When you have answered all the prompts and selected the components you want installed, the procedure allows you to review your selections and make changes, and then displays information about the various components and products that were installed, as shown in the following sample display in which the review is not chosen. You might see an %UPGRADE-I-FIXUP message, which indicates that obsolete files on the system were incorrectly saved by remedial kits. The "fixup" allows them to be correctly removed.

Do you want to review the options? [NO] **NO**

Execution phase starting ...

The following products will be installed to destinations:

VSI I64VMS CDSA V2.4-322A	DISK\$I64084:[VMS\$COMMON.]
VSI I64VMS DECNET_PLUS V8.4-1H1	DISK\$I64084:[VMS\$COMMON.]
VSI I64VMS HPBINARYCHECKER V1.1-A	DISK\$I64084:[VMS\$COMMON.]
VSI I64VMS KERBEROS V3.2-256	DISK\$I64084:[VMS\$COMMON.]
VSI I64VMS OpenVMS V8.4-1H1	DISK\$I64084:[VMS\$COMMON.]
VSI I64VMS VMS E8.4-1H1	DISK\$I64084:[VMS\$COMMON.]
VSI I64VMS WBEMCIM V2.99-B100614	DISK\$I64084:[VMS\$COMMON.]
VSI I64VMS WBEMPROVIDERS V2.2-3A	DISK\$I64084:[VMS\$COMMON.]

The following products will be removed from destinations:

HP I64VMS CDSA V2.2	DISK\$I64084:[VMS\$COMMON.]
HP I64VMS DECNET_PLUS V8.3	DISK\$I64084:[VMS\$COMMON.]
HP I64VMS KERBEROS V3.0	DISK\$I64084:[VMS\$COMMON.]
HP I64VMS OpenVMS V8.3	DISK\$I64084:[VMS\$COMMON.]
HP I64VMS VMS V8.3	DISK\$I64084:[VMS\$COMMON.]

Portion done: 0%..10%..20%..30%..40%..50%..60%..70%..80%..90%..100%

The following products have been installed:

VSI I64VMS CDSA V2.4-322A	Layered Product
VSI I64VMS DECNET_PLUS V8.4-1H1	Layered Product
VSI I64VMS HPBINARYCHECKER V1.1-A	Layered Product

## UPGRADE Procedure

```
VSI I64VMS KERBEROS V3.2-256          Layered Product
VSI I64VMS OpenVMS V8.4-1H1          Platform (product suite)
VSI I64VMS VMS E8.4-1H1             Operating System
VSI I64VMS WBEMCIM V2.99-B100614.....Layered Product
VSI I64VMS WBEMPROVIDERS V2.2-3A.....Layered Product
```

The following products have been removed:

```
HP I64VMS CDSA V2.2                  Layered Product
HP I64VMS DECNET_PLUS V8.2           Layered Product
HP I64VMS KERBEROS V3.0              Layered Product
HP I64VMS OpenVMS V8.3               Platform (product suite)
HP I64VMS VMS V8.3                   Operating System
```

VSI I64VMS OpenVMS V8.4-1H1: OpenVMS and related products Platform

VSI I64VMS KERBEROS V3.1-152

Configure and set up Kerberos

If Kerberos will be run on this system, but has not been used previously, you need to perform the following steps.

- o Run the Kerberos configuration procedure:

```
@SYS$STARTUP:KRB$CONFIGURE.COM
```

- o Add the following line to SYS\$MANAGER:SYSTARTUP\_VMS.COM:

```
$ @SYS$STARTUP:KRB$STARTUP
```

- o Add the following line to SYS\$MANAGER:SYLOGIN.COM:

```
$ @SYS$MANAGER:KRB$SYMBOLS
```

...similar messages will appear for other installed products...

Press RETURN to continue:

## Upgrade Creates and Validates Boot Options

At this point in an upgrade, the procedure creates and validates boot options if you chose to have the procedure do so (see “Create and Validate Boot Options”).

- **If you answered NO**, the following message is displayed

If there is an existing boot option that was used to boot this system disk, you may be able to use it. Otherwise, you will have to use the EFI Shell the first time that you boot the newly installed system. After booting, use the OpenVMS Boot Manager to create a Boot Option. To do this log in to a privileged account and execute this command:

```
$ @SYS$MANAGER:BOOT_OPTIONS
```

The procedure then informs you that the upgrade is complete and prompts you to press **Return (Enter)** to continue, at which point it returns you to the OpenVMS main menu. You can select option 8 (“Execute DCL commands and procedures”) on the OpenVMS main menu and enter the command at the DCL triple dollar sign prompt (\$\$\$) to start the OpenVMS Boot Manager utility.

## UPGRADE Procedure

- **If you answered YES**, the procedure determines whether a boot entry already exists for the system disk (in this example, DKB400):
- **If an entry is found**, a message similar to the following is displayed:

```
The EFI Boot Manager menu includes the following boot option(s)
for DKB400:
```

```
Validate EFI Boot Options list:      Timeout = 0 secs.
```

```
-----
1 DKB400 PCI(0|20|1|0) Scsi(Pun1,Lun0) "OpenVMS on DKB400: PKA0.1"
-----
```

```
1 entries found.
```

In this example, one boot option is found. If multiple entries are found and if they are all SCSI devices, the procedure displays the following message and then notifies you that the upgrade is complete:

```
The EFI Boot Manager menu includes multiple Boot Options for $1$DGA1200:
Boot Options cannot be created or validated automatically.
```

```
Please use the OpenVMS Boot Manager to ensure that you
have a valid boot option for the system you have just installed.
```

When one entry is found, or when multiple Fibre Channel entries are found, the procedure validates the boot options, as in the following example, in which the found entry fails to boot and is then fixed and validated:

```
Validate EFI Boot Options list:      Timeout = 0 secs.
```

```
-----
1 DKB400: PKA0.1
   DKB400 PCI(0|20|1|0) Scsi(Pun1,Lun0)
   efi$bcfg: Option Failed. Fixing Boot Entry automatically.
```

```
efi$bcfg: Entry 1 Boot0001 removed.
efi$bcfg: DKB400 PCI(0|20|1|0) Scsi(Pun1,Lun0) (Boot0001) Option
successfully added
```

```
-----
1 entries validated.
```

- **If no existing entry is found**, a boot option is created and the procedure displays validation text as in the following example:

```
efi$bcfg: DKB400: (Boot0003) Option successfully added
```

```
The Boot Option is called OpenVMS on DKB400;;
it is the first entry in the Boot Options menu, and is
configured (by default) to boot from SYS0.
```

```
VMS_FLAGS are set to -fl 0,0
```

## Upgrade Completed

The upgrade procedure is now complete. The procedure displays information about the special startup procedure that runs when the newly installed system is first booted. It then prompts you to press **Return (Enter)** to continue. After you do so, you are returned to the OpenVMS operating system menu. The following is a sample display:

## UPGRADE Procedure

The upgrade is now complete.

When the newly upgraded system is first booted, a special startup procedure will be run. This procedure will:

- o Run AUTOGEN to set system parameters.
- o Reboot the system with the newly set parameters.

You may shut down now or continue with other operations.

Process I64VMS\_INSTALL logged out at 12-MAR-2015 14:45:49.54

Press Return to continue...

\*\*\*\*\*

You can install or upgrade the OpenVMS I64 operating system or you can install or upgrade layered products that are included on the OpenVMS I64 distribution media (CD/DVD).

You can also execute DCL commands and procedures to perform "standalone" tasks, such as backing up the system disk.

Please choose one of the following:

- 1) Upgrade, install or reconfigure OpenVMS I64 Version 8.4-1H1
- 2) Display layered products that this procedure can install
- 3) Install or upgrade layered products
- 4) Show installed products
- 5) Reconfigure installed products
- 6) Remove installed products
- 7) Find, Install or Undo patches; Show or Delete recovery data
- 8) Execute DCL commands and procedures
- 9) Shut down this system

Enter CHOICE or ? for help: (1/2/3/4/5/6/7/8/9/?)

## Shutting Down the System

Unless you want to perform any other operations prior to booting the upgraded disk, shut the system down by choosing the shutdown option (9) on the menu:

```
Enter CHOICE or ? for help: (1/2/3/4/5/6/7/8/9/?) 9
  Shutting down the system
  .
  .
  .
  SYSTEM SHUTDOWN COMPLETE
```

After the system shuts down, you can boot the newly upgraded system disk. AUTOGEN will run automatically, after which the system shuts down again and automatically reboots. If you are doing a concurrent or rolling upgrade in an OpenVMS Cluster environment, do not boot any other cluster members now.

**Now go to “*After Installing or Upgrading OpenVMS*” and check for any postupgrade tasks that need to be performed before the system and cluster can be used. Once you have completed all required postupgrade tasks, you can reboot and then use other cluster members.**

# **Part III. After Installing or Upgrading**

This part of the manual provides information you should review following your installation or upgrade. Skim through the section titles in this part of the manual and review those which apply to your computing environment.

# Table of Contents

8. After Installing or Upgrading OpenVMS .....	96
After Installation or Upgrade Tasks .....	96
Booting the newly installed VSI OpenVMS System Disk .....	98
Logging In to the SYSTEM Account .....	99
Logging In from a Character-Cell Terminal .....	99
Logging In from a Workstation .....	100
Running Autogen. Running AUTOGEN .....	100
Autogen. Running AUTOGEN to Tune the System .....	101
Rebooting After AUTOGEN .....	102
Joining an OpenVMS Cluster .....	103
System Disk Backup. Backing Up Your System Disk .....	104
Registering Licenses. Registering Your Licenses .....	105
Shadow Parameters. Set System Parameters for Volume Shadowing (Optional) .....	106
Forming a Shadow Set. Forming the Shadow Set .....	107
Customizing the System (New Installations, Some Upgrades) .....	108
Network Proxy Files. Creating Network Proxy Authorization Files .....	109
Queue Manager. Setting Up the Queue Manager and Default Queues .....	109
Configuring DECnet. Configuring DECnet .....	110
Configuring TCPIP. Configuring TCP/IP Services for OpenVMS .....	111
Configuring Additional Software. Installing and Configuring Third-Party Networking Software .....	111
Multihead Display. Configuring a Multihead System (Optional) .....	111
Configuring CDSA. Initializing CDSA (Optional) .....	112
Configuring Availability Manager. Configuring the Availability Manager Base Software (Optional) .....	113
Configuring Kerberos. Configuring Kerberos (Optional) .....	113
Configuring SSL. Configuring SSL for OpenVMS (Optional) .....	114
Configuring WBEM Services. Configuring WBEM Services for OpenVMS (Optional) ...	115
Configuring WBEM Services for OpenVMS (Where Not Configured Previously) .....	116
Configuring WBEM Services for OpenVMS (Where Configured Previously) .....	117
Configuring WBEM Providers. Configuring WBEM Providers for OpenVMS (Optional) .....	119
Configuring TDC. Configuring and Running the Performance Data Collector Base Software (Optional) .....	122
User Privileges and Quotas .....	122
Startup File .....	123
Compatibility with Prior Releases .....	123
Running TDC_RT .....	124
Installation in OpenVMS Clusters .....	124
Configuring Management Station. Configuring the OpenVMS Management Station (Optional) .....	124
Configuring a Welcome Message. Creating a System-Specific Login Welcome Message (Optional) .....	125
Configuring COM Files. Examining Your Command Procedures (Upgrades Only) .....	125
Add or Remove SYSTEM files. Adding and Removing Operating System Files (Optional) .....	126
Compressing Libraries. Compressing the System Libraries (Optional; Not Recommended) .....	128
Installing Patches. Installing Patches (Optional but Recommended) .....	128
Installing Layered Products. Installing and Configuring Layered Products .....	129
Alternative Procedure .....	130
Creating Print Queues. Creating Print Queues .....	131
Starting Layered Products. Updating SYSTARTUP_VMS.COM to Start Layered Products and Print Queues .....	131

## After Installing or Upgrading

Creating Accounts. Creating Accounts (New Installations, Some Upgrades) .....	132
Running UETP. Testing the System with UETP (Optional) .....	132
Backup after Customization. Backing Up the Customized System Disk and Initiating System Backups .....	132
Reforming a Shadow Set. Reforming the Shadow Set as Final Postupgrade Backup .....	132
Rebooting Cluster Members. Rebooting Cluster Members (Upgrades Only) .....	133
Modifying System Parameters. Modifying System Parameters .....	133
General Notes About Modifying System Parameters .....	133
Modifying System Parameters After an Upgrade .....	133

# Chapter 8. After Installing or Upgrading OpenVMS

After you have installed or upgraded the OpenVMS operating system, you must perform several important tasks to prepare the system for operation.

## After Installation or Upgrade Tasks

Use the following checklist to ensure that you perform any necessary post-installation or upgrade tasks.

**Table 8.1. AFTER Installation or Upgrade Checklist**

	TASK	SECTION
•	<p>For a newly installed system disk, you can back up the disk or re-install OpenVMS on a backup disk.</p> <p>For a newly upgraded system disk, if it is <i>not</i> going to be a shadow set member, back up the system disk as a safeguard before proceeding with the next steps. If your newly upgraded system disk is going to be a shadow set member, you can re-form it in a later step. As an optional precaution, you can back up the system disk as well.</p>	Section System Disk Backup
•	Register any licenses that were not registered during the installation; for an upgrade, register any new licenses.	Section Registering Licenses
•	<i>New installations only (optional):</i> Set system parameters to enable <i>volume shadowing</i> .	Section Shadow Parameters
•	If you set system parameters to enable volume shadowing, run AUTOGEN and reboot.	Section Running Autogen
•	If you want to form a shadow set for a system disk, you can do this now or later. If you upgrade a disk in a volume shadowing environment, re-form the shadow set.	Section Forming a Shadow Set
•	<p><i>New installations, some upgrades:</i> Perform the following tasks that generally apply to new installations only but could also apply after an upgrade:</p>	
•	Create proxy files, if required.	Section Network Proxy Files
•	Set up the queue manager and start the default batch and print queues.	Section Queue Manager
•	Configure a multihead system, if applicable.	Section Multihead Display
•	Configure DECnet if it was installed. After an upgrade, perform only if DECnet was added during the upgrade.	Section Configuring DECnet
•	Configure TCP/IP Services for OpenVMS if it was installed. After an upgrade, configure TCP/IP Services only if it was added during the upgrade.	Section Configuring TCPIP

After Installing or  
Upgrading OpenVMS

TASK	SECTION
<ul style="list-style-type: none"> <li>• If you are using neither DECnet nor TCP/IP Services, install and configure third-party networking software, if necessary. Networking software is required to download patches and for certain layered products.</li> </ul>	Section Configuring Additional Software
<ul style="list-style-type: none"> <li>• Initialize or configure the following products, as needed:               <ul style="list-style-type: none"> <li>• Initialize CDSA.</li> <li>• Configure Availability Manager.</li> <li>• Configure Kerberos.</li> <li>• Configure SSL for OpenVMS.</li> <li>• On systems using services that depend on WBEM Services for OpenVMS, configure WBEM Services for OpenVMS.</li> <li>• On systems using services that depend on WBEM Providers, configure WBEM Providers for OpenVMS.</li> <li>• Initialize and run the Performance Data Collector base software (TDC_RT).</li> <li>• Create or edit a system-specific or clusterwide login welcome message SYS\$MANAGER:WELCOME.TXT (optional).</li> <li>• <i>Upgrades only:</i> Examine command procedures for which the upgrade may have provided new template files.</li> <li>• Add and remove operating system files (optional).</li> <li>• If necessary, compress the system libraries using LIBDECOMP.COM (optional, VSI recommends keeping libraries in expanded format).</li> <li>• Download and apply any relevant OpenVMS or networking patches that are available (optional but recommended).</li> <li>• <i>New installations, some upgrades:</i> Install and configure layered products.</li> <li>• <i>New installations, some upgrades:</i> Create print queues.</li> <li>• Update SYSTARTUP_VMS.COM to have layered products, print queues, and other products or devices start at boot.</li> <li>• <i>Installations and possibly upgrades:</i> Create user accounts.</li> <li>• Run the User Environment Test Package (UETP) to test the system (optional).</li> <li>• Back up the system disk and start a systematic routine for backing up the application, data, and user disks.</li> </ul> </li> </ul>	Section Configuring CDSA Section Configuring Availability Manager Section Configuring Kerberos Section Configuring SSL Section Configuring WBEM Services Section Configuring WBEM Providers Section Configuring TDC Section Configuring a Welcome Message Section Configuring COM Files Section Add or Remove SYSTEM files Section Compressing Libraries Section Installing Patches Section Installing Layered Products Section Creating Print Queues Section Starting Layered Products Section Creating Accounts the section called “Testing the System with UETP (Optional)” Section Backup after Customization

	TASK	SECTION
	<ul style="list-style-type: none"> <li>If the system disk was pulled out of the shadow set and all the appropriate postupgrade steps recommended in this chapter thus far were performed on that disk, then re-form the shadow set once again.</li> </ul>	Section Reforming a Shadow Set
	<ul style="list-style-type: none"> <li><i>Upgrades only:</i> Reboot cluster members, if applicable.</li> </ul>	Section Rebooting Cluster Members
	<ul style="list-style-type: none"> <li>Tune your operating system: After the system has run for at least 24 hours with users or a typical application workload on the system, run AUTOGEN to collect feedback. If necessary, modify the MODPARAMS.DAT file.</li> </ul>	Section Running Autogen Section Modifying System Parameters

## Booting the newly installed VSI OpenVMS System Disk

The following steps explain how to boot your new VSI OpenVMS system disk. For more information about this and special booting operations, see “Distribution Media Boot Methods”.

### Note

Be sure to remove the DVD from the DVD drive before booting the system disk.

The actions you take to boot the system disk depend on whether you have configured your system with a boot option for your system disk:

- **If you have configured your system with a boot option for your system disk**, your system disk is displayed as a boot option in the EFI Boot Manager menu. Select your system disk and press **Enter**. If your system disk is the first option in the EFI Boot Manager menu, it might boot automatically after the 10-second countdown.
- **If you have not configured your system with a boot option for your disk**, follow these steps:
  1. Press **Enter** or any other key. (You might see text that instructs you to "hit any key to cold reboot.") The machine displays several boot-related messages and then displays the EFI Boot Manager menu.
  2. Go to the EFI Shell prompt by selecting the EFI Shell [Built-in] option from the EFI Boot Manager menu. (This might be selected automatically if you do not make a selection before the EFI countdown completes.) A display similar to the following appears. An explanation of the two types of devices shown (**blk** and **fs**) follows the example.

```

Loading.: EFI Shell [Built-in]
EFI Shell version 1.10 [14.61]
Device mapping table
fs { fs0 : Acpi (HWP0002,100) /Pci (1|0) /Scsi (Pun0,Lun0) /HD (Part1,Sig8FCF6F11-...
    fs1 : Acpi (HWP0002,100) /Pci (1|0) /Scsi (Pun0,Lun0) /HD (Part4,Sig8FCF6F10-...
blk { blk0 : Acpi (HWP0002,0) /Pci (2|0) /Ata (Primary,Master)
    blk1 : Acpi (HWP0002,100) /Pci (1|0) /Scsi (Pun0,Lun0)
    blk2 : Acpi (HWP0002,100) /Pci (1|0) /Scsi (Pun0,Lun0) /HD (Part1,Sig8FCF6F11-...
    blk3 : Acpi (HWP0002,100) /Pci (1|0) /Scsi (Pun0,Lun0) /HD (Part2,Sig8FCF6F10-...
    blk4 : Acpi (HWP0002,100) /Pci (1|0) /Scsi (Pun0,Lun0) /HD (Part3,Sig8FCF6F11-...
    blk5 : Acpi (HWP0002,100) /Pci (1|0) /Scsi (Pun0,Lun0) /HD (Part4,Sig8FCF6F10-...
    blk6 : Acpi (HWP0002,100) /Pci (1|0) /Scsi (Pun0,Lun0) /HD (Part5,Sig8FCF6F10-...
Shell>
  
```

## After Installing or Upgrading OpenVMS

- fs** The fs devices are file-structured logical partitions on physical disks that are included with your system. One or more fs device exists for each volume with a bootable *partition* or diagnostic partition. Generally, fs0: corresponds to the target disk on which you installed the operating system (unless the DVD was not removed, in which case fs1: corresponds to the target disk). For example, if the target disk is DKA0, then fs0: most likely corresponds to the target disk. On the other hand, if the target disk is a DKA100 or DKB200 or similar, the corresponding EFI device depends on what partitions are configured on the target disk.
- blk** The blk devices are block devices. Multiple blk devices exist for each volume that has a bootable partition or diagnostic partition. These devices may include the DVD device as well as the diagnostic partitions on VSI OpenVMS system disks. Diagnostic partitions are intended and reserved for use by VSI Services.

3. To boot the VSI OpenVMS system disk, enter the following command at the EFI Shell prompt, where *fsn:* is the device associated with the system disk (probably fs0:):

```
Shell> fsn:\efi\vms\vms_loader.efi
```

The VSI OpenVMS operating system now starts booting. After indentifying itself, the operating system will prompt for user name and password:

```
VSI OpenVMS Industry Standard 64 Operating System, Version 8.4-1H1  
© Copyright 2015, VMS Software, Inc.
```

HP Integrity servers maintain a system event log (SEL) within system console storage, and VSI OpenVMS servers automatically transfer the contents of the SEL into the OpenVMS Error Log. On certain machines, during a successful boot operation while using a console, you might see a message indicating that the Baseboard Management Controller (*BMC*) SEL is full. You can safely continue when the BMC SEL is full by following the prompts; OpenVMS processes the contents of the SEL.

## Logging In to the SYSTEM Account

The following two sections explain how to log in to the SYSTEM account from a character-cell terminal and from a workstation.

### Logging In from a Character-Cell Terminal

Log in from a character-cell terminal by entering the user name SYSTEM followed by the password. The display is similar to the following:

```
OpenVMS I64 Operating System, Version 8.4-1H1  
  
Username: SYSTEM  
Password:  
.  
.  
.  
OpenVMS I64 Operating System, Version 8.4-1H1
```

If you forget your password for the SYSTEM account, follow the instructions in “Emergency Booting” to perform an emergency startup.

## Logging In from a Workstation

If you installed the DECwindows Motif for OpenVMS software on your workstation, do the following after the login window is displayed on your screen:

1. Enter the user name SYSTEM, press **Tab**, and then enter the password.
2. Press **Enter** or click **OK** with your mouse.
3. At this point, you can create a DECterm session or initiate other management functions. For information about creating a DECterm session, see the *DECwindows Motif for OpenVMS Applications Guide*.

## Running AUTOGEN

After an installation or upgrade, the system automatically runs AUTOGEN to evaluate your hardware configuration and estimate typical workloads. AUTOGEN then sets system parameters, the sizes of page, swap, and dump files, and the contents of VMSIMAGES.DAT. When AUTOGEN finishes and your system reboots, the installation procedure is complete.

Although AUTOGEN may have already run during installation or upgrade, you have the option of running it again after making any significant changes to the system configuration or installed products. AUTOGEN should also be run again after your system has been in active use under normal loads as it uses feedback mechanisms to more precisely tune system parameters.

The installation procedure displays messages similar to the following:

```
AUTOGEN will now be run to compute the new system parameters. The system
will then shut down and reboot, and the installation or upgrade will be
complete.
```

After rebooting you can continue with such system management tasks as:

```
Configuring networking software (TCP/IP Services, DECnet, other)
Using SYS$MANAGER:CLUSTER_CONFIG.COM to create an OpenVMS Cluster
Creating FIELD, SYSTEST, and SYSTEST_CLIG accounts if needed
```

```
%AUTOGEN-I-BEGIN, GETDATA phase is beginning.
%AUTOGEN-I-NEWFILE, A new version of SYS$SYSTEM:PARAMS.DAT has been created.
    You may wish to purge this file.
%AUTOGEN-I-END, GETDATA phase has successfully completed.
%AUTOGEN-I-BEGIN, GENPARAMS phase is beginning.
%AUTOGEN-I-NEWFILE, A new version of SYS$MANAGER:VMSIMAGES.DAT has been created
    You may wish to purge this file.
%AUTOGEN-I-NEWFILE, A new version of SYS$SYSTEM:SETPARAMS.DAT has been created.
    You may wish to purge this file.
%AUTOGEN-I-END, GENPARAMS phase has successfully completed.
%AUTOGEN-I-BEGIN, GENFILES phase is beginning.
%SYSGEN-I-EXTENDED, SYS$SYSROOT:[SYSEXE]PAGEFILE.SYS;1 extended
%SYSGEN-I-EXTENDED, SYS$SYSROOT:[SYSEXE]SWAPFILE.SYS;1 extended
%SYSGEN-I-CREATED, SYS$SYSROOT:[SYSEXE]SYSDUMP.DMP;1 created

%AUTOGEN-I-REPORT, AUTOGEN has produced some informational messages that
    have been stored in the file SYS$SYSTEM:AGEN$PARAMS.REPORT. You may
    wish to review the information in that file.

%AUTOGEN-I-END, GENFILES phase has successfully completed.
%AUTOGEN-I-BEGIN, SETPARAMS phase is beginning.
```

## After Installing or Upgrading OpenVMS

```
%AUTOGEN-I-SYSGEN, parameters modified
%AUTOGEN-I-END, SETPARAMS phase has successfully completed.
%AUTOGEN-I-BEGIN, REBOOT phase is beginning.
```

The system is shutting down to allow the system to boot with the generated site-specific parameters and installed images.

### Note

After booting and running AUTOGEN, several messages are displayed at DECwindows startup. For information about these messages and how to avoid them, see the *HP DECwindows Motif for OpenVMS Release Notes*.

## Running AUTOGEN to Tune the System

When you install or upgrade the OpenVMS operating system, the system executes the AUTOGEN.COM procedure to set the values of system parameters and the sizes of the page, swap, and dump files according to the system configuration.

After running your system for at least 24 hours with users or a typical application workload on the system, run the AUTOGEN.COM procedure again to tune the system properly. Run AUTOGEN as follows. (In an OpenVMS Cluster, you must follow these steps to run AUTOGEN on each cluster node.)

1. Run AUTOGEN in feedback mode, examine AGEN\$PARAMS.REPORT, and reboot the system. To run AUTOGEN in feedback mode, use the following command:

```
$ @SYS$UPDATE:AUTOGEN SAVPARAMS SETPARAMS FEEDBACK
```

To view AGEN\$PARAMS.REPORT on your screen, enter the following command:

```
$ TYPE SYS$SYSTEM:AGEN$PARAMS.REPORT
```

You can print this file or examine it using the EDIT/READ\_ONLY command.

If the report includes a message similar to the following, you might need to modify the size of the page, swap, or dump file:

```
%AUTOGEN-W-DSKSPC, The disk on which DKA0:[SYS0.SYSEXE]PAGEFILE.SYS
    resides would be over 95% full if it were modified to hold 20000 blocks.
```

For more information about AGEN\$PARAMS.REPORT, see the *OpenVMS System Manager's Manual, Volume 2: Tuning, Monitoring, and Complex Systems*.

2. Run AUTOGEN again in feedback mode two work days later and examine AGEN\$PARAMS.REPORT, and then reboot the system. For information about the importance of having a current AGEN\$FEEDBACK.DAT file, see “Ensuring a Recent FEEDBACK.DAT File”.
3. VSI recommends that you run AUTOGEN from the SAVPARAMS phase through the TESTFILES phase weekly thereafter until the system stabilizes (that is, until AUTOGEN finds nothing that needs to be adjusted). Make sure you run AUTOGEN when your system is running under a typical workload. Examine AGEN\$PARAMS.REPORT to determine the need for additional changes.

### Important

If you start AUTOGEN without specifying the execution-mode parameter (FEEDBACK, NOFEEDBACK, or CHECK\_FEEDBACK), AUTOGEN uses the feedback information in

## After Installing or Upgrading OpenVMS

its calculations. However, if the feedback information reflects system up time of less than 24 hours, or if the feedback information is more than 30 days old, AUTOGEN includes warnings in the AGEN\$PARAMS.REPORT file to alert you to potential problems with the feedback data. If you wrongly assume the feedback is valid, the parameter settings might vary significantly from your expectations.

If you specify FEEDBACK (or NOFEEDBACK), AUTOGEN uses (or does not use) the feedback regardless of the data's reliability. AUTOGEN proceeds through the SETPARAMS phase (if you specified SETPARAMS, SHUTDOWN, or REBOOT as the end phase) and sets system parameters to the values it computed.

If you specify CHECK\_FEEDBACK, AUTOGEN checks the validity of the feedback data. If AUTOGEN determines the feedback is suspect, then AUTOGEN ignores the feedback when computing parameter values. It stops at the TESTFILES phase and issues a warning in the report that parameters have not been changed. You must read the report and decide whether the calculated values are acceptable. You can either use them (by running the AUTOGEN SETPARAMS phase) or rerun AUTOGEN with valid feedback data.

4. After the system has stabilized, VSI recommends that you run AUTOGEN at least monthly to save feedback information for future use. Use the following command:

```
$ @SYS$UPDATE:AUTOGEN SAVPARAMS
```

If you do not maintain current feedback information for AUTOGEN, you will not have the needed information the next time you upgrade your system. As a result, you may have to reboot and rerun AUTOGEN several times to make your upgraded system operational.

For more information about running AUTOGEN, see the *OpenVMS System Manager's Manual, Volume 2: Tuning, Monitoring, and Complex Systems*.

## Rebooting After AUTOGEN

After AUTOGEN finishes, the system automatically shuts down and displays messages similar to the following:

```
The system will automatically reboot after the shutdown and the
installation will be complete.
```

```
SHUTDOWN -- Perform an Orderly System Shutdown
           on node I64CSI
```

```
%SHUTDOWN-I-BOOTCHECK, performing reboot consistency check...
%SHUTDOWN-I-CHECKOK, basic reboot consistency check completed
.
.
.
```

After a shut down, OpenVMS reboots automatically if you have set the system disk boot option accordingly; otherwise, you must boot the system manually, as described in “Booting the newly installed VSI OpenVMS System Disk”.

When the system reboots, it displays informational messages and accounting information indicating that your OpenVMS operating system has finished booting and is now ready for use. For example:

```
%SET-I-INTSET, login interactive limit = 64, current interactive value = 0
SYSTEM      job terminated at 12-MAR-2015 14:51:23.47
Accounting information:
Buffered I/O count:          2177      Peak working set size:      6848
```

After Installing or  
Upgrading OpenVMS

Direct I/O count:	1358	Peak page file size:	179552
Page faults:	1805	Mounted volumes:	0
Charged CPU time:	0 00:00:13.37	Elapsed time:	0 00:01:06.20

## Joining an OpenVMS Cluster

At installation, you are prompted to determine if the node will join an OpenVMS cluster. If you answered as No, and if the node will not be a cluster member, you can skip to “Running AUTOGEN”.

If you answered NO to the question about joining an OpenVMS Cluster, but you do intend to add this node to a new or existing OpenVMS Cluster, you can do so only after the system has rebooted (at the end of this phase of the installation). You must manually run the cluster configuration utility.

You can do this by entering the following command:

```
$ @SYS$MANAGER:CLUSTER_CONFIG_LAN
```

For more information about cluster configuration, see the *HP and VSI OpenVMS Cluster Systems* manual or the *Guidelines for OpenVMS Cluster Configurations* manual.

If you answered YES to the question about joining an OpenVMS Cluster, the system now prompts you for information about your configuration. The following table lists the OpenVMS Cluster prompts and suggested responses. These prompts appear if you answered YES to the question about joining an OpenVMS Cluster or if you manually execute SYS\$MANAGER:CLUSTER\_CONFIG\_LAN.COM. Note that, depending on your responses and the particular cluster configuration, some prompts are not displayed.

**Table 8.2. Prompts for OpenVMS Cluster Configurations**

QUESTION	RESPONSE
Will this node be a cluster member (Y/N)?	Enter Y.
What is the node's DECnet node name?	Enter the DECnet node name (for example, MYNODE). The DECnet node name can be from one to six alphanumeric characters in length and cannot include dollar signs (\$) or underscores (_). This is the name you specified in step 12 of the installation procedure.
What is the node's DECnet node address?	Enter the DECnet node address; for example, 2.2. This is the address you specified in step 13 of the installation procedure.
Enter this cluster's group number: <sup>a</sup>	Enter a number in the range of 1 to 4095 or 61440 to 65535.
Enter this cluster's password: <sup>a</sup>	Enter the cluster password. The password must be from 1 to 31 alphanumeric characters in length and can include dollar signs (\$) and underscores (_).
Reenter this cluster's password for verification:	Reenter the password.
Will MYNODE be a disk server (Y/N)?	Enter Y if you want local disks to be served to the cluster (mandatory for local area and mixed-interconnect configurations). See the <i>HP and VSI OpenVMS Cluster Systems</i> manual for information about served cluster disks.
Enter a value for MYNODE's ALLOCLASS parameter.	In an OpenVMS Cluster environment, the allocation class value cannot be zero if volume shadowing will be used on this system. The ALLOCLASS value must be a number from 1 to 255.  VSI recommends that you thoroughly review the chapter on cluster storage devices in the <i>HP and VSI OpenVMS Cluster Systems</i> manual.

QUESTION	RESPONSE
Does this cluster contain a quorum disk (Y/N)?	This manual also includes the rules for specifying allocation class values.  For SCSI, local area, and mixed-interconnect configurations, enter Y or N, depending on your configuration. If you enter Y, the system asks for the name of the quorum disk. Enter the device name of the quorum disk. For information about quorum disks, see the <i>HP and VSI OpenVMS Cluster Systems</i> manual.

<sup>a</sup>Cluster group number and password are required by any cluster nodes that use the local area network. In a cluster that uses mixed interconnects, if any of the interconnects require the cluster number and password, then you must set the cluster number and password for all nodes.

## Backing Up Your System Disk

Unless your newly installed or upgraded system disk will be part of a shadow set, it is recommended that you back up the system disk before performing the tasks described in this chapter. If you encounter problems while performing any of these tasks, having a backup copy of the system disk ensures that you can restore it to a known condition without having to repeat the installation or upgrade.

If your system disk will be part of a multiple-member shadow set, then a backup is not necessary. Either form or re-form the shadow set, as described in “Forming the Shadow Set”; this creates a backup copy of the newly installed or upgraded system disk through the shadow copy operation. Remember to dismount any added shadow set members after the shadow copy has completed, complete any steps described in this chapter that you need to perform and, when you are finished, re-form the shadow set.

If your newly installed or upgraded system disk will not be in a shadow set, back up the system disk by performing the following steps. (For a newly installed system disk, it might be just as easy to reinstall the operating system.)

1. Shut down the system (as described in “Shutting Down the System”).
2. Boot the operating system media, as described in “Booting the VSI OpenVMS Distribution Media”.
3. Use the OpenVMS operating system menu to enter the DCL environment (option 8).
4. Mount the system device and the target device on which you are making the backup copy. (If you are backing up to tape, skip to the next step.) For example, if your system disk is on DKA0: and the target device is on DKA100:, you might use the following commands (colons are required). The /OVERRIDE qualifier used in this example enables you to mount the system disk without entering its volume label. The /FOREIGN qualifier is required for the target disk when you use the BACKUP /IMAGE command.

```
$$$ MOUNT /OVERRIDE=IDENTIFICATION DKA0:  
$$$ MOUNT /FOREIGN DKA100:  
$$$ BACKUP /IMAGE /LOG DKA0: DKA100:
```

The /IMAGE qualifier causes the Backup utility to produce a functionally equivalent copy of the system disk, which is also bootable. The /LOG qualifier causes the procedure to display the specification of each save set file being processed. To compare the backed up files to the source files, use the /VERIFY qualifier. If any discrepancies are detected, the Backup utility displays an error message.

5. To back up the system disk to a magnetic tape, enter the following commands, where MTA0: is the magnetic tape drive and *label* is the volume label. Note that the BACKUP command automatically mounts the tape and begins the backup to it.

```
$$$ INITIALIZE MTA0: label
```

## After Installing or Upgrading OpenVMS

```
$$$ MOUNT /OVERRIDE=IDENTIFICATION DKA0:  
$$$ BACKUP /IMAGE /LOG DKA0: MTA0:label.BCK
```

6. Log out from the DCL environment.
7. Shut down the system by selecting option 9 on the menu.
8. Boot from the disk on which you either upgraded or installed OpenVMS.

In addition to backing up the system disk now before you customize it, you should back up your system disk again after you successfully complete your customization tasks and install layered products.

For more complete information about backup operations, including a description of an alternative method that does not require booting from the operating system media and that enables you to back up a shadowed disk without disabling the shadow set, see “*Backing Up and Restoring the System Disk*”. For more information about the Backup utility, see the *OpenVMS System Management Utilities Reference Manual: A-L*.

## Registering Your Licenses

If you did not register your OpenVMS licenses during the installation, you must do so before you can use the OpenVMS operating system. You must also register the licenses for OpenVMS layered products. If your operating system came preinstalled, you must register licenses. The licenses are not preinstalled. If you plan to form a volume shadow set for your newly installed system disk, you must enter and load the VOLSHAD license.

If you have upgraded your operating system, register any new OpenVMS or layered product licenses. For VSI OpenVMS systems, a single OE license grants the right to use all the components bundled in the purchased OE. Each OE is offered with Per Core Licenses (PCLs).

For information about registering licenses, see the following documents:

- *OpenVMS License Management Utility Manual*
- *VSI OpenVMS Version 8.4-IH1 Release Notes*
- *Operating Environments for OpenVMS for HP Integrity Servers Software Product Description (SPD 82.34.xx)*.

To register licenses, use the OpenVMS License utility as follows:

1. Start the OpenVMS License utility by entering the following command at the OpenVMS system prompt. (You can also use the LICENSE REGISTER command.)

```
$ @SYS$UPDATE:VMSLICENSE
```

2. The utility displays a menu screen similar to the following. Select the REGISTER option (press **Enter** or enter 1 at the prompt), and enter each license key until you have successfully registered all required PAKs.

VMS License Management Utility Options:

1. REGISTER a Product Authorization Key
2. AMEND an existing Product Authorization Key
3. CANCEL an existing Product Authorization Key
4. LIST Product Authorization Keys
5. MODIFY an existing Product Authorization Key
6. DISABLE an existing Product Authorization Key
7. DELETE an existing Product Authorization Key

## After Installing or Upgrading OpenVMS

8. COPY an existing Product Authorization Key
9. MOVE an existing Product Authorization Key
10. ENABLE an existing Product Authorization Key
11. SHOW the licenses loaded on this node
12. SHOW the unit requirements for this node

99. Exit this procedure

Type '?' at any prompt for a description of the information requested. Press Ctrl/Z at any prompt to return to this menu.

Enter one of the above choices [1]

3. After each license is successfully registered, the procedure asks whether the license should be loaded. Answer YES.
4. After you have registered and loaded all your licenses, exit the License Management procedure by entering option 99.

## Set System Parameters for Volume Shadowing (Optional)

If you plan to form a shadowed system disk, you must add system parameters to the SYSS\$SYSTEM:MODPARAMS.DAT file. Add the following lines to the bottom of the MODPARAMS.DAT file:

```
SHADOWING=2           !Enable volume shadowing
SHADOW_SYS_DISK=1     !Enable shadowing of the system disk
SHADOW_SYS_UNIT=n     !Optional: default is 0, which creates DSA0
SHADOW_MAX_COPY=4     !Allow up to 4 shadow copies or merges going on at the same time
ALLOCLASS=x           !This number must be non-zero;
                       !it must be used if local non-FC devices are going to be
                       !shadow set members
```

If a non-zero ALLOCLASS value is already assigned to your system, do not change the ALLOCLASS value. For more information about these and other system parameters you can set for volume shadowing, see the *Volume Shadowing for OpenVMS* manual. For more information about setting ALLOCLASS for clusters, see the *HP and VSI OpenVMS Cluster Systems* manual.

If you modified MODPARAMS.DAT to enable or modify shadowing parameters (see “Set System Parameters for Volume Shadowing (Optional)”), then run AUTOGEN and reboot the system by performing the following steps to make the changes take effect.

1. Run AUTOGEN by entering the following command:

```
$ @SYS$UPDATE:AUTOGEN GETDATA TESTFILES NOFEEDBACK
```

2. After AUTOGEN completes, display or print the SYSS\$SYSTEM:AGEN\$PARAMS.REPORT file and review it. This file lists changes being made to SYSGEN parameters or changes that AUTOGEN wanted to make but could not because of a hardcoded or maximum value that was specified in MODPARAMS.DAT.
3. If other changes need to be made to MODPARAMS.DAT based on a review of the AGEN\$PARAMS.REPORT file, make them now and then resume at step 1.
4. Once you are satisfied with the parameter settings, enter the following AUTOGEN command:

```
$ @SYS$UPDATE:AUTOGEN GENPARAMS SETPARAMS NOFEEDBACK
```

## After Installing or Upgrading OpenVMS

This command makes the parameter changes permanent so that they are used on subsequent reboots.

5. Reboot the system by entering the following command:

```
$ @SYS$SYSTEM:SHUTDOWN
```

For more information about AUTOGEN, see *OpenVMS System Management Utilities Reference Manual: A-L*.

## Forming the Shadow Set

If you have upgraded a disk in a volume shadowing environment, you must now re-form the shadow set. If you want to form a shadow set for a newly installed system disk, you can do this now or later. To do so requires that the VOLSHAD license has been entered and loaded. In addition, you must set several system parameters, as explained in “Set System Parameters for Volume Shadowing (Optional)”, and then you must run AUTOGEN and reboot the system, as explained in “Running AUTOGEN”.

Forming the shadow set with the newly installed or upgraded disk as the master causes the other disks in the shadow set to be updated with a copy of the disk. (In a single-member shadow set, although no other disks exist to be updated, the shadow set can be used to facilitate replacement of a failed drive.)

After forming the shadow set, dismount one of the shadow set members and keep it as a backup. After you perform the steps recommended in this chapter, you can place another volume into the shadow set instead of doing the final backup, or re-add the volume that was dismounted.

Form the shadow set as follows:

1. Enter the SHOW DEVICE D command to display a list of disks available on your system. For example:

```
$ SHOW DEVICE D
Device          Device      Error   Volume      Free  Trans  Mnt
Name            Status      Count   Label        Blocks Count Cnt
$11$DKB100:    (NODE1)   Online     0              0      0
$11$DKB200:    (NODE1)   Mounted    I64084    918150    1  31
```

2. Enter a command in the following format:

```
MOUNT/CONFIRM/SYSTEM DSA $n$ : /SHADOW=(upgraded-disk:new-member):  
volume-label
```

where:

- *DSA $n$* : is the virtual unit name of the shadow set, where  $n$  is a unique number from 0 to 999.
- *upgraded-disk*: is the name of the shadowed system disk on which you just upgraded or installed OpenVMS.
- *new-member*: is the name of the disk you want to add as a member of the shadow set.
- *volume-label* is the volume label of the shadow set you just upgraded or the disk you are creating.

### Note

When you form the shadow set, the contents of the new member are replaced by the contents of the disk you upgraded. Specifying the /CONFIRM qualifier reminds you of this fact,

## After Installing or Upgrading OpenVMS

confirming that you are specifying the correct name of a disk that either is blank or contains files you no longer need.

### Example

```
$ MOUNT/CONFIRM/SYSTEM DSA54: /SHADOW=($11$DKB200:,$11$DKB100:) I64084

%MOUNT-F-SHDWCOPYREQ, shadow copy required
Virtual Unit - DSA54 Volume label I64A084
  Member                Volume label Owner UIC
  $11$DKB100: (NODE1)   SCRATCH   [100,100]
Allow FULL shadow copy on the above member(s)? [N]: YES
```

### Note

Before continuing with the next step in this chapter, after the shadow copy completes, dismount one of the shadow set members to use as a backup. Normally, this should be the unit you just added to the upgraded volume when you formed the shadow set (in the preceding example, \$11\$DKB100:).

To add a shadowed system disk in a multiple-member shadow set to the EFI boot device list and dump device list, VSI recommends using the OpenVMS Boot Manager utility (SYS \$MANAGER:BOOT\_OPTIONS.COM). Be sure to add all members to both lists.

## Customizing the System (New Installations, Some Upgrades)

You can customize the system to meet your site-specific needs. In addition, if your system is part of an OpenVMS Cluster environment, you must prepare the cluster environment and configure the cluster. The following subsections describe the customization tasks you can perform at this time. In general, these tasks apply to new installations only; however, in some cases, they apply to upgrades. The tasks are as follows:

1. Create network proxy authorization files (“Creating Network Proxy Authorization Files”).
2. Set up the queue manager, configure shared files (when multiple system disks are present), and start the default batch and print queues (“Setting Up the Queue Manager and Default Queues”).
3. Configure your multihead system, if applicable (“Configuring a Multihead System (Optional)”).
4. Configure DECnet if it was installed or added during an upgrade (“Configuring DECnet”).
5. Configure TCP/IP Services for OpenVMS if it was installed or added during an upgrade (“Configuring TCP/IP Services for OpenVMS”).
6. If neither DECnet nor TCP/IP Services for OpenVMS is being used, install and configure third-party networking software, if necessary (“Installing and Configuring Third-Party Networking Software”).
7. Update SYSTARTUP\_VMS.COM to have networking software (and, optionally, any other additional products you have installed) start at boot (“Updating SYSTARTUP\_VMS.COM to Start Layered Products and Print Queues”).

For instructions on customizing the system, review the following documentation:

- The release notes, for notes and restrictions that might be relevant to your customization plans

## After Installing or Upgrading OpenVMS

- The *OpenVMS System Manager's Manual*, for instructions on customizing and using your system

Note that other customization tasks are described later in this chapter.

## Creating Network Proxy Authorization Files

After a new installation of OpenVMS that includes DECnet, or after an upgrade in which you have added DECnet, create your network proxy authorization files. These files include security authorization information for users using network proxy accounts. If you do not create these network authorization files before starting up your system, you might see messages such as the following during startup:

```
Message from user SYSTEM on HOMER
%SECSRV-E-NOPROXYDB, cannot find proxy database file NET$PROXY.DAT
%RMS-E-FNF, file not found
```

The NET\$PROXY.DAT file is the primary network proxy authorization file. The other network authorization file to be created is NETPROXY.DAT. To create the network proxy authorization files, enter the following commands:

```
$ SET DEFAULT SYS$COMMON: [SYSEXE]
$ MC AUTHORIZE CREATE/PROXY
$ SET DEFAULT SYS$LOGIN
```

### Note

Be sure you create the network proxy authorization files before starting the queue manager (as described in “Setting Up the Queue Manager and Default Queues”).

If you see messages similar to the following when you create the proxy files, you can ignore them:

```
%UAF-W-NETCHANERR, error assigning a channel to NET:
-SYSTEM-W-NOSUCHDEV, no such device available
```

For more information about network proxy accounts and files, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*. For more information about the Authorize utility, see the *OpenVMS System Management Utilities Reference Manual: A-L*.

## Setting Up the Queue Manager and Default Queues

The initial installation of OpenVMS does not create the queue manager or any queues. VSI recommends that you create the queue manager and your default batch and print queues now. When you install layered products (as described in “Installing and Configuring Layered Products”), some of these products expect such queues to be present or try to create queues themselves.

### Note

Normally, you create a queue manager only once. The system stores the START QUEUE command in the queue database to enable the queue manager to start automatically whenever the system reboots. If the queue manager has been started before on your system, do not specify this START QUEUE command again; the /NEW\_VERSION qualifier causes your system to overwrite your current queue database files.

To configure shared files on multiple system disks or off the system disk, edit the SYS\$MANAGER:SYLOGICALS.COM file as described in *OpenVMS System Manager's Manual, Volume 1: Essentials*.

To set up the queue manager and a batch queue for new installations, enter the following commands at the DCL prompt.

## After Installing or Upgrading OpenVMS

```
$ START QUEUE /MANAGER /NEW_VERSION  
$ INITIALIZE /QUEUE /START /BATCH SYS$BATCH
```

### Note

If you did an upgrade of the operating system, do not specify the START QUEUE command with the /NEW\_VERSION qualifier.)

As noted, the queue manager starts automatically the next time you boot your OpenVMS system. To have the SYS\$BATCH queue start automatically, edit the line in the SYS\$STARTUP:SYSTARTUP\_VMS.COM file that starts the SYS\$BATCH queue by removing the exclamation mark (!) and, if present, the extra dollar sign (\$). The following example shows the line before and after editing. In that section, you can also define a default system print queue (SYS\$PRINT).

Before:            \$!\$ START /QUEUE SYS\$BATCH

After:            \$ START /QUEUE SYS\$BATCH

For more information about starting and creating queues, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*.

## Configuring DECnet

If you installed DECnet, or if you added DECnet during an upgrade, you must now configure DECnet. Follow the instructions provided for the version of DECnet you installed. The DECnet End System License is included with the Base Operating Environment (BOE). If you want your system to take advantage of the advanced features of DECnet (such as routing, DTSS server, DNS server), you must register and install the DECnet-Plus Extended Function License.

To load and register licenses, perform the steps described in “Registering Your Licenses”.

If you installed DECnet-Plus for OpenVMS software, see the *DECnet-Plus for OpenVMS Release Notes* and the *DECnet-Plus for OpenVMS Installation and Configuration* manual for information about how to configure this software using the NET\$CONFIGURE procedure.

If you installed DECnet Phase IV, see the *DECnet for OpenVMS Guide to Networking* manual for information about configuring this software using the NETCONFIG command procedure.

Once you have configured DECnet Phase IV, edit SYS\$COMMON:[SYSMGR]SYSTARTUP\_VMS.COM so that the software starts when the system reboots. (This step is not required if you are running DECnet-Plus.) You can have the software start interactively or in batch mode by making one of the following changes:

Locate and uncomment the line:

```
$!$ START/NETWORK DECNET
```

So it now appears as:

```
$ START/NETWORK DECNET
```

To start the network in a batch job (speeds up startup) locate and uncomment the line:

```
$!$ SUBMIT SYS$MANAGER:STARTNET.COM
```

So it now appears as:

```
$ SUBMIT SYS$MANAGER:STARTNET.COM
```

## Important

If you intend to run both DECnet Phase IV and a TCP product, DECnet must start first. In this case, VSI recommends starting DECnet using interactive mode.

For information about editing STARTUP-VMS.COM, see “Updating SYSTARTUP\_VMS.COM to Start Layered Products and Print Queues”.

## Configuring TCP/IP Services for OpenVMS

If you plan to run TCP/IP Services for OpenVMS software, note the following:

- Configure your system for networking by executing the interactive command procedure SYS\$MANAGER:TCPIP\$CONFIG.COM. Be sure to consult the *TCP/IP Services for OpenVMS Installation and Configuration* manual for specifics about configuring TCP/IP Services for OpenVMS and for configuring IPv6 support.
- After completing the configuration, edit the command pertaining to TCP/IP Services for OpenVMS in SYS\$COMMON:[SYSMGR]SYSTARTUP\_VMS.COM (as instructed in “Updating SYSTARTUP\_VMS.COM to Start Layered Products and Print Queues”) so that the TCP/IP Services software starts automatically when your system is rebooted.

## Important

Do not configure TCP/IP Services for OpenVMS without first starting the queue manager.

## Installing and Configuring Third-Party Networking Software

You need networking software to download patches and as a requirement for certain layered products. If you are using neither DECnet nor TCP/IP Services for OpenVMS, you should install and configure third-party networking software now. See the appropriate vendor’s product documentation.

## Configuring a Multihead System (Optional)

A multihead configuration consists of a single system that supports multiple graphics options. A graphics option consists of a graphics controller (card) and a graphics display interface (monitor).

Your system can be configured automatically for multihead use if you copy the private server setup template file to a command procedure file type (.COM). The DECwindows Motif server loads this command procedure on startup or restart.

To set up your system for multihead support, perform these steps:

### Note

The DECwindows Motif software must already be installed on the system prior to completing this procedure. If DECwindows is not installed, you must install the software, load the license and reboot the system prior to completing this procedure.

1. Copy the private server setup template file to a new .COM file by entering the following command:

```
$ COPY SYS$MANAGER:DECW$PRIVATE_SERVER_SETUP.TEMPLATE  
_To: SYS$MANAGER:DECW$PRIVATE_SERVER_SETUP.COM
```

2. Restart the DECwindows server by entering the following command:

```
$ @SYS$STARTUP:DECW$STARTUP RESTART
```

## After Installing or Upgrading OpenVMS

For more information about customizing your DECwindows environment using the SYS\$MANAGER:DECW\$PRIVATE\_SERVER\_SETUP.COM file, see the most recent version of the *DECwindows Motif for OpenVMS Installation Guide* and *Managing DECwindows Motif for OpenVMS Systems*.

# Initializing CDSA (Optional)

The Common Data Security Architecture (CDSA) software is installed, configured, and initialized automatically with the operating system installation or upgrade. CDSA is required for Secure Delivery purposes and other security features; otherwise, use of CDSA is not required.

Note that if you installed a new CDSA kit without upgrading the base operating system, you must enter the following command to initialize CDSA prior to its first use. Enter the command from an account that has both SYSPRV and CMKRNL privileges (for example, the SYSTEM account).

```
$ @SYS$STARTUP:CDSA$UPGRADE
```

The following is an example of the output you might see:

```
Module uninstalled successfully.
```

```
CDSA-I-Init, CDSA has previously been initialized on this system.  
CDSA-I-Init, Re-initializing CDSA.
```

```
CDSA-I-Init, Initializing CDSA  
MDS installed successfully.
```

```
.  
.
```

```
CDSA-I-Init, CDSA Initialization complete  
CDSA-I-Init, Initializing Secure Delivery  
Install completed successfully.  
Install completed successfully.  
Module installed successfully.  
Module installed successfully.  
CDSA-I-Init, Secure Delivery Initialization complete
```

## Note

Do not attempt to explicitly remove CDSA from your system. The PRODUCT REMOVE command is not supported for CDSA although there appears to be an option to remove CDSA. CDSA is installed with the operating system and is tightly bound with it. Attempts to remove it might not work as expected and can create undesirable side effects. An attempt to remove it results in a message similar to the following:

```
%PCSI-E-HRDREF, product VSI I64VMS CDSA V2.3 is referenced by  
VSI I64VMS OpenVMS V8.4-1H1
```

The two products listed above are tightly bound by a software dependency. If you override the recommendation to terminate the operation, the referenced product will be removed, but the referencing product will have an unsatisfied software dependency and may no longer function correctly. Please review the referencing product's documentation on requirements.

Answer YES to the following question to terminate the PRODUCT command. However, if you are sure you want to remove the referenced product then answer NO to continue the operation.

```
Terminating is strongly recommended. Do you want to terminate? [YES]
```

For more information about CDSA, see *Open Source Security for OpenVMS, Volume 1: Common Data Security Architecture*.

## Configuring the Availability Manager Base Software (Optional)

The Availability Manager base kit is installed automatically with the operating system; however, use of Availability Manager is not required. If you do not plan to use Availability Manager or any products that depend on it, skip to the next section.

The files in the Availability Manager base kit make up what is called the Data Collector. The Data Collector is used to collect data for the Availability Manager product. To display the data, you need to install an Availability Manager Data Analyzer kit on an OpenVMS or Microsoft Windows™ node in the local LAN. The kit is included in the OpenVMS upgrade media, or you can obtain it from the following website:

<http://www.hp.com/products/OpenVMS/availabilitymanager>

For more information refer to the (*Availability Manager Installation Instructions*). This and other Availability Manager documents are available at the website mentioned previously. Update documents will be available from the VSI website soon.

### Warning

Do not attempt to explicitly remove the Availability Manager from your system. The PRODUCT REMOVE command is not supported for Availability Manager although there appears to be an option to remove Availability Manager. The Availability Manager base software is installed with the operating system and is tightly bound with it. Attempts to remove it might not work as expected and can create undesirable side effects.

## Configuring Kerberos (Optional)

The Kerberos for OpenVMS software, which is based on MIT Kerberos, is installed automatically with the operating system; however, use of Kerberos is not required. If you do not plan to use Kerberos or any products that depend on Kerberos, skip to the next section.

To configure Kerberos, perform the following steps from a privileged OpenVMS user account (for example, SYSTEM).

1. Run the following command procedure to configure the Kerberos clients and servers:

```
$ @SYS$STARTUP:KRB$CONFIGURE.COM
```

2. Add the following line to your SYLOGIN command procedure or to the LOGIN.COM of each user who will use Kerberos:

```
$ @SYS$MANAGER:KRB$SYMBOLS
```

3. Edit SYSS\$MANAGER:SYSTARTUP\_VMS.COM to remove the exclamation point from the KRB\$STARTUP.COM line so that it appears as shown in the following example. (Note that SYSTARTUP\_VMS.COM has TCP/IP Services for OpenVMS starting before Kerberos. This is required.)

```
$ @SYS$STARTUP:KRB$STARTUP.COM
```

For additional setup and configuration information, see the *Open Source Security for OpenVMS, Volume 3: Kerberos* manual. This document contains links to the MIT Kerberos documentation and is available from the OpenVMS Version 8.4-1H1 kit.

## Note

Do not attempt to explicitly remove Kerberos from your system. The PRODUCT REMOVE command is not supported for Kerberos although there appears to be an option to remove Kerberos. Kerberos is installed with the operating system and is tightly bound with it. Attempts to remove it might not work as expected and can create undesirable side effects. An attempt to remove it results in a message similar to the following:

```
%PCSI-E-HRDREF, product VSI I64VMS Kerberos V3.1 is referenced by VSI I64VMS  
OpenVMS V8.4-1H1
```

The two products listed above are tightly bound by a software dependency. If you override the recommendation to terminate the operation, the referenced product will be removed, but the referencing product will have an unsatisfied software dependency and may no longer function correctly. Please review the referencing product's documentation on requirements.

Answer YES to the following question to terminate the PRODUCT command. However, if you are sure you want to remove the referenced product then answer NO to continue the operation.

Terminating is strongly recommended. Do you want to terminate? [YES]

## Configuring SSL for OpenVMS (Optional)

The VSI SSL for OpenVMS software is installed automatically with the operating system; however, use of SSL is not required. If you do not plan to use SSL or any products that depend on it, skip to the next section.

The SSL\$STARTUP.COM command procedure has been added to VM\$LPBEGIN-050 to enable SSL to start automatically.

Add the following line to SY\$MANAGER:SY\$SHUTDOWN.COM:

```
$ @SYS$STARTUP:SSL$SHUTDOWN.COM
```

If you are upgrading and have an earlier version of SSL installed, copy your SSL \$STARTUP.TEMPLATE file (located in SY\$STARTUP) to SSL\$STARTUP.COM in the SY\$STARTUP directory.

Several other post-installation and post-upgrade tasks are required, as described in the SSL release notes, available in SY\$HELP:SSL $nnn$ .RELEASE\_NOTES, where  $nnn$  is the version of the SSL software, such as 013.

For more information about SSL, see *Open Source Security for OpenVMS, Volume 2: HP SSL for OpenVMS*.

## Note

Do not attempt to explicitly remove SSL from your system. The PRODUCT REMOVE command is not supported for SSL although there appears to be an option to remove SSL. SSL is installed with the operating system and is tightly bound with it. Attempts to remove it might not work as expected and can create undesirable side effects. An attempt to remove it results in a message similar to the following:

```
%PCSI-E-HRDREF, product VSI I64VMS SSL V1.4 is referenced by VSI I64VMS Open
```

The two products listed above are tightly bound by a software dependency. If you override the recommendation to terminate the operation, the

## After Installing or Upgrading OpenVMS

referenced product will be removed, but the referencing product will have an unsatisfied software dependency and may no longer function correctly. Please review the referencing product's documentation on requirements.

Answer YES to the following question to terminate the PRODUCT command. However, if you are sure you want to remove the referenced product then answer NO to continue the operation.

Terminating is strongly recommended. Do you want to terminate? [YES]

# Configuring WBEM Services for OpenVMS (Optional)

WBEM Services for OpenVMS is installed automatically with OpenVMS installation. As with other similar products, an OpenVMS upgrade does not automatically include WBEM Services for OpenVMS if it is not already installed on the target system disk. In this case, you must install the product separately using the PCSI PRODUCT INSTALL command. If you do not plan to use WBEM Services for OpenVMS or any products that depend on it, simply do not configure the software; if you have already configured the software, you can choose not to start it.

You must configure WBEM Services for OpenVMS to obtain the services provided by HP SIM (Version 5.2 or later) and products such as HP Instant Capacity and HP gWLM. To provide services over the network, both TCP/IP Services for OpenVMS and SSL (for security purposes) are required and must be configured and running. (For information about configuring TCP/IP Services for OpenVMS, see "Configuring TCP/IP Services for OpenVMS".

To configure WBEM Services for OpenVMS on a system on which WBEM Services for OpenVMS has never been installed and configured, follow the steps described in "Configuring WBEM Services for OpenVMS (Where Not Configured Previously)". If you are configuring the product on a system on which it has been configured previously, see "Configuring WBEM Services for OpenVMS (Where Configured Previously)".

For more information about HP WBEM products, see the following website:

<http://www.hp.com/go/wbem>

## Note

VSI recommends that you do not remove the WBEM Services for OpenVMS product even if you do not have a need for it. If you attempt to use the PRODUCT REMOVE command to remove this product, you might see a message similar to the following. This message is automatically displayed for any product that is required with OpenVMS. The consequences of removing WBEM Services for OpenVMS might not be as severe as implied by the message unless other software is using the product on your server.

```
%PCSI-E-HRDREF, product VSI I64VMS WBEMCIM V2.91 is referenced by VSI I64VMS
```

The two products listed above are tightly bound by a software dependency. If you override the recommendation to terminate the operation, the referenced product will be removed, but the referencing product will have an unsatisfied software dependency and may no longer function correctly. Please review the referencing product's documentation on requirements.

Answer YES to the following question to terminate the PRODUCT command. However, if you are sure you want to remove the referenced product then answer NO to continue the operation.

Terminating is strongly recommended. Do you want to terminate? [YES]

## Configuring WBEM Services for OpenVMS (Where Not Configured Previously)

To configure WBEM Services for OpenVMS on a system for the first time, follow these steps:

1. Enter the following command

```
$ RUN SYS$SYSROOT:[WBEM_SERVICES]WBEM_SERVICES$CONFIG
```

This command invokes the utility that configures and initializes the environment for WBEM Services for OpenVMS.

2. After displaying the initial configuration utility banner, the utility informs you where it will store the configuration files and repository and asks if you want to change the location.

```
The configuration files and repository will be placed in the following location  
SYS$SPECIFIC:[WBEM_Services].
```

```
Do you want to change this location (Yes/No) [No]?:
```

### Note

The repository, a compiled version of the Common Information Model (CIM) class schema, requires an ODS-5 formatted disk (the repository uses UNIX-style file names, which are not supported on ODS-2 formatted disks). If the default location is on an ODS-2 formatted disk, you must change the location to an ODS-5 disk.

When you accept the default location, the utility informs you that all configuration questions have been answered and asks whether you want to continue, as shown in the following example. If you choose to continue, the utility creates the CIMServer repository tree in the location indicated earlier. The CIMServer is the WBEM Services for OpenVMS process that runs on the system to support certain applications. It also creates the following command files:

```
SY$STARTUP:WBEM_Services$Startup.com  
SY$STARTUP:WBEM_Services$Shutdown.com  
SYS$SYSROOT:[WBEM_SERVICES]WBEM_Services$Define_Commands.com
```

The SY\$STARTUP:WBEM\_Services\$Startup.com file defines system logicals for the WBEM Services for OpenVMS environment.

```
All configuration questions have been answered.
```

```
Do you want to continue (Yes/No) [YES]?:
```

```
%WBEMCONFIG-I-CREREPBEGIN, Create Repository Begins...  
%WBEMCONFIG-I-CREREPCOMPLETE, Create Repository Complete.
```

```
This utility creates:
```

```
SY$STARTUP:WBEM_Services$Startup.com
```

```
which should be added to SY$STARTUP:SYSTARTUP_VMS.COM.
```

```
This utility creates:
```

```
SY$STARTUP:WBEM_Services$Shutdown.com
```

```
which should be added to SY$STARTUP:SYSHUTDWN.COM.
```

```
This utility creates:
```

```
SYS$SYSROOT:[wbem_services]WBEM_Services$Define_Commands.com
```

```
which users who use this product can add to their login.com.
```

3. The utility asks whether to start the CIMServer:

## After Installing or Upgrading OpenVMS

Do you want to start the CIMServer now (Yes/No) [Yes]?:

CIMServer must be running so that your system can use such applications as HP Instant Capacity and HP gWLM. You can start CIMServer now, or you can perform other postinstallation or postupgrade tasks first and then start CIMServer. If you choose to start CIMServer now, the utility displays the progress and operating system information, as in the following example:

```
%RUN-S-PROC_ID, identification of created process is 21A00599
%WBEMCIM-I-STARTUPWAIT, Waiting for CIMServer to start... 120 seconds remain
%WBEMCIM-S-CSSTARTED, CIMServer successfully started.
OperatingSystem Information
Host: vmssoftware.com
Name: OpenVMS
Version: V8.4-1H1
UserLicense: Unlimited user license
Number of Users: 1 users
Number of Processes: 29 processes
OSCapability: 64 bit
LastBootTime: Jan 1, 2015 10:52:55 (-0400)
LocalDateTime: Jan 3, 2015 10:14:58 (-0400)
SystemUpTime: 256923 seconds = 2 days, 23 hrs, 22 mins, 3 secs
%RUN-S-PROC_ID, identification of created process is 21A00599
```

4. To ensure that CIMServer starts automatically at each reboot, add the following line to SYS\$MANAGER:SYSTARTUP\_VMS.COM after the line that starts TCP/IP:

```
$ @SYS$STARTUP:WBEM_Services$Startup.com
```

To have CIMServer shut down automatically with the operating system, add the following line to the SYS\$MANAGER:SYSSTARTUP:SYSHUTDOWN.COM file:

```
$ @SYS$STARTUP:WBEM_Services$Shutdown.com
```

All users who use this product should also add the following line to their LOGIN.COM file:

```
$ @SYS$STARTUP:WBEM_Services$Define_Commands.com
```

5. In an OpenVMS Cluster, each member that runs WBEM Services for OpenVMS needs its own repository. Therefore, you must perform the WBEM Services for OpenVMS configuration procedure on each of those cluster members.

## Configuring WBEM Services for OpenVMS (Where Configured Previously)

To configure WBEM Services for OpenVMS on a system where it has been configured previously, follow these steps:

1. Enter the following command

```
$ RUN SYS$SYSROOT:[WBEM_SERVICES]WBEM_SERVICES$CONFIG
```

This command starts the utility that configures and initializes the environment for WBEM Services for OpenVMS.

If the WBEM Services for OpenVMS product is already configured on your system, the following error message and the recommended remedial actions appear:

```
%WBEMCONFIG-E-SYSCOMMONLOGICAL, WBEM_VAR can no longer be defined to point to
a location in SYS$COMMON. The repository files in WBEM_VAR should not be sha
```

## After Installing or Upgrading OpenVMS

with other cluster members.

Follow these manual steps to move the repository out of the SYS\$COMMON area and complete the post installation configuration tasks:

- o Delete the sys\$common:[WBEM\_Services.var...] directory tree.
- o Deassign the WBEM\_VAR system logical.
- o Run this procedure again.

Perform the recommended steps, as in the following example:

```
$ DELETE SYS$COMMON:[WBEM_SERVICES.VAR...] *.*;*
$ DELETE SYS$COMMON:[WBEM_SERVICES]VAR.DIR;*
$ DEASSIGN/SYS WBEM_VAR
$ RUN SYS$SYSROOT:[WBEM_SERVICES]WBEM_SERVICES$CONFIG
```

After you start the configuration procedure, go to “Configuring WBEM Services for OpenVMS (Where Not Configured Previously)” and follow the steps described there, starting with step 2.

2. After displaying the initial configuration utility banner, the utility informs you where it will store the configuration files and repository and asks if you want to change the location.

The configuration files and repository will be placed in the following location:  
SYS\$SPECIFIC:[WBEM\_Services].

Do you want to change this location (Yes/No) [No]?:

The repository is a compiled version of the CIM class schema. This example assumes you accept the current location.

3. As shown in the following example, the utility informs you that all configuration questions have been answered and asks whether you want to continue.

If the utility determines that the repository schema has not changed, the utility informs you and continues. The utility does not need to upgrade the repository.

If the utility determines that the current repository needs upgrading, or if the utility does not find a repository (perhaps WBEM Services for OpenVMS had been installed but not configured), the utility displays a message informing you that the repository will be upgraded or created and that this will take 10 to 15 minutes depending on your processor and disk I/O speed. In the following example, the utility needs to create the repository tree.

The utility also creates the SYS\$STARTUP:WBEM\_Services\$Startup.com, SYS\$STARTUP:WBEM\_Services\$Shutdown.com, and SYS\$SYSROOT:[WBEM\_SERVICES]WBEM\_Services\$Define\_Commands.com command files. The SYS\$STARTUP:WBEM\_Services\$Startup.com file defines system logicals for the WBEM Services for OpenVMS environment.

All configuration questions have been answered.

Do you want to continue (Yes/No) [Yes]?:

```
%WBEMCONFIG-I-CREREPBEGIN, Create Repository Begins...
%WBEMCONFIG-I-CREREPCOMPLETE, Create Repository Complete.
```

This utility creates:

```
    SYS$STARTUP:WBEM_Services$Startup.com
```

which should be added to SYS\$STARTUP:SYSTARTUP\_VMS.COM.

This utility creates:

```
    SYS$STARTUP:WBEM_Services$Shutdown.com
```

## After Installing or Upgrading OpenVMS

which should be added to `SYS$STARTUP:SYSHUTDOWN.COM`.

This utility creates:

```
SYS$SYSROOT:[wbem_services]WBEM_Services$Define_Commands.com
```

which users who use this product can add to their `login.com`.

4. The utility now asks you whether to start the CIMServer:

```
Do you want to start the CIMServer now (Y/N) {Y}?:
```

CIMServer must be running so that your system can use such applications as HP Instant Capacity and HP gWLM. You can start CIMServer now, or you can perform other postinstallation or postupgrade tasks first and then start CIMServer. If you choose to start CIMServer now, the utility displays the progress and operating system information, as in the following example:

```
%RUN-S-PROC_ID, identification of created process is 21A00599
%WBEMCIM-I-STARTUPWAIT, Waiting for CIMServer to start... 120 seconds remain
%WBEMCIM-S-CSSTARTED, CIMServer successfully started.
OperatingSystem Information
Host: bolton.vmssoftware.com
Name: OpenVMS
Version: V8.4-1H1
UserLicense: Unlimited user license
Number of Users: 1 users
Number of Processes: 29 processes
OSCapability: 64 bit
LastBootTime: Jan 1, 2015 10:52:55 (-0400)
LocalDateTime: Jan 3, 2015 10:14:58 (-0400)
SystemUpTime: 256923 seconds = 2 days, 23 hrs, 22 mins, 3 secs
%RUN-S-PROC_ID, identification of created process is 21A00599
```

5. To ensure that CIMServer starts automatically at each reboot, add the following line to the `SYS$MANAGER:SYSSTARTUP_VMS.COM` file:

```
$ @SYS$STARTUP:WBEM_Services$Startup.com
```

To have CIMServer shut down automatically with the operating system, add the following line to the `SYS$MANAGER:SYSSTARTUP:SYSHUTDOWN.COM` file:

```
$ @SYS$STARTUP:WBEM_Services$Shutdown.com
```

All users who use this product should also add the following line to their `LOGIN.COM` file:

```
$ @SYS$STARTUP:WBEM_Services$Define_Commands.com
```

6. In an OpenVMS Cluster, each member that will run WBEM Services for OpenVMS needs its own repository. Therefore, you must perform the WBEM Services for OpenVMS configuration procedure on each of those cluster members.

## Configuring WBEM Providers for OpenVMS (Optional)

WBEM Providers for OpenVMS is installed automatically with OpenVMS installation. As with other similar products, an OpenVMS upgrade does not include WBEM Providers for OpenVMS if it is not currently installed on the target system disk. In this case, you must install the product separately using the `PCSI PRODUCT INSTALL` command.

You must configure WBEM Providers for OpenVMS to obtain the services provided by HP SIM and HP GiCAP. WBEM Providers for OpenVMS requires WBEM Services for OpenVMS.

## Note

If you are using WBEM Providers for OpenVMS, and have performed an OpenVMS upgrade, you must re-configure WBEM Providers by following the steps below.

To configure WBEM Providers for OpenVMS, follow these steps:

1. If not done so already, define the WBEM Services logicals by entering the following command:

```
$ @SYS$COMMON:[WBEM_SERVICES]WBEM_Services$Define_Commands.com
```

2. Ensure that the CIM Server is running and verify the list of providers installed by entering the following command:

```
$ CIMPROVIDER -L -S
```

This displays output similar to the following:

MODULE	STATUS
OperatingSystemModule	OK
ComputerSystemModule	OK
ProcessModule	OK
IPProviderModule	OK

3. To configure the WBEM Providers for OpenVMS software, enter the following command:

```
$ @SYS$COMMON:[WBEMPROVIDERS]WBEMPROVIDERS$CONFIGURE.COM
```

You are prompted to enter the primary owner name and contact information.

```
%WBEMPROVIDERS-I-STARTING, Info:Starting WBEMPROVIDERS Configuration.  
Enter Primary Owner name of the system: system  
Enter Primary owner contact information: 25166235  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of EventIndicationConsum  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of EMSWrapperProviderMod  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of VMSLANIndicationProvi  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of StateChangeIndication  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of ChassisProviderModule  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of cpuprovidermodule...  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of MemoryModule...  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of FirmwareRevisionProvi  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of MPPProviderModule...  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of EnclosureProviderModu  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of HPHealthStateProvider  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of HPVMSLANProviderModul  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of HPVMSLANCSPProviderMod  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of CSChassisProviderModu  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of HPVMPProviderModule...  
%WBEMPROVIDERS-I-CONTINUECONFIG, Info:configuration of HP_UtilizationProvide  
%RUN-S-PROC_ID, identification of created process is 00006939  
%WBEMPROVIDERS-I-WAIT, Info:Waiting for 1 Minute for the Inventory to Initia  
%RUN-S-PROC_ID, identification of created process is 0000693F  
%RUN-S-PROC_ID, identification of created process is 00006940  
%WBEMPROVIDERS-I-PROVCONFIG, Info:Completed configuration of WBEMPROVIDERS.
```

The configuration process takes a few minutes to complete and displays output similar to the following:

```
Starting WBEMPROVIDERS Configuration. This would take around
```

## After Installing or Upgrading OpenVMS

5 minutes

Starting WBEMPROVIDERS. This would take around 2 minutes

Inventory is not ready! Waiting for 2 Minutes

%RUN-S-PROC\_ID, identification of created process is  
23800EC2

WBEMPROVIDERS configuration is completed.

This command procedure registers the WBEM Providers software with the CIM Server and copies the node specific files to SYSS\$SPECIFIC:[WBEMPROVIDERS].

4. Verify the list of providers installed and their status by entering the following command:

```
$ CIMPROVIDER -L -S
```

This displays output similar to the following:

MODULE	STATUS
OperatingSystemModule	OK
ComputerSystemModule	OK
ProcessModule	OK
IPProviderModule	OK
EventIndicationConsumerModule	OK
EMSWrapperProviderModule	OK
HPVMSLANIndicationProviderModule	OK
StateChangeIndicationProviderModule	OK
ChassisProviderModule	OK
cpuprovidermodule	OK
MemoryModule	OK
FirmwareRevisionProviderModule	OK
MPPProviderModule	OK
EnclosureProviderModule	OK
HPHealthStateProviderModule	OK
HPVMSLANProviderModule	OK
HPVMSLANCSPProviderModule	OK
CChassisProviderModule	OK
HPVMPProviderModule	OK
HP_UtilizationProviderModule	OK

To configure WBEM Providers for OpenVMS, follow the directions provided in the *HP WBEM Providers Installation and Administrator's Guide*, available in the SYSS\$COMMON:[WBEMPROVIDERS.DOCUMENTATION] directory on your OpenVMS system disk. For the latest information, see the following website and select the appropriate link:

[http://h71000.www7.hp.com/OpenVMS/system\\_management.html](http://h71000.www7.hp.com/OpenVMS/system_management.html)

### Note

VSI recommends that you do not remove the WBEM Providers for OpenVMS product even if you do not have a need for it. If you attempt to use the PRODUCT REMOVE command to remove this product, you might see a message similar to the following. This message is automatically displayed for any product that is required with OpenVMS; the consequences of removing WBEM Providers for OpenVMS might not be as severe as implied by the message unless other software (such as HP SIM) is using the product on your system.

```
%PCSI-E-HRDREF, product VSI I64VMS WBEMPROVIDERS V2.0 is referenced by VSI I
```

The two products listed above are tightly bound by a software dependency. If you override the recommendation to terminate the operation, the referenced product will be removed, but the referencing product will have

## After Installing or Upgrading OpenVMS

an unsatisfied software dependency and may no longer function correctly. Please review the referencing product's documentation on requirements.

Answer YES to the following question to terminate the PRODUCT command. However, if you are sure you want to remove the referenced product then answer NO to continue the operation.

Terminating is strongly recommended. Do you want to terminate? [YES]

# Configuring and Running the Performance Data Collector Base Software (Optional)

The Performance Data Collector for VSI OpenVMS (TDC) collects and manages configuration and performance data for analysis by other applications. TDC\_RT Version 2.3-20 is a run-time only (base) variant of the TDC software that is installed automatically with the OpenVMS operating system for use on specific operating system platforms.

Use of the TDC\_RT software is not required. If you do not plan to use TDC\_RT or any products that depend on it, you can skip to the next section.

TDC\_RT does not run automatically when the system starts, but any suitably privileged user can start the software manually. This section includes information about system parameters, privileges and quotas, startup, and installation in OpenVMS Clusters.

## Note

Do not attempt to explicitly remove TDC\_RT from your system. The PRODUCT REMOVE command is not supported for TDC\_RT although there appears to be an option to remove it. TDC\_RT is installed with the operating system and is tightly bound with it. HP or third-party applications might require TDC\_RT. Attempts to remove it might not work as expected and can create undesirable side effects. An attempt to remove it results in a message similar to the following:

```
%PCSI-E-HRDREF, product VSI TDC_RT V2.3 is referenced by VSI I64VMS OpenVMS  
V8.4-1H1
```

The two products listed above are tightly bound by a software dependency. If you override the recommendation to terminate the operation, the referenced product will be removed, but the referencing product will have an unsatisfied software dependency and may no longer function correctly. Please review the referencing product's documentation on requirements.

Answer YES to the following question to terminate the PRODUCT command. However, if you are sure you want to remove the referenced product then answer NO to continue the operation.

Terminating is strongly recommended. Do you want to terminate? [YES]

## User Privileges and Quotas

Users of TDC\_RT require various privileges, depending on the types of data to be collected. Online help is available when running the collector application and specifies the privileges required to collect each type of data. Enabling the following set of privileges enables collection of all data items: CMKRNL, LOG\_IO, NETMBX, PHY\_IO, SYSLCK, SYSPRV, WORLD.

Users of the product also require working set quotas (WSQUO) greater than 7000 pagelets.

## Startup File

TDC\_RT provides a startup file that should be launched during system startup. The startup file defines several logical names required for use of the product, but the startup file does not actually start the data collector.

Add the following line to SYSS\$MANAGER:SYSTARTUP\_VMS.COM:

```
$ @SYS$STARTUP:TDC$STARTUP
```

To directly run TDC\$STARTUP.COM, SYSNAM privilege is required.

## Compatibility with Prior Releases

Note the following about prior releases of TDC software.

- TDC Version 1.*n*

For users of some third-party system-management applications, TDC Version 1.*n* was distributed by web download. Applications developed using TDC Version 1.*n* will not work with TDC Version 2.2 software until they are rebuilt using the TDC Version 2.2 Software Developer's Kit (SDK). You can obtain this SDK kit from the following website:

<http://www.hp.com/products/OpenVMS/tdc/>

Data files created using TDC Version 1.*n* cannot be read by TDC\_RT Version 2.2. Data files created using TDC\_RT Version 2.2 cannot be read using TDC Version 1.*n*.

When TDC\_RT Version 2.1 or any newer version of TDC is installed, files associated with TDC Version 1.*n* are not removed. In any case, TDC\_RT Version 2.1 (or later) and TDC Version 1.*n* can safely coexist on a system. You can remove the older TDC files by uninstalling TDC (use the DCL command PRODUCT REMOVE).

- TDC Version 2.2 on an earlier version of OpenVMS

If you upgrade to OpenVMS Version 8.4-1H1 from an earlier version of OpenVMS on which TDC Version 2.2 was installed, files shared by TDC\_RT Version 2.2 and TDC Version 2.2 are updated; these files are the documentation and support files listed in SYSS\$COMMON:[TDC]README.TXT as common to all kit variants. Unless the TDC and TDC\_RT kits share the same baselevel number (for example, 102), image files installed with TDC Version 2.2 are retained in their installed locations. Most likely, the downloaded TDC Version 2.2 software will be more recent (higher baselevel number) than the TDC\_RT Version 2.2 software installed with OpenVMS Version 8.4-1H1. The TDC Version 2.2 SDK (if installed) and any additional documentation files installed with TDC Version 2.2 are retained.

Running SYSS\$STARTUP:TDC\$STARTUP.COM causes the most recent TDC/TDC\_RT Version 2.2 images to be used at runtime, regardless of whether they were installed with TDC Version 2.2 or with TDC\_RT Version 2.2.

You can remove TDC Version 2.2 without affecting the integrity of the TDC\_RT Version 2.2 installation if their baselevel numbers differ.

As of OpenVMS Version 8.2, TDC and TDC\_RT use the same naming scheme for image files. A build number is tagged to the image file names. For example, if the version of TDC\_RT that ships with your operating system is Version 2.2-60 (where 60 is the build number), then the files that are installed will have names such as TDC\$APISHR\$I\_V841-0060.EXE, where \$I denotes HP Integrity servers), V841 denotes the version of OpenVMS (8.4-1), and 0060 is the build number. The SYSS\$STARTUP:TDC\$STARTUP.COM startup file, which is also identical for both TDC and TDC\_RT, uses this build number to determine which image files to use. When a subsequent installation is performed with

software that has higher build numbers, the TDC\$STARTUP.COM startup file uses the image files with the highest build number appropriate for the current platform.

## Running TDC\_RT

To run the collector application, users can enter the TDC command at the DCL prompt. But first, because the TDC command is not included in the system command table SYS\$LIBRARY:DCLTABLES.EXE, each user must add the command to their table by entering the following command at the DCL prompt:

```
$ SET COMMAND SYS$COMMON:[TDC]TDC$DCL
```

Each user can add this SET command to their LOGIN.COM file. However, because elevated privileges are required for most data collection operations, it might not be appropriate to add this command to SYS\$MANAGER:SYLOGIN.COM.

To start the collector application, enter the TDC command:

```
$ TDC
```

For more information about running the application, see the file SYS\$COMMON:[TDC]TDC\_README.TXT. Release notes are located in the file SYS\$COMMON:[TDC]TDC\_RELEASE\_NOTES.TXT. See both of these files before running the collector application.

## Installation in OpenVMS Clusters

TDC\_RT is installed in SYS\$COMMON:[TDC] by default. Included are only those files required to run the data collector with the particular operating system version it was distributed with. Once TDC\_RT is installed and SYS\$STARTUP:TDC\$STARTUP.COM has been run on each cluster member, then all cluster members in a single-version, single-architecture OpenVMS Cluster should be able to run the software.

For mixed-version and mixed-architecture clusters, you should obtain and install a complete Performance Data Collector kit (TDC Version 2.2) from the following website:

<http://www.hp.com/products/OpenVMS/tdc>

The complete kit provides an SDK and run-time environments for all supported OpenVMS configurations. It supports installation on a clusterwide basis in mixed-version and mixed-architecture OpenVMS Clusters.

## Configuring the OpenVMS Management Station (Optional)

If you installed the OpenVMS Management Station software on your system (either by accepting all default values or by selecting the component manually during the installation or upgrade procedure), you must perform several tasks on your OpenVMS system and your PC before you can use OpenVMS Management Station. These tasks include the following:

- Editing system files
- Starting OpenVMS Management Station on other nodes
- Verifying that you have the proper memory, disk space, media, and the required software to install and run OpenVMS Management Station on your PC
- Installing the client software on your PC
- Defining DECnet nodes (after a new installation only)

## Creating a System-Specific Login Welcome Message (Optional)

You can use SYSSWELCOME to display a system-specific welcome message at login. The message could inform users of scheduled down time, recent updates to the system, whom to contact about system problems, and so forth. A template file is provided by the operating system. To create your own SYSSWELCOME file, do the following:

1. Copy the template file using the following command:

```
$ COPY SYS$MANAGER:WELCOME.TXT SYS$SPECIFIC:[SYSMGR]WELCOME.TXT
```

For a clusterwide welcome message, you can copy the file to SYSSCOMMON:[SYSMGR].

2. Replace the text in SYSSSPECIFIC:[SYSMGR]WELCOME.TXT with text specific to your system.
3. Edit SYSSMANAGER:SYSTARTUP\_VMS.COM to remove the exclamation point (!) from the line that defines SYSSWELCOME.

If you do not want to use a node-specific welcome file, you can optionally define the logical in SYSSMANAGER:SYSTARTUP\_VMS.COM to display a message, such as in the following example:

```
$ DEFINE SYSSWELCOME "Welcome to node HOMER"
```

For more information about creating login welcome messages, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*.

## Examining Your Command Procedures (Upgrades Only)

The upgrade procedure retains the site-specific versions of the following files located in the [VMS \$COMMON] directory:

- [SYSMGR]LAT\$SYSTARTUP.COM
- [SYSMGR]LOGIN.COM
- [SYSMGR]SYCONFIG.COM
- [SYSMGR]SYLOGICALS.COM
- [SYSMGR]SYLOGIN.COM
- [SYSMGR]SYPAGSWPFILES.COM
- [SYSMGR]SYSECURITY.COM
- [SYSMGR]SYSHUTDOWN.COM
- [SYSMGR]SYSTARTUP\_VMS.COM
- [SYSMGR]TFF\$SYSTARTUP.COM
- [SYSMGR]WELCOME.TXT
- [SYSSSTARTUP]ESS\$LAST\_STARTUP.DAT

The upgrade procedure might provide new templates for some of these files with the .TEMPLATE file extension. The new templates might include features that are not in your site-specific files. Check the templates against your site-specific files and edit your files as necessary.

### Note

The DCL command DECRAM has been removed because it conflicts with the newer DECRYPT command (DECRYPT overwrites the default definition of DECR, which you might have been using to run DECram). You should update any command procedures that use the DECRAM command so that they use the foreign command style of DCL to run DECRAM:

## After Installing or Upgrading OpenVMS

```
$ DECRAM == "$MDMANAGER"
```

This change affects only the use of the DCL command; all other aspects of the DECram product remain the same.

# Adding and Removing Operating System Files (Optional)

If you decide after the installation or upgrade to change which OpenVMS operating system files you want installed on your system, you can use the menu system contained on the OpenVMS distribution media to add or remove files.

## Note

You can obtain information about individual system files by entering the HELP SYS\_FILES command at the dollar sign prompt (\$).

## Caution

Unless you have a specific need to exclude operating system files from your system disk, VSI strongly recommends that you accept the defaults and install all files that are part of OpenVMS. In general, limited disk space is not a good reason to exclude files; problems encountered when needed files are missing can cost much more than the cost of a larger disk.

To add or remove operating system files:

1. Mount and boot the OpenVMS distribution media.
2. Choose Option 1 on the Installation Menu.
3. Select the PRESERVE option.
4. Enter the name of the device that contains the system disk and answer the questions.
5. After you answer the question "Do you want detailed descriptions?," information regarding reconfiguring or reinstalling is displayed. Read the instructions, then choose the desired entry on the menu of options.

The following is a sample display:

Please choose one of the following:

- 1) Upgrade, install or reconfigure OpenVMS I64 Version 8.4-1H1
- 2) Display layered products that this procedure can install
- 3) Install or upgrade layered products
- 4) Show installed products
- 5) Reconfigure installed products
- 6) Remove installed products
- 7) Find, Install or Undo patches; Show or Delete recovery data
- 8) Execute DCL commands and procedures
- 9) Shut down this system

```
Enter CHOICE or ? for help: (1/2/3/4/5/6/7/8/9/?) 1
```

```
*****
```

```
.  
.
.
```

```
Do you want to INITIALIZE or to PRESERVE? [PRESERVE] PRESERVE
```

## After Installing or Upgrading OpenVMS

.  
. .  
.

Version 8.4-1H1 of the OpenVMS operating system is already installed on the target disk. You may choose one of the following actions:

- o Reconfigure the OpenVMS platform.

This action will allow you to change your selections of which of the windowing and network products you included with your OpenVMS operating system installation.

- o Reconfigure the OpenVMS operating system.

This action will allow you to change your choices about which options you included for the OpenVMS operating system.

- o Reinstall the OpenVMS operating system.

This action will cause ALL operating system files to be replaced. You can also change your choices about which options you included for the OpenVMS operating system.

Reinstall will take longer than Reconfigure. Reinstall may be appropriate if you suspect that files in the operating system, or in the windowing and network products have become corrupted.

If you want to reinstall any of the windowing and network products, choose "Install or upgrade layered products" from the main menu.

If you want to change your choices about which options you included for any of the windowing and network products, choose "Reconfigure installed products" (option 5) from the main menu.

Please choose one of the following:

- 1) Reconfigure the OpenVMS platform.
- 2) Reconfigure the OpenVMS operating system.
- 3) Reinstall the OpenVMS operating system.
- 4) Return to the Main Menu (abort the upgrade/installation).

Enter choice or ? for help: (1/2/3/4/?) **2**

The following product has been selected:

VSI I64VMS VMS V8.4-1H1 Operating System

Configuration phase starting ...

You will be asked to choose options, if any, for each selected product and for any products that may be installed to satisfy software dependency requirements.

VSI I64VMS OpenVMS V8.4-1H1: OpenVMS and related products Platform

COPYRIGHT 1976,2015...

VMS Software, Inc.

Do you want the defaults for all options? [YES] **NO**

## After Installing or Upgrading OpenVMS

Answer NO to this question as shown, and select the options you want, as described in step 18 of the installation procedure in “STEP-BY-STEP Installation Example”. (“Component Options and Suboptions” shows a list of the component options.) After you respond to the prompts, the display continues and the installation procedure completes. The following is a continuation of the sample display:

```
Do you want to review the options? [NO]
Execution phase starting ...
```

```
The following product will be reconfigured:
```

```
VSI I64VMS VMS V8.4-1H1
```

```
Portion done: 0%...10%...20%...30%...40%...50%...60%...80%...90%...100%
```

```
The following product has been reconfigured:
```

```
VSI I64VMS VMS V8.4-1H1
```

```
.
.
.
```

For detailed instructions on how to remove the OpenVMS operating system from your disk, see “*Removing the OpenVMS Operating System*”.

## Compressing the System Libraries (Optional; Not Recommended)

The libraries included with OpenVMS are installed in expanded (uncompressed) format. VSI recommends keeping the libraries in expanded format. Compressing them can hinder system performance. If you decide that you need to compress or decompress or list the files and size of these libraries, use the command procedure `SY$UPDATE:LIBDECOMP.COM`.

For more information about the utility, you can request help by entering the following command:

```
$ @SY$UPDATE:LIBDECOMP HELP
```

You can list the sizes and format (reduced or expanded) of the libraries by using the following command:

```
$ @SY$UPDATE:LIBDECOMP LIST
```

For complete information about expanding and reducing system library files and using `LIBDECOMP.COM`, see the *OpenVMS System Manager's Manual, Volume 2: Tuning, Monitoring, and Complex Systems*.

## Installing Patches (Optional but Recommended)

VSI recommends installing any relevant OpenVMS and networking patches that are available. Most patches are optional, but some layered products might require one or more patches on the system before their software is installed. For more information about patches that might be required on your system, see the *VSI OpenVMS Version 8.4-1H1 Release Notes*, and the documentation provided for the relevant layered products.

VSI OpenVMS patch files are validated using the Secure Delivery feature. Each patch file includes an associated digital signature file (also referred to as a manifest) that is used to validate the patch file. This validation involves authenticating the originator (VSI, in this case) and verifying the contents of the file.

## Caution

VSI strongly recommends backing up your system disk before installing patches.

To download and install OpenVMS patches, do the following:

1. Create a directory on a non-system disk called [PATCHES] and set default to that directory.
2. Using the established support procedures, access and download the appropriate patches to the [PATCHES] directory.

## Note

As of the date of this publication, VSI has not issued any patches and has not yet established a formal location for accessing patches. Because HP may post relevant patches pertaining to layered products, we suggest that you check for any relevant HP patches using their established support procedures.

3. The patches are downloaded as compressed files. To decompress them, use the RUN command, as in the following example:

```
$ RUN VMS84I_MX2-V0100.ZIPEXE
```

This decompresses the patch into an installable file.

4. Install the decompressed patches as described in the patch release notes.

# Installing and Configuring Layered Products

The OpenVMS distribution media includes several layered products. These include the System Integrated Product (SIP) kits for the following products that are installed automatically:

- Availability Manager (base) for OpenVMS (required)
- CDSA for OpenVMS (required)
- Kerberos for OpenVMS (required)
- SSL for OpenVMS (required)
- Performance Data Collector base software, TDC\_RT (required)
- HP Binary Checker for OpenVMS
- WBEM Services for OpenVMS
- WBEM Providers for OpenVMS

Additionally, if you have purchased the *High Availability Operating Environment (HAOE)* license, you will have some additional SIP kits, including:

- OpenVMS Clusters
- RTR Reliable Transaction Router
- RMS Journalling
- Volume Shadowing

Always refer to the *Software Product Description* for exact details of what is included in each operating environment.

The distribution media also includes optional SIP kits for the following products that you can install during the OpenVMS installation:

- DECwindows Motif for OpenVMS
- DECnet-Plus for OpenVMS
- DECnet Phase IV for OpenVMS
- TCP/IP Services for OpenVMS

## After Installing or Upgrading OpenVMS

These layered products are included on the OpenVMS distribution media and can be installed using either the steps shown in this section or the alternative procedure described in “Alternative Procedure”. Other layered products, whether provided by VSI on other distribution DVDs in the Software Product Library DVD set, or on a DVD provided by a third-party company—should be installed using the steps shown in “Alternative Procedure”.

In addition to the SIPs, the VSI OpenVMS OE DVD includes kits for various products that are part of the OpenVMS OEs. VSI does not support installing these OE product kits while booted from the OE DVD. To install these OE products, you must use the procedure described in “Alternative Procedure”.

Most PCSI kits included on the OpenVMS distribution media are signed using Secure Delivery. Signed PCSI kits that are installed from the distribution media are validated. Signed PCSI kits that you install subsequently are validated (including signed kits on the distribution media).

### Note

To use the OpenVMS Installation Menu Option 3 to install products, the target system must have the identical version of OpenVMS as the distribution media. If you need to install layered products on a target system that has a different version of the operating system, use the alternative procedure.

To use the OpenVMS Installation Menu Option 3, follow these steps:

1. Before you install any layered products, be sure you back up the system disk.
2. Boot the OpenVMS distribution media. The Installation Menu will be displayed.
3. To view a list of products that can be installed, choose Option 2 on the menu. If the layered product that you want to install is not listed in the display, install the product by using the alternative procedure described in “Alternative Procedure”, or see the documentation you received with the layered product. Note that VSI does not support VMSINSTAL, PRODUCT INSTALL, or other PRODUCT commands from the DCL option on the operating system menu.
4. To install layered products, choose Option 3 on the menu. For more instructions, see “OPTION 3: Install or upgrade layered products”.
5. After the installation completes, shut down the system by selecting Option 9 on the menu. When you boot the target system, the layered products you installed will be present.

For additional information about installing layered products, see the *OpenVMS System Manager's Manual*.

## Alternative Procedure

Use this alternative procedure to install the following products:

- Layered products on a target system that has a different operating system version than that of the operating system media DVD
- Layered products that require VMSINSTAL (indicated in the directories by save-set file names with file types of .A, .B, and so on)
- OpenVMS OE products
- SIP kits (as an alternative to using menu option 3 of the operating system menu on the media)
- Products on the Layered Products, Freeware, System Tools, and e-Business Integration and Infrastructure disks
- Third-party software products (such as database products, accounting software, and so forth)

## After Installing or Upgrading OpenVMS

For a list of layered products you can install, see the Software Product Descriptions included with your operating system kit. Note that some products require a license key (PAK) from VSI.

Follow these steps:

1. Before you install all your layered products, be sure you back up the system disk. In addition, ensure that a license has been loaded for the software. Note also that most layered products require changes to SYSGEN parameters or AUTHORIZE values, and to system files such as SYLOGICALS.COM, SYLOGIN.COM, and SYSTARTUP\_VMS.COM. For more information, see the following:

- Installation guides for these layered products
- *OpenVMS System Manager's Manual, Volume 1: Essentials*
- “Modifying System Parameters” in this manual
- “Updating SYSTARTUP\_VMS.COM to Start Layered Products and Print Queues” in this manual

2. After your target system disk runs AUTOGEN and boots (if necessary), mount the OpenVMS operating system media. For example, if the device with the operating system media is DKA400:, use the following command:

```
$ MOUNT/OVERRIDE=IDENTIFICATION DKA400
```

3. Locate the directories and files containing the available layered products. For example, if the device name is DKA400:, enter the following command:

```
$ DIRECTORY /NOHEAD/NOTRAIL DKA400:[*.KIT]
```

You can use the PRODUCT FIND command to locate kits by using the PCSI utility. For example:

```
$ PRODUCT FIND * /SOURCE=DKA400:[*.KIT]
```

4. To install layered products that require VMSINSTAL (indicated in the directories by save-set file names with file types of .A, .B, and so on), enter the @SYS\$UPDATE:VMSINSTAL command and then specify the device name and directory at the prompt. For example:

```
$ @SYS$UPDATE:VMSINSTAL
```

```
* Where will the distribution volumes be mounted: DKA400:[DIAA032.KIT]
```

To install layered products that require the PCSI utility (indicated in the directories by file names with file types of .PCSI or .PCSI\$COMPRESSED), use the PRODUCT INSTALL command to specify the device name and directory. Following is an example of the PRODUCT INSTALL command:

```
$ PRODUCT INSTALL FORTRAN /SOURCE=DKB400:[I64_FORT075.KIT]
```

## Creating Print Queues

If you have a large number of print queues to add and you need to get the system in use quickly, you can set up one print queue per area or work group and then add the other print queues later, after the user accounts are added (“Creating Accounts (New Installations, Some Upgrades)”). For more information about adding print queues, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*.

## Updating SYSTARTUP\_VMS.COM to Start Layered Products and Print Queues

After installing and configuring any layered products or adding new print queues, you should update the SYSTARTUP\_VMS.COM file to start these products and print queues. For more about updating the SYSTARTUP\_VMS.COM file, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*.

## Creating Accounts (New Installations, Some Upgrades)

During installation, DEFAULT and SYSTEM accounts are created automatically. You should create additional user accounts now. If you plan to have VSI (or HP) service representatives test your system or if you plan to run testing software such as UETP (User Environment Test Program), you must create accounts for each representative and a SYSTEST (standalone system) or SYSTEST\_CLIG (OpenVMS Cluster system) account to run UETP.

For complete information about creating and managing user accounts and about creating accounts for HP service representatives and UETP, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*.

## Testing the System with UETP (Optional)

The User Environment Test Package (UETP) is a software package that tests whether the OpenVMS operating system is installed correctly. It tests the hardware, including disk drives, tape drives, CD drives, line printers (if any), network cards, and so forth. Running UETP is optional; but we recommend that you run UETP after an installation or if new hardware was added as part of an upgrade.

Before using UETP, you must create a SYSTEST (standalone system) or SYSTEST\_CLIG (OpenVMS Cluster system) account. You should also create an account for your service representatives to use. You can use the CREATE\_SPECIAL\_ACCOUNTS.COM file to create these accounts, as explained in *OpenVMS System Manager's Manual, Volume 1: Essentials*.

For complete information about using UETP, see the *OpenVMS System Manager's Manual, Volume 2: Tuning, Monitoring, and Complex Systems*.

## Backing Up the Customized System Disk and Initiating System Backups

After you customize the OpenVMS operating system to your satisfaction and perform the other steps recommended thus far in this chapter that are relevant to your system, protect your work by making a standalone backup copy of the system disk to tape or other suitable backup media. To do so, follow the instructions in “Backing Up Your System Disk”. If you are going to be saving to disk, specify a disk that will not be (or is not) part of a shadow set.

For complete information about backup operations, including a description of an alternative method that does not require booting from the OpenVMS distribution media, see “*Backing Up and Restoring the System Disk*”.

VSI also recommends creating a systematic routine for backing up the application, data, and user disks. For more information, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*.

## Reforming the Shadow Set as Final Postupgrade Backup

If your system disk participates in a volume shadowing environment, re-form the shadow set again to generate another shadow copy onto the other disks in the set. To do so, follow the instructions in “Forming the Shadow Set”.

## Rebooting Cluster Members (Upgrades Only)

If you are performing a rolling upgrade in an OpenVMS Cluster environment and have completed all the postupgrade tasks required thus far for your upgraded system disk, reboot each system that boots from that system disk.

For more information about booting your system, see “*OpenVMS, Hardware and Boot Operations*”.

At this point, your system is ready for general use.

## Modifying System Parameters

Based on your examination of an AUTOGEN report (AGEN\$PARAMS.REPORT), you might need to modify parameter values in MODPARAMS.DAT. Read the notes in “General Notes About Modifying System Parameters”. These notes apply to modifications being made after a new installation and after an upgrade. If you are modifying system parameters after an upgrade, also see “Modifying System Parameters After an Upgrade”.

## General Notes About Modifying System Parameters

When modifying system parameters, note the following:

- In general, let AUTOGEN calculate system parameters. You can hardcode values (such as `GBLPAGES=value`), but doing so overrides AUTOGEN and might not allow it to set an optimal value based on observed usage.
- Whenever possible, use `MIN_parameter` values (such as `MIN_GBLPAGES`) to set the minimum value that can be set for a parameter by AUTOGEN. AUTOGEN increases the value if necessary. It also adjusts related parameters unless they are hardcoded, in which case information is provided in the AGEN\$PARAMS.REPORT file. Use `MAX_parameter` values to set a maximum value when it is necessary to limit a parameter to a known maximum value (this is rarely necessary).
- Enter numeric values as integers without commas (for example, 10000). Enter alphabetic characters in lower or uppercase.
- We suggest that you include comments in the MODPARAMS.DAT file indicating who changed the value, when it was done, and why it was done. An exclamation point (!) serves as a comment starter and can appear anywhere on a line. The following example illustrates the modifications recommended in the preceding bulleted items:

```
! the following changes made by K.Frog on 3/27/15
!  
SWAPFILE=0                ! Don't re-size the SWAPFILE on AUTOGEN runs  
MIN_gblsections=750      ! Required for DECwindows MOTIF  
MIN_NPAGEDYN=2750000     ! Set npagedyn to a min of 2.75 million
```

For more information about the MODPARAMS.DAT file and about using AUTOGEN in general, see the *OpenVMS System Manager's Manual, Volume 2: Tuning, Monitoring, and Complex Systems*.

## Modifying System Parameters After an Upgrade

Review the file SYSS\$SYSTEM:MODPARAMS.DAT. The upgrade procedure created a new version of this file. The old version is named SYSS\$SYSTEM:MODPARAMS.DAT\_OLD. The new

## After Installing or Upgrading OpenVMS

MODPARAMS.DAT file contains all the parameters in the old file, plus various parameters that the upgrade procedure added to ensure that all necessary system parameters are properly propagated from the earlier version of OpenVMS. The upgrade procedure also adds comment lines to explain the source of the parameters in each section of the new MODPARAMS.DAT file.

Note that the old MODPARAMS.DAT is included in the new MODPARAMS.DAT each time an upgrade is performed. Because of this, if MODPARAMS.DAT is not reviewed and cleaned up after each upgrade, it might eventually contain many levels of duplicated parameters. For this reason, you should review MODPARAMS.DAT after each upgrade. This enables you to eliminate any duplication. You can also take this opportunity to modify any parameters, if necessary.

Based on your examination of AUTOGEN's AGEN\$PARAMS.REPORT, you might need to modify parameter values in MODPARAMS.DAT.

The following subsections are examples of instances where you need to modify parameters in MODPARAMS.DAT.

## System File Sizes

AUTOGEN sets the following files at sizes appropriate for your system:

- [SYSEXE]SYSDUMP.DMP
- [SYSEXE]PAGEFILE.SYS
- [SYSEXE]SWAPFILE.SYS

If you have special workloads or configurations, you can specify different sizes for these files by performing the following steps:

1. Log in to the SYSTEM account.
2. Enter the following command:  

```
$ @SYS$UPDATE:AUTOGEN SAVPARAMS TESTFILES
```
3. If the file sizes displayed need to be adjusted, add symbols to the MODPARAMS.DAT file (described in detail in the *OpenVMS System Manager's Manual, Volume 2: Tuning, Monitoring, and Complex Systems*), and repeat step 2 until you are satisfied with the file sizes.
4. When you are satisfied with the file sizes, enter the following command to ensure that the modified system files are installed when the system is rebooted:

```
$ @SYS$UPDATE:AUTOGEN GENPARAMS SETPARAMS
```

## OpenVMS Cluster Parameters

If you are upgrading an OpenVMS Cluster system, note the following:

- The upgrade procedure creates a new MODPARAMS.DAT for each system root on your system disk. Normally, there is one root for each computer that boots from the system disk. You must review and adjust each of these MODPARAMS.DAT files individually.

The MODPARAMS.DAT file for the system on which you are running is located in the SYS\$SYSROOT:[SYSEXE]MODPARAMS.DAT file. The MODPARAMS.DAT files for other roots on the same system disk can be found in SYS\$SYSDEVICE:[SYSx.SYSEXE]MODPARAMS.DAT, where *x* represents the root number; for example, SYS0, SYS1, SYS2, and so forth. (Valid root numbers might include hexadecimal digits—SYSA, SYSB, and so forth.)

- Be sure the EXPECTED\_VOTES value is correct. This value is the sum of all votes in the cluster. For example, if there are five computers in the cluster and each has one vote, the value is 5.

# Part IV. Boot Methods and Tools

This part of the manual describes the configuration and management tools that may be available and also explains how to set up the system console, configure boot options, boot and shut down the operating system. This part also includes a brief section on troubleshooting procedures.

Although you have probably booted your system enough times by now to know the basics, there are many variations of booting that may help you at some point. Consider this section as a reference, should you ever need these options.

# Table of Contents

9. OpenVMS, Hardware and Boot Operations .....	137
Configuration and Management Utilities .....	137
Overview of Utilities and Console Options .....	137
Configuration and Management Utilities on Cell-Based Servers .....	140
Using the Delete or Backspace Key .....	140
EFI Usage Overview .....	140
General Notes About Using EFI .....	141
Enabling or Disabling Hyper-Threading on Dual-Core Processors .....	144
Configuring and Managing OpenVMS Booting .....	144
Boot Options. Setting Boot Options for Your System Disk .....	145
Writing a New Boot Block .....	150
Booting Operations .....	151
Overview of Booting on a Cell-Based Server .....	152
Alternate Method of Booting the DVD with EFI .....	154
Booting the VSI OpenVMS OE DVD from the InfoServer .....	156
Booting from a Fibre Channel Device .....	156
Booting Manually from the Local System Disk .....	156
Performing a Conversational (Interactive) Boot .....	157
Booting with Minimum Startup .....	158
Booting with the XDelta Utility (XDELTA) .....	159
Booting from a Different Root Directory .....	159
Emergency Booting .....	159
Booting with Default System Parameters .....	160
Booting Without Startup and Login Procedures .....	161
Booting Without a User Authorization File .....	162
Halt and Shutdown Procedures .....	163
Halting a Server to Recover from Hangs and Crashes .....	163
Shutting Down the System .....	164
Troubleshooting Procedures .....	165
If the System Does Not Boot .....	165
Detecting and Responding to System Problems .....	166
Network Booting. Setting Up and Performing Network Booting .....	166
InfoServer Client Setup. Setting Up Your System as an InfoServer Client .....	168
Determining the Local Network I/O Card to Be Used .....	168
Adding the Network Boot Option to the EFI Boot Manager .....	169
Verifying the Network I/O Device Is Bootable by EFI .....	171
InfoServer Server Setup. Setting Up the InfoServer Server .....	172
InfoServer BOOTP Setup. Setting Up the BOOTP Boot Server and TFTP Server .....	175
InfoServer Booting. Booting OpenVMS from the InfoServer .....	179
InfoServer Troubleshooting. Troubleshooting InfoServer Boot Problems .....	183
Setting Up and Booting Fibre Channel Storage Devices .....	184
Checking the Firmware Version .....	184
Obtaining the IPF Offline Diagnostics and Utilities .....	185
Configuring and Booting FC Boot Device .....	186
Configuring Additional Nodes to Boot into a Cluster Using a Shared Disk .....	188

# Chapter 9. OpenVMS, Hardware and Boot Operations

This chapter contains the following information:

- Hardware/firmware configuration management interfaces and features
- Setting up your system console
- Overview of the Extensible Firmware Interface (EFI)
- Enabling or disabling *Hyper-Threading* on nPartitions that have dual-core processors that support it
- Configuring and managing boot operations such as the following:
  - Setting the system for automatic booting
  - Setting and showing boot devices
  - Setting boot parameters
  - Writing a new boot block
- Booting operations, including the following:
  - Booting the OE DVD
  - Booting the system disk
  - Performing a conversational (interactive) boot
  - Booting with minimum startup
  - Booting with the XDelta utility (XDELTA)
  - Booting from a different root directory
  - Booting in an emergency
- Halting and shutting down operations
- Troubleshooting procedures

## Note

Any information about hardware and utilities is provided in this manual for your convenience and is not intended to replace the hardware documentation included with your HP Integrity system or the latest documentation available on the Web. HP Integrity servers are available in many different configurations. Hardware, utilities, and certain hardware configuration procedures might differ significantly across models, and even across versions of the same model. Please see your hardware documentation for the most up-to-date information specific to your particular model and version. Note that the hardware documentation includes model-specific illustrations to guide you. The latest version of documentation for your server can be found online at:

<http://docs.hp.com/en/hw.html>

<http://docs.hp.com>

<http://www.hp.com/support/itaniumservers>

## Configuration and Management Utilities

This section provides a brief overview of the configuration and management utilities that are typically available for your system. For more information, see the appropriate hardware documentation.

## Overview of Utilities and Console Options

The main interfaces that are typically available for configuring and managing your server environment are:

- The Extensible Firmware Interface (EFI).
- The Management Processor (MP).
- The Integrated Lights Out (iLO) Management Processor.
- The Baseboard Management Control (BMC) utility.
- The Insight Power Management (IPM) interface>

## Note

IPM provides centralized monitoring and control of server power consumption and thermal output. (Although OpenVMS still supports the SYSGEN parameter CPU\_POWER\_MGMT, the iLO interface takes precedence over this parameter.) Before installing OpenVMS, check that power management is set in the state that you prefer. For more information, see the *VSI OpenVMS Utility Routines Manual*.

EFI is the main boot and preboot interface; it is the core interface to the system firmware and console commands on all models. BMC is provided on entry-class HP Integrity servers (although on a few systems the interface itself is hidden). BMC provides basic management capabilities and access to EFI. MP (or iLO) is available on most systems. In addition to providing access to EFI, MP provides advanced management functionality, including remote management, network console with Web-based access, and enhanced diagnostic capabilities. Both BMC and MP (iLO) can operate on standby power—even when the main power switch is turned off.

You can use MP (iLO) or BMC to interact with the capabilities of the EFI console interface.

The following list briefly describes some of the main features of EFI, MP, and BMC.

- Extensible Firmware Interface (EFI)

EFI is a menu and command-line interface between the operating system and the system firmware. The EFI interface is available only when the operating system is not booted. To configure EFI boot options while the operating system is running, OpenVMS provides the OpenVMS Boot Manager utility (SYSS\$MANAGER:BOOT\_OPTIONS.COM). Changes made by this utility do not take effect until the system is rebooted.

The *EFI Boot Manager*, like the *OpenVMS Boot Manager*, provides support for operating system loaders and enables you to configure the firmware and control the booting environment. A FAT formatted partition on the boot disk stores the system loader. The Boot Configuration menu (or in some versions of EFI, the Boot Option Maintenance Menu) enables you to add or delete a boot option, change the boot order, select the active console, and more.

After you power up the server, the EFI boot manager presents different ways to bring up the system, depending on how you have set up the boot options. For example, you can boot to the EFI Shell instead of an operating system. When you select the EFI Shell option, you can enter EFI commands at the Shell> prompt. For more information about EFI options and commands, see “EFI Usage Overview” and the appropriate hardware documentation.

- Management Processor (MP)

Management Processor (or, on entry-class HP Integrity servers, iLO) provides both local and remote access for controlling the system console, reset/power management, and transfer of control (TOC) capabilities. It also enables you to monitor tasks and display detailed information about various internal subsystems.

On cell-based servers, MP is a complex-wide tool and is always available, even if nPartitions are not configured or booted in the server complex. In contrast, EFI does not operate as a complex-wide tool and is only available when the nPartition is in an active state but has not booted an operating system; each nPartition has its own EFI interface. Using MP, you can select the partition for which you want EFI access. You can access all hardware and nPartitions in the complex.

The following is a brief summary of MP’s main features:

## OpenVMS, Hardware and Boot Operations

- Console Connectivity

As a console interface, MP enables you to interact with EFI and to power the server on or off; ultimately, it can function as the OPA0: terminal port on OpenVMS.

- Virtual Front Panel (VFP)

MP provides a virtual front panel that you can use to monitor the front panel LEDs from a remote location.

- Command Interface

MP provides an extensive menu system and a command-line interface.

- Multiple, Simultaneous Viewers

Multiple users can access the MP console or a particular nPartition console. Only one user at a time is allowed interactive access. All other users have read-only access. Output from the interactive user is reflected to the read-only users currently accessing the console. Access to MP can be restricted by password-protected user accounts.

- Availability/standby Power

MP is available whenever the system is connected to a power source, even if the server's main power switch is in the off position.

- Accessibility

MP is accessible in several ways, including by direct monitor connection using a terminal, PC, laptop or desktop computer connected to the MP serial port (with certain HP Integrity servers, you can also use a VGA monitor and USB keyboard and mouse); by modem through an EIA-232 port; or by Telnet or Web browser on the LAN. MP is accessible through Secure Shell (SSH), which is provided by TCP/IP Services for OpenVMS. **The SSH method of access is more secure than any of the other methods.**

- Console Log

MP records recent output from the system console. The **cl** command enables you to view the recorded information.

- Event Logs

MP includes event logs that include information about system events and booting. The **sl** command displays the contents of system status logs.

- Baseboard Management Controller (BMC)

BMC is more limited in functionality than MP. BMC enables you to control some management features built into the system board, such as diagnostics, configuration, and hardware management. BMC provides a console connection on some systems. As with MP, BMC enables you to interact with EFI; it can function as the OPA0: terminal port on OpenVMS. BMC also operates on standby power. However, BMC is accessible only through the serial port on the back of the system.

BMC commands enable you to control the BMC interface, view logs, get help, display firmware revisions, reset the system, turn the system locator LED on or off, and change the BMC password. BMC is not provided on cell-based HP Integrity servers. On some systems, the BMC user interface is hidden but is still present and functional. For more information about BMC commands, see the appropriate hardware documentation.

## Configuration and Management Utilities on Cell-Based Servers

For the complex environments of cell-based servers, a wider variety of tools are provided. Systems with multiple nPartitions provide a separate EFI interface for each nPartition. MP provides access to, and allows management across, the complex and each nPartition EFI interface.

In addition to MP and EFI (cell-based servers do not provide BMC), these systems offer Partition Manager and other tools that vary from system to system and operating system to operating system. The Partition Manager (parmgr) utility provides a graphical interface for managing nPartitions and complex hardware. It centralizes all nPartition management functions in one place, providing the system manager with the tools to dynamically reconfigure, power on, power off, create, delete, and modify nPartitions.

Partition Manager can be run on HP-UX or Microsoft Windows™ systems. You can use either of these to manage nPartitions for OpenVMS. Partition Manager is a free product that you can download from the following website (PARMGR must be uppercase as shown):

<http://www.docs.hp.com/en/PARMGR2/download.html>

## Using the Delete or Backspace Key

Some versions of the EFI, MP and BMC console interfaces still interpret the **Delete** (or **Backspace**) key as do UNIX systems, which is different from the way OpenVMS or Microsoft Windows™ systems interpret it. Whereas the OpenVMS operating system uses the ASCII DEL/RUBOUT character (7F hexadecimal) to delete the last character typed in a command line, these facilities use **Ctrl/H**.

When you enter commands for these servers, if you press **Delete** at a VTxxx terminal (or the key you have mapped to send the DEL/RUBOUT character code in your terminal emulator), the last character typed is not deleted.

You can remap a terminal so that the **Delete** key removes the last character typed by adding the following DCL command to your login command procedure (generally, LOGIN.COM):

```
$ SET TERMINAL/BACKSPACE=DELETE
```

This command remaps **Ctrl/H** to DEL. The driver does not remap these keys if the terminal is in one of the following states:

- Terminal attribute is set to PASSALL
- Terminal attribute is set to PASTHRU
- IOS\_READALL
- IOS\_READPBLK
- **Ctrl/V** is entered, which tells the driver to pass the next character and skip the remap check.

Alternatively, you can set up your terminal emulator so that the **Backspace** key deletes the last character typed. However, for the key to work properly on OpenVMS, you must still enter the SET TERMINAL command described earlier.

## EFI Usage Overview

EFI is the basic interface between the operating system and firmware on all HP Integrity systems; it is similar to SRM (Standards Reference Manual) on HP Alpha systems. EFI provides a boot option menu and the ability to configure boot options. EFI is accessible when the operating system is not booted.

On cell-based servers, EFI is available when the nPartition is in an active state but has not booted an operating system. Each nPartition has its own EFI interface and system boot environment that enables you to interact with the nPartition before an operating system has booted on it.

When you power on a server system, you see a series of diagnostic messages followed by the EFI Boot Manager screen (unless MP is available, in which case you see the MP login screen). However, if your server came with the OpenVMS operating system pre-installed, then the OpenVMS operating system is the first option and it boots automatically.

## Note

On some systems that include MP, you might first see the MP login screen. In addition, on cell-based servers, you initially must select the console for the nPartition you want to access. As noted previously, the behavior of HP Integrity server systems can vary significantly from model to model as well as from version to version of the firmware.

To select an option from the EFI Boot Manager menu, use the up or down arrow key to highlight an item (or for some (with some terminal emulators, you might have to use the letter `v` to scroll down and the caret (^) to scroll up), and then press **Enter** to activate the selection. You can use EFI to configure numerous options for your server and OpenVMS operating system.

For the first boot of a system on which OpenVMS is not pre-installed, you probably need to use EFI to get started. When you select the EFI Shell, the console displays much activity before the EFI Shell prompt is displayed. If you do not see the EFI Shell prompt, press **Enter**.

The EFI boot menu lists boot options. Each item in the boot options list references a specific boot device and provides a specific set of boot options or arguments to be used when booting the device. You can add boot options to the boot menu. The OpenVMS installation and upgrade procedure can assist you in adding and validating a boot option for your newly installed system disk. The procedure uses the OpenVMS Boot Manager utility (SYSS\$MANAGER:BOOT\_OPTIONS.COM) to add and validate boot options. You can use this utility directly at the OpenVMS DCL prompt.

VSI recommends using either of these methods for configuring boot options rather than using EFI. The OpenVMS Boot Manager utility is easier to use than EFI and enables you to configure the most pertinent options for your system (while OpenVMS is running), including:

- Display boot options known to the EFI Boot Manager.
- Add a boot option to the EFI Boot Manager so that your system disk boots automatically when the system is powered on or rebooted.
- Remove or change the position of a boot option in the EFI Boot Manager list.
- Validate and fix the boot option list.
- Change how long EFI pauses before booting or rebooting.

Use of this utility is optional for most devices but is required for configuring boot options on Fibre Channel devices. VSI recommends using this utility to add members of a multiple-member shadow set to the boot list and dump device list. (Be sure to add all members to both lists.)

For instructions on how to use the utility, see “Configuring and Managing OpenVMS Booting”. For more information about configuring Fibre Channel devices with this utility, see “Setting Up and Booting Fibre Channel Storage Devices”. For information about using the OpenVMS Boot Manager utility to display boot options, see “Displaying EFI Boot Entries and Mapped OpenVMS Devices”. For information about setting the pause length, see “Setting EFI Boot Option Countdown Timer (Timeout)”. The OpenVMS Boot Manager utility also enables you to configure dump off the system disk (DOSD) devices and debug devices; for more information about this, see the *OpenVMS System Manager's Manual, Volume 2: Tuning, Monitoring, and Complex Systems*.

## General Notes About Using EFI

Note the following:

- **Using EFI on cell-based servers:** A separate EFI interface exists for each nPartition. Be sure to access the appropriate nPartition console.

To determine which nPartition EFI interface you are using, use the **info sys** command at the EFI Shell prompt. This lists the local nPartition number and details about active cells. For processor details, use the **info cpu** command.

You can use the MP console interface to access any nPartition's EFI console. Press **Ctrl/B** to move from EFI (or from your OpenVMS session) to the MP interface. Log in to MP if you are prompted. A menu then displays the names of all available nPartitions. Select from this list the nPartition that you want to access. To gain console write access for an nPartition console, press **Ctrl/E** and enter the letters **cf**. You can use the MP **pd** command to set a default nPartition for MP login; this helps to ensure you are brought to the intended nPartition.

To return to the EFI console (when OpenVMS is not booted), enter the **co** command at the MP> prompt.

- **Navigating EFI file system directories:** To switch to a different file system, enter the file system name. The following example shows how to switch to fs3: from the current location (top level of the EFI Shell):

```
Shell> fs3:
fs3:\>
```

Note that the prompt is now fs3:\. The EFI Shell prompt changes to reflect the file system currently accessed. The Shell prompt is displayed again if you reset the system. Also note that the file system number might change when remapped after hardware changes are made to the server (for example, after an I/O drive is added to the server and the nPartition boots or the **map -r** command is issued).

- **File structure of EFI file systems:** The file structure of an fs disk is identical to MS-DOS (FAT) and the commands to move around the structure are similar to MS-DOS commands. For example, to move to directory efi on disk fs0:, enter the **cd** command:

```
fs0:\> cd efi
fs0:\efi>
```

To display the contents of the **efi** directory, use the **dir** command.

- **EFI commands for OpenVMS:** Most commands that you issue for OpenVMS purposes at the EFI Shell prompt are issued from **\efi\vms** on the file system associated with the system disk. You can enter such commands directly from the top level by specifying **\efi\vms** in the path for subsequent commands, or by first moving to **\efi\vms** and entering the commands without the path specification. The first example that follows shows how to enter commands from the top level. The second example shows how to move to **\efi\vms** before entering the commands. The **vms\_show** command displays the equivalent OpenVMS device name for devices mapped by EFI, and the **vms\_set** command can be used to set a debug or dump device. These EFI commands for OpenVMS, known as EFI Utilities for OpenVMS, are usable only when the operating system is not running. To display and set EFI-mapped devices while the operating system is running, use the OpenVMS Boot Manager utility (SYSS\$MANAGER:BOOT\_OPTIONS.COM), as described in “Configuring and Managing OpenVMS Booting”. The EFI Utilities for OpenVMS are described in the *OpenVMS System Management Utilities Reference Manual*.

### Example 1 — From Top Level

```
fs0:\> \efi\vms\vms_show device
.
.
fs0:\> \efi\vms\vms_set dump_dev dga3730
```

### Example 2 — First Moving to \efi\vms

```
fs0:\> cd \efi\vms
```

```
fs0:\efi\vms> vms_show device
.
.
.
fs0:\efi\vms> vms_set dump_dev dga3730
```

## Note

The directory structure and contents of the OpenVMS system disk differs from those of the VSI OpenVMS OE DVD. Note also that the bootstrap on the system disk is located at `\efi\vms\vms_loader.efi`, while on the DVD it is at `\efi\boot\bootia64.efi`. (These two files are identical in content.)

- **EFI aliases:** You can define aliases for EFI commands that are easier to remember. For example, to define the alias `dir` for the `ls` command, use the `alias` command as follows:

```
fs0:\> alias dir "ls"
```

To define an alias for the command that boots OpenVMS from fs0:, enter the following command:

```
fs0:\> alias bvms "fs0:\efi\vms\vms_loader.efi"
```

## Note

Setting an alias to point to a specific device can lead to unexpected results. For example, if you insert a DVD, fs0: now points to the DVD drive. VSI recommends using the OpenVMS HP Boot Manager utility to set your system disk as a boot device for EFI, as explained in “Configuring and Managing OpenVMS Booting”.

To list the aliases currently defined, enter the `alias` command:

```
fs0:\> alias
dir      : ls
bvms     : fs0:\efi\vms\vms_loader.efi
```

- **Boot device list:** Any changes in storage configuration after the system is booted to EFI (such as inserting a DVD into a drive or adding SCSI drives on storage enclosures) is not automatically detected by the EFI Shell environment. To have the EFI Shell recognize the device, you must reconnect the device driver (on cell-based servers, use the EFI `search` command; on other servers, use the EFI `reconnect` command).

The EFI shell environment creates default mappings for all the device handles that support a recognized file system. After you change the system configuration or add a new device, you must regenerate these mappings. For information about reconnecting devices and regenerating mappings, see “Alternate Method of Booting the DVD with EFI” and your hardware documentation.

- **Moving between EFI and MP:** To move from MP interface to EFI, type `co`(for Console) at the MP> prompt. If you are in command mode (at the MP:CM> prompt), first press **Ctrl/B** to return to the MP> prompt.

When you move to EFI from MP, confirm that you are at the main EFI main menu. If you are at a submenu, to access the main menu exit from the submenu and any subsequent submenus until you return to the main menu.

To move from the EFI to MP, press **Ctrl/B** (this assumes MP is present and configured).

# Enabling or Disabling Hyper-Threading on Dual-Core Processors

Systems that have Intel Itanium Dual-Core processors can support Hyper-Threading. Hyper-Threading provides the ability for processors to create an additional *logical CPU* that might allow additional efficiencies of processing. For example, a dual-core processor with Hyper-Threading active provides four logical CPUs, two on each core. The effect that Hyper-Threading has on performance depends heavily on the applications running on your system. Start with Hyper-Threading disabled and experiment later, if you wish.

## Note

VSI OpenVMS V8.4-1H1 currently supports up to 64 *processing units*, be those cores or threads. When you enable threads, the resulting processing units will be assigned logical CPU IDs during boot, up to the maximum of 64. Systems with a greater number of processing units will not be fully enumerated. Future releases will remove this limitation.

You can enable or disable Hyper-Threading for a system whose processors support it. To display the Hyper-Threading state for a system, use the EFI **info cpu** or **cpuconfig** command. (The display indicates that “CPU threads” are turned on or off.) For example:

```
Shell> cpuconfig
```

```
PROCESSOR MODULE INFORMATION
```

CPU Module	# of Logical CPUs	Speed	L3 Cache Size	L4 Cache Size	Family/Model (hex.)	Rev	Processor State
0	4	1.4 GHz	6 MB	None	20/00	CO	Active

```
CPU threads are turned on.
```

To enable or disable Hyper-Threading, use the EFI **cpuconfig threads on** or **cpuconfig threads off** command. For more information, enter **help cpuconfig** at the EFI Shell prompt or see the appropriate hardware documentation. The Partition Manager also supports Hyper-Threading.

After enabling or disabling Hyper-Threading, the system must be reset for the change to take effect. Use the EFI Shell **reset** command. When Hyper-Threading is enabled, it remains active on the next reboot of the system.

# Configuring and Managing OpenVMS Booting

This section explains how to configure and manage the booting behavior of your server. You can use the EFI Boot Manager (while the operating system is not running) or the OpenVMS Boot Manager (while the operating system is running) to configure boot options.

You can configure multiple boot entries for a single operating system. On cell-based servers running multiple operating systems, you can configure boot options for all currently installed operating systems. On cell-based servers, each nPartition has a local instance of EFI that is specific to that partition. Each partition can be booted and stopped independently of other nPartitions in the system, and each partition executes its own operating system image.

## Important

To configure booting on a Fibre Channel storage device, you must use the OpenVMS Boot Manager utility. (For information about configuring Fibre Channel devices, see “Setting Up and

Booting Fibre Channel Storage Devices”). VSI also recommends using this utility to add members of a multiple-member shadow set to the boot device list and dump device list. Be sure to add all members to both lists.

If you have just completed the initial setup of your server, perform the following steps before continuing:

1. Power up your system.

### Note

If you see a warning that the BMC system event log (SEL) is full, you can safely continue by following the prompts; OpenVMS processes the contents of the SEL after booting. If you want to clear the SEL manually, see the instructions in the first note of “Distribution Media Boot Methods”.

2. If you have a cell-based server, check that the ACPI configuration is correct for the OpenVMS operating system. For more information, see “Checking the ACPI Configuration (Cell-Based Servers)”.
3. At the EFI Boot Manager menu, select the EFI Shell [Built-in] option. You can now boot your system manually, or you can add a new entry to the EFI Boot Manager menu to have your system booted automatically whenever you power on or reboot your system.

This section discusses the following topics:

- Checking the ACPI configuration for nPartition booting (“Checking the ACPI Configuration (Cell-Based Servers)”)
- Setting automatic booting and boot flags for your system disk (“Setting Boot Options for Your System Disk”) (also includes how to set automatic booting using EFI commands)
- Displaying EFI boot entries and mapped OpenVMS devices, using the OpenVMS Boot Manager utility (“Displaying EFI Boot Entries and Mapped OpenVMS Devices”) (also includes how to display boot entries using EFI commands)
- Setting the EFI boot option timeout value, using the OpenVMS Boot Manager utility (“Setting EFI Boot Option Countdown Timer (Timeout)”)
- Writing a new boot block, using the OpenVMS SET BOOTBLOCK command (“Writing a New Boot Block”)

## Setting Boot Options for Your System Disk

You can establish and manage boot options for your system disk in any of three ways:

1. During installation or upgrade, allowing the installation/upgrade procedure to automatically establish an EFI boot option for your system disk
2. Using the OpenVMS Boot Manager utility (SYSS\$MANAGER:BOOT\_OPTIONS.COM) while the operating system is running
3. Using EFI (after the system disk has been created or updated and only while the operating system is not running)

The recommended OpenVMS Boot Manager utility is a menu-based utility that enables you to configure EFI boot options. It is easier to use than EFI. With this OpenVMS utility, you can perform actions such as the following:

- Add your system disk as an EFI boot option (you can optionally configure it to boot automatically on hardware startup and reboot).
- Manage multiple system disks.
- Set boot flags.
- Display the EFI boot options.
- Add, move, and remove boot options in the EFI Boot Manager menu.
- Enable or disable the EFI boot countdown timer (timeout) and set the countdown value.

This section explains how to perform most of these operations (except moving and removing boot options). For more information about the OpenVMS Boot Manager utility, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*. This section also explains how to use EFI to add a boot option for automatic booting.

VSI recommends that you configure your system with a boot option for your system disk. You can enable automatic reboot of the system disk by specifying your system disk as the first boot option in the EFI Boot Manager menu. When the EFI timeout (countdown) occurs, your system disk boots automatically.

## Note

To configure booting on Fibre Channel devices, you must use the OpenVMS Boot Manager utility. (Use of this utility is optional for other devices but mandatory for Fibre Channel devices.) VSI also recommends using this utility to add members of a multiple-member shadow set to the boot device list and dump device list. Be sure to add all members to both lists. For more information about the utility, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*. For more information about configuring and booting Fibre Channel devices, see “Setting Up and Booting Fibre Channel Storage Devices”.

## Adding a Boot Option and Setting Boot Flags

To add a boot option and set boot flags using the OpenVMS Boot Manager utility, follow these steps:

1. At the DCL prompt, enter the following command to start the OpenVMS Boot Manager utility:

```
$ @SYS$MANAGER:BOOT_OPTIONS.COM
```

2. When the utility starts, the main menu is displayed. To add your system disk as a boot option, enter 1 at the prompt, as in the following example:

```
OpenVMS Boot Manager Boot Options List Management Utility

(1) ADD an entry to the Boot Options list
(2) DISPLAY the Boot Options list
(3) REMOVE an entry from the Boot Options list
(4) MOVE the position of an entry in the Boot Options list
(5) VALIDATE boot options and fix them as necessary
(6) Modify Boot Options TIMEOUT setting

(B) Set to operate on the Boot Device Options list
(D) Set to operate on the Dump Device Options list
(G) Set to operate on the Debug Device Options list

(E) EXIT from the Boot Manager utility
```

## OpenVMS, Hardware and Boot Operations

You can also enter Ctrl-Y at any time to abort this utility

Enter your choice: **1**

### Note

While using this utility, you can change a response made to an earlier prompt by entering the caret (^) character as many times as needed. To end and return to the DCL prompt, press **Ctrl/Y**.

3. The utility prompts you for the device name. Enter the system disk device you are using for this installation. In the following example, the device name is DKA0:

```
Enter the device name (enter "?" for a list of devices): DKA0:
```

4. The utility prompts you for the position you want your entry to take in the EFI boot option list. To see a list of the current boot options, enter a question mark (?):

```
Enter the desired position number (1,2,3,...) of the entry.  
To display the Boot Options list, enter "?" and press Return.  
Position [1]: ?
```

5. The list in the following example includes only one boot option. To add your boot option entry to the top of the list (the default) so that your system disk boots automatically when the server starts or the EFI countdown timer expires, enter 1:

```
EFI Boot Options list:      Timeout = 0 secs.  
-----  
01. VenHw(d65a6b8c-71e5-4df0-d2f009a9) "EFI Shell [Built-in]"  
-----  
1 entries found.
```

```
Enter the desired position number (1,2,3,...) of the entry.  
To display the Boot Options list, enter "?" and press Return.  
Position [1]: 1
```

6. The utility prompts you for OpenVMS boot flags. By default, no flags are set. Enter the OpenVMS flags (for example, 0,1), or press **Enter** to set no flags, as in the following example:

```
Enter the value for VMS_FLAGS in the form n,n.  
VMS_FLAGS [NONE]:
```

Optionally, you can use any of the standard OpenVMS boot flags such as the following:

Flags	Description
<b>0,1</b>	Enable SYSBOOT to change system parameters; enable conversational booting for debugging purposes.
<b>0,2</b>	Load XDELTA.
<b>0,4</b>	Take the initial EXEC_INIT breakpoint.
<b>0,20000</b>	Print debug messages on boot.
<b>0,30000</b>	Print more debug messages on boot.
<b>0,400000</b>	Print even more debug messages on boot (ACPI).
<b>0,430000</b>	Print unbelievably more debug messages on boot!

7. The utility prompts you for a description to include with your boot option entry. By default, the device name is used as the description. You can enter more descriptive information as in the following example. This example shows a sample confirmation message (for devices with

multiple paths, such as Fibre Channel devices, a separate confirmation message is displayed for each path). EFI\$BCFG is the name of the executor file for the OpenVMS Boot Manager utility.

```
Enter a short description (do not include quotation marks).  
Description ["DKA0"]: DKA0: OpenVMS V8.4-1H1 for PLMs System
```

```
efi$bcfg: DKA0: (BOOT003) Option successfully added
```

8. When you have successfully added your boot option, exit the utility by entering E at the prompt:

```
Enter your choice: E  
$
```

## Using EFI to Set Automatic Booting of Your System Disk

VSI recommends allowing the OpenVMS installation or upgrade procedure to set your system disk to boot automatically. Or, use the OpenVMS Boot Manager utility (SYS\$MANAGER:BOOT\_OPTIONS.COM). However, you can use also EFI directly.

This section explains how to use EFI to set up your server to automatically boot your system disk. You should use the OpenVMS Boot Manager utility to set boot flags. Optionally, you can use the **vms\_loader.efi -flags n,n** command at the EFI prompt to set any of the standard OpenVMS boot flags, as documented earlier in this appendix.

Access the EFI Shell and enter the following line at the prompt, where *fsn*: (such as fs0: or fs1:) is the device associated with the system disk:

```
Shell> bcfg boot add 1 fsn:\efi\vms\vms_loader.efi "VSI OpenVMS I64"
```

This command adds OpenVMS to position 1 in the EFI Boot Manager menu. The quoted text is the displayed label. You can enter any text that helps you identify the disk. During system power up, the position 1 item is automatically executed after the countdown.

Alternatively, you can add an EFI boot menu option by using the EFI menu interface:

1. Select the Boot Configuration option (or in some versions of EFI, the Boot Option Maintenance Menu).
2. Select Add a Boot Option.
3. Select the boot device and boot file.

### Note

All EFI boot options embed the disks Globally Unique ID (GUID). Therefore, if you reinstall OpenVMS or restore a system disk from an image backup, you must first delete the old boot options and then add a new boot option. To delete a boot option, use the Delete Boot Option(s) option in the Boot Configuration menu (or Boot Option Maintenance Menu).

Still another method to add a boot entry to the EFI Boot Manager menu is to use the EFI **vms\_bcfg** command, which accepts OpenVMS device names and also enables you to set flags. However, this command has limited capabilities; for example, it cannot handle Fibre Channel paths as can the OpenVMS Boot Manager utility. In the following example, DKA0: is the OpenVMS system disk being added as the first boot option:

```
Shell> \efi\vms\vms_bcfg boot add 1 dka0: -fl 0,2 "VSI OpenVMS I64"
```

For more information about EFI utilities for OpenVMS, see the *OpenVMS System Management Utilities Reference Manual*.

## Displaying EFI Boot Entries and Mapped OpenVMS Devices

The EFI Boot Manager shows the various paths to the boot device. You can use the OpenVMS Boot Manager utility to display the OpenVMS boot device options known to EFI.

Start the utility at the DCL prompt **@SYSSMANAGER:BOOT\_OPTIONS.COM** and select Option 2 on the menu (shown in “Setting Boot Options for Your System Disk”). The utility displays the following prompt. In this example, the listings for the DQA0: device are requested and displayed.

```
To display all entries in the Boot Options list, press Return.  
To display specific entries, enter the entry number or device name.  
(Enter "?" for a list of devices): DQA0
```

```
EFI Boot Options list:   Timeout = 20 secs.
```

```
-----  
04. DQA0 PCI(0|0|2|0) ATA(Primary,Master) "DVD-ROM "  
-----
```

```
1 entries found.
```

You can also display all bootable devices mapped by the EFI console and their equivalent OpenVMS device names by using the EFI Utilities for OpenVMS **vms\_show** command at the EFI Shell prompt (from **\efivms**). For more information about EFI utilities for OpenVMS, see the *OpenVMS System Management Utilities Reference Manual*.

## Setting EFI Boot Option Countdown Timer (Timeout)

Whenever the EFI Boot Manager menu is displayed, it waits for you to select an option. The wait depends on the current setting of the EFI countdown timer. After the timer expires, EFI boots the first boot option. If the first option is not available or does not boot, EFI waits the same duration before booting the next option in the list.

The OpenVMS Boot Manager utility allows you to change this timeout value and enable or disable the countdown.

Select Option 6 on the OpenVMS Boot Manager main menu (the main menu is shown in “Setting Boot Options for Your System Disk”). The utility displays the following prompt. To change the value, enter YES and then enter the new value. In this example, the timeout value is changed to 20 seconds.

```
efi$bcfg: Boot Timeout period is 10 secs
```

```
Would you like to modify the Timeout value? (Yes/No) [NO] YES  
Please enter the Timeout value in seconds: 20
```

```
efi$bcfg: Boot Timeout period is 20 secs
```

To disable the timer so that automatic booting occurs instantaneously, enter 0 as the value, as in the following example:

```
Please enter the Timeout value in seconds: 0
```

```
efi$bcfg: Boot Timeout is Disabled
```

## Saving and Restoring EFI Settings

Certain EFI settings, such as the Hyper-Threading setting, cannot be restored if lost. VSI recommends that you write down your customized EFI settings in case they are lost in a system hardware or firmware failure. You can use the EFI **info cpu** command or the EFI **cpuconfig** command to display current settings, such as the setting of the Hyper-Threading feature.

You might need to restore boot options, such as if they get lost during a firmware upgrade. You can save and restore your EFI boot path settings using the OpenVMS Boot Manager utility. You can also use the EFI **variable -s** command to save boot option variables and the **variable -r** command to restore

them. After using the **variable** command to restore boot options, a reset might be required. Use the EFI Shell **reset** command.

You can use the OpenVMS-specific EFI utility **vms\_bcfg** (\efi\vms\vms\_bcfg) to set boot options, and the **vms\_show** utility (\efi\vms\vms\_show) to display them; however, these utilities are more limited in scope than the OpenVMS Boot Manager utility. For example, they cannot work with Fibre Channel boot paths as can the OpenVMS Boot Manager utility. You can use the EFI **variable** command to restore the boot options list from a previously saved file.

You could also use the EFI Shell **variable** command to restore variables such as boot path options; you must have first saved them in a known location by using the **variable -save** command. For more information, see the service manual provided for your server.

## Writing a New Boot Block

The boot block structures on the system disk contain the size and location of the boot partition and other details relevant to the bootstrap of OpenVMS. The size and location of the boot partition stored within the boot block structures must be maintained and must reference the current location of the OpenVMS file SYS\$EFL.SYS.

Current versions of BACKUP maintain the boot block structures as well as the size and location of the boot partition during image operations (analogous to the similar BACKUP/IMAGE operations that maintain the boot block on HP Alpha disks). Older versions of BACKUP do not maintain these structures and do not correctly locate core OpenVMS bootstrap files.

If the boot partition file SYS\$EFL.SYS is manually replaced or relocated, you must use the DCL command SET BOOTBLOCK or the SYS\$SETBOOT image to rewrite the boot block structures. The SET BOOTBLOCK command and SYS\$SETBOOT provide HP Integrity servers with the equivalent of what the WRITEBOOT utility provides on HP Alpha.

### Note

Do not use the HP Alpha WRITEBOOT utility to rewrite boot block structures on an HP Integrity OpenVMS system disk.

The SET BOOTBLOCK command enables you to establish the boot block pointers necessary for the EFI console to find and bootstrap an HP Integrity OpenVMS system disk. You must use this command if the target system disk was originally created by one of the following methods:

- A version of BACKUP that does not support the OpenVMS system disk structure. VSI recommends that you do *not* use these versions of BACKUP for archiving or restoring a VSI OpenVMS system disk.
- A non-image backup of a system disk (possibly corrupting the boot block and various directory backlinks that must be manually reset). VSI recommends that you do *not* use non-image backups.
- A non-image restore of a system disk from an image save set. VSI recommends that you do *not* use a non-image restoration.

### Note

If the target system disk has an incorrectly-placed [000000]GPT.SYS file, the disk cannot be used reliably as an OpenVMS system disk. Typically, the file gets incorrectly placed due to the use of an older version of BACKUP/IMAGE, a file-based BACKUP disk restoration, or an errant disk defragmentation tool (the file is set with /NOMOVE to disable move operations; defragmentation tools that do not honor this setting will corrupt the file).

A correctly-located GPT.SYS file will have at least two file extents, the first beginning at LBN 0 and the last at the disk capacity minus the size of the last extent (an extent is one or more adjacent clusters allocated to a file). The size of each of the two extents varies according to the disk cluster

factor on the target disk. The first extent size is currently 34 or more blocks, and the last extent 33 or more blocks. For example:

```
$ DUMP/HEADER/BLOCK=END=0 SYS$SYSDEVICE:[000000]GPT.SYS ...
Map area
  Retrieval pointers:
    Count:          36      LBN:          0
    Count:          36      LBN:       71132925
```

This example is from a disk with 71132960 blocks. The placement of the final extent is 71132924, which is calculated by subtracting 36 (the size of the last extent) from the disk capacity (71132960).

You may be able to temporarily recover from this condition and attempt to bootstrap the target system disk by renaming GPT.SYS to GPT.BAD, and then entering the SET BOOTBLOCK command. To correctly recover from this condition, you must INITIALIZE the target disk and then reload the disk contents using a file-based BACKUP restoration or a file-based COPY operation. No supported means exists for adding a GPT.SYS file onto an existing disk nor for adding the file during a BACKUP/IMAGE restoration operation.

To write the boot block structures onto a system disk, enter the SET BOOTBLOCK command using the following format:

```
$ SET BOOTBLOCK [/PRESERVE=SIGNATURES] [/I64] [boot-partition-name]
```

You can specify the file name for the boot partition (*boot-partition-name*). If you do not specify a file or device name, the command defaults to the following file for the boot partition:

```
SYSS$SYSDEVICE:[VMS$COMMON.SYS$LDR]SYS$EFI.SYS
```

The command also assumes the current architecture. To specify OpenVMS for HP Integrity servers, include /HP in the command line.

Use the /PRESERVE=SIGNATURES qualifier to preserve the existing GUID disk signature value and the associated root aliases. Using the OpenVMS Backup utility creates a new disk signature when restoring a bootable disk image.

If you reset the boot block structures, you might need to remove any EFI boot aliases that reference the disk, and then add them back again. You can use the EFI **alias** command to remove and add aliases; VSI recommends using the OpenVMS Boot Manager utility (SYS\$MANAGER:BOOT\_OPTIONS.COM) to maintain EFI console boot aliases.

## Note

The boot partition file must be contiguous and movefile operations on the file must be disabled. If the file is not contiguous, use the DCL command COPY/CONTIGUOUS (or equivalent) to re-create a contiguous version of the file. To disable movefile operations, use the DCL command SET FILE/NOMOVE. This prevents bootstrap failures that could result from the normal and expected operations of disk defragmentation tools.

Alternatively, you can write a boot block by entering the following command:

```
$ RUN SYS$SYSTEM:SYS$SETBOOT
```

The utility prompts you for the required input (in a way similar to the operation of the OpenVMS Alpha Writeboot utility).

# Booting Operations

This section describes various methods for booting your OpenVMS operating system.

## Note

To boot your OpenVMS operating system, you can use a VGA graphics device (except on servers that lack the firmware capabilities), a serial device, or a network interface for the console. For information about setting up the console on your server, see “Selecting a Primary and Secondary Console”.

When using a VGA console and installing from a USB DVD drive with the keyboard plugged into a USB hub, if the keyboard does not respond, simply unplug the hub and plug it back in.

## Note

HP Integrity servers maintain a system event log (SEL) within system console storage, the operating system automatically transfers the contents of the SEL into the OpenVMS error log. During a successful boot operation while using a console, you might see a message indicating that the BMC SEL is full. You can safely continue when the BMC SEL is full by following the prompts; OpenVMS processes the contents of the SEL.

# Overview of Booting on a Cell-Based Server

This section gives an overview of booting the nPartition hardware and booting OpenVMS on an nPartition.

Each nPartition runs its own firmware and has its own system boot environment. You can boot an nPartition independently of any other nPartitions in the same server complex.

The nPartition boot process includes two phases: the cell boot phase and the nPartition boot phase. These phases occur only as part of the hardware boot process, not as part of the operating system boot.

- Cell boot phase—This phase occurs when cells are powered on or reset. The main activities during this phase are the power-on-self-test activities. During this phase, cells operate independently of other cells in the complex. Cells do not necessarily proceed through this phase at the same pace, because each cell may have a different amount of hardware to discover and test, or cells might be reset or powered on at different times.
- nPartition boot phase—This phase occurs when an nPartition has been booted, after its cells have completed their self tests. During this phase, “nPartition rendezvous” occurs, in which each cell contacts the other active cells in the nPartition and selects a core cell that is responsible for managing the rest of the nPartition boot process. A processor on the core cell runs the nPartition EFI system boot environment. When the operating system boot process is initiated, the core cell passes control to the operating system loader.

You can view progress of these phases by using the Virtual Front Panel (VFP) to check the nPartition boot state. Access VFP from the MP main menu.

For information about how to boot the nPartition hardware, see your hardware documentation.

## Caution

To prevent loss of data when booting OpenVMS, note the following:

- You must first ensure that the nPartition has its ACPI configuration set to the default (see “Checking the ACPI Configuration (Cell-Based Servers)”).

## Note

OpenVMS Version 8.4 introduced support for cell local memory (CLM) on HP Integrity cell-based servers. Prior OpenVMS versions had a restriction — they used only interleaved memory (ILM). You can use the Partition Manager to check or configure CLM. For more information

on Partition Manager, see the *nPartition Administrator's Guide* (previously titled *HP System Partitions Guide: Administration for nPartitions*) or the following website:

<http://docs.hp.com/en/PARMGR2/>

You can also use the EFI Shell **info mem** command to determine the ILM and CLM configuration. If the reported non-interleaved memory is less than 512 MB, the cell is configured completely as interleaved memory (the indicated amount of non-interleaved memory is used by the firmware).

As with all HP Integrity servers that run OpenVMS, you can boot OpenVMS either by selecting a boot entry from the EFI Boot Manager or by starting the system loader (VMS\_LOADER.EFI) from the EFI Shell. To boot OpenVMS access the nPartition console and use either of these two methods:

- From the EFI Boot Manager, select the OpenVMS boot entry from the boot options list and press **Enter**.
- From the EFI Shell, start the OpenVMS system loader by entering the following command at the EFI Shell prompt, where *fsn:* (such as *fs1:*) is the device associated with the OpenVMS system disk:

```
Shell> fsn:\efi\vms\vms_loader.efi
```

When starting the VMS\_LOADER.EFI system loader, you must either specify its full path (as shown in this example) or start it from the **\efi\vms** directory. For more information, see “General Notes About Using EFI”.

For booting the VSI OpenVMS OE DVD, the path is different. Enter the following command instead:

```
Shell> fsn:efi\boot\bootia64.efi
```

## Note

The nPartition must be at EFI before beginning the boot process. If the nPartition is not at EFI, you can use VFP to check the nPartition boot state. An nPartition might be inactive or cells might be powered off. If VFP indicates that all cells in the nPartition are in the boot-is-blocked (*BIB*) state, the nPartition is inactive and you must use the MP **bo** command to boot the nPartition past BIB and make it active. For more information, see your hardware documentation.

To boot the VSI OpenVMS OE DVD, follow these steps. To boot the DVD on a cell-based server, a DVD device must be accessible for the nPartition that OpenVMS is being installed on.

1. Make sure your server is powered on. If your system has an attached external device, make sure it is turned on and operational.
2. Insert the DVD into the drive.
3. Cycle power so firmware mounts the DVD drive.
4. From the main EFI boot menu (for cell-based servers, this must be the EFI boot menu for the nPartition on which OpenVMS is to be booted), select the appropriate item from the boot options list. The EFI boot menu is timed; press any key to stop the countdown timer.

For some systems, the boot option to select is the Internal Bootable DVD option. If that option is not listed in your EFI boot menu, move to the Boot From a File menu and select the Removable Media Boot option, if present.

Alternatively (and this method is recommended for cell-based servers), boot the DVD drive from the EFI Shell prompt by entering the command shown in the following example, where *fsn:* corresponds to the server's DVD drive (such as *fs0:*). If you have navigated to a particular file system, the EFI Shell prompt would reflect that file system; for example, if the current file system is *fs0:*, the EFI Shell prompt would be *fs0:>*.

```
Shell> fsn:\efi\boot\bootia64.efi
```

To determine which device is the bootable DVD drive, examine the list of mapped devices and look for an fs device listing that includes the text CDROM, as in the following example, where *fsn* is the file system associated with the drive, which is usually fs0: (instead of *fsn*, you might see something like V8.4-1H1; instead of Ata, you might see Scsi, depending on the server model):

```
fsn      :      Acpi(HWP0002,400)/Pci(4|1)/Ata(Primary,Master)/  
CDROM(Entry0)
```

Use the **vms\_show dev** command to display the mapping of various EFI device names to OpenVMS device names, as in the following example where *fsn* is the device you want to check (such as fs0):

```
Shell> fsn:\efi\vms\vms_show dev -fs
```

For more information about the **vms\_show** command, see the *OpenVMS System Management Utilities Reference Manual*.

### Note

By default, certain versions of EFI might interpret the **Delete** (or **Backspace**) key differently than do OpenVMS Alpha systems or Microsoft Windows computers. In such cases, press **Ctrl/H** to delete the last character entered. For more information, see “Using the Delete or Backspace Key”.

When the DVD boots properly, the OpenVMS operating system banner is displayed, followed by the operating system menu. You can now install your OpenVMS operating system onto the target disk; see “Performing the INSTALLATION”. If the DVD fails to boot properly use the alternate method of booting described in “Alternate Method of Booting the DVD with EFI”.

### Note

When booting OpenVMS from the installation DVD for the first time on any system with a SAN storage device, you might experience a delay in EFI initialization because the entire SAN is scanned. Depending on the size of the SAN, this delay might range from several seconds to several minutes.

## Alternate Method of Booting the DVD with EFI

If the DVD does not boot using the methods described above, follow these steps:

1. To ensure that EFI can access the DVD, enter the following commands at the EFI Shell prompt of entry-class or single-cell HP Integrity servers. Enter the commands in the order shown. (The EFI Shell prompt may not necessarily be Shell> as in this example; it could be a prompt that reflects the current file system, such as fs0:>.)

```
Shell> reconnect -r  
Shell> map -r
```

For a multiple-cell nPartition on a cell-based server, use the **search all** command instead of the **reconnect -r** command, followed by the **map -r** command. See your hardware documentation for more information about EFI commands.

The **reconnect -r** command discovers any devices added after booting the server. The **search all** command discovers all devices including any that were not in the boot options list or connected to the core cell’s I/O chassis. (On large server systems, the **search all** command could take significant time to complete. You can reduce the search time by specifying a more directed search,

such as for a specific I/O chassis connected to a cell or a specific PCI card in a chassis. For more information, see the help information provided for the **search** command.)

The **map -r** command remaps and rebuilds the list of known devices that have a bootable EFI system partition. For a multiple-cell nPartition on a cell-based server, if you insert the DVD after EFI is loaded, you must use the search command to allow EFI to detect the inserted DVD; otherwise, EFI would not recognize the DVD in the DVD drive. When EFI detects a valid, bootable DVD in the DVD drive, it maps an fs device to it and lists that device in the mapping table displayed by the **map -r** command.

2. To boot the DVD, enter the following command at the EFI Shell prompt, where *fsn*: is the DVD drive (such as fs0:).

```
Shell> fsn:\efi\boot\bootia64.efi
```

If this command does not work, or if you have doubts about which device maps to the DVD drive, you can use the EFI Boot Manager menu system to boot the OE DVD, as described in the following steps:

- a. From the main EFI boot menu, select the Boot Configuration option (or in some versions of EFI, the Boot Option Maintenance Menu).
- b. From the Boot Configuration menu, select the Boot From a File option.
- c. From the Boot From a File menu, select the menu item that includes the text CDROM, as in the following example, and press **Enter**.

## Note

The contents of the screens shown in the following examples vary according to the firmware and devices installed on your server.

```
Boot From a File. Select a Volume
```

```
V8.3 [Acpi (HWP0002, 400) / Pci (2|0) / Ata (Primary, Master) / CDROM (Entry0)
Load File [EFI Shell [Built-in]]
Load File [Acpi (HWP0002, 0) / Pci (3|0) / Mac (00306EF3A2B6) ]
Load File [Acpi (HWP0002, 100) / Pci (2|0) / Mac (00306EF312E4) ]
Exit
```

- d. A screen is displayed that shows the top-level directory structure of the DVD, similar to the screen in the following example. Select the **efi** directory.

```
EFI Boot Maintenance Manager ver n.nn[nn.nn]
```

```
Select file or change to new directory:
```

```
n/nn/nn 06:21a<DIR> 2,048 efi
[Treat like Removable Media Boot]
Exit
```

- e. The next screen to appear shows the first level of subdirectories below the top level, similar to the following example. Select the boot directory (it contains the boot file).

```
EFI Boot Maintenance Manager ver n.nn[nn.nn]

Select file or change to new directory:

n/nn/nn 06:21a<DIR>      2,048 .
n/nn/nn 06:21a<DIR>      0 ..
n/nn/nn 06:21a<DIR>      2,048 boot
n/nn/nn 06:21a<DIR>      2,048 vms

Exit
```

- f. The next screen displays the files within the boot directory. Select the file named **bootia64.efi**.

```
EFI Boot Maintenance Manager ver n.nn[nn.nn]

Select file or change to new directory:

n/nn/nn 06:21a<DIR>      2,048 .
n/nn/nn 06:21a<DIR>      2,048 ..
.
.
.
n/nn/nn 06:21a          334,848 BOOTIA64.EFI
.
.
.

Exit
```

## Booting the VSI OpenVMS OE DVD from the InfoServer

To boot from a virtual DVD drive on the LAN using OpenVMS InfoServer software, you must initially perform certain configuration steps (one time only). These steps and the instructions on performing the network boot are described in “Setting Up and Performing Network Booting”.

## Booting from a Fibre Channel Device

For instructions on booting from a Fibre Channel (FC) storage device, see “Setting Up and Booting Fibre Channel Storage Devices”.

## Booting Manually from the Local System Disk

VSI recommends setting up your EFI console with a boot option for your OpenVMS system disk. In this way, booting the system disk simply requires selecting the boot option from the EFI Boot Manager boot options list. You can set the EFI boot option to boot automatically on powering on or rebooting. The OpenVMS installation and upgrade procedures can assist you in adding and validating a boot option for your system disk; you can also use the OpenVMS Boot Manager utility (SYSS\$MANAGER:BOOT\_OPTIONS.COM), as explained in “Setting Boot Options for Your System Disk”.

The steps that follow explain how to boot the OpenVMS operating system disk manually.

### Note

If you have recently booted the VSI OpenVMS OE DVD, make sure you remove this DVD before booting the system disk.

The system disk must be mounted locally (on the system you are booting) or on a SAN storage device.

1. If OpenVMS is not running, skip to the next step. If OpenVMS is running, access the EFI console by shutting down the operating system (see the instructions in “Halt and Shutdown Procedures”).
2. Boot the system disk manually by entering the following command at the EFI Shell prompt, where *fsn*: (such as fs1:) is the device associated with the system disk:

```
Shell> fsn:\efi\vms\vms_loader.efi
```

You must either specify the full path (as shown in this example) or start the system loader from the `\efi\vms` directory. For more information, see “General Notes About Using EFI”.

## Performing a Conversational (Interactive) Boot

A conversational boot is most commonly used in research and development environments and during software upgrades. Perform a conversational boot to stop the boot process before it completes. The boot process stops after it loads `SYSSYSTEM:SYSBOOT.EXE` and displays the `SYSBOOT>` prompt. At the `SYSBOOT>` prompt, you can enter specific OpenVMS System Generation utility (SYSGEN) commands to do the following:

- Examine system parameter values
- Change system parameter values
- Specify another parameter file
- Specify another system startup command procedure
- Select the default system parameter file (IA64VMSSYS.PAR) if you modified system parameters to values that render the system unbootable
- Specify a minimum startup

There are several ways to perform a conversational boot. The following procedure is the most direct:

IF ...	THEN GO TO...
OpenVMS is running.	Step 1
OpenVMS is <i>not</i> running.	Step 4

1. Log in to the SYSTEM account.
2. Enter the following command:

```
$ @SYSSYSTEM:SHUTDOWN
```

3. Answer the questions displayed by the system. When the procedure asks whether an automatic reboot should be performed, press **Enter** for NO. When the procedure is finished, it displays the following message:

```
SYSTEM SHUTDOWN COMPLETE
```

4. Halt the system or nPartition. (See “Halt and Shutdown Procedures” for more information about how to halt your server).
5. Begin the conversational boot by entering the following command at the EFI Shell prompt, where *fsn*: is the device (such as fs1:) associated with the system disk:

```
Shell> fsn:\efi\vms\vms_loader.efi -flags 0,1
```

6. At the SYSBOOT> prompt, you can enter any of the SYSGEN commands listed in “SYSGEN Commands Used by SYSBOOT Procedures”. For more information about these SYSGEN commands, see the *OpenVMS System Management Utilities Reference Manual: M-Z*.
7. When you finish using the SYSGEN commands, enter the CONTINUE command to complete the boot process.

**Table 9.1. SYSGEN Commands Used by SYSBOOT Procedures**

COMMAND	DESCRIPTION
CONTINUE	Resumes the boot procedure.
DISABLE CHECKS	Inhibits checking of parameter values specified with the SET command.
ENABLE CHECKS	Permits checking of parameter values specified with the SET command.
HELP	Displays a summary of the SYSBOOT commands on the terminal screen.
SET <i>parameter-name</i>	Establishes the value of a system parameter.
SET/STARTUP	Sets the name of the system startup command procedure.
SHOW [ <i>parameter</i> ]	Displays active, current, default, maximum, and minimum values for specific parameters. (Use qualifiers to display characteristics of parameters grouped by categories.)
USE [ <i>file-spec</i> ]	Specifies a parameter file to be used as a source of values. You must enter the entire file specification, including device and directory; you cannot specify a logical name.
USE DEFAULT	Specifies that default values be used for all parameters.

For examples of conversational booting, see “Bootting with Minimum Startup” and “Emergency Booting”.

## Bootting with Minimum Startup

In certain cases, you might want to boot your system without performing the full sequence of startup events. For example, if a startup event prevents you from logging in, you might want to boot the system without executing the startup so that you can log in and fix the problem. You can use the conversational boot to specify a minimum startup.

### Note

Because this procedure bypasses specific startup operations, it does not autoconfigure the system's peripheral devices.

Boot the system with minimum startup as follows:

1. Begin the conversational boot by entering the following command at the EFI Shell prompt, where *fsn:* is the device (such as fs1:) associated with the system disk and the system root is [SYS0...]:
 

```
Shell> fsn:\efi\vms\vms_loader.efi -flags 0,1
```
2. Enter the following command:
 

```
SYSBOOT> SET STARTUP_P1 "MIN"
```
3. Enter the following command to ensure that the operating system does not record for subsequent system reboots the STARTUP\_P1 parameter change you made in step 2:

```
SYSBOOT> SET WRITESYSPARAMS 0
```

4. Enter the following command to continue booting:

```
SYSBOOT> CONTINUE
```

## Booting with the XDelta Utility (XDELTA)

The XDelta utility (XDELTA) is a low-level debugging tool that system programmers use. The procedure for booting all servers with XDELTA is the same. .

The following table describes the valid values you can specify when booting with XDELTA:

Value	System Response
0	Normal, nonstop boot (default).
1	Begins a conversational boot and then displays the SYSBOOT prompt.
2	Includes XDELTA but does not take the initial breakpoint.
3	Displays the SYSBOOT prompt and includes XDELTA but does not take the initial breakpoint.
6	Includes XDELTA and takes the initial breakpoint.
7	Includes XDELTA, displays the SYSBOOT prompt, and takes the initial breakpoint at system initialization.

The following is an example of booting with XDELTA from fs1: at the EFI> prompt:

```
EFI> fs1:\efi\vms\vms_loader.efi -flags 0,7
```

For more information about using XDELTA, see the *OpenVMS Delta/XDelta Debugger Manual*.

## Booting from a Different Root Directory

By default, the OpenVMS operating system is installed in the system root directory [SYS0]. However, if you have created a cluster system disk, you can use the SYS \$MANAGER:CLUSTER\_CONFIG\_LAN.COM procedure to add a copy of the operating system to a different root directory. (For more information about using the SYS \$MANAGER:CLUSTER\_CONFIG\_LAN.COM procedure, see the *OpenVMS System Manager's Manual* .)

To boot from a different root (for example, [SYS3]), enter the following command at the EFI Shell prompt, where *fsn:* (such as fs1:) is the device associated with the system disk:

```
Shell> fsn:\efi\vms\vms_loader.efi -flags 3,0
```

## Emergency Booting

If a system problem prevents your system from booting, you might need to perform an emergency boot operation. The table below summarizes these emergency boot operations, and the sections that follow describe each boot operation in more detail.

**Table 9.2. Emergency Boot Procedures**

OPERATION	WHEN TO USE
Booting with default system parameters	When parameter values in the parameter file have been modified so that the system is unbootable

OPERATION	WHEN TO USE
Booting without startup and login procedures	If an error in the startup or login procedure prevents you from logging in
Booting without the user authorization file	If you have forgotten the password and cannot log in to a privileged account

## Booting with Default System Parameters

If the current values stored in the parameter file have been incorrectly modified, these incorrect values might cause the system to become unbootable. With a conversational boot operation, you can reset the active values for all system parameters to the default value. In most cases, VSI recommends that you use AUTOGEN to modify system parameters. In certain cases, however, you can use a conversational boot to modify a parameter value *temporarily*. To change a parameter value *permanently*, you must edit MODPARAMS.DAT and run AUTOGEN. For instructions, see the *OpenVMS System Manager's Manual, Volume 2: Tuning, Monitoring, and Complex Systems*. The default values allow you to boot the system temporarily so you can correct the problem.

1. Begin the conversational boot by entering the following command at the EFI Shell prompt, where *fsn*: (such as fs1:) is the device associated with the system disk:

```
Shell> fsn:\efi\vms\vms_loader.efi -flags 0,1
```

2. At the SYSBOOT> prompt, enter the following command:

```
SYSBOOT> USE DEFAULT
```

The USE DEFAULT command specifies that default values should be used for all parameters.

3. To avoid starting all layered products on a system that is not tuned for them, possibly causing the system to hang, set the STARTUP\_P1 system parameter as follows:

```
SYSBOOT> SET STARTUP_P1 "MIN"
```

4. Enter the following command to ensure that the operating system does not record for subsequent system reboots the STARTUP\_P1 parameter change you made in step 3:

```
SYSBOOT> SET WRITESYSPARAMS 0
```

5. Enter the following command to continue booting:

```
SYSBOOT> CONTINUE
```

6. When the system finishes booting, determine which changed parameter caused the problem and reset the parameter value. If you specified the value for the parameter in the AUTOGEN parameter file MODPARAMS.DAT, fix the value in that file and run AUTOGEN. For more information, see the *OpenVMS System Manager's Manual, Volume 2: Tuning, Monitoring, and Complex Systems*.

7. After your system runs for at least 24 hours, run AUTOGEN in feedback mode, following the steps described in "Running AUTOGEN". Be sure to examine the AGEN\$PARAMS.REPORT, as recommended. If necessary, modify system parameters as instructed in "Modifying System Parameters". If you need assistance, contact your software support representative. Once you feel confident that the problem is corrected, and AUTOGEN has been run through the SETPARAMS phase, reboot the system.

### Example

```
SYSBOOT> USE DEFAULT
```

```
SYSBOOT> SET STARTUP_P1 "MIN"  
SYSBOOT> SET WRITESYSPARAMS 0  
SYSBOOT> CONTINUE  
Username: SYSTEM  
Password:  
$ EDIT SYS$SYSTEM:MODPARAMS.DAT  
.  
.  
.  
[Insert line(s) to reset parameter value(s)]  
.  
.  
.
```

## Booting Without Startup and Login Procedures

If the system does not complete the startup procedures or does not allow you to log in, you might need to bypass the startup and login procedures. The startup and login procedures provided by HP should always work. However, if you introduce an error when you modify the startup or login procedure, you could accidentally lock yourself out of the system.

### How to Perform This Task

1. Begin the conversational boot by entering the following command at the EFI Shell prompt, where *fsn:* (such as *fs1:*) is the device associated with the system disk:

```
Shell> fsn:\efi\vms\vms_loader.efi -flags 0,1
```

2. Enter the following command at the SYSBOOT> prompt:

```
SYSBOOT> SET/STARTUP OPA0:
```

3. Enter the following command to ensure that the operating system does not record for subsequent system reboots the STARTUP\_P1 parameter change you made in step 2:

```
SYSBOOT> SET WRITESYSPARAMS 0
```

4. Enter the following command to continue booting:

```
SYSBOOT> CONTINUE
```

5. When the system is booted, the operator console displays the DCL command prompt (\$). You are now logged in.

6. Enter the following two DCL commands:

```
$ SPAWN  
$ SET NOON
```

The SPAWN command enables you to stay connected to the console, and the second command instructs the operating system to ignore any errors that might occur. If you do not enter these commands and you invoke an error, the system logs you out. Without the SPAWN command, you are logged out when the startup procedure completes in step 8.

7. Correct the error condition that caused the login failure. (That is, make the necessary repairs to the startup or login procedure, or to the SYSUAF.DAT file.)

Use a text editor to correct the startup or login file. Some system displays might not support a screen-mode editor. You can also copy a corrected file and delete the incorrect version by using the RENAME and DELETE commands.

8. Perform a normal startup by entering the following command:

```
$ @SYS$SYSTEM:STARTUP
```

## Example

```
SYSBOOT> SET/STARTUP OPA0:  
SYSBOOT> SET WRITESYSPARAMS 0  
SYSBOOT> CONTINUE  
$ SPAWN  
$ SET NOON  
$ SET DEFAULT SYS$SYSROOT:[SYSEXE]  
$ @SYS$SYSTEM:STARTUP
```

## Booting Without a User Authorization File

Ordinarily, the startup and login procedures provided by OpenVMS work; however, certain conditions can cause them to fail. A simple way to lock yourself out of the system is to set passwords to login accounts and forget them. Another way to be locked out is if one or more core system Product Authorization Key (PAK) software licenses are unavailable or expired. In such emergencies, perform a conversational emergency boot by performing the steps given in this section.

## How to Perform This Task

1. Halt the system or nPartition. (See “Halt and Shutdown Procedures” for more information about how to halt your server.)
2. Begin the conversational boot by entering the following command at the EFI Shell prompt, where *fsn*: (such as *fs1*:) is the device associated with the system disk:

```
Shell> fsn:\efi\vms\vms_loader.efi -flags 0,1
```

You need your hardware system’s password for logging in to the console. By default, both the user name and password are set to Admin. If you do not have this password, contact VSI or HP Customer Support to reset the hardware console password.

3. Enter the following commands at the SYSBOOT> prompt:

```
SYSBOOT> SET/STARTUP OPA0:  
SYSBOOT> SET WINDOW_SYSTEM 0  
SYSBOOT> SET WRITESYSPARAMS 0  
SYSBOOT> CONTINUE
```

The first three commands request the following:

- OpenVMS read the system startup commands directly from the system console.
- The windowing system (if any) not start.
- OpenVMS not record the parameter changes for subsequent system reboots.

The last command causes the booting to continue.

4. At the DCL prompt, the system now accepts startup commands directly from the console. Enter the following two commands. These commands allow a normal system startup while you are left logged in on the console. Without the SPAWN command, you are logged out when the startup completes.

```
$ SPAWN
```

```
$ @SYS$SYSTEM:STARTUP
```

5. Once you log out of this session, the system completes the startup and can be used normally. Optionally, you can choose to reboot the system.

## Example

```
SYSBOOT> SET/STARTUP OPA0:  
SYSBOOT> SET WINDOW_SYSTEM 0  
SYSBOOT> SET WRITESYSPARAMS 0  
SYSBOOT> CONTINUE  
$ SPAWN  
$ @SYS$SYSTEM:STARTUP  
$
```

## Note

Instead of using the SET/STARTUP OPA0: command in emergency conditions, you can set the UAFALTERNATE system parameter to use the alternate authorization file rather than the standard user authorization file. Setting the system parameter UAFALTERNATE defines the logical name SYSUAF to refer to the file SYSS\$SYSTEM:SYSUAFALT.DAT. If this file is found during a normal login, the system uses it to validate the account and prompts you for the user name and password.

VSI does not recommend this method. If an alternate SYSUAFALT.DAT file has been configured on your system, the UAFALTERNATE method will likely fail (assuming you do not know the password for the privileged account stored within the SYSUAFALT.DAT file). In addition, the OPA0: system console is critical to system operations and system security and allows access when the SYSUAF system authorization database is unavailable or corrupted; when core product license PAKs are not registered, are expired, or are disabled; and in various system failures.

# Halt and Shutdown Procedures

The following sections describe halt and shutdown procedures for OpenVMS on HP Integrity servers.

## Halting a Server to Recover from Hangs and Crashes

If your system hangs and you want to force a crash, you can use MP, if available. Use the **tc** command. Confirm your intention when prompted. The **tc** command forces a crash dump. You can reset the machine (without forcing a crash) by using the MP **rs** command.

For cell-based servers, when you enter the **tc** or **rs** command, you are first prompted to select the partition for which you want the operating system shut down.

Alternatively, when the operating system controls the console, press **Ctrl/P**. The next step taken by the system depends on whether XDELTA is loaded:

- If XDELTA is loaded, the system enters XDELTA after you press **Ctrl/P**. The system displays the instruction pointer and current instructions. You can force a crash from XDELTA by entering ;C, as in the following example:

```
$  
Console Brk at 8068AD40  
8068AD40!          add    r16 = r24, r16 ;; (New IPL = 3)  
;C
```

- If XDELTA is not loaded, pressing **Ctrl/P** causes the system to enter the IPC facility. Pressing **Ctrl/P** within the utility brings the “Crash? (Y/N)” prompt. Enter Y to cause the system to crash

and to bring you eventually to EFI. If you enter any other character, the system returns back to the IPC facility.

## Shutting Down the System

Before you shut down the operating system, decide if you want it to reboot automatically or if you want to enter console-mode commands after the shutdown completes. If you want the system to reboot automatically after the shutdown, first set up automatic booting, as described in “Setting Boot Options for Your System Disk”.

You can perform the following two types of shutdown operations, as discussed in the indicated sections:

- An orderly shutdown with SYSSYSTEM:SHUTDOWN.COM (see “Orderly Shutdown”)
- An emergency shutdown with OPCCRASH.EXE (see “Emergency Shutdown with OPCCRASH.EXE”)

### Orderly Shutdown

The SHUTDOWN.COM procedure shuts down the operating system while performing maintenance functions such as disabling future logins, stopping the batch and printer queues, dismounting volumes, and stopping user processes. To use the SHUTDOWN.COM command procedure, log in to the SYSTEM account, enter the following command:

```
$ @SYSSYSTEM:SHUTDOWN
```

For more information about the SHUTDOWN.COM command procedure, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*.

On cell-based HP Integrity servers, two special types of nPartition reboot are supported: reboot for reconfiguration, which reboots an nPartition and enables cell configuration changes to occur, and shutdown for reconfiguration, which puts an nPartition into an inactive state.

- To perform a reboot for reconfiguration from HP Integrity servers running OpenVMS in an nPartition, enter the OpenVMS @SYSSYSTEM:SHUTDOWN command, and then answer YES to the prompt that asks whether to perform an automatic system reboot.

On cell-based HP Integrity servers, an operating system reboot is equivalent to a reboot for reconfiguration. Performing a reboot for reconfiguration enables any cell assignment changes for the nPartition (for example, removing an active cell or activating a newly added cell).

The reboot for reconfiguration takes all cells assigned to the nPartition through a cell boot phase. The cells with a Yes use-on-next-boot attribute proceed through the nPartition boot phase to become active cells whose resources are available to software running on the nPartition.

- To perform a shutdown for reconfiguration of an nPartition running OpenVMS, first enter the OpenVMS @SYSSYSTEM:SHUTDOWN command and then answer NO to the prompt asking whether to perform an automatic system reboot. Next, access MP and use the **rr** command (specify the OpenVMS nPartition to shut down for reconfiguration).

A shutdown for reconfiguration takes all cells assigned to the nPartition through a cell boot phase and then stops their boot progress at the boot-is-blocked (BIB) state. When all cells assigned to the nPartition are at the BIB state, the nPartition is inactive and no software can run on the nPartition until it is manually booted past BIB.

To boot an inactive nPartition past BIB, use the MP **bo** command and specify which nPartition to make active. Booting past the BIB state involves all cells that are assigned to the nPartition and that have a Yes use-on-next-boot attribute. The cells are taken through the nPartition boot phase to become active cells whose resources are available to software running on the nPartition.

For more information about shutting down HP Integrity servers or an nPartition, see the appropriate hardware documentation.

## Emergency Shutdown with OPCCRASH.EXE

If you cannot perform an orderly shutdown with the SHUTDOWN.COM procedure, run the OPCCRASH.EXE emergency shutdown program. To run the OPCCRASH.EXE program, log in to the SYSTEM account and enter the following command:

```
$ RUN SYS$SYSTEM:OPCCRASH
```

For more information about the OPCCRASH program, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*.

On cell-based HP Integrity servers, entering the OpenVMS RUN SYS\$SYSTEM:OPCCRASH command results in the system dumping memory and then halting at the P00>>> prompt. To reset the nPartition following OPCRASH, access the nPartition console and press any key to reboot.

Using the MP **tc** command to reset an nPartition results in the system dumping memory and then automatically resetting the nPartition.

## Troubleshooting Procedures

The following sections describe procedures that you can follow if you encounter problems with your system.

### If the System Does Not Boot

If the system does not boot because a hardware problem occurs, a question mark (?) usually precedes the error message displayed on the console terminal. An example of a hardware problem is a read error on a disk. Another is a BIB condition in an nPartition on a cell-based server. You can use VFP to check the nPartition boot state. If VFP indicates that all cells in the nPartition are at BIB, the nPartition is inactive and you must use the MP **bo** command to boot the nPartition past BIB and make it active.

One way to get to the EFI Boot Manager to attempt to reboot is to use the MP **rs** command.

For more information about using VFP and MP, see your hardware documentation.

### For Hardware Problems

If you suspect a hardware problem, do the following:

1. Consult the hardware manual for your server.
2. Contact Customer Support.

### For Software Problems

When the operating system is loaded into memory, a message similar to the following is displayed on the terminal screen:

```
SYSTEM    job terminated at 12-MAR-2015 15:05:03.17
```

If the system does not display this message, a software problem has probably occurred. Do the following:

1. Turn off the system. Turn it back on and try to reboot.

2. Perform a conversational boot using the default system parameters or try one of the emergency boot procedures described in “Emergency Booting”.
3. If the system boots, run the AUTOGEN procedure. For more information about the AUTOGEN procedure, see the *OpenVMS System Manager's Manual, Volume 2: Tuning, Monitoring, and Complex Systems*.
4. If the system still doesn't boots, contact Customer Support.

## Detecting and Responding to System Problems

If your system exhibits unexpected behavior, note the following:

- If the system displays a bugcheck message on the console terminal and shuts itself down, it means the system encountered a problem that made further operation impossible or dangerous. If the system does not reboot automatically, reboot the system manually as described in “Booting Manually from the Local System Disk”.
- If the system stops responding to your commands (that is, if the system hangs), there is a possible failure in a system software or hardware component or a possible power failure.
- If the system exhibits erratic behavior (it does not respond according to specifications), it indicates a possible failure in a system software or hardware component.

To determine whether the failure is a system problem:

- Be sure that you did not press **F1 (Hold Screen)**. The Hold Screen light turns on when you press either **F1** or **Ctrl/S**.
- Press **Ctrl/T** to check the status of your process. A status line should appear indicating the name of the program that is executing and other information. If the status line does not appear, the program you are executing might be stalled or hanging. (If you have disabled **Ctrl/T** by entering the command `SET NOCONTROL=T`, or if you have set the terminal to `NOBROADCAST` mode by entering the command `SET TERMINAL/NOBROADCAST`, this procedure does not work.)
- Make sure the cable connecting the terminal or monitor to the system is secure.

If you determine that you have a system problem, take the following steps:

1. Force an exit from a stalled or hanging program by pressing **Ctrl/Y**. Pressing **Ctrl/Y** causes any work performed by the program and not saved on disk to be lost.
2. If the system is still unresponsive, halt it (see “Halting a Server to Recover from Hangs and Crashes” for more information.)
3. Note in detail the sequence of events that caused the problem and notify Customer Support.

## Setting Up and Performing Network Booting

This section explains the steps required to enable your system to boot over the LAN using the OpenVMS InfoServer utility. It also describes how to boot the virtual DVD drive from the network.

InfoServer network booting is supported for VSI OpenVMS installations and upgrades on any HP Integrity server having a DVD drive. For HP Integrity server systems, InfoServer network booting is supported on all LAN cards (also referred to as LAN devices or adapters) that are supported by EFI.

### Warning

Refer to the release notes and contact VSI if you have questions or difficulties.

For both installations and upgrades, you can boot from a virtual DVD drive on the LAN using the OpenVMS InfoServer utility. This support provides the additional advantage of allowing a network administrator to upgrade multiple OpenVMS systems on the network from a single copy of the OpenVMS distribution DVD.

Using the InfoServer utility requires several one-time-only configuration steps.

Booting from the *software* InfoServer utility differs significantly from booting from the *hardware* InfoServer system traditionally used with HP Alpha systems. For example, while HP Alpha systems use the Maintenance Operations Protocol (MOP) to request the primary bootstrap file (APB.EXE) to start the boot, the HP Integrity console uses Intel's Preboot Execution Environment (PXE) bootstrap protocol in conjunction with the TCP/IP Services for OpenVMS BOOTP server and TFTP.

The EFI console first loads the primary bootstrap file VMS\_LOADER.EFI (an EFI application). VMS\_LOADER.EFI then uses TFTP to request the primary bootstrap IPB.EXE (first IA64 application) from the *boot server*.

**Table 9.3. Enabling InfoServer Network Booting**

<b>InfoServer Client Setup</b>		
<b>ARCH</b>	<b>ACTIONS REQUIRED</b>	<b>SECTION</b>
IA64 Clients	<ol style="list-style-type: none"> <li>Determine the LAN I/O card to be used on your local server for the network boot and report the associated OpenVMS device name, its IP address, and its MAC address to the network administrator responsible for setting up the BOOTP server.</li> <li>Optionally (and recommended), add this network device as an EFI boot option—this procedure can be repeated on any other system in the LAN that will use the InfoServer server for network booting.</li> <li>Verify that the network device is supported by EFI as a bootable device.</li> </ol>	Section InfoServer Client Setup
<b>InfoServer Utility Setup</b>		
<b>ARCH</b>	<b>ACTIONS REQUIRED</b>	<b>SECTION</b>
IA64 Servers	Designate at least one OpenVMS system in the LAN as the InfoServer server. Upgrade the system if necessary (OpenVMS HP Integrity must be Version 8.2-1 or later).	Upgrade Procedure
IA64	<ol style="list-style-type: none"> <li>Copy SYSSSTARTUP:ESS \$LAD_STARTUP.TEMPLATE to SYS \$STARTUP:ESS\$LAD_STARTUP.DAT and then modify parameters in SYSSSTARTUP:ESS \$LAD_STARTUP.DAT.</li> <li>Determine which network device will be used for InfoServer LAD operations.</li> <li>Copy SYSSSTARTUP:ESS \$LAST_STARTUP.TEMPLATE to SYS \$STARTUP:ESS\$LAST_STARTUP.DAT and then modify parameters in SYSSSTARTUP:ESS \$LAST_STARTUP.DAT.</li> <li>Add a line to SYS \$MANAGER:SYSTARTUP_VMS.COM to start the SYSSSTARTUP:ESS\$LAD_STARTUP.COM file at startup.</li> </ol>	Section InfoServer Server Setup

5. If you changed any SYSGEN parameters, run AUTOGEN and reboot; if you did not change SYSGEN parameters, skip the reboot and execute the SYSSSTARTUP:ESS\$LAD\_STARTUP.COM file manually.
6. Use the InfoServer control program to create a service for the DVD drive.

IA64 Servers Set up the TCP/IP Services for OpenVMS BOOTP Section Infoserver BOOTP server and TFTP server. (For each new release of Setup. OpenVMS, update the client entries in the BOOTP database to point to the new version-specific boot file.) The person responsible for setting up the boot server needs information about your InfoServer client. OpenVMS boot files are unique for each version of OpenVMS. Latest boot files must be available and referenced in the BOOTP server database.

---

### Note

The discussion of InfoServer booting in this manual pertains to environments where the boot clients and servers are located in the same LAN. For more complex circumstances, consult with Customer Support.

## Setting Up Your System as an InfoServer Client

To set up your local OpenVMS system as an InfoServer client for network booting, you must perform the following steps.

1. Determine the LAN I/O card to be used on your local HP Integrity server for the network boot. Report the associated OpenVMS device name and its IP address and MAC address to the network administrator responsible for setting up the BOOTP server.
2. Optionally (and recommended), add the network device as a boot option in the EFI Boot Manager menu.
3. Verify that the network device is supported by EFI as a bootable device.

### Note

The ability to boot over the network requires that the nearest switch or router be configured to autonegotiate.

## Determining the Local Network I/O Card to Be Used

Select a LAN I/O card (also referred to as a LAN I/O device or adapter) on your HP Integrity server. This device must be supported by EFI firmware. At minimum, EFI supports the *core I/O* LAN cards installed in an HP Integrity server. On all HP Integrity servers, devices supported by OpenVMS are either EI or EW devices (for example, EIA0 or EWA0). The EFI firmware might also support variants of the core I/O cards, such as additional network interface cards (NICs) of the same type. It might also support other NICs that are installed in the system but not classified as core I/O cards. In any case, you can verify that the device you select is supported by EFI.

If multiple I/O cards are available on your system, you can choose more than one to serve for network booting.

To list the installed LAN I/O devices known to your system, follow these steps:

1. If your operating system is not running, access the OpenVMS DCL triple dollar sign prompt (\$ \$\$) from your VSI OpenVMS OE DVD Installation Menu by selecting Option 8 (Execute DCL commands and procedures). Otherwise, skip to the next step.
2. At the DCL prompt, enter the following command to start the OpenVMS Boot Manager utility.

```
@SYS$MANAGER:BOOT_OPTIONS
```

3. Start the LANCP utility and enter the LANCP command SHOW CONFIGURATION at the LANCP prompt, as in the following example. The resulting display lists four LAN devices, two of which are available (connected), as indicated by the Link column (Up means the device is available; Down means it is not). You can use a device that is in use by other protocols. Decide which available devices you want to use for network booting and record the device's name, MAC address, and IP address. (The MAC address should be labeled on the physical device.) Once the LAN device is verified as bootable by EFI, you provide this information to the person responsible for maintaining the BOOTP server database (see "Setting Up the BOOTP Boot Server and TFTP Server").

```
$$$ RUN SYS$SYSTEM:LANCP
LANCP> SHOW CONFIGURATION
LAN Configuration:
```

Device	Parent or PrefCPU	Medium/User	Version	Link	Speed	Duplex	Auto	BufSize	MAC Ad
EIA0	0	Ethernet	X-21	Up	1000	Full	Yes	1500	AA-00-04 00-13-21
EIB0	1	Ethernet	X-21	Up	1000	Full	Yes	1500	AA-00-04 00-13-21
EWA0	0	Ethernet	X-59	Down	-	-	Yes	1500	00-11-0A
EWB0	1	Ethernet	X-59	Down	-	-	Yes	1500	00-11-0A

## Adding the Network Boot Option to the EFI Boot Manager

To add the LAN device (virtual DVD drive) as a network boot option, use the OpenVMS Boot Manager utility, as follows:

1. At the DCL prompt, enter the following command to start the OpenVMS Boot Manager utility:

```
$ @SYS$MANAGER:BOOT_OPTIONS
```

### Note

When booting OpenVMS Version 8.4 or later, you need to specify a special boot flag and the name of InfoServer service name. The BOOT\_OPTIONS.COM procedure now accepts InfoServer service name in addition to the boot flags.

2. The OpenVMS Boot Manager Boot Options main menu is displayed. To add a network boot option, enter 1 at the prompt:

```
OpenVMS Boot Manager Boot Options List Management Utility
```

- (1) ADD an entry to the Boot Options list
- (2) DISPLAY the Boot Options list
- (3) REMOVE an entry from the Boot Options list
- (4) MOVE the position of an entry in the Boot Options list

## OpenVMS, Hardware and Boot Operations

- (5) VALIDATE boot options and fix them as necessary
- (6) Modify Boot Options TIMEOUT setting

- (B) Set to operate on the Boot Device Options list
- (D) Set to operate on the Dump Device Options list
- (G) Set to operate on the Debug Device Options list

- (E) EXIT from the Boot Manager utility

You can also enter Ctrl-Y at any time to abort this utility

Enter your choice: **1**

### Note

While using this utility, you can change a response made to an earlier prompt by entering the caret (^) character as many times as needed. To end and return to the DCL prompt, press **Ctrl/Y**.

3. Enter the device name. In the following example, the device name is EIA0:

Enter the device name (enter "?" for a list of devices): **EIA0:**

4. Enter the position you want your entry to take in the EFI boot option list. Enter any position number other than 1. (The number 1 position sets the device for automatic rebooting, which is not desirable for upgrades.)

Enter the desired position number (1,2,3,,,) of the entry.  
To display the Boot Options list, enter "?" and press Return.  
Position [1]: **4**

5. Enter boot flags. By default, no flags are set. Enter the OpenVMS flags (for example, 0,1), or accept the default (NONE) to set no flags as in the following example:

Enter the value for VMS\_FLAGS in the form n,n.  
VMS\_FLAGS [NONE]:

If you are booting OpenVMS Version 8.4 onwards, VSI recommends the value of VMS\_FLAGS be set to 0,200400.

6. Enter the service name from OpenVMS Version 8.4 onwards if you have entered 0,200400 as the boot flags. The service name is mandatory.

INFOSERVER\_SERVICE:

### Note

The service name entered must be in uppercase.

7. The utility asks whether the device will be used for cluster satellite booting. Answer NO as in the following example:

Will EIA0 be used for cluster satellite boot? (Yes/No): **NO**

(For information about establishing a device for cluster satellite booting, see the *HP and VSI OpenVMS Cluster Systems* manuals.)

8. Enter a description to include with your boot option entry. By default, the device name and MAC address is used as the description. You can enter more descriptive information, as in the following

## OpenVMS, Hardware and Boot Operations

example. As shown in the display of boot entries that follows, the device name and MAC address (without dashes) are included anyway in the boot entry line.

```
Enter a short description (do not include quotation marks).  
Description ["EIA0"]: I64 UPGRADE VIA NET
```

```
efi$bcfg: eia0 (Boot0002) Option successfully added
```

Using the utility to display the devices at this point (selecting 2 on the main menu), you see your device listed, as in the following example:

```
Enter your choice: 2
```

```
To display all entries in the Boot Options list, press Return.  
To display specific entries, enter the entry number or device name.  
(Enter "?" for a list of devices):
```

```
EFI Boot Options list: Timeout = 10 secs.
```

```
-----  
01. DKB0 PCI(0|20|1|1) Scsi(Pun0,Lun0) "Boot VMS from DKB0" OPT  
02. DKB200 PCI(0|20|1|1) Scsi(Pun2,Lun0) "Boot VMS from DKB200" OPT  
03. VenHw(d65a6b8c-71e5-4df0-d2f009a9) "EFI Shell [Built-in]"  
04. EIA0 PCI(0|0|2|0) Mac(0013215b85e4) "I64 Upgrade VIA NET"  
-----
```

```
4 entries found.
```

9. Exit the utility by entering E at the prompt:

```
Enter your choice: E
```

### Note

The Boot Configuration Menu provided by EFI or the EFI tool VMS\_BCFG are other alternatives for adding a boot entry. For more information on EFI tools, see the *System Management Utilities Reference Manual*.

## Verifying the Network I/O Device Is Bootable by EFI

Finally, verify that the LAN device you selected for your system's InfoServer client is bootable by EFI. Verification is recommended if the selected device is not one of the core I/O LAN devices installed on your server. To verify that the selected LAN device is bootable by EFI, follow these steps:

1. Access the EFI console for your server. If your operating system is running, you must shut down your system to access EFI. (For details about accessing and using EFI, see your hardware documentation.)
2. From the EFI main menu, select the Boot Configuration option (or in some versions of EFI, the Boot Option Maintenance Menu). Make a selection before the EFI timeout expires; otherwise, the first entry of the EFI Boot Manager is selected automatically. If you are brought to the EFI Shell prompt, enter the **exit** command at the prompt to move back to the EFI main menu. If an autoboot begins, you can perform a cold reset of the server to get back to the EFI console. (For more information, see your hardware documentation.) Otherwise, you must wait for your system to boot and shut it down again.
3. At the EFI Boot Configuration menu, select the Boot From a File option. In the Boot From a File list, look for the load file that corresponds to the LAN device you selected for network booting. This is the load file with a matching MAC address, as in the following example:

```
Load File [Acpi(HWP0002,0)/Pci(2|0)/Mac(0013215b85e4)]
```

The MAC address of the EIA0 network device selected earlier was 00-13-21-5B-85-E4, which matches the MAC address shown (without dashes). This verifies that the selected device is visible to the EFI console. If none of the Boot From a File options listed matches your selected device, then try another available device (as listed with the LANCP command SHOW CONFIGURATION in “Determining the Local Network I/O Card to Be Used”).

4. Provide the device name and its IP address and MAC address to the person responsible for setting up the BOOTP server.

## Setting Up the InfoServer Server

At least one system in the LAN must be designated as the InfoServer SERVER. For OpenVMS Version 8.4 and later, if you select to boot via memory disk by specifying the appropriate boot flag and service name, make sure that the LAN server and the Boot server are the same system. This is the system that hosts the physical DVD drive from which network booting is performed. This system must be running OpenVMS Version 8.2-1 or later for HP Integrity. The InfoServer software comes as part of the base operating system on these systems.

The following steps are necessary to set up the InfoServer software on the designated system:

1. Copy SYSS\$STARTUP:ESS\$LAD\_STARTUP.TEMPLATE to ESS\$LAD\_STARTUP.DAT (save the ESS\$LAD\_STARTUP.TEMPLATE file as a backup).
2. Edit SYSS\$STARTUP:ESS\$LAD\_STARTUP.DAT to modify parameters as needed. This file configures InfoServer parameters affecting the OpenVMS LASTport/Disk (LAD) server, which allows access to the DVD drive. The following is an example of the configuration file (with default settings):

```
!++
! ESS$LAD_STARTUP.TEMPLATE
!
! Copy this file to SYSS$STARTUP:ESS$LAD_STARTUP.DAT and edit it
! to suit your local situation.
!
! This file is used by SYSS$STARTUP:ESS$LAD_STARTUP.COM to set up
! the parameters for the InfoServer Application on OpenVMS
! LASTport/Disk (LAD) server.
!
! Note:
! The LAD disk block cache is structured as a number of fixed-size
! buckets. You must specify both the bucket size and the number of
! buckets for the cache.
!
! The LAD cache is allocated from non-paged pool and is in no way
! associated with the XFC cache. The total LAD cache size in bytes
! may be determined by the formula:
!
! cache-bytes = bucket-size-in-blocks * number-of-buckets * 512
!
! Be sure the SYSGEN parameters NPAGDYN/NPAGEVIR are sized appropriately.
!
! The following keywords with values are accepted by this procedure:
!
!     BUFFER_SIZE - A number between 3 and 8 denoting the
!                   bucket size in blocks as follows:
!                   3 - 8 blocks
!                   4 - 16 blocks
!                   5 - 32 blocks
```

## OpenVMS, Hardware and Boot Operations

```

!           6 - 64 blocks
!           7 - 128 blocks
!           8 - 256 blocks
!   CACHE_BUCKETS - Number of buckets
!   MAXIMUM_SERVICES - Maximum number of services (max=1024)
!   WRITE_LIMIT - Server wide count of asynchronous writes
!--

BUFFER_SIZE = 3           ! default (8 block buckets)
CACHE_BUCKETS = 512      ! Default setting
WRITE_LIMIT = 0          ! No async writes
MAXIMUM_SERVICES = 256   ! default (typically more than enough)

```

The following table provides a short description of each of the parameters:

PARAMETER	DESCRIPTION												
BUFFER_SIZE	<p>The InfoServer block cache is structured as an array of fixed-size buffers (also called buckets). The BUFFER_SIZE parameter determines the size of each buffer or bucket. The numeric value of this parameter is an integer in the range 3 through 8, representing the bucket size in 512-byte blocks as follows. Bucket sizes larger than 32 blocks might not be appropriate for most users. The OpenVMS client segments I/O requests larger than 31 blocks into 31-block chunks, which could result in excessive I/O activity to the disk. The cache is allocated from nonpaged pool and is dedicated solely to the LAD driver.</p> <table style="margin-left: 40px;"> <tr><td>3</td><td>8 blocks (default)</td></tr> <tr><td>4</td><td>16 blocks</td></tr> <tr><td>5</td><td>32 blocks</td></tr> <tr><td>6</td><td>64 blocks</td></tr> <tr><td>7</td><td>128 blocks</td></tr> <tr><td>8</td><td>256 blocks</td></tr> </table>	3	8 blocks (default)	4	16 blocks	5	32 blocks	6	64 blocks	7	128 blocks	8	256 blocks
3	8 blocks (default)												
4	16 blocks												
5	32 blocks												
6	64 blocks												
7	128 blocks												
8	256 blocks												
CACHE_BUCKETS	Determines the number of buckets in the cache. The default is 512. Numbers larger than 16384 might adversely affect performance. To reach a desirable cache size, consider increasing the BUFFER_SIZE parameter.												
MAXIMUM_SERVICES	Sets the maximum number of services that can be defined at one time for the server. The value of this parameter must be a power of 2. The default and minimum value is 256 (adequate for most circumstances); the maximum value is 1024. Each service descriptor consumes nonpaged pool; however, unused services consume 4 bytes each.												
WRITE_LIMIT	The number of asynchronous write operations that can be outstanding for the server at any time. The default is 0 (no outstanding asynchronous write operations).												

### Note

As indicated in the file comments, the LAD cache comes out of nonpaged pool. If you increase the cache significantly, you might need to increase the nonpaged pool SYSGEN parameters (NPAGEDYN and NPAGEVIR).

- Determine which network device will be used for InfoServer LAD operations. You can use any network device that is visible to OpenVMS. Typically, any network device that works with DECnet or TCP/IP Services for OpenVMS should work. Use the LANCP command SHOW

## OpenVMS, Hardware and Boot Operations

CONFIGURATION to determine which device to use, as described in “Determining the Local Network I/O Card to Be Used”.

For this release of OpenVMS, the LASTport protocol runs on only a single network device. To enable this device, copy the SYS\$STARTUP:ESS\$LAST\_STARTUP.TEMPLATE file to the SYS\$STARTUP:ESS\$LAST\_STARTUP.DAT file, and then open the SYS\$STARTUP:ESS\$LAST\_STARTUP.DAT file and make the following changes:

- a. Remove the comment character (!) from the line that has the following text: DEVICE = (). Within the parentheses, specify the device name. For example: DEVICE = (EIA).
- b. Comment out the line that specifies ALL\_CONTROLLERS = ON (comment out a line by inserting an exclamation point (!) at the beginning of the line).

The following example shows the SYS\$STARTUP:ESS\$LAST\_STARTUP.DAT file with the suggested changes made (shown in **bold**):

```
!++
! This file will be used to set the appropriate LASTTCP qualifiers. The foll
! LASTTCP qualifiers: ALL_CONTROLLERS, CHECKSUM, TRANSMIT_QUOTA, or SLOW_MOD
! can be set by using the following statement format:
! LASTTCP qualifier = 1 to enable e.g. SLOW_MODE = 1 enables SLOW_MODE
! LASTTCP qualifier = 0 to disable e.g. SLOW_MODE = 0 disables SLOW_MODE
! The remaining LASTTCP qualifiers will require the appropriate value settin
DEVICE = (EIA) ! Uncommented; device name specified
! TIMEOUT = n minimum interval in seconds
! CIRCUIT_MAXIMUM = n maximum number of nodes
! GROUP = n Group number
! NODE_NAME = name Node name
! CONTROLLERS = ([{controller letter,}...]) Controller list
! TRANSMIT_QUOTA = n Number of transmit buffers
!--
!ALL_CONTROLLERS = ON ! Commented out
```

4. Add the following line to the system startup file SYS\$MANAGER:SYSTARTUP\_VMS.COM:

```
@SYS$STARTUP:ESS$LAD_STARTUP.COM
```

5. If you changed any SYSGEN parameters, run AUTOGEN and reboot (for information about running AUTOGEN, see “Running AUTOGEN”). If no SYSGEN parameters were changed, you can skip the reboot and execute the SYS\$STARTUP:ESS\$LAD\_STARTUP.COM file manually.

After you complete these steps, the InfoServer server software is running and available to serve boot requests. The network devices are LAD0 (the LAD Server Virtual Device) and LAST0 (the LAST Transport Layer Virtual Device).

6. The InfoServer server can run on the same system as the InfoServer client. You might want to start the InfoServer client on this system, allowing the system to mount InfoServer devices. To start the InfoServer on this system, enter the following command at the DCL prompt:

```
@SYS$STARTUP:ESS$STARTUP DISK
```

To have the InfoServer client start at system boot, include the command in SYS\$MANAGER:SYSTARTUP\_VMS.COM.

7. Now that you have set up and enabled the InfoServer server, you must use the InfoServer control program to create a service for the DVD drive. Follow these steps:
  - a. Mount the OpenVMS distribution media system-wide. In the following example, DQA0 is the DVD drive name (typically, DQA0 or DNA0 is the drive name) and I64084 is the OpenVMS volume label:

```
$ MOUNT/SYSTEM DQA0 I64084
```

- b. Enter the following command at the DCL prompt to define the InfoServer control program as a foreign command, or enter the line in a startup or login command file:

```
$ INFOSERVER := $ESS$INFOSERVER
```

Alternatively, you can enter the following command to start the program:

```
$ RUN SYS$SYSTEM:ESS$INFOSERVER
```

- c. Start the InfoServer control program and create the service, as in the following example (the colon after the device name DQA0 is required):

```
$ INFOSERVER  
INFOSERVER> CREATE SERVICE I64084 DQA0:  
INFOSERVER> EXIT
```

The created service should now be available for any InfoServer clients in the same LAN (these clients broadcast service solicitations over the LAN).

Started as in this example, the InfoServer control program accepts multiple commands until you exit by entering the EXIT command (or pressing **Ctrl/Z**). You can also enter a single command at the DCL prompt, returning you immediately to the DCL prompt again:

```
$ INFOSERVER CREATE SERVICE I64084 DQA0:  
$
```

The InfoServer control program commands are similar, though not identical, to those supported by the hardware InfoServer used traditionally by OpenVMS Alpha systems. For more information, see the InfoServer help (at the **InfoServer** prompt, enter **HELP**) or the *OpenVMS System Management Utilities Reference Manual*.

## Setting Up the BOOTP Boot Server and TFTP Server

The BOOTP boot server for the OpenVMS InfoServer utility can be on the same system or on any system in the same LAN as the InfoServer application for OpenVMS Version 8.3-1H1 and lower. For OpenVMS Version 8.4 onwards, when booting via memory disk, make sure that the BOOTP server and LAN server is the same system. TFTP is required on the boot server for supplying the boot files to the client systems.

The steps necessary to set up the boot server and boot files are as follows:

### Note

All instructions and examples assume the use of TCP/IP Services for OpenVMS. Other IP products might work but have not been tested and are not supported at this time.

### Important

You do not have to perform steps 2 and 3 when booting an HP Integrity server running OpenVMS Version 8.4 or later if boot flags are set to 0,200400.

1. Make sure TCP/IP Services for OpenVMS is installed and that:
  - At least one IP interface is defined.

- The BOOTP server and TFTP server are configured and started.
- Optionally, make sure TELNET and FTP are configured and started.

To display IP interface information, use the TCPIP SHOW INTERFACE command.

To verify that the BOOTP and TFTP servers are configured and started, use the TCP/IP Services for OpenVMS SYSS\$MANAGER:TCPIP\$CONFIG.COM configuration procedure. From the Main Configuration menu, select option 3 (Server components). If a BOOTP or TFTP service is not enabled and started, select the appropriate server option, and then enable and start the service accordingly. For more information about configuring and starting TCP/IP Services for OpenVMS components, see the *TCP/IP Services for OpenVMS Installation and Configuration* and *TCP/IP Services for OpenVMS Management* manuals.

## Note

If you are currently using the DHCP service, you must disable it. The BOOTP service must be enabled instead. For information about disabling or enabling services, see the *TCP/IP Services for OpenVMS Management* manual.

2. Set up a location for boot files by creating the directory accessible by TFTP, as in the following example. (VSI recommends that you create a separate boot file directory for each version of the operating system.)

```
$ CREATE/DIRECTORY TCPIP$TFTP_ROOT:[V831H1]
```

## Important

For each subsequent upgrade of OpenVMS, you must create a separate directory for the boot files specific to the OpenVMS version and, where appropriate, modify the path specified for each client's boot files (as in step 6). To make subsequent upgrades easier, you can use systemwide or clusterwide logical names.

3. Copy the following two files from the DVD to the **TCPIP\$TFTP\_ROOT:[V831H1]** directory:
  - **[SYS0.SYSCOMMON.SYSEXE]VMS\_LOADER.EFI**
  - **[SYS0.SYSCOMMON.SYSEXE]IPB.EXE**
4. Gather data for each boot client (that is, each node that is going to boot the DVD over the network), including the following information for the client's network device (the client servers' core I/O card):
  - IP address
  - MAC address
5. Define each boot client's host name in the TCP/IP Services for OpenVMS local host database using the TCPIP SET HOST command. In the following example, *hostname* is the host name of the boot client and *ipaddress* is its IP address.

```
$ TCPIP SET HOST hostname/ADDRESS=ipaddress
```

The IP address does not have to be the actual address you plan to use for the boot client host; it must be in the same LAN as the BOOTP server and must not be currently in use. However, if you use statically assigned IP addresses, VSI recommends (for simplicity) using the assigned address of the boot client's network device. To display and verify the assigned IP address, use the TCPIP SHOW HOST command.

6. For each boot client, add an entry in the BOOTP database to associate the MAC address of the client's LAN device with the boot file to be loaded from the boot server, as in the following

example. In this example, *hostname* is the host name of the boot client, and *MACaddress* is the client's MAC address in the format *xx-xx-xx-xx-xx*. The boot file specification need not include "TCPIP\$TFTP\_ROOT:", if steps 2 and 3 were performed and VMS\_LOADER.EFI and IPB.EXE are copied to the newly created directory. Otherwise, the boot file specification is the complete path for VMS\_LOADER.EFI and in the below example, it is in the DVD identified by device DQA0:

```
$ TCPIP SET BOOTP hostname /HARDWARE=ADDRESS=MACaddress-
_$ /FILE=[V831H1]VMS_LOADER.EFI (For Version 8.3-1H1 and lower)
$ TCPIP SET BOOTP hostname /HARDWARE=ADDRESS=MACaddress-
_$ /FILE=DQA0:[SYS0.SYSCOMMON.SYSEXE]VMS_LOADER.EFI (For Version 8.4 and hi
```

You might need to specify a gateway (/GATEWAYS) and network mask (/NETWORK\_MASK). To determine the names of the gateways and the subnet information, consult your network administrator. For more information about this command, see the TCP/IP Services for OpenVMS documentation. To display and verify your BOOTP server configuration, use the TCPIP SHOW BOOTP/FULL command.

## Important

For each new version of OpenVMS, you must modify the client entry in the BOOTP database to point to the new, version-specific boot file.

The following example shows the commands for setting up a boot server for a client named MOZART. An explanation of each command follows the example.

### Example 9.1. Setting Up the Boot Server and Client (for Version 8.3-1H1 and Lower)

```
$ CREATE/DIRECTORY TCPIP$TFTP_ROOT:[V831H1] ❶
$ COPY DQA0:[SYS0.SYSCOMMON.SYSEXE]VMS_LOADER.EFI TCPIP$TFTP_ROOT:[V831H1]VMS_L
$ COPY DQA0:[SYS0.SYSCOMMON.SYSEXE]IPB.EXE TCPIP$TFTP_ROOT:[V831H1]IPB.EXE ❷
$ TCPIP SET HOST MOZART/ADDRESS=1.1.110.117 ❸
$ TCPIP SET BOOTP MOZART/HARDWARE=ADDRESS=00-13-21-5B-85-E4 -
_TCPIP> /FILE=[V831H1]VMS_LOADER.EFI ❹
$ TCPIP SHOW HOST MOZART ❺
```

```
      BIND Database
Server:  1.1.128.41
```

```
Host address      Host name
16.32.110.117    MOZART...
```

```
$TCPIP SHOW BOOTP MOZART/FULL ❻
```

```
Host:            1.1.110.117    mozart
```

```
Hardware Address: 00-13-21-5B-85-E4
```

```
Network mask:    255.0.0.0
```

```
Type:           Ethernet
```

```
File:            [V831H1]VMS_LOADER.EFI
```

```
Time offset:     0
```

```
Vendor: ACME, Inc.
```

```
Gateways:       not defined
```

```
Servers:
```

```
.
.
```

- ❶ Creates the directory TCPIP\$TFTP\_ROOT:[V831H1] on the system to be the TFTP and BOOTP server.
- ❷ Copies [SYS0.SYSCOMMON.SYSEXE]VMS\_LOADER.EFI from the DVD to TCPIP\$TFTP\_ROOT:[V831H1].
- ❸ Copies [SYS0.SYSCOMMON.SYSEXE]IPB.EXE from the DVD to TCPIP\$TFTP\_ROOT:[V831H1].
- ❹ Adds the boot client host MOZART to the TCP/IP hosts database, specifying MOZART's IP address as 1.1.110.117.
- ❺ Adds host MOZART as a client entry in the BOOTP database, where the MAC address of the client's LAN device is 00-13-21-5B-85-E4 (as was determined in the example for the client in "Determining the Local Network I/O Card to Be Used") and the boot file for the client is [V831H1]VMS\_LOADER.EFI.
- ❻ Displays information about the boot client MOZART as stored in the local host database (use this command to verify that the client has been configured appropriately).
- ❼ Displays information about the boot client MOZART as stored in the BOOTP database (use this command to verify that the client has been configured appropriately).

### Example 9.2. Setting Up the Boot Server and Client (for Version 8.4 and Higher)

```

$ TCPIP SET HOST MOZART/ADDRESS=1.1.110.117 ❶
$ TCPIP SET BOOTP MOZART/HARDWARE=ADDRESS=00-13-21-5B-85-E4 -
$_TCPIP> /FILE=DQA0:[SYS0.SYSCOMMON.SYSEXE ]VMS_LOADER.EFI ❷
$ $ TCPIP SHOW HOST MOZART ❸

      BIND Database
Server:  1.1.128.41

Host address      Host name
16.32.110.117    MOZART...
$TCPIP SHOW BOOTP MOZART/FULL ❹

Host:             1.1.110.117    mozart

                                     Hardware Address: 00-13-21-5B-85-E4
Network mask: 255.0.0.0          Type:      Ethernet
File:             [DQA0: [SYS0.SYSCOMMON.SYSEXE ]VMS_LOADER.EFI

Time offset:             0
Vendor: ACME, Inc.

Gateways:             not defined

Servers:
.
.
.

```

- ❶ Adds the boot client host MOZART to the TCP/IP hosts database, specifying MOZART's IP address as 1.1.110.117.
- ❷ Adds host MOZART as a client entry in the BOOTP database, where the MAC address of the client's LAN device is 00-13-21-5B-85-E4 (as was determined in the example for the client in Section B.2.1 (page 191)) and the boot file for the client is DQA0:[SYS0.SYSCOMMON.SYSEXE]VMS\_LOADER.EFI.
- ❸ Displays information about the boot client MOZART as stored in the local host database (use this command to verify that the client has been configured appropriately).

- 4 Displays information about the boot client MOZART as stored in the BOOTP database (use this command to verify that the client has been configured appropriately).

After you complete these steps, in addition to the required steps in the preceding sections, you can boot a client over the network using the InfoServer application. Instructions on performing the InfoServer boot are in “Booting OpenVMS from the InfoServer”. A troubleshooting section is included in “Troubleshooting InfoServer Boot Problems”.

## Booting OpenVMS from the InfoServer

After you set up the InfoServer software and the boot server properly and ensure that the InfoServer service is available, you can boot the remote DVD served by the InfoServer by following these steps:

### Note

You can copy the DVD to an LD device and boot from the LD device. This process is faster than using a DVD.

1. Make sure the DVD is mounted systemwide on the OpenVMS system serving as the InfoServer, and make sure an InfoServer service for the DVD drive is available on the network and accessible from your client system (the system to be booted from the InfoServer). The service should point to the server DVD drive on which the OpenVMS DVD is mounted. To ensure that the InfoServer service is available on the network, use the following command:

```
$ MC ESS$LDACP SHOW SERVICES
```

The following is a sample display:

```
Interrogating network for Disk services, please wait...
```

```
.  
. .  
. .
```

```
Disk services offered by node MOOSIC (LAD V3.1, Address: AA-00-04-00-AB-4E)
```

Service:	Device:	Rating:	Current Connects:	Writes Allowed?:
I64084	OpenVMS	65535	0	No
.	.	.	.	.
.	.	.	.	.
.	.	.	.	.

In this example, the service I64084 is the virtual disk unit that corresponds to the DVD drive on the InfoServer server named MOOSIC. This is the drive from which the OpenVMS distribution media is booted. The display shows that this service is available and that a service binding to the InfoServer DVD drive is established.

2. Access EFI on your server. If you added a boot option for network (InfoServer) booting to the EFI Boot Manager options list, as described in “Adding the Network Boot Option to the EFI Boot Manager”; then select the appropriate boot option from the list. To move to the option, use the up or down arrow key. (Depending on how your terminal emulator is set up, you might have to use the letter v to scroll down or the caret (^) to scroll up.) Press **Enter** to toggle the selection. After selecting the boot option, skip to step 3.

### Note

If you do not select an option within the default 10-second limit, the first option in the list is selected automatically.

If you did not add a boot option for InfoServer booting to the EFI Boot Manager options list, then initiate the boot by either following the steps in “Booting with the EFI Boot Manager” or, on some of the more recent HP Integrity servers, using the simpler method described in “Booting with EFI **lanboot select** command”.

## Booting with the EFI Boot Manager

- a. From the EFI Boot Manager screen, select the Boot Configuration option (or in some versions of EFI, the Boot Option Maintenance Menu).
- b. From the EFI Boot Configuration menu, select the Boot From a File option.
- c. The Boot From a File menu lists the bootable devices (in EFI terminology, load files), including their MAC addresses. The composition of the list depends on how your server is set up. Select the appropriate device (search for the correct MAC address). For example, the following load file listed in the Boot From a File menu corresponds to the LAN device with MAC address 00-13-21-5B-85-E4:

```
Load File [Acpi(HWP0002,0)/Pci(2|0)/Mac(0013215b85e4)]
```

Each device is identified by the unique MAC address assigned to the device by the hardware vendor. Normally, the MAC address is labeled on the physical device. See your hardware documentation for more information.

To further help you identify the LAN devices, you can use the EFI **pci** command, which displays all devices. Alternatively, you can try each of the LAN devices one at a time until you find the right one. Finally, you can make sure all LAN devices are connected to the appropriate network and are bootable using the InfoServer, in which case it does not matter which one you select. Note also that once you have OpenVMS running, you can display the devices and their corresponding MAC addresses by using the LANCP command SHOW CONFIG at the DCL prompt. The command lists the OpenVMS device names along with the MAC address and other characteristics. Likewise, with OpenVMS running, the EFI Utilities for OpenVMS **vms\_show** command might provide additional information about any devices on the local system.

## Booting with EFI lanboot select command

For OpenVMS Version 8.3-1H1 and lower:

- a. From the EFI Boot Manager screen, select the EFI Shell [Built-in] option.
- b. At the Shell prompt, enter the **lanboot select** command.
- c. When prompted, enter the number for the LAN device that has the MAC address.

For OpenVMS Version 8.4 and later:

- a. From the EFI Boot Manager screen, select the EFI Shell [Built-in] option.
- b. At the Shell prompt, enter the following commands to setup appropriate boot flags and service name:

```
Shell> SET VMS_FLAGS 0,200400  
Shell> SET INFOSERVER_SERVICE I64084
```

(where I64084 is the InfoServer service name to be used for booting/installation. The service name entered must be in uppercase.)

## OpenVMS, Hardware and Boot Operations

- c. Now enter **lanboot select** at the shell prompt. When prompted, enter the number for the LAN devices that have the MAC address specified when you configured BOOTP in “Setting Up the BOOTP Boot Server and TFTP Server”.

An alternate to this is to setup a Directed Boot profile by specifying the flags and InfoServer service name as part of optional data in the following manner.

```
dbprofile -dn <profile name> -sip <server IP address> -cip <Client IP address>
```

For more information on the DBPROFILE command, see the EFI online help. Now execute the **lanboot select** command as follows:

```
lanboot select -dn <profile name>
```

3. When you select the appropriate entry, you see several lines of messages and then the InfoServer boot menu (the same boot menu you would see on an Alpha system), as in the following examples. The DHCP (Dynamic Host Communication Protocol) message indicates the loading of the loader image (VMS\_LOADER.EFI) that uses the EFI console to load and start the OpenVMS bootstrap (IPB.EXE). The Trivial File Transfer Protocol (TFTP) loads the bootstrap. In the first example, “HP Integrity Server Upgrade VIA NET” is the boot option for the InfoServer service. It was selected from the EFI Boot Manager options list (not shown). In the second example, you notice the loading of memory disk message prior to IPB load. Since the service name is pre-decided by setting the environment variable or have specified it through BOOT\_OPTIONS.COM, the InfoServer service menu is not displayed in the second example.

### Example 9.3. DHCP Messages

```
Loading.: Network Boot, 10/100  
Running LoadFile()
```

```
CLIENT MAC ADDR: 00 13 21 5H 85 E4  
DHCP. /  
CLIENT IP: 1.1.24.219   MASK: 255.0.0.0   DHCP IP: 0.240.0.0  
Running LoadFile()
```

```
Starting: I64 Upgrade VIA NET  
%EIA-I-BOOTDRIVER, Starting auto-negotiation  
%EIA-I-BOOTDRIVER, Auto-negotiation selected 100BaseTX FDX
```

```
Network Initial System Load Function  
Version 1.2
```

FUNCTION ID	FUNCTION
1 -	Display Menu
2 -	Help
3 -	Choose Service
4 -	Select Options
5 -	Stop

```
Enter a function ID value:
```

4. Respond to the prompts by pressing **Enter** after each entry; use the default service name indicated or one suggested by the system manager:
  - a. Enter 3 for the function ID.

OpenVMS, Hardware  
and Boot Operations

- b. Enter 2 for the option ID.
- c. Enter the service name (I64084 is the default service name for the VSI OpenVMS OE DVD; check with your system or network manager for the service name to specify).

A sample display follows:

```
Enter a function ID value: 3
OPTION          OPTION
  ID
  1      -      Find Services
  2      -      Enter known Service Name

Enter an Option ID value: 2
Enter a Known Service Name: I64084
```

After you boot, the system displays the OpenVMS Installation Menu. To install your OpenVMS operating system, follow the instructions in “Performing the INSTALLATION”. To upgrade your system, follow the instructions in “Performing the UPGRADE”.

### Example 9.4. Loading of Memory Disk Message

```
Loading.: Network Boot Mac(00-15-60-04-f4-1e)
```

```
Client MAC Address: 00 15 60 04 F4 1E .- Client IP Address: 1.1.238.63 Subnet M
```

```
Retrieving File Size.|
Retrieving File (TFTP).Loading memory disk from IP 1.1.238.239 .....
Loading file: LDA3:[VMS$COMMON.SYSEXEC]IPB.EXE from IP 1.1.238.239 %IPB-I-SUCCESS
```

```
VSI OpenVMS Industry Standard 64 Operating System, Version 8.4-1H1
© Copyright 2015 VMS Software, Inc.
```

```
%SMP-I-CPUTRN, CPU #1 has joined the active set.
%SMP-I-CPUTRN, CPU #2 has joined the active set.
%SMP-I-CPUTRN, CPU #3 has joined the active set.
%SMP-I-CPUTRN, CPU #4 has joined the active set.
```

```
%EIA0, Link up: 100 mbit, full duplex, flow control (receive only)
```

```
Installing required known files...
```

```
Configuring devices...
```

```
%PKA0, Copyright (c) 1998 LSI Logic PKW V3.2.20 ROM 4.19 %PKA0, SCSI Chip is SY
```

```
*****
```

```
You can install or upgrade the OpenVMS I64 operating system
or you can install or upgrade layered products that are included
on the OpenVMS I64 distribution media (CD/DVD).
```

```
You can also execute DCL commands and procedures to perform
"standalone" tasks, such as backing up the system disk.
```

```
Please choose one of the following:
```

- 1) Upgrade, install or reconfigure OpenVMS I64 Version E8.4

## OpenVMS, Hardware and Boot Operations

- 2) Display layered products that this procedure can install
- 3) Install or upgrade layered products
- 4) Show installed products
- 5) Reconfigure installed products
- 6) Remove installed products
- 7) Find, Install or Undo patches; Show or Delete Recovery Data
- 8) Execute DCL commands and procedures
- 9) Shut down this system

Enter CHOICE or ? for help: (1/2/3/4/5/6/7/8/9/?)

### Note

If you boot the VSI OpenVMS OE DVD from an InfoServer but lose your connection during the installation or upgrade procedure (the system is unresponsive and pressing **Ctrl/Y** does not return you to the menu), do the following:

IF...	THEN...
You previously chose the INITIALIZE option	<ol style="list-style-type: none"><li>1. Reboot the OpenVMS CD DVD.</li><li>2. Choose the install/upgrade option (1) on the menu and perform the installation or upgrade procedure again.</li></ol>
You previously chose the PRESERVE option	<ol style="list-style-type: none"><li>1. Reboot the OpenVMS CD or DVD.</li><li>2. Enter the DCL environment by choosing option 8 on the menu.</li><li>3. Mount the device containing your backup copy of the target disk and the device that is your target disk.</li><li>4. Restore the backup copy of your target disk by entering the appropriate BACKUP commands. (See <i>“Backing Up and Restoring the System Disk”</i> for complete information about using MOUNT and BACKUP commands to restore a system disk.)</li><li>5. Log out from the DCL environment.</li><li>6. Choose the install/upgrade option (1) on the menu and perform the installation or upgrade procedure again.</li></ol>

## Troubleshooting InfoServer Boot Problems

For problems using the OpenVMS InfoServer software for network booting, consider the following:

1. When you attempt to boot over the network, check your console display for the following:
  - The IP address of the boot server that sends your EFI console the OpenVMS loader file (VMS\_LOADER.EFI). If this IP address is not as expected, your client host might be in the database of the wrong boot server. Enter your client host IP address in the database of the correct boot server (see step 5 of “Setting Up the BOOTP Boot Server and TFTP Server”), and remove your client from the database of any other boot servers.
  - The version number of the IPB.EXE bootstrap file that is loaded (for this release, the version should be 8.4-1H1). If this version number is not the correct version of OpenVMS, a message indicates there is a mismatch. The boot server might be the source of the problem. Make sure that it is configured correctly. Make sure the client entry in the boot server’s database has been updated to point to the current version of the loader file (see step 3 and step 6 of “Setting Up the BOOTP Boot Server and TFTP Server”).

- Evidence that DHCP is not responding. If you do not see a message indicating autonegotiation has been started, make sure the closest network device or switch is set for autonegotiation.
2. If the network boot succeeds but your attempt to choose a service or to display services at the InfoServer menu fails, a device might be filtering the LASTport/Disk (LAD) protocol. This protocol does not provide routing functions and only works within a LAN. If filtering devices are used in an extended LAN, the devices must allow this protocol (protocol type is 80-41) to pass through unfiltered so that clients can access the InfoServer across the filtering device.

For LANCP and LANACP problems, see the *OpenVMS System Manager's Manual, Volume 2: Tuning, Monitoring, and Complex Systems* for more information.

## Setting Up and Booting Fibre Channel Storage Devices

This section describes how to set up and boot from a Fibre Channel (FC) Storage Area Network (SAN) storage device. You may prefer booting from an FC storage device because of its speed and because it can serve as a common cluster system disk in a SAN. FC storage is supported on all storage arrays that are supported on OpenVMS systems. For a list of supported devices, see the *VSI OpenVMS Version 8.4-1H1 Software Product Description (SPD 82.35.xx)*.

This section describes how to check the firmware version of the flash memory of the FC storage device, how to obtain the latest copy of the IPF Offline Diagnostics and Utilities CD, and how to configure the boot device paths for the storage device.

First, verify that your EFI firmware is set to scan the SAN for devices. Refer to the appropriate documentation and command help for your system.

The HBA requires the latest RISC firmware and EFI firmware and driver.

Fibre Channel device booting supports point-to-point topology. There is no plan to support FC arbitrated loop topology.

## Checking the Firmware Version

Before you can boot on a FC device on OpenVMS systems, the EFI bootable firmware of the flash memory of the FC HBA must be the latest supported revision.

### Important

If you have an entry-class HP Integrity server, you can update the firmware yourself. If you have a cell-based HP Integrity server, you must contact HP Customer Support to update the firmware for you. Please refer to the appropriate documentation for update procedures specific to your device.

To flash the memory of the FC HBA on an entry-class server, update the EFI driver and RISC firmware to the latest versions available. In addition, to enable the HBA factory default settings, update the NVRAM resident in the FLASH ROM on the HBA, if necessary.

To determine the most current supported versions of the RISC firmware and EFI driver, see the appropriate README text file provided on the latest, supported HP IPF Offline Diagnostics and Utilities CD. For example, for a 2 GB FC device, locate this file by navigating to the `\efi\hp\tools\io_cards\fc2` directory. To update the driver and firmware, you can use a script on the CD that updates the driver and firmware automatically. Use the following command in the directory previously mentioned:

```
fc_d_update2.nsh
```

For a 4 GB FC device, navigate to the **fc4** directory (`\efi\hp\tools\io_cards\fc4`) to locate the README text file. To update the driver and firmware, use the following command (located in the **fc4** directory):

```
fc4_update4.nsh
```

You can also use the **efiutil.efi** utility located in either directory.

Similar procedures will exist for newer versions. For instructions on obtaining the Offline Diagnostics and Utilities CD, see “Obtaining the IPF Offline Diagnostics and Utilities”. For additional information about updating the bootable firmware of the FC device, see the *Guidelines for OpenVMS Cluster Configurations*.

You can determine the versions of the driver and RISC firmware currently in place on your server in two ways: from the console during system initialization or by using the **efiutil** utility.

- The driver and RISC firmware versions are shown in the booting console message that is displayed during system initialization, as in the following example. The RISC firmware version is indicated in the format **n.nn.nnn**.

```
HP 2 Port 2Gb Fibre Channel Adapter (driver n.nn, firmware n.nn.nnn)
```

- The driver and RISC firmware versions are also shown in the display of the **efiutil info** command:

```
fs0:\efi\hp\tools\io_cards\fc2\efiutil> info
```

```
Fibre Channel Card Efi Utility n.nn (11/1/2004)
```

```
2 Fibre Channel Adapters found:
```

Adapter	Path	WWN	Driver (Firmware)
A0	Acpi(000222F0,200)/Pci(1 0)	50060B00001CF2DC	n.nn (n.nn.nnn)
A1	Acpi(000222F0,200)/Pci(1 1)	50060B00001CF2DE	n.nn (n.nn.nnn)

## Obtaining the IPF Offline Diagnostics and Utilities

Obtain the latest copy of the IPF Offline Diagnostics and Utilities CD by either of the following methods:

- Order the CD free of charge from the HP Software Depot site main page at:

```
http://www.hp.com/go/softwaredepot
```

Type **ipf offline** in the Search bar and select the latest version listed (dates are indicated in the listed product names).

- Burn your own CD locally after downloading a master ISO image of the IPF Offline Diagnostics and Utilities CD from the following website:

```
http://www.hp.com/support/itaniumservers
```

1. Select your server product from the list provided.
2. From the HP Support page, select “Download drivers and software”.
3. From the “Download drivers and software page”, select “Cross operating system (BIOS, Firmware, Diagnostics, etc)”.
4. Download the Offline Diagnostics and Utilities software. Previous versions of the software might be listed along with the current (latest) version. Be sure to select the latest version.

Alternatively, you can select the appropriate Offline Diagnostics and Utilities link under the Description heading on this web page. Then you can access the installation instructions and

release notes as well as download the software. The README text file on the CD also includes information about how to install the software and update the firmware.

5. Burn the full ISO image onto a blank CD, using a CD burner and suitable CD burning software. To complete the recording process, see the operating instructions provided by your CD burner software. The downloaded CD data is a single ISO image file. This image file must be burned directly to a CD exactly as is. This creates a dual-partition, bootable CD.

## Configuring and Booting FC Boot Device

The process of setting up an FC boot device has been automated by the OpenVMS installation and upgrade procedures.

The OpenVMS installation/upgrade procedure displays the name of an FC disk as a boot device and prompts you to add the Boot Option. VSI recommends that you accept this default. Alternatively, after the installation or upgrade completes, you can run the OpenVMS Boot Manager to set up or modify an FC boot device, as described in the following steps. Always use the OpenVMS installation/upgrade procedure or the OpenVMS Boot Manager to set up or modify an FC boot device; do not use EFI for this purpose.

### Note

On certain entry-level servers, if no FC boot device is listed in the EFI boot menu, you might experience a delay in EFI initialization because the entire SAN is scanned. Depending on the size of the SAN, this delay might range from several seconds to several minutes. Cell-based systems (such as rx7620, rx8620, and the Superdome) are not affected by this delay.

When booting OpenVMS from the installation DVD for the first time on any OpenVMS system, you might also experience a similar delay in EFI initialization.

If you did not allow the OpenVMS installation or upgrade procedure to automatically set up your FC boot device, or if you want to modify the boot option that was set up for that device, use the OpenVMS Boot Manager utility, by following these steps:

1. If your operating system is not running, access the OpenVMS DCL triple dollar sign prompt (\$\$\$) from the OpenVMS operating system main menu by choosing option 8 (Execute DCL commands and procedures). Otherwise, skip to the next step.
2. At the DCL prompt, enter the following command to start the OpenVMS Boot Manager utility:  

```
$$$ @SYS$MANAGER:BOOT_OPTIONS
```
3. When the utility is launched, the main menu is displayed. To add your FC system disk as a boot option, enter 1 at the prompt, as in the following example:

```
OpenVMS Boot Manager Boot Options List Management Utility
```

- ```
(1) ADD an entry to the Boot Options list
(2) DISPLAY the Boot Options list
(3) REMOVE an entry from the Boot Options list
(4) MOVE the position of an entry in the Boot Options list
(5) VALIDATE boot options and fix them as necessary
(6) Modify Boot Options TIMEOUT setting

(B) Set to operate on the Boot Device Options list
(D) Set to operate on the Dump Device Options list
(G) Set to operate on the Debug Device Options list
```

## OpenVMS, Hardware and Boot Operations

(E) EXIT from the Boot Manager utility

You can also enter Ctrl-Y at any time to abort this utility

Enter your choice: **1**

### Note

While using this utility, you can change a response made to an earlier prompt by entering the caret (^) character as many times as needed. To end and return to the DCL prompt, press **Ctrl/Y**.

4. The utility prompts you for the device name. Enter the FC system disk device you are using for this installation. In the following example, the device is a multipath FC device named \$1\$DGA1:. This ensures that the system will be able to boot even if a path has failed.

Enter the device name (enter "?" for a list of devices): **\$1\$DGA1:**

5. The utility prompts you for the position you want your entry to take in the EFI boot option list. Enter 1 to enable automatic reboot, as in the following example:

Enter the desired position number (1,2,3,,,) of the entry.  
To display the Boot Options list, enter "?" and press Return.  
Position [1]: **1**

6. The utility prompts you for OpenVMS boot flags. By default, no flags are set. Enter the OpenVMS flags (for example, 0,1), or accept the default (NONE) to set no flags, as in the following example:

Enter the value for VMS\_FLAGS in the form n,n.  
VMS\_FLAGS [NONE]:

7. The utility prompts you for a description to include with your boot option entry. By default, the device name is used as the description. You can enter more descriptive information. In the following example, the default is taken:

Enter a short description (do not include quotation marks).  
Description ["\$1\$DGA1"]:

```
efi$bcfg: $1$dga1 (Boot0001) Option successfully added
efi$bcfg: $1$dga1 (Boot0002) Option successfully added
efi$bcfg: $1$dga1 (Boot0003) Option successfully added
efi$bcfg: $1$dga1 (Boot0004) Option successfully added
```

This display example shows four different FC boot paths were configured for your FC system disk.

8. After you successfully add your boot option, exit the utility by entering E at the prompt.

Enter your choice: **E**

9. Log out from the DCL level and shut down the system.
10. When you next see the boot option list displayed at your console by EFI, it should look similar to the following (assuming you took the default in step 7). In this example, the device is \$1\$DGA1 for two dual-ported SAN storage arrays (the four separate boot paths are identified in the display). The following figure illustrates the host FC ports (FGA0 and FGB0) on the server and the corresponding FC SAN storage controller configuration.

Please select a boot option

```
$!$dga1 FGA0.5000-1FE1-0011-B15C
$!$dga1 FGA0.5000-1FE1-0011-B158
$!$dga1 FGB0.5000-1FE1-0011-B15D
$!$dga1 FGB0.5000-1FE1-0011-B159
EFI Shell [Built-in]
```

The text to the right of `!$dga1` identifies the boot path from the host adapter to the storage controller, where:

- FGA0 or FGB0 are the FC ports (also known as host adapters).
- Each 5000-1FE1-0011-B15 *n* number (where *n* is C, 8, D, or 9, respectively) is the factory-assigned FC storage port 64-bit worldwide identifier (WWID), otherwise known as the FC port name.

If you get confused, simply boot the OpenVMS OE distribution DVD and use the OpenVMS Boot Manager utility to remove the current boot options (Option 3) and then to add your boot options again.

For more information about this utility, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*.

Boot the FC system disk by selecting the appropriate boot option from the EFI Boot Manager menu and pressing **Enter**. If your FC boot path is the first option in the menu, it might boot automatically after the countdown timer expires.

## Configuring Additional Nodes to Boot into a Cluster Using a Shared Disk

If you have booted the VSI OpenVMS OE DVD and installed the operating system onto an FC (SAN) disk and configured the system to operate in an OpenVMS Cluster environment, you can configure additional HP Integrity systems to boot into the OpenVMS Cluster by following these steps:

1. Run the cluster configuration utility on the initial cluster system to add the new node to the cluster.  

```
$ @SYS$MANAGER:CLUSTER_CONFIG_LAN
```
2. Boot the VSI OpenVMS OE DVD on the target node (the new node).
3. Select Option 8 from the operating system menu to access OpenVMS DCL.
4. Start the OpenVMS Boot Manager utility by entering the following command at the DCL prompt:

### Note

The OpenVMS Boot Manager utility requires the shared FC disk be mounted. If the shared FC disk is not mounted clusterwide, the utility tries to mount the disk with a `/NOWRITE` option. If the shared FC disk is already mounted clusterwide, user intervention is required.

```
$$$ @SYS$MANAGER:BOOT_OPTIONS
```

5. Use the utility to add a new entry for the shared cluster system disk. Follow the instructions provided in “Configuring and Booting FC Boot Device”.
6. Boot the new system into the cluster.

# Appendix A. Backing Up and Restoring the System Disk

This appendix describes how to perform backup and restore operations on the system disk. You perform these tasks by entering commands from a specialized backup environment. You access this environment through the menu that is displayed when you boot the VSI OpenVMS OE DVD, or through an alternative method that does not require the DVD.

This specialized backup environment is required because it allows you to create an exact copy of the system disk. You cannot create an exact copy in a standard operating system environment because the OpenVMS Backup utility saves only what is on the disk at the moment the BACKUP command is executing, excluding portions of open files contained in memory or data about files not yet written back to the disk (cache).

For more information about backup operations, including procedures for backing up and restoring files and directories, see the *OpenVMS System Manager's Manual, Volume 1: Essentials*.

## Reasons for Backing Up the System Disk

The primary reason for having a backup copy of the system disk is so you can fully restore your system in case any hardware or software problem affects the integrity of your original system disk or your ability to access it. For example, use the backup copy to restore your system under the following conditions:

- When a problem occurs during an OpenVMS upgrade or update, or during the installation of other software products. If you back up the system disk before you attempt any of those procedures, you can restore the system disk and attempt the procedure again.
- When a system file that is accidentally deleted renders the system disk nonoperational. If you back up the system disk after you installed or upgraded the OpenVMS operating system and any other software products, you can restore the system disk.
- When the drive that holds the system disk malfunctions. If you have a backup copy of the system disk, you can restore it to a functioning disk and continue to use the system.

Another reason for backing up the system disk is to eliminate disk fragmentation, which occurs when files are stored noncontiguously on the disk. The BACKUP/IMAGE command creates a copy on which files are stored contiguously.

## Suggested Procedures

VSI recommends the following:

- The preferred method for performing system disk backup and restore operations is to boot the operating system media, choose the DCL option from menu, and then enter the appropriate backup commands. The detailed procedures are described in “Backing Up the System Disk” and “Restoring the System Disk”.

However, if you do not have access to the CD or if you want to back up a shadowed system disk without disabling the shadow set, you can use a different procedure, which is described in “Alternative Backup and Restore Procedure (Minimum OpenVMS Environment)”.

- Store the backup media in a safe place.
- If you have an OpenVMS Cluster environment with more than one system disk, be sure the volume labels on each system disk and on backup copies of system disks are unique. Use the SET VOLUME/LABEL command to change a volume label, if necessary.

## OpenVMS Cluster Caution

If any nodes except the node used to run BACKUP are booted during the backup operations described in this appendix, your cluster will become partitioned, where nodes in the existing cluster divide into two or more independent clusters. This condition can cause data file corruption.

In addition, these backup environments do not restrict your use of DCL commands to the BACKUP command only, which further increases your risk of accidentally destroying or corrupting data on a disk. Therefore, to avoid jeopardizing the integrity of your data in any way, you should shut down the entire OpenVMS Cluster system before you back up your system disk.

## Backing Up the System Disk

The following sections describe how to back up the system disk.

### Getting Started

Before you back up the system disk, do the following:

1. In an OpenVMS Cluster environment, dismount the system disk from all systems in the cluster that have the disk mounted as a data disk (rather than as the system disk).
2. Shut down all systems booted from that disk.
3. Boot the operating system media. (For booting the VSI OpenVMS OE DVD, see “Distribution Media Boot Methods”.)
4. Choose the DCL option (8) on the menu. For example:

```
*****
```

```
You can install or upgrade the OpenVMS I64 operating system  
or you can install or upgrade layered products that are included  
on the OpenVMS I64 distribution media (CD/DVD).
```

```
You can also execute DCL commands and procedures to perform  
"standalone" tasks, such as backing up the system disk.
```

```
Please choose one of the following:
```

- 1) Upgrade, install or reconfigure OpenVMS I64 Version 8.4-1H1
- 2) Display layered products that this procedure can install
- 3) Install or upgrade layered products
- 4) Show installed products
- 5) Reconfigure installed products
- 6) Remove installed products
- 7) Find, Install, or Undo patches; Show or Delete recovery data
- 8) Execute DCL commands and procedures
- 9) Shut down this system

```
Enter CHOICE or ? for help: (1/2/3/4/5/6/7/8/9/?) 8
```

5. At the triple dollar sign prompt (\$\$\$), enter the SHOW DEVICES command.
6. Examine the list of devices to determine which device is the source drive (the system disk you want to back up) and which device is the target drive (the supported disk or tape device that will hold the backed up files).

## Mounting Devices

After you determine the source drive and target drive, mount those devices (and any other output devices you plan to use) before you perform any backup operations. Enter the MOUNT commands in the following format:

```
$$$ MOUNT/OVERRIDE=IDENTIFICATION source-drive  
$$$ MOUNT/FOREIGN target-drive
```

In these commands:

- *source-drive* is the name of the drive holding the system disk.
- *target-drive* is the name of the drive that will hold the backup files.

## Performing the System Disk Backup

When the system disk and output devices are mounted, back up the system disk by entering the BACKUP command in the following format:

```
$$$ BACKUP/IMAGE/VERIFY source-drive: target-drive:
```

### Example 1

In this example, the system disk and a target disk are mounted so the BACKUP command can create a backup disk. (You can use a backup disk as a system disk.)

```
$$$ MOUNT/OVERRIDE=IDENTIFICATION DKA200  
$$$ MOUNT/FOREIGN DKA300  
$$$ BACKUP/IMAGE/VERIFY DKA200: DKA300:
```

### Example 2

In this example, the system disk and a target tape device are mounted so the BACKUP command can create a backup tape.

```
$$$ INITIALIZE MKA300: label  
$$$ MOUNT/OVERRIDE=IDENTIFICATION DKA200  
$$$ MOUNT/FOREIGN MKA300  
$$$ BACKUP/IMAGE/VERIFY DKA200: MKA300:SEP_08_BACKUP.BCK/SAVE_SET/REWIND
```

## Changing the Disk Volume Cluster Size

The BACKUP/IMAGE command maintains a set of disk volume parameters from the input volume, altering attributes such as the disk volume cluster size as appropriate for the target device. (Cluster size refers to the basic unit of space allocation on the disk, *not* to OpenVMS Cluster environments.)

To change the disk volume cluster size, you must restore the disk contents to a disk that has been previously initialized with the desired cluster size (using BACKUP/IMAGE/NOINITIALIZE). For more information about initializing a disk and using the BACKUP command, see the *OpenVMS System Manager's Manual, Volume 1: Essentials* and the *OpenVMS System Management Utilities Reference Manual: A-L*, and see the description of the INITIALIZE and BACKUP commands in the *OpenVMS DCL Dictionary*.

## Logging Out, Shutting Down, and Rebooting

After you complete the backup operation:

## Backing Up and Restoring the System Disk

1. Enter the LOGOUT command to exit the DCL environment and return to the menu.
2. Choose the shutdown option (9).
3. After the shutdown completes, boot from the system disk.

# Restoring the System Disk

The following sections describe how to restore the system disk. Note that restoring a system disk also serves to defragment the disk. In addition, it validates the backup, ensuring that the backed up system disk is usable.

## Getting Started

Before you can restore the system disk, follow these steps:

1. Shut down the system.
2. Boot the operating system media. (see "Distribution Media Boot Methods").
3. Choose the DCL option (8) on the menu. For example:

```
You can install or upgrade the OpenVMS I64 operating system
or you can install or upgrade layered products that are included
on the OpenVMS I64 distribution (CD/DVD).
```

```
You can also execute DCL commands and procedures to perform
"standalone" tasks, such as backing up the system disk.
```

Please choose one of the following:

- 1) Upgrade, install or reconfigure OpenVMS I64 Version 8.4-1H1
- 2) Display layered products that this procedure can install
- 3) Install or upgrade layered products
- 4) Show installed products
- 5) Reconfigure installed products
- 6) Remove installed products
- 7) Find, Install, or Undo patches; Show or Delete recovery data
- 8) Execute DCL commands and procedures
- 9) Shut down this system

```
Enter CHOICE or ? for help: (1/2/3/4/5/6/7/8/9/?) 8
```

4. At the triple dollar sign prompt (\$\$\$), enter the SHOW DEVICES command.
5. Examine the list of devices to determine which device is the source drive (the drive holding the backed up files you want to restore) and which device is the target drive (the disk on which you want the files restored).

## Mounting Devices

After you determine the source drive and target drive, mount those devices (and any other output devices you plan to use) before you perform any restore operations. Enter the MOUNT commands in the following format:

```
$$$ MOUNT/OVERRIDE=IDENTIFICATION source-drive
$$$ MOUNT/FOREIGN target-drive
```

In these commands:

## Backing Up and Restoring the System Disk

- *source-drive* is the device holding the files you want to restore

(Note, however, that you must use the MOUNT/FOREIGN command if the source drive is a tape device.)

- *target-drive* is the destination

## Performing the System Disk Restore

Enter the BACKUP command in the following format to restore the system disk:

```
$$$ BACKUP/IMAGE/VERIFY source-drive: target-drive:
```

### Example 1

In this example, a backup disk and a target disk are mounted so the BACKUP command can restore the system disk from the backup disk:

```
$$$ MOUNT/OVERRIDE=IDENTIFICATION DKA300  
$$$ MOUNT/FOREIGN DKA200  
$$$ BACKUP/IMAGE/VERIFY DKA300: DKA200:
```

### Example 2

In this example, a backup tape and a target disk are mounted so the BACKUP command can restore the system disk from the backup tape:

```
$$$ MOUNT/FOREIGN MKA300  
$$$ MOUNT/FOREIGN DKA200  
$$$ BACKUP/IMAGE/VERIFY MKA300:SEP_08_BACKUP.BCK/SAVE_SET DKA200:
```

## Logging Out, Shutting Down, and Rebooting

After you complete the restore operation, follow these steps:

1. Enter the LOGOUT command to exit the DCL environment and return to the menu.
2. Choose the shutdown option (9).
3. After the shutdown completes, boot from the system disk.

## Alternative Backup and Restore Procedure (Minimum OpenVMS Environment)

This section describes an alternative method of performing backup and restore operations. This method is similar to creating a Standalone Backup directory on a disk, as supported by OpenVMS VAX systems and certain earlier versions of OpenVMS Alpha (using SY\$\$UPDATE.STABACKIT.COM). This method installs a Minimum OpenVMS Environment (install with no options) on another disk from which you can perform your backup and restore operations on the system disk. The Minimum OpenVMS Environment is created in the SYSE root ([SYSE]) on the disk, which runs a subset of OpenVMS and is indicated by the triple dollar sign (\$\$\$) system prompt. Use this method under the following conditions:

- If you do not have access to the operating system media and its menu system
- If you want to back up a shadowed system disk without disabling the shadow set

## Note

You can back up your running system disk by using the /IGNORE=INTERLOCK qualifier with the BACKUP command and ignoring warning messages. However, that method requires that all other use of the system be suspended, including disabling logins, stopping print and batch queues, and turning off networking software. In addition, you cannot use this method to restore files to the running system disk. Because of these limitations, VSI recommends that, if you must use an alternative backup or restore method, you use the method described in this section.

## Preparing an Alternate System Disk

Prepare an alternate system disk as follows:

1. Log in to a privileged account on your running OpenVMS system.
2. Using the SHOW DEVICE command, identify a data disk on which you can install the operating system, with no options. This is your target disk during that installation. To install the operating system with no options on your target disk, you need the following amount of free disk space:
  - OpenVMS Alpha: approximately 5,21,552 blocks (267 MB)
  - Approximately 10,09,762 blocks (517 MB)

Existing data remains on the disk.

3. The target disk must be mounted privately to your process. (This prevents other users from accessing this disk during the installation and backup procedures.) Therefore, if the target disk was mounted with the /SYSTEM, /CLUSTER, /GROUP, or /SHARE qualifier, dismount that disk and mount it without those qualifiers or the /FOREIGN qualifier. For example:

```
$ MOUNT/OVERRIDE=IDENTIFICATION DKA200
```

4. Enter the following command:

```
$ @SYS$SYSTEM:I64VMS$PCSI_INSTALL_MIN.COM [target-disk]
```

(The procedure prompts you for a device name if you do not specify it on the command line.)

5. As the procedure completes the installation, the display is similar to the following:

```
HP I64VMS OpenVMS V8.4-1H1: OpenVMS and related products platform
```

```
  COPYRIGHT (c) ...  
  Hewlett-Packard Development Company, L.P.
```

```
Execution phase starting ...
```

```
The following product will be installed:  
  HP I64VMS VMS V8.4-1H1
```

```
Portion Done: 0%..10%..20%..30%..40%..50%..60%..70%..80%..90%..100%
```

```
The following product has been installed:  
  HP I64VMS VMS V8.4-1H1
```

```
  .  
  .  
  .
```

```
The installation of minimum OpenVMS I64 is now complete.
```

```
Use EFI or the boot option you just created or validated (if any)
```

## Backing Up and Restoring the System Disk

to boot minimum OpenVMS. If you use EFI remember to set VMS\_FLAGS to E,0 before booting, and to reset VMS\_FLAGS to 0,0 (or as required by your system).

```
BOOT -FLAGS E,0 device-name
```

(Some configurations may require a boot option to boot.)

### Caution

If your system is a cluster member, you should shut down the entire OpenVMS Cluster system before you back up your system disk. This will prevent you from creating a partitioned cluster and from jeopardizing the integrity of your data in any other way.

## Using the Alternate System Disk

Use the alternate system disk (on which you installed the operating system with no options) to perform backup and restore operations as follows:

1. Shut down your system.
2. Boot the alternate system disk from the SYSE root.

You can add the alternate system disk as a boot option in the EFI Boot Manager menu by using the OpenVMS Boot Manager utility (SYSS\$MANAGER:BOOT\_OPTIONS.COM), as described in “Setting Boot Options for Your System Disk”. When prompted, set the flags as e,0. Alternatively, boot the alternate system disk manually by entering the following command at the EFI Shell prompt, where *fsn*: (such as fs1:) is the device associated with the system disk:

```
Shell> fsn:\efi\vms\vms_loader.efi -flags e,0
```

The system automatically logs you in to the SYSTEM account and then displays a triple dollar sign prompt (\$\$\$).

### Note

During the boot and login operations on this minimum version of the operating system, you can ignore license messages that are similar to the following:

```
%LICENSE-I-NOLICENSE, no license is active for this software product
```

3. If your system disk is shadowed, install and load a Volume Shadowing for OpenVMS license on this data disk. Then you can back up the shadowed system disk from this data disk without disabling the shadow set.

### Note

VSI recommends that you do *not* install any other licenses, including OpenVMS licenses, on this alternate system. You can use the system only from the console.

4. Mount the system disk and any output devices you plan to use during the backup or restore operations. See “Mounting Devices” for more information.
5. Perform the necessary backup or restore operations by entering the appropriate BACKUP commands. For examples of using the BACKUP command to back up the system disk, see “Performing the System Disk Backup”; for examples of using the BACKUP command to restore the system disk, see “Performing the System Disk Restore”.
6. Shut down the system.

## Backing Up and Restoring the System Disk

7. Boot from your original system disk.

# Appendix B. Removing the OpenVMS Operating System

This appendix explains how to remove the OpenVMS operating system from your disk.

You can remove the OpenVMS operating system from your disk in the following ways:

- If the disk contains a small number of user files, copy those user files elsewhere and then reinitialize the disk.
- If the disk contains many user files, use the `PRODUCT REMOVE` command to remove an obsolete or extra copy of the OpenVMS operating system without removing any of the user files. You must also delete or archive certain operating system files that the `PRODUCT REMOVE` command cannot delete.

Follow these steps to remove OpenVMS operating system files:

1. If your system disk has multiple system-specific roots, boot the system and execute `SYS$MANAGER:CLUSTER_CONFIG_LAN.COM` to remove all roots except the one from which you are booted.
2. Shut down and boot from the distribution media or from a system disk other than the one from which OpenVMS is being removed. Then do one of the following:
  - If OpenVMS is not running from the distribution media, log in to a privileged account.
  - If OpenVMS is running from the distribution media, choose the option to execute DCL commands.
3. Enter the following DCL commands:

```
$ DEFINE/NOLOG PC$I$SYSDEVICE target-disk
$ DEFINE/NOLOG PC$I$SPECIFIC target-disk: [SYSx.]
$ DEFINE/NOLOG PC$I$DESTINATION target-disk: [VMS$COMMON]
```

where:

- *target-disk* is the device name of the disk from which OpenVMS is being removed.
  - *SYSx* is the root number that you did not remove in step 1.
4. If the disk also contains layered products that were installed using the PC\$I utility, VSI recommends that you remove them as well. Remove any layered products *before* using the `PRODUCT REMOVE VMS` command.

Use the following command to remove all the products at once. Select the layered products you want to remove from the menu.

```
$ PRODUCT REMOVE * /REMOTE
```

Use the following commands to remove individual products:

```
$ PRODUCT SHOW PRODUCT/REMOTE
$ PRODUCT REMOVE product-name /REMOTE
```

5. Enter the following DCL command:

## Removing the OpenVMS Operating System

\$ **PRODUCT REMOVE VMS /REMOTE**

6. Because the PRODUCT REMOVE command does not delete certain files, review the target disk to determine whether you want to delete, move, or archive the operating system files that still remain on the disk.

Following are lists of the files that the PRODUCT REMOVE command does not delete:

- In *target-disk*:**[SYS\*.SYSEXE]**, where \* is the hexadecimal number of any additional OpenVMS Cluster root on the target disk:
  - IA64VMSSYS.PAR
  - MODPARAMS.DAT
  - PAGEFILE.SYS
  - SWAPFILE.SYS
- In *target-disk*:**[VMS\$COMMON.SYSEXE]**:
  - LMF\$LICENSE.LDB
  - PCSI\$FILE\_SYSTEM.PCSI\$DATABASE
  - PCSI\$PROCESSOR.PCSI\$DATABASE
  - PCSI\$ROOT.PCSI\$DATABASE
  - RIGHTSLIST.DAT
  - SYSUAF.DAT

As you examine the preceding lists of files, you might want to archive, rather than delete, the following files:

- IA64VMSSYS.PAR (VSI OpenVMS)
- MODPARAMS.DAT
- LMF\$LICENSE.LDB
- RIGHTSLIST.DAT
- SYSUAF.DAT

Also, if you previously removed layered products, those products might have created additional files that you might want to delete, move, or archive.

7. Review the target disk for the directory structures **[VMS\$COMMON...]** and **[SYSx...]** that remain after you remove the OpenVMS operating system. You might want to delete these directories.

The directories **[SYSx]SYSCOMMON.DIR** (in all **[SYSx]**) are aliases for the file **[000000]VMS\$COMMON.DIR**. Do not delete these SYSCOMMON.DIR files. Instead, use the SET FILE / REMOVE command as follows:

\$ **SET FILE /REMOVE [SYS\*]SYSCOMMON.DIR**

After you execute this command and delete, move or archive all the files in **[VMS\$COMMON...]**, you can delete **[000000]VMS\$COMMON.DIR**. Then you can delete, move, or archive the files in each **[SYSx]** directory.

# Appendix C. Alternative Ways to Initialize the System Disk

The usual way to create a new OpenVMS system disk is to install OpenVMS with the INITIALIZE option. When you do this, the installation process responds as follows:

- A diagnostic partition is created. The diagnostic partition is visible only from the console; it corresponds to the contents of SYSS\$MAINTENANCE:SYSS\$DIAGNOSTICS.SYS on the system disk. The partition is intended and reserved for use by VSI Services (it is used with the IPF Offline Diagnostics and Utilities CD provided with the purchase of your HP Integrity server). For more information about offline diagnostics, see your hardware documentation and the following website:

<http://docs.hp.com/hpux/diag>

VSI recommends creating the system disk with this partition and not removing it. However, it is not required for operation of OpenVMS.

If you do not want the diagnostic partition, you can prevent its creation by initializing the disk before installing OpenVMS, performing the steps in “Alternative Method of Initialization”. Alternatively, if you have already created the system disk and the partition, you can remove it by performing the steps in “Removing the Diagnostic Partition File”.

- The disk is initialized with volume expansion (INITIALIZE/LIMIT).

This method of initialization (using the /LIMIT qualifier) might make your target system disk incompatible with versions of OpenVMS prior to 7.2. VSI recommends that you create your system disk in the default manner unless you need to mount the disk on a version of OpenVMS prior to 7.2.

You can avoid use of the /LIMIT qualifier by initializing your target system disk before you install OpenVMS, performing the steps in “Alternative Method of Initialization”. As a result of this alternate method, your new system disk might include a relatively large minimum allocation size (as defined by /CLUSTER\_SIZE). Small files will use more space than would be used otherwise. Therefore, perform these steps *only* for system disks that must be mounted on versions of OpenVMS prior to Version 7.2.

## Alternative Method of Initialization

Use the following initialization method to avoid use of the /LIMIT qualifier or to prevent creation of the diagnostic partition.

### Note

When you initialize your target disk using the following method, you must use the PRESERVE option during the installation of OpenVMS on the disk. If you use the INITIALIZE option, the disk is reinitialized using the defaults.

1. After booting the operating system media, and before installing the operating system, select Option 8 (“Execute DCL commands and procedures”) on the main menu.
2. Initialize the intended target disk with the following command:

```
$$$ INIT/SYSTEM/HEADERS=150000/STRUCTURE=ods-level disk label
```

where:

- *ods-level* is 2 (for ODS-2) or 5 (for ODS-5).

## Alternative Ways to Initialize the System Disk

- *disk* is the device for the target disk (such as DKA100:).
- *label* is the label for the target disk (you can change the label later).

If you specified ODS-5 and you want support for hard links, include the /VOLUME\_CHARACTERISTICS=HARDLINKS qualifier with the INITIALIZE command.

If you are using this method of initialization to prevent creation of a diagnostic partition, and you do not intend to mount the disk on an OpenVMS system prior to version 7.2, include the /LIMIT qualifier with the INITIALIZE command. If you do not use the /LIMIT qualifier, your new system disk might be initialized with a relatively large minimum allocation size. This can cause small files to use more space than necessary.

3. Exit DCL (log off), and then select option 1 (“Upgrade, install or reconfigure OpenVMS”) on the main menu.
4. When you are asked whether to initialize or preserve the target disk, choose PRESERVE (the default).
5. Continue with the installation.

## Removing the Diagnostic Partition File

To remove the diagnostic partition on a system disk and to recover the disk space occupied, delete the file SYSS\$MAINTENANCE:SYSS\$DIAGNOSTICS.SYS and then reset the boot block. This file can contain hardware diagnostics but is not essential for operations. To delete the file, enter the following command:

```
$ DELETE SYSS$MAINTENANCE:SYSS$DIAGNOSTICS.SYS;*/LOG
```

Reset the boot block by entering the SET BOOTBLOCK command at the DCL prompt, as in the following example, where *target-disk* is the device on which your target system disk is mounted:

```
$ SET BOOTBLOCK /PRESERVE=SIGNATURE target-disk: [VMS$COMMON.SYSS$LDR]SYSS$EFI.SYS
```

# Index

## A

- Accounts
  - creating after installation or upgrade, 132
- ACPI configuration, 16
- AGEN\$INCLUDE files
  - returning to system disk, 25
- Aliases
  - with hard links enabled, 60
- Allocation class (ALLOCLASS parameter)
  - for shadow sets, 106, 106
  - setting during installation, 33, 103
- ANALYZE/DISK\_STRUCTURE command
  - using before an upgrade, 23
- Architectures
  - in OpenVMS Cluster, 31, 35
- Archived files
  - deleting, 21
  - saving, 21
- Authorization
  - files, 24
    - network proxy, 109
  - returning to system disk, 24
- AUTOGEN
  - reboot after, 102, 102
  - running after an installation or upgrade, 101
  - running at end of installation, 100
  - tuning operating system, 101
- Availability Manager
  - configuring, 113
  - installing, 68
  - installing or upgrading, 45
  - upgrading, 85

## B

- Backing up the system disk, 189-196
  - after customizing, 132
  - after installation or upgrade, 104
  - before upgrade, 28
  - in a shadow set, 193, 193
  - without booting the OpenVMS CD or DVD, 193
- Backspace key, 140
- BACKUP command, 189
  - caution, 190
- Batch queue
  - creating, 109
- Before Clustered Installation Tasks
  - OpenVMS Cluster environment, 31-34
- BIB (boot-is-blocked state), 153, 164, 165
- BMC (Baseboard Management Controller)
  - description, 137
  - system event log (SEL), 151
- BOE
  - licensing, 67
- Boot block, writing, 150

- Boot command
  - qualifiers for XDELTA, 159
- Boot device list, 143
- Boot device paths
  - configuring on FC, 186
- Boot flags, 146
- Boot Options
  - setting during installation, 61
- Boot options
  - boot devices, 145
  - changing EFI boot timeout, 149
  - displaying, 148, 149
  - during upgrade, 90
  - setting, 145
  - setting during installation, 74
  - setting during upgrade, 83
- Boot server
  - configuration for InfoServer, 175
- Booting
  - automatic, 145, 148
  - cell-based servers, 152
  - conversational, 157
  - emergency, 159
    - with default system parameters, 160
    - without startup and login procedures, 161
    - without the user authorization file, 162
  - failure, 165
  - from a different root, 159
  - from Fibre Channel storage devices, 184-188
  - from InfoServer, 43, 156, 179
  - from local drive, 42
  - manually, 156
  - problems, 160
  - satellite, 170
  - setting boot flag parameters, 146
  - with minimum startup, 158
  - with XDELTA, 159
- Bugcheck, 166

## C

- CDSA
  - initializing, 112
  - installing, 68
  - installing or upgrading, 45
  - upgrading, 85
- Cell boot phase, 152
- Cell-based servers
  - booting, 152
  - EFI, 141
- Checklist
  - installation, 9
  - postinstallation and postupgrade, 96
  - preinstallation for OpenVMS Cluster, 31
  - preupgrade, 19
  - preupgrade for OpenVMS Cluster, 35
- Cluster size (disk volume), 191
- Command procedures
  - checking after upgrade, 125

- site-specific, 125
- Concurrent upgrades
  - description, 36
  - preparing system for, 36
- Configuration options
  - during upgrade, 78
- Console
  - delete or backspace key, 140
  - system serial port, 10
- Console (HP Integrity servers)
  - interface, 137
- CONTINUE command, 158
- Customizing the system, 108-111

**D**

- DCL option (from the Installation Menu), 56
- Debug devices
  - configuring, 141
- DECnet
  - declaring during installation, 63
  - installing or upgrading, 45
  - node address, 33
    - providing during installation, 103
  - node name, 33
    - possible values, 103
    - providing during installation, 103
- DECnet Phase IV
  - configuring, 110, 110
  - ignoring during startup, 110
  - installing, 68
  - registering license after installation, 105
  - running with DECwindows, 110
  - upgrading, 85
- DECnet-Plus
  - configuring, 110
  - installing, 68
  - upgrading, 85
- DECram
  - DCL command DECRAM, 84, 126
- DECRYPT command, 84, 126
- DECwindows Motif
  - client files, 86
  - installing, 68
  - installing or upgrading, 45
  - upgrading, 85
- Delete key, 140
- Device name
  - conventions, 7
- Diagnostic partition, 199
  - removing, 200
- Disk space
  - amount needed for upgrade, 24
- Dump file
  - checking size, 134
  - modifying size, 101
- Dump Off the System Disk (DOSD)
  - configuring, 141
- DWMOTIF\_SUPPORT, 86

**E**

- EFI (Extensible Firmware Interface)
  - adding boot options, 145
  - boot path settings
    - storing and restoring, 149
  - changing boot option timeout, 149
  - description, 137
  - displaying boot options, 148, 149
  - on nPartition, 141
  - using, 140-143
- EFI Boot Manager
  - adding boot options to
    - manually, 148
    - using OpenVMS Boot Manager utility, 145
  - setting boot behavior, 145
  - setting timeout, 149
- EFI Utilities for OpenVMS
  - documentation, 149
  - entering commands, 142
  - vms\_bcfg, 148
  - vms\_show command, 149
- Emergency system startup, 159
  - with default system parameters, 160
  - without startup and login procedures, 161
  - without the UAF, 162
- ENCRYPT command, 84, 126
- Errors
  - cluster hang during preupgrade shutdown, 38
  - running ANALYZE/DISK\_STRUCTURE, 23
  - troubleshooting system problems, 165

**F**

- FEEDBACK.DAT file, 26
- Fibre Channel
  - configuring and booting, 184-188
  - configuring for booting, 141, 146, 186
    - in cluster, 188
  - configuring for dumping, 186
  - displaying device information, 185
  - firmware, 184, 185
  - newly installed disk, 61
  - system disk booting, 188
- FIELD account
  - creating after installation or upgrade, 132

**G**

- Getting Started
  - setting up and booting, 6
- Gigabit Ethernet
  - cluster, 34
- Graphics
  - console device, 10, 16
  - interface, DECwindows, 44
  - option
    - multihead configuration, 111

**H**

- Halting the system, 163
- Hard links
  - specifying, 60
- Hardware
  - documentation
    - HP Integrity servers, 137
  - problems, diagnosing
    - HP Integrity servers, 165
- HP Binary Checker
  - installing, 68
  - installing or upgrading, 45
  - upgrading, 85
- HP Integrity servers
  - boot behavior
    - configuring, 144
  - boot device
    - setting, 144, 146
    - showing, 144, 146, 148
  - boot flag parameters
    - setting, 146
  - boot options
    - during upgrade, 83
    - EFI boot menu, 141
    - managing, 144
  - booting
    - automatic, 145, 148
    - conversational, 157
    - emergency, 159
    - failure, 165
    - from a different root, 159
    - manually, 156
    - with minimum startup, 158
    - with XDELTA, 159
  - documentation, 137
  - halting, 163
  - hangs or crashes, 163
  - shutting down, 164
  - system event log (SEL), 151
  - troubleshooting procedures, 166
  - utilities and console options, 137-140, 137-140
- Hyper-Threading
  - enabling and disabling, 144
  - saving or restoring state of, 149

**I**

- iLO (Integrated Lights Out), 137
- InfoServer
  - booting, 179
  - client configuration, 168
  - LAN devices supported, 168
  - losing connection, 183
  - software application
    - boot server configuration, 175
    - booting OpenVMS, 179
    - configuration, 166-184
    - server configuration, 172
  - troubleshooting, 183

- INITIALIZE
  - option
    - alternative use of, 199
    - on OpenVMS main menu, 46, 58
- Installable products
  - displaying, 48
- Installation, 9
  - and AUTOGEN, 100
  - booting
    - new system disk, 74, 98
    - operating system DVD, 9
  - completing the procedure, 71
  - component options, list of, 71
  - help text, 69
  - information needed for OpenVMS Cluster, 31-34
  - layered products, 68, 71
    - after installation or upgrade, 129
  - license registration, 67
  - PCSI, 45
  - procedure, 56-76
  - rebooting system, 102
  - selecting component options, 70
  - setting passwords, 61
  - specifying OpenVMS Cluster configuration, 103
  - stages of, 9
  - system information, providing, 61
  - third-party networking software, 111
  - windowing and networking products, 68
- Installed products
  - displaying, 51
  - removing, 53
- IPC (Interrupt Priority C), 38
- IPF Offline Diagnostics and Utilities CD, 185

**K**

- Kerberos
  - configuring, 113
  - installing, 68
  - installing or upgrading, 45
  - upgrading, 85

**L**

- LAN devices
  - InfoServer support, 168
- Layered products
  - installing
    - after OpenVMS installation or upgrade, 129
    - alternative procedure, 130
    - during OpenVMS installation, 68, 71
    - during OpenVMS upgrade, 92
  - installing or upgrading independently of system, 49, 129
  - reconfiguring, 52
  - registering, 49
  - Secure Delivery, 49, 69, 87, 130
  - system upgrade effect on, 21

- LIBDECOMP.COM, 128
  - Libraries
    - compressing and decompressing, 101
    - expanding or compressing, 128
  - License Management utility
    - using, 105
  - Licenses, 67
    - registering
      - after installation or upgrade, 105
      - during installation, 67
    - requirements for system upgrade, 20
    - upgrade effect on layered products, 21
  - Logging in
    - problems due to forgotten password, 162
    - problems due to login procedure, 161
    - problems due to startup procedure, 161
  - Logical names
    - UAFALTERNATE, 163
  - Login command procedures
    - booting without, 161
    - errors preventing login, 161
  - Login welcome message
    - defining, 125
- M**
- Migration support, 31, 35
  - Minimum startup, 158
  - Mixed-architecture OpenVMS Cluster systems, 31, 35, 37
  - Mixed-version OpenVMS Cluster systems, 31, 35, 37
  - MODPARAMS.DAT parameter file
    - modifying after installation or upgrade, 133, 133
    - modifying after upgrade, 134
    - modifying before upgrade, 26
    - modifying for cluster, 134
  - MP (Management Processor)
    - description, 137
    - setting as console interface, 10
  - Multihead system
    - configuring, 111
- N**
- NETCONFIG.COM procedure
    - running, 110
  - Network booting
    - InfoServer, 166-184
  - Network proxy authorization files
    - creating, 109
  - Networking products, 111
    - (see also TCP/IP Services for OpenVMS, DECnet, DECnet Phase IV, DECnet-Plus)
    - configuring, 110
    - installing, 68
    - reconfiguring, 52
    - third-party
      - installing, 111
    - upgrading, 85
  - nPartition
    - ACPI configuration, 16
    - BIB (boot-is-blocked state), 153, 164, 165
    - boot phase, 152
    - hardware booting, 152
    - reboot for reconfiguration, 164
    - shutdown for reconfiguration, 164
    - software booting, 152
- O**
- ODS-2
    - selecting on installation, 59
    - selecting on upgrade, 81
  - ODS-5
    - selecting on installation, 59
    - selecting on upgrade, 81
  - OE (Operating Environment)
    - for OpenVMS
      - licensing, 67
      - options, 71
  - On-Disk Structure Level
    - specifying, 59
  - OPCCRASH.EXE, 165
  - OpenVMS Boot Manager (BOOT\_OPTIONS.COM) utility, 144
    - adding boot entry for system disk, 61, 145
    - changing EFI boot timeout value, 149
    - displaying boot options, 148
  - OpenVMS Boot Manager utility
    - overview, 141
  - OpenVMS Cluster
    - BACKUP caution, 190
    - becoming a member
      - during installation, 62
      - during upgrade, 84
    - configuring
      - after installation, 62, 103
      - during installation, 103
    - EXPECTED\_VOTES parameter, 134
    - group number
      - rules for creating, 34
    - information required for OpenVMS installation, 31-34
    - installation
      - prompts, 103, 103
    - installing, 103
    - installing TDC\_RT, 124
    - label for system disk, 189
    - migration support, 31, 35
    - mixed-version support, 35
    - parameters
      - after upgrade, 134
    - password
      - rules for creating, 34
    - quorum
      - adjusting using Availability Manager or DECams, 39
      - adjusting using IPC, 38

- maintaining during rolling upgrades, 38
    - rebooting members, 133
    - upgrade
      - concurrent, 36
      - preparing for, 35-39, 36, 37
      - rolling, 37, 37
      - setting membership information, 84
      - types of, 36-39
    - warranted support, 31, 35
  - OpenVMS HP Integrity servers
    - boot behavior
      - configuring, 145
    - boot flags, 146
    - booting
      - automatic, 148
      - conversational, 157
      - from a different root, 159
      - manually, 156
      - with minimum startup, 158
      - with XDELTA, 159
    - shutting down, 164
  - OpenVMS Installation Menu
    - using, 42-56
  - OpenVMS Management Station
    - preparing to use, 124
  - Operating system
    - files
      - removing, 197
  - Operating system DVD
    - booting for installation, 42
  - Operating system menu
    - accessing DCL, 56
    - displaying installed products, 51-52
    - displaying layered products, 48
    - installing OpenVMS, 45, 56-76
    - installing or upgrading layered products, 49-51
    - patches and recovery data operations, 55-56
    - reconfiguring installed products, 52-53
    - removing installed products, 53-55
    - shutting down the system, 56
    - upgrading OpenVMS, 45, 77-92
- P**
- Page file
    - checking size, 134
    - modifying size, 101
  - PAK (Product Authorization Key)
    - registering after an installation or upgrade, 105
    - registering during installation, 67
  - Partition Manager, 140
  - Password
    - forgotten, 99, 162
    - minimum length, 61
    - setting during installation, 61
  - Patches
    - finding, installing, removing
      - using distribution media menu option, 55
    - installing from download, 128
    - Secure Delivery, 128
  - PCSI
    - and recovery data, 80
    - installing layered products independently, 131
    - installing patches
      - using FTP, 128
    - installing the operating system, 45
    - upgrading the operating system, 45
  - Performance Data Collector base software (TDC\_RT)
    - compatibility with prior releases, 123
    - initializing and running, 122
    - installing, 68
      - in OpenVMS Clusters, 124
    - installing or upgrading, 45
    - running the software, 124
    - startup file, 123
    - upgrading, 85
    - user privileges and quotas, 122
  - Postinstallation tasks
    - accounts, 132
    - AUTOGEN
      - tuning the system, 101
    - Availability Manager configuration, 113
    - backing up the system disk, 104, 132
    - CDSA initialization, 112
    - checklist, 96
    - customizing the system, 108-111
    - DECnet configuration, 110
    - Kerberos configuration, 113
    - layered products, 129
    - license registration, 105
    - login welcome message, 125
    - MODPARAMS.DAT file, 133
    - network proxy authorization files, 109
    - OpenVMS Management Station, 124
    - patches, 128
    - print queues, 131
    - queue manager and default queues, 109
    - shadow sets
      - system parameters, 106
    - shadow sets, forming, 107
    - SSL configuration, 114
    - SYSTARTUP\_VMS.COM procedure, 111, 131
    - system files, 126
    - system libraries, 128
    - TCP/IP Services for OpenVMS configuration, 111
    - TDC\_RT initialization, 122
    - testing the system, 132
    - third-party networking software configuration, 111
    - WBEM Providers for OpenVMS, 119
    - WBEM Services for OpenVMS configuration, 115
  - Postupgrade tasks
    - accounts, 132
    - AUTOGEN
      - turning the system, 101
    - Availability Manager configuration, 113
    - backing up the system disk, 104, 132
    - CDSA initialization, 112

- checklist, 96
  - cluster members, 133
  - command procedure templates, 125
  - customizing the system, 108-111
  - DECnet configuration, 110
  - dump file size, 101
  - Kerberos configuration, 113
  - layered products, 129
  - license registration, 105
  - login welcome message, 125
  - MODPARAMS.DAT file, 133, 133
  - network proxy authorization files, 109
  - OpenVMS Management Station, 124
  - page file size, 101
  - patches, 128
  - print queues, 131
  - queue manager and default queues, 109
  - shadow sets
    - license required, 105
  - shadow sets reformation, 132
  - shadow sets, forming, 107
  - SSL configuration, 114
  - swap file size, 101
  - SYSTARTUP\_VMS.COM procedure, 111, 132
  - system files
    - adding or removing, 126
    - sizes, 134
  - system libraries, 128
  - TCP/IP Services for OpenVMS configuration, 111
  - TDC\_RT initialization, 122
  - testing the system, 132
  - third-party networking software configuration, 111
  - tuning the operating system, 101
  - WBEM Providers for OpenVMS configuration, 119
  - WBEM Services for OpenVMS configuration, 115
  - Preinstallation tasks
    - collecting information for, 43
  - PRESERVE option, 47
  - Preupgrade tasks
    - backing up system disk, 28
    - checklist, 19
      - OpenVMS Cluster, 35
    - FEEDBACK.DAT file, 26
    - shutting down system, 29
    - system disk, 22, 23
    - volume shadowing, 27
  - Print queue
    - creating after installation or upgrade, 131
    - default
      - creating, 109
  - Problems
    - booting, 160
      - troubleshooting, 165
    - locked out of system, 162
    - logging in, 161, 162
  - PRODUCT INSTALL command, 130
  - PRODUCT REMOVE command
    - files not removed with, 197, 198
    - removing operating system files, 197
- ## Q
- Queue database
    - creating, 109
  - Queue manager
    - starting, 109
  - Quorum
    - adjusting, 38, 39
    - maintaining during rolling upgrades, 38
- ## R
- Reboot, 102
    - (see also Boot, Booting)
    - after AUTOGEN, 102
    - after installation, 102
    - automatic after AUTOGEN, 102
    - example, 160
    - OpenVMS Cluster members, 133
  - Recovery data
    - checking for during upgrade, 80
    - displaying and installing
      - using distribution media menu option, 55
  - Release notes
    - after installation or upgrade, 108
  - Remedial kits
    - deleting archived files, 21
    - saving archived files, 21
  - Removing operating system files, 197
  - Restoring system disk, 192
    - without booting the OpenVMS CD or DVD, 193
  - Restrictions
    - for OpenVMS upgrade, 20
  - Rolling upgrades
    - caution, 39
    - description, 37
    - maintaining cluster quorum, 38
    - preparing system for, 37
    - restrictions, 37
- ## S
- SAN disk, 188
  - SAN storage device
    - delay in EFI initialization, 43, 154, 186
  - Satellite booting, 170
  - Save sets
    - transferring to system disk, 58
  - SCSSYSTEMID system parameter
    - specifying, 63
  - Secure Delivery
    - and distribution kits, 49, 69, 87, 130
    - and installing patches, 128
  - Selecting active console devices, 16
  - SET BOOT command, 150
  - SETBOOTBLOCK command, 150
  - Shadow sets, 27
    - (see also Volume shadowing)

- adding to boot and dump device lists, 61, 83
- backing up system disk, 193
- forming, 107
  - license required, 105
  - system parameters, 106
- reforming, 132
- system disk
  - upgrading, 27
- Shutdown
  - after installation, 102, 102
  - before an upgrade, 29, 36, 38
  - procedures, 164
- Shutdown option, 56
- SHUTDOWN.COM, 164, 164
- SIPs (System Integrated Products)
  - installing after installation or upgrade, 129
  - Secure Delivery, 49, 130
    - during installation, 69
    - during upgrade, 87
- Site-specific command procedures
  - restored during upgrade, 125
- Source drive, 191
- SSL for OpenVMS
  - configuring, 114
  - installing, 68
  - installing or upgrading, 45
  - upgrading, 85
- Standalone Backup, 193
- Startup command procedure
  - errors preventing login, 161, 161
- Swap file
  - checking size, 134
  - modifying size, 101
- SWAPFILES.COM procedure
  - executing to change system file sizes, 134
- SYSS\$BATCH queue
  - creating, 109
- SYSS\$EFI.SYS file
  - and writing a boot block, 150
- SYSS\$PRINT queue
  - creating, 109
- SYSS\$UPDATE.STABACKIT.COM procedure, 193
- SYSS\$WELCOME
  - defining, 125
- SYSBOOT.EXE, 157
  - commands, 158
- SYSGEN
  - ALLOCLASS parameter
    - for shadow sets, 106
    - setting during installation, 33, 103
  - commands for conversational boot, 158, 158
- SYSTARTUP\_VMS.COM procedure
  - editing to control DECnet Phase IV, 110
  - for starting network software at boot, 111
  - updating to start layered products and print queues, 132
- System
  - customizing, 108-111
- files
  - adding, 126
  - removing, 126
- hang, 166
- libraries
  - compressing and decompressing, 101
  - expanding or compressing, 128
- parameters
  - booting with default, 160
  - for volume shadowing, 106
  - incorrect values prevent boot, 160
  - modifying after installation or upgrade, 133
  - modifying after upgrade, 134
  - modifying before upgrade, 26
  - verifying, 25
- problems
  - troubleshooting, 165, 166
- shutting down before upgrade, 29
- startup in an emergency, 159
  - with default system parameters, 160
  - without startup and login procedures, 161
  - without the UAF, 162
- SYSTEM account
  - forgotten password, 99
  - logging in, 99
  - setting password, 61
- System disk
  - adding boot entry to EFI Boot Manager menu, 61, 74, 83, 90, 145
  - adding system files, 126
  - analyzing and repairing, 23
  - backing up, 189-196
    - after an installation, 132
    - after installation or upgrade, 104
    - alternate disk for, 193
    - before an upgrade, 28
  - boot options, 145
  - booting, 98, 156
    - after installation, 102
  - creating, 58
  - initializing, 58, 77
    - alternative methods, 46, 199, 199
  - preparing an alternate for backup, 194
  - preparing for upgrade, 22
  - preserving, 47, 58, 77
  - removing system files, 126
  - restoring, 192
  - specifying
    - during installation, 58
    - during upgrade, 78
  - unique volume label requirement, 189
  - upgrading, 27
- System event log (SEL), 151
- SYSTEST account
  - creating after installation or upgrade, 132
- SYSUAFALT.DAT file, 163

**T**

- Target disk
  - using backup copy for, 28
- Target drive, 191
- TCP/IP
  - third-party
    - installing, 111
- TCP/IP Services for OpenVMS
  - configuring, 111
  - installing, 68
  - installing or upgrading, 45
  - upgrading, 85
- TDF
  - setting during an installation, 66
- Time zones
  - setting during an installation, 64
  - updating during an upgrade, 84
- Timeout
  - EFI boot option, 149
- Troubleshooting
  - InfoServer boot problems, 183
  - system problems, 165
- Tuning operating system, 101

**U**

- UAFALTERNATE logical name, 163
- UETP (User Environment Test Package), 132
- Uninstall
  - OpenVMS operating system, 197
  - recovery data for, 80
- Upgrade, 77
  - cautions and restrictions, 20
  - concurrent (OpenVMS Cluster), 36
  - disk space requirement, 24
  - effect
    - on command procedures, 125
    - on MODPARAMS.DAT file, 133
  - OpenVMS Cluster
    - preliminary tasks, 35-39
    - preparing for, 35-39
    - required operating system version, 37
  - paths, 20
  - PCSI, 45
  - preparation checklist, 19
  - procedure, 77-92
  - recovery data, 80
  - rolling (OpenVMS Cluster), 37
  - shadowed disks, 27
  - time zones, 84
- User accounts
  - creating after installation or upgrade, 132

**V**

- VGA graphics as console device, 15, 16
- vms\_bcfg command, 148, 149
- vms\_show command, 149
- VMSINSTAL utility, 130

- installing layered products independently, 131
- Volume label
  - requirement for OpenVMS Clusters, 189
  - specifying
    - during installation, 58
    - during upgrade, 81
- Volume shadowing, 27
  - (see also Shadow sets)
  - backing up the system disk, 193, 193
  - forming shadow set, 107
    - license required, 105
    - system parameters, 106
  - preparing for upgrade, 27
  - reforming shadow set, 132
- VOTES parameter
  - checking for rolling upgrades, 38

**W**

- Warranted support, 31, 35
- WBEM Providers for OpenVMS
  - configuring, 119
- WBEM Services for OpenVMS
  - configuring, 115
  - installing, 68
  - installing or upgrading, 45
  - upgrading, 85
- Welcome message
  - defining, 125
- Windowing products
  - installing, 68
  - reconfiguring, 52
  - upgrading, 85