digital

DEC 3000 Model 400S/600S/700S AXP Rackmount Server Installation/Owner's **Guide Information Update**

EK-RSNDP-UD. A01

January 1995

This document provides updated installation information for the DEC 3000 Model 400S/600S/700S AXP Rackmount Server Installation/Owner's Guide, Order Number: EK-RSNDP-IN. C01.

This addendum describes changes to the topic, Preparing the Slides, in Chapter 3, *Installing the Rackmount Server*, as follows:

- Step 1 Adds front and rear RH brackets.
- Step 4 Identifies the rear bracket (Item 5) as the right hand (RH) rear bracket.
- Step 5 Identifies the rear bracket (Item 5) as the right hand (RH) rear bracket.
- Step 7 Identifies the front bracket (Item 10) as the right hand (RH) front bracket.
- Steps 8a and b Identifies the front bracket (Item 10) as the right hand (RH) front bracket.
- Step 9 Adds front and rear LH brackets.
- Step 10 Identifies the rear and front brackets as left hand (LH) rear and front brackets.

© Digital Equipment Corporation 1995. All Rights Reserved.

Digital Equipment Corporation makes no representations that the use of its products in the manner described in this publication will not infringe on existing or future patent rights nor do the descriptions contained in this publication imply the granting of licenses to make, use, or sell equipment or software in accordance with the description.

Preparing the Slides

Please mark the procedure on pages 3-2 and 3-3 in your system manual to reflect this updated information.

- 1. Find the slide assembly ①, and front ② and rear ⑤ bracket, all labeled RH that are shipped with the system. (If the slide assemblies are not labeled, pull out the inside race ② until the arrow ③ and locking lever ④ are visible (do not remove the inside race). The RH slide is the one with the locking lever ④ pointing to the left and the arrow ③ next to it pointing upward as shown in Figure 3-1. Mark the slide RH.)
- 4. Slide the long bracket (rear bracket labeled RH) **6** on the rear of the slide assembly **1** in the direction of the arrow.
- 5. Fasten the rear bracket (RH) **6** to the slide assembly **1** using two 8-32 screws **6**, flat washers **7**, lock washers **9** and nuts **9**.
- 7. Slide the short bracket (front bracket labeled RH) **10** on the front of the slide assembly **10** in the direction of the arrow.
- 8. To fasten the front bracket to the slide assembly, proceed as follows:
 - a. Pull out the inside slide 1 about half way, enough to align two half-inch access holes on the inside slide with the mounting holes 2 on the slide assembly 1 and the front bracket labeled RH 0.
 - b. Fasten the front bracket labeled RH ① to the slide assembly ① using two 8-32 screws ②, flat washers ④, loc washers ⑤, and nuts ⑥.
- 9. Find the slide assembly \bullet , and front and rear brackets \bullet \bullet , all labeled LH that are shipped with the system.
- 10. Attach the rear and front brackets (labeled LH) following steps 2 through 8.