EK-PCIRM-RN. C03


OpenVMS currently supports only the CCMAA-AA PCI adapter

If you are running OpenVMS on your MEMORY CHANNEL cluster, you must use only CCMAA $-\underline{\mathbf{A}}$ A adapters in your systems' PCI slots. Support for CCMAA $-\underline{\mathbf{B}}$ A is expected soon, but is not yet available.

To verify the CCMAA adapter variant, check the 54-part barcode label on the end of the board. The CCMAA-AA adapters have an -01 extension as shown in Figure 1-1. The CCMAA-BA adapters have an

-02 extension.

Figure 1-1: Identifying the CCMAA-AA Adapter Variant



bx0854J-96

Table 1-1: CCMAA Adapters, Variant, and Operating Systems

CCMAA	54-class P/N min rev	Use with Operating System
-AA	54-23663-01.C05	Open VMS and Digital UNIX
-ВА	54-23663-02.A01	Digital UNIX only

_

[™] Memory Channel is a trademark of Encore Computer Corporation.