



RAID Array 450 Unpacking and Installation

Refer to the *Getting Started* manual, which can be found in the Platform Kit for your specific system, for unpacking and installing your StorageWorks RAID Array 450 Subsystem

This box contains:

- DS-SWXRA-Wx StorageWorks RAID Array 450 Subsystem
- *RAID Array 450 Office Expansion Enclosure User's Guide* (EK-SMCPN-UG) or the *RAID Subsystem Shelf* (EK-SMCPJ-UG)
- Serial Communications Kit
- Power Cable
- Enclosure Keys
- Single HSZ50-AF controller with 32MB of cache memory
- Single Intelligent Write-Back Cache Battery
- Tri-link connector
- Tri-link terminator
- Either a 5- or a 10-meter host SCSI cable
- One dual redundant SCSI cable

WARNING

The procedures for unpacking and installing Digital's enclosures vary from product to product. Refer to the instructions in the referenced manual for the proper procedures for this product.

Serious injury or equipment damage can result if the specified procedures are not followed.

NOTE

Make sure that the RAID Controller Write-back Cache battery is fully charged. This is accomplished by supplying power to the RAID Controller for up to 6 hours.
