

MS7AA-FA Memory Module Service Guide

Order Number: EK-MS7AA-SV .A01

These instructions describe the procedure for identifying and replacing a failing SIMM on the VAX 7000/10000 or DEC 7000/10000 MS7AA-FA 2-gigabyte memory module.

Copyright © Digital Equipment Corporation. 1994. All rights reserved.

**Digital Equipment Corporation
Maynard, Massachusetts**

The MS7AA-FA memory module is the 2-gigabyte memory module for VAX 7000/10000 and DEC 7000/10000 systems. It is populated with 36 64-Mbyte single in-line memory modules (SIMMs). Should a SIMM fail it can be replaced in the field.

These instructions tell how to identify the failing SIMM and how to replace a SIMM.

- Section 1 tells how to identify the failing SIMM from the operating system error log.
- Section 2 tells how to replace the SIMM.
- Section 3 tells how to identify the SIMM from the console level. This information may be needed if the operating system cannot be booted.

NOTE

The part number for the 64-Mbyte SIMM is 54-21718-01. This SIMM can only be used on a 2-Gbyte module.

1 How to Identify a Failing SIMM from an Operating System Error Log

First you must identify the failing SIMM.

1. From the error log, locate the error syndrome (for OpenVMS, see Example 1).
2. Determine if the string is odd or even; is it string 1, 3, 5, or 7, or string 0, 2, 4, or 6?
3. Determine if the memory interface controller (MIC) error is a MIC A or a MIC B error.
4. Find the SIMM number in the matrix of Table 1.

For example, from the OpenVMS AXP error log in Example 1, you see:

- The MS7AA-FA module has an error syndrome 34 (see ❶).
- The failing string is 3, which is odd (see ❷).
- The MIC is B (see ❸).

Therefore, from Table 1 you find 34 in the first column, labeled Syndrome. The string, 3, is odd so you look at the columns labeled Odd. The number under MIC B is J31, the socket that holds the failing SIMM.

NOTE

The OSF/1 operating system error log will appear in the next version of this document.

Example 1: Sample OpenVMS System Error Report

```
V M S                      SYSTEM ERROR REPORT                      COMPILED 24-JAN-1994 08:28:00
                                                                    PAGE 23.

***** ENTRY 84. *****
ERROR SEQUENCE 630.          LOGGED ON: CPU_TYPE 00000002
DATE/TIME 21-JAN-1994 10:27:26.26      SYS_TYPE 00000003
SYSTEM UPTIME: 0 DAYS 16:29:20
SCS NODE: SUVB02                      VMS V1.5

HW_MODEL: 00000402 Hardware Model = 1026.

MEMORY ERROR KN7AA DEC 7000 MODEL 620
  CRD FLAGS          0000
  LOG REASON        0004
RELATED ENTRY 1 OF 1
  BAD PAGES         00000000
  MEMDSC SIZE      00000020
  MEMDSC OFFSET    00000060
  NUM OF FPRINTS   00000001
  FPRINT SIZE      00000050
  FPRINT OFFSET    00000080

MEMORY DESCRIPTOR #1
  NODE              00000006
  LDEV              00004000
  MCR                0000000C
  AMR                00000343

MEMORY DESCRIPTOR #2
  NODE              00000007
  LDEV              00004000
  MCR                0000000C
  AMR                0000034B

1 FOOTPRINTS IN THIS PACKET
CRD FOOTPRINT #1
  FOOTPRINT         0004000D
                   00000006

                                Syndrome = 34(X) ①
                                Bit in Error = 6.
                                Failing string = 3. ②
                                MICB error        ③
                                Failing node = 6.
                                20-JAN-1994 20:18:02.93

SYSTEM TIME
LOW ADDRESS          00000000 0153AE00
HIGH ADDRESS        00000000 115E2600
CUM ADDRESS         00000000 100DF800
SCRUB BLOCKSIZE    00000040
STATIC FLAGS       0001
LOG REASON         0008
CALLER FLAGS       00000000
SCRUB FAIL         00000000
MATCH COUNT        0000000E
SCRUB COUNT        0000000E
LAST SCRUB TIME    21-JAN-1994 08:50:02.93
```

Table 1: 2-Gigabyte SIMM Isolation Matrix

		String: Even		Odd				String: Even		Odd		
Syndrome	MIC		MIC		Syndrome	MIC		MIC		Syndrome	MIC	
	A	B	A	B		A	B	A	B			
00	na	na	na	na	51	J10	J34	J11	J35			
01	J22	J36	J23	J37	52	J10	J34	J11	J35			
02	J22	J36	J23	J37	54	J8	J28	J9	J29			
04	J20	J36	J21	J37	58	J4	J28	J5	J29			
07	J2	J24	J3	J25	61	J4	J18	J5	J19			
08	J18	J36	J19	J37	62	J4	J20	J5	J21			
0B	J22	J30	J23	J31	64	J4	J20	J5	J21			
0D	J2	J24	J3	J25	68	J10	J14	J11	J15			
0E	J14	J26	J15	J27	70	J4	J22	J5	J23			
10	J18	J32	J19	J33	80	J14	J26	J15	J27			
13	J8	J16	J9	J17	83	J10	J22	J11	J23			
15	J8	J20	J9	J21	85	J12	J18	J13	J19			
16	J14	J32	J15	J33	86	J20	J36	J21	J37			
19	J10	J36	J11	J37	89	J6	J26	J7	J27			
1A	J10	J26	J11	J27	8A	J12	J26	J13	J27			
1C	J8	J16	J9	J17	8C	J6	J22	J7	J23			
1F	J24	J32	J25	J33	8F	J18	J34	J19	J35			
20	J14	J34	J15	J35	91	J6	J28	J7	J29			
23	J12	J14	J13	J15	92	J10	J28	J11	J29			
25	J6	J18	J7	J19	94	J2	J28	J3	J29			
26	J20	J32	J21	J33	98	J8	J30	J9	J31			
29	J4	J26	J5	J27	A1	J2	J32	J3	J33			
2A	J10	J26	J11	J27	A2	J12	J30	J13	J31			
2C	J2	J24	J3	J25	A4	J12	J36	J13	J37			
2F	J6	J20	J7	J21	A8	J4	J30	J5	J31			
31	J8	J30	J9	J31	B0	J18	J34	J19	J35			
32	J6	J30	J7	J31	C1	J20	J32	J21	J33			
34	J12	J30	J13	J31	C2	J18	J34	J19	J35			
38	J2	J28	J3	J29	C4	J16	J28	J17	J29			
40	J14	J30	J15	J31	C8	J16	J28	J17	J29			
43	J6	J24	J7	J25	D0	J8	J22	J9	J23			
45	J2	J24	J3	J25	E0	J24	J34	J25	J35			
46	J16	J36	J17	J37	F1	J2	J16	J3	J17			
49	J8	J26	J9	J27	F2	J16	J32	J17	J33			
4A	J4	J32	J5	J33	F4	J22	J34	J23	J35			
4C	J6	J24	J7	J25	F8	J12	J14	J13	J15			
4F	J12	J16	J13	J17								

2 How to Replace a SIMM


After you have determined the failing SIMM on the memory module, remove the module from the system and follow this procedure.

CAUTION

You must wear an antistatic wrist strap attached to the cabinet when you handle any modules.

1. Remove the cover that shields side 1 of the module by removing the eight small Phillips screws.
2. Determine the location of the failing SIMM from Figure 1.
3. Locate the row of SIMMs on the module that holds the failing SIMM.


Figure 1: SIMM J Connector Numbers



BXB-0687-94

4. Beginning with the SIMM closest to the gate arrays, remove each SIMM up to and including the failing SIMM. To remove a SIMM, release the latches on both ends of the SIMM connector. Insert a #1 Phillips screwdriver as shown in Figure 2, and rotate the screwdriver until the latch releases. Open both latches. Then turn the SIMM at a 45 degree angle toward the gate arrays and pull the card out of the connector.
5. Put the failing SIMM aside for return to the appropriate repair facility.
6. Insert a new SIMM in place of the failing SIMM, angling it into the connector at 45 degrees. Turn it to a vertical position until the latches snap into place. The connector is keyed in the center so that the correct side of the SIMM faces front.
7. Insert the other SIMMs back into their connectors.
8. Replace the module cover.

Figure 2: Removing a SIMM



BXB-0699A-94

3 How to Identify a Failing SIMM at Console Level on a DEC 7000/10000

While in console mode, you can determine which SIMM has failed. Example 2 shows a sample console session with the steps to take to identify a failing SIMM.

Example 2: Sample Console Display

```
>>> set mode diag 1
>>> set d_startup on
d_startup set to on

>>> show mem 2

Set   Node   Size   Base Addr   Intlv   Position
---   ---   ---   ---         ---   ---
A     1     2048Mb 000000000   2-Way   0

3 # 2048MB = 2GB = 8000 0000 (hex)

>>> mem_ex -t 1 -sa 1000000 -ea 7ffffffc0

4 # 8000 0000 - 40 = 7FFF FFC0

-----
ID   Program   Device   Pass Hard/Soft Test   Time
-----
49   mem_ex     mem      0     0     0     20:59:54

CPU 0
unexpected exception/interrupt through vector 00000066
process mem_ex, pcb = 007F0620

pc: 00000000 000D6B40 ps: 30000000 00000004
r2: 00000000 0013F8A0 r5: 00000000 00001F04
r3: 00000000 001ECCA0 r6: 00000000 1FBFFFF0
r4: 00000000 00000020 r7: FFFFFFFF FFFFFFFF

      [listing of GPRs and FPRs]

Machine Check Logout - base: 00006000

flags:      00000000 00000000      byte_count: 80000000 000001D8
offsets:    000001A0 00000110      das_debug:  00E00555 00000020
pt0:       00000001 00000100      pt1:        00000000 000000FC

      [listing of registers]

lbesr2:     00000000 0000007F      lbesr3:     00000000 0000007F
lbecr0:     00000000 03000500 5      lbecr1:     00000000 000C8040
# 03000500 x 20 (hex) = 6 000A000

lmmr0:      00000000 00000000      lmmr1:      00000000 00000321

      [more registers]

ms7aa0_lber:00000000 00040203      ms7aa0_lbecr0: 00000000 03000500
ms7aa0_lbecr1:00000000 000C8040      ms7aa0_mera:  00000000 00000C07
ms7aa0_msynda:00000000 000000F3      ms7aa0_merb:  00000000 00000007
ms7aa0_msyndb:00000000 000000F3

Failing FRU: ms7aa0 6
>>> CPU:0 Halt Code = 1
operator initiated halt
PC = 13ee0c

>>> dep -l ms7aa0:21c0 10000002 7

>>> mem_ex -t 1 -f -sa 60000000 -l 2000000 8
```

Example 2 (continued on next page)

Example 2 (Cont.): Sample Console Display

```

      ID Program          Device      Pass Hard/Soft Test      Time
-----
      4f mem_ex           mem        0    0    0      21:01:29

>>> dep -l ms7aa0:21c0 10000000      ⑨
>>> dep -l ms7aa0:2140 ff            ⑩
>>> dep -l ms7aa0:2440 ff
>>> mem_ex -t 1 -f -sa 60000000 -l 2000000      ⑪

      ID Program          Device      Pass Hard/Soft Test      Time
-----
      51 mem_ex           mem        0    0    0      21:01:31

>>> ex -l ms7aa0:2140      ⑫      # Address of MERA register
ms7aa0: 00002140 00000015
>>> ex -l ms7aa0:2180      ⑬      # Address of MYSNDA register
ms7aa0: 00002180 00000045      ⑭
>>> ex -l ms7aa0:4180      # Address of MYSNDB register
ms7aa0: 00004180 000000F3
>>> ex -l ms7aa0:2100      ⑮      # Address of FADR register
ms7aa0: 00002100 03000500      ⑯
>>>

```

- ① Enter diagnostic mode.
- ② Determine the size of physical memory using the **show memory** command.
- ③ Subtract 40 from the highest memory address to determine the ending address for `mem_ex`.
- ④ Run `mem_ex` test 1 from 16 meg (100 0000) to the top of memory.
- ⑤ Multiply the contents of the `LBERC0` register by 20 (hex) to get the failing address.
- ⑥ Determine the failing memory module, `ms7aa0`.
- ⑦ Disable ECC checking on the failing module.
- ⑧ Initialize all of memory on the failing module by running `mem_ex` test 1 with the `-f` option on the 32 meg address block that contains the failing address. This will clear the double-bit errors that were generated during memory self-test.

Starting address = 30 0500 X 20 = 6000 A000 = failing byte address
 ^ from callout ⑯

Test address = 6000 0000
 Length = 20 0000

- ⑨ Enable ECC checking on the memory module by depositing 1000 0000 into Memory Diagnostic Register A.
- ⑩ Clear the error registers on the memory module.
- ⑪ Run `mem_ex` test 1 with the `-f` option on the 32 meg address block that contains the failing address.
- ⑫ Examine Memory Error Register A on the failing memory module to determine the failing syndrome (see Figure 3).
- ⑬ Examine Memory Error Syndrome Registers A and B to determine the failing bank.

- ⑭ The contents of Memory Error Syndrome Register A gives the error syndrome.
- ⑮ Examine the Failing Address Register (FADR) on the failing module. Use Table 2 to determine if the failing string is Odd or Even.
- ⑯ The contents of FADR indicates the string.

From this information you can identify the failing SIMM.

For example, from the console display in Example 2, you see:

- The MS7AA-FA module has an error syndrome 45 (see ⑭).
- The string is even (see ⑮). From the **show mem** command (see ②) we know the interleave is 2-way. Using the contents of FADR ⑯ and Table 2 we know the string is even.
- The MIC is A (see ⑫) because CERA is set in MERA (see ⑫ and Figure 3).


Therefore, from Table 1 you find 45 in the first column, labeled Syndrome. The failing string is even so you look at the columns labeled Even. The number under MIC A is J2, the socket that holds the failing SIMM.

Table 2: Using FADR Bit to Determine Odd/Even String

No. of 2-Gbyte Modules	Interleave Count	FADR Bit
1*	2	bit 1 (0 = Even string 1 = Odd string)
2	4	bit 2 (0 = Even string 1 = Odd string)
4	8	bit 3 (0 = Even string 1 = Odd string)

*The interleave count for one 2-Gbyte module with four 512-Mbyte modules is 4. Use FADR bit 2 in this case.

Figure 3: Memory Error Register A



NOTE

For more information about the memory registers, see the *MS7AA Memory Technical Manual*.