

# DIGITAL NetRider

---

## DIGITAL Remote Access Security Installation

Part Number: AA-QWW7B-TE

June 1997

<b>Revision/Update Information:</b>	This is a revised document.
<b>Operating System and Version:</b>	Microsoft Windows NT, Version 3.51 or higher Microsoft Windows 95 OpenVMS Version 6.1 or higher DIGITAL UNIX Version 3.2 or higher
<b>Software and Version:</b>	DIGITAL Remote Access Security, Version 2.2

Digital Equipment Corporation makes no representations that the use of its products in the manner described in this publication will not infringe on existing or future patent rights, nor do the descriptions contained in this publication imply the granting of licenses to make, use, or sell equipment or software in accordance with the description.

Possession, use, or copying of the software described in this publication is authorized only pursuant to a valid written license from DIGITAL or an authorized sublicensor.

© Digital Equipment Corporation 1997. All rights reserved. Printed in U.S.A.

The following are trademarks of Digital Equipment Corporation: DEC, DECserver, DIGITAL, NetRider, OpenVMS, VAX, and the DIGITAL logo.

The following are third-party trademarks:

Defender is a trademark of Digital Pathways, Inc.

Intel is a registered trademark of Intel Corporation.

SecurID is a registered trademark of Security Dynamics Technologies, Inc.

S/Key is a trademark of Bellcore Labs.

UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Ltd.

WatchWord is a trademark of Racal-Guardata, Inc.

Windows 95 is a registered trademark of Microsoft Corporation.

Windows and Windows NT are trademarks of Microsoft Corporation.

All other trademarks and registered trademarks are the property of their respective holders.

# Contents

---

## Preface

## 1 Installation

Overview . . . . .	1-1
In This Chapter . . . . .	1-1
Software Components . . . . .	1-1
Release Notes . . . . .	1-1
Microsoft Windows NT and Windows 95 Installation . . . . .	1-2
Preparing for Installation . . . . .	1-2
Special Note About DHCP Clients . . . . .	1-2
Installing the Software . . . . .	1-3
Installing DRAS as an NT Service . . . . .	1-3
Starting the DRAS Server . . . . .	1-4
Starting the DRAS Manager . . . . .	1-4
Environment Variables . . . . .	1-4
Using HOST Authentication on Windows NT Domain Controllers . . . . .	1-5
Running DRAS in Console Trace Mode on Windows NT . . . . .	1-6
Running the DRAS Server in Debug Trace Mode . . . . .	1-6
Files Installed on Windows NT Systems . . . . .	1-7
Files Installed on Windows 95 Systems . . . . .	1-9
Deinstallation . . . . .	1-10
OpenVMS Installation . . . . .	1-11
Before You Install . . . . .	1-11
Installing the Software . . . . .	1-11
Logicals . . . . .	1-12
Starting the DRAS Server . . . . .	1-12
Running the DRAS Server in Debug Trace Mode . . . . .	1-13
Files Installed . . . . .	1-14
DIGITAL UNIX Installation . . . . .	1-16
Introduction . . . . .	1-16
Installing the Software . . . . .	1-16
Environment Variables . . . . .	1-18

Starting the DRAS Server as a Console . . . . .	1-18
Starting the DRAS Server as a Daemon . . . . .	1-18
Running the DRAS Server in Debug Trace Mode . . . . .	1-19
Stopping the DRAS Server . . . . .	1-19
Files Installed . . . . .	1-20
Deinstallation . . . . .	1-21
Postinstallation . . . . .	1-22
Introduction . . . . .	1-22
Configuring DECserver Units . . . . .	1-22
Registering DECserver clients . . . . .	1-23
Troubleshooting Management Connection Failures . . . . .	1-23

## A DRAS Server Initialization File

Overview . . . . .	A-1
In This Appendix . . . . .	A-1
Initialization File Description . . . . .	A-2
File Names . . . . .	A-2
Initialization File Example . . . . .	A-2
[Storage] Section . . . . .	A-4
Description . . . . .	A-4
Entry Descriptions . . . . .	A-4
[Server] Section . . . . .	A-6
Description . . . . .	A-6
Entry Descriptions . . . . .	A-6
[Policy] Section . . . . .	A-7
Description . . . . .	A-7
Entry Descriptions . . . . .	A-7
[Ports] Section . . . . .	A-9
Description . . . . .	A-9
Entry Descriptions . . . . .	A-9

---

# Preface

---

## Overview

### Purpose

This document explains how to install the DIGITAL Remote Access Security (DRAS) software for the following operating systems:

- Microsoft Windows NT
- Microsoft Windows 95 (management utility only)
- OpenVMS
- DIGITAL UNIX

### Intended Audience

This document is written for system or network administrators responsible for managing remote access network devices and remote access network connections.

## Conventions

This document uses the following conventions:

Convention	Description
<i>italics</i>	Italic text in commands indicates variables whose value you supply.
monospace	Monospaced text in command examples indicates system output.
<b>monospace bold</b>	Monospaced text in bold face in command examples indicates commands that you enter.

## Associated Documents

The following documents are available:

- *DIGITAL Remote Access Security Use*
- DRAS Manager online help
- *Network Access Server Management*

---

## How to Order Additional Documentation

To order additional documentation, use the following information:

---

<b>To Order:</b>	<b>Contact:</b>
By Telephone	USA (except Alaska, New Hampshire, and Hawaii): 1-800-DIGITAL (1-800-344-4825) Alaska, New Hampshire, and Hawaii: 1-603-884-6660 Canada: 1-800-267-6215
Electronically (USA only)	Dial 1-800-DEC-DEMO (For assistance, call 1-800-DIGITAL)
By Mail (USA and Puerto Rico)	DIGITAL EQUIPMENT CORPORATION P.O. Box CS2008 Nashua, New Hampshire 03061 (Place prepaid orders from Puerto Rico with the local DIGITAL subsidiary: 809-754-7575)
By Mail (Canada)	DIGITAL EQUIPMENT of CANADA LTD. 940 Belfast Road Ottawa, Ontario, Canada K1G 4C2 Attn.: A&SG Business Manager
Internationally	DIGITAL EQUIPMENT CORPORATION Attn.: A&SG Business Manager c/o local DIGITAL subsidiary or approved distributor
Internally	U.S. Software Supply Business (SSB) DIGITAL EQUIPMENT CORPORATION 8 Cotton Road Nashua, New Hampshire 03063

---

---

## Correspondence

### Documentation Comments

If you have comments or suggestions about this document, send them to the DIGITAL documentation organization.

Attn.: Documentation Project Manager

FAX: (508) 486-5655

E-mail: [doc\\_quality@lkg.mts.dec.com](mailto:doc_quality@lkg.mts.dec.com)

### Online Services

To locate product-specific information, refer to the following online services:

#### **BBS**

To read the Bulletin Board System, set your modem to 8 bits, no parity, 1 stop bit, and dial 508-486-5777 (U.S.). To call from outside the U.S., dial (access code) 1-508-486-5777.

#### **WWW**

The Digital Equipment Corporation Network Products Business Home Page on the World Wide Web is at the following addresses:

North America: <http://www.networks.digital.com>

Europe: <http://www.networks.europe.digital.com>

Australia: <http://www.digital.com.au/networks>



# Chapter 1

---

## Installation

---

### Overview

#### In This Chapter

This chapter provides instructions about installing the DIGITAL Remote Access Security (DRAS) software on systems that run Microsoft Windows NT, Microsoft Windows 95, OpenVMS, or DIGITAL UNIX operating systems.

#### Software Components

The following table lists the software components that the DRAS installation procedure installs:

<b>For This Operating System:</b>	<b>The Procedure Installs:</b>
Microsoft Windows NT	DRAS server software and the DRAS Manager (the management utility)
Microsoft Windows 95	DRAS Manager (the management utility)
OpenVMS	DRAS server software and the unsupported command line manager utility
DIGITAL UNIX	DRAS server software

#### **DRAS Server Management**

To manage a DRAS server running on a DIGITAL UNIX or OpenVMS system, use the DRAS Manager running on a Windows NT or Windows 95 system.

#### Release Notes

Each installation kit contains release notes. The release notes contain additional technical information that is not currently in the documentation. Please read the release notes before you use the DRAS software.

---

## Microsoft Windows NT and Windows 95 Installation

### Preparing for Installation

The following table lists the prerequisites for installing the DRAS software on a Microsoft Windows NT or Windows 95 system:

<b>For This:</b>	<b>You Need This for the DRAS Server:</b>	<b>And This for the DRAS Manager:</b>
Operating system	Windows NT Version 3.51 or 4.0	Either of the following: <ul style="list-style-type: none"><li>•Windows NT Version 3.51 or 4.0</li><li>•Windows 95</li></ul>
Memory	32 MB	32 MB
Disk space for files	Database files can vary depending on activity. See the Release Notes or README.TXT file for details.	Database files and user cache size can vary depending on activity. See the Release Notes or README.TXT file for details.
System setup	TCP/IP stack installed and running.	TCP/IP stack installed and running.

### Special Note About DHCP Clients

Do not install the DRAS server software on a Windows NT system that is a DHCP (Dynamic Host Configuration Protocol) client. A DHCP server can assign a different IP address to the DHCP client each time the client requests an IP address. This can cause problems with accessing the DRAS server.

## Installing the Software

To install the software, do the following:

Step	Action
1	<p>Insert the DRAS installation CD into your CD-ROM drive and run the appropriate SETUP.EXE file using the Program Manager or the Start menu:</p> <ul style="list-style-type: none"><li>•If installing on a Windows NT or Windows 95 Intel system, run \WINNT\I386\SETUP.EXE.</li><li>•If installing on a Windows NT Alpha system, run \WINNT\ALPHA\SETUP.EXE.</li></ul> <p><b>Example:</b> The following example installs the DRAS software on a Windows NT Intel system whose CD-ROM drive is drive D.</p> <pre>D:\WINNT\I386\SETUP.EXE</pre> <p>If this is a new installation or if you want to install DRAS into a different directory, reboot your system before proceeding.</p>
2	<p>To initialize your DRAS server's database, go to the DRAS installation directory and run the setupDb command line utility from a console window.</p> <p>Enter your management station's Internet address and its secret when prompted. The installation procedure creates a database that contains:</p> <ul style="list-style-type: none"><li>•An administration group object named Admin.</li><li>•A users group object named Users.</li><li>•An administrator user object. The procedure prompts you to enter a user name and password.</li><li>•A client object for a management station.</li><li>•Authentication objects for the standard authentication methods.</li></ul>

## Installing DRAS as an NT Service

After installing the DRAS software, install DRAS as an NT service. Use the following command in the NT console window:

```
C:\> Drassrv install
```

## Starting the DRAS Server

After you install the DRAS server as an NT service, do the following to start a DRAS server at any time:

Step	Action
1	Open the Control Panel.
2	Run the Services application.
3	Select Remote Access Security from the displayed list.
4	Click Start to start the DRAS service.

### Modifying Startup Parameters

When you install DRAS as an NT service, the startup type is set to manual. Use the Services application to modify the DRAS startup parameters if you want DRAS to start automatically each time the system boots.

## Starting the DRAS Manager

To start the DRAS Manager, click on the DRAS Manager icon in your DRAS program group. Refer to the *DIGITAL Remote Access Security Use* guide for details about using the DRAS Manager or see the DRAS Manager's online help.

## Environment Variables

The installation procedure defines the following environment variables:

Variable	Description
DRAS_DIR	Defines the full path where the DRAS server stores its database files. <b>Default Path:</b> \DRAS
DRAS_CALLOUT	Defines the full path where the DRAS callout DLL files reside. <b>Default Path:</b> \DRAS

## Using HOST Authentication on Windows NT Domain Controllers

If you install the DRAS server on a Windows NT server that is a primary domain controller, you must change the account of any local user that is authenticated by HOST authentication:

---

<b>Step</b>	<b>Action</b>
<b>1</b>	From the Programs menu, select Administrative Tools and then User Manager.
<b>2</b>	Click User and then New Local Group... from the menu.
<b>3</b>	Create a new group named "DRAS Users".
<b>4</b>	Click Policies and then User Rights from the menu.
<b>5</b>	Select "Log on locally" from the drop-down list box.
<b>6</b>	Add the right to the DRAS Users group.
<b>7</b>	Select the user accounts from which you will interactively run the DRAS server and add them as members of the DRAS Users group.

---

See the *DIGITAL Remote Access Security Use* guide for more information about HOST authentication.

## Running DRAS in Console Trace Mode on Windows NT

To perform host authentication on Windows NT while running in interactive trace mode, you must use an account with the privilege to act as part of the operating system:

Step	Action
1	From the Programs menu, select Administrative Tools and then User Manager.
2	Click User and then New Local Group... from the menu.
3	Create a new group named "DRAS Server".
4	Click Polices and then User Rights from the menu.
5	Check the Show Advanced User Rights check box.
6	Select "Act as part of the operating system" from the drop-down list box.
7	Add the right to the DRAS Server group.
8	Select the user accounts from which you will interactively run the DRAS server and add them as members of the DRAS Server group.
9	Log out and then log on to enable the new privileges.

## Running the DRAS Server in Debug Trace Mode

You can run the DRAS server from the console in debug trace mode. The trace often provides sufficient information to solve authentication and remote management connection problems. You can also verify that the server is able to start and initialize. To run trace mode:

Step	Action
1	Stop the server if it is running as a service.
2	Make sure the environment variable DRAS_DIR points to the location of the DRAS database files.
3	Go to the DRAS installation directory.
4	Start the server using the following command: > <b>drassrv console 5</b>

You can view more detailed trace information using a trace level of 6, 7, or 998.

## Files Installed on Windows NT Systems

The following table lists the files that the installation procedure installs:

File Name	Description
<b>Files in \DRAS</b>	
README.TXT	Release Notes
DRASSRV.EXE	DRAS server executable
DRASMAN.EXE	DRAS Manager executable
DRASMAN.HLP	DRAS Manager online help
DRASRC.DLL	DRAS Manager Windows resources
DRASCOAR.DLL	Accounting database interface
DRASCOUR.DLL	User and server database interface
DRASCOSP.DLL	Static password authentication module
DRASCOWW.DLL	WatchWord authentication module
DRASCOCH.DLL	CHAP authentication module
DRASCODS.DLL	Defender authentication module
DRASCOHP.DLL	Host password authentication module
DRASCOSD.DLL	SecurID authentication module
DRASCOSK.DLL	OTP authentication module
SETUPDB.EXE	SetupDb utility
DRAS.INI	Initialization file
<b>Files in %SystemRoot%\System32</b>	
ADVAPI32.DLL	API for NT system services
GRID32.OCX	Access Hour grid control
MFC40.DLL	Microsoft Foundation Class library, Version 4.0
MFC42.DLL	Microsoft Foundation Class library, Version 4.2

## Microsoft Windows NT and Windows 95 Installation

<b>File Name</b>	<b>Description</b>
MSVCRT.DLL	Microsoft Visual C++ Run Time library
MSVCIRT.DLL	Microsoft Visual C++ library
OLEPRO32.DLL	Specific OLE grid control
REGSVR32.EXE	Creates entries in the Windows Registration Database



## Microsoft Windows NT and Windows 95 Installation

### Files Installed on Windows 95 Systems

The following table lists the files that the installation procedure installs:

<b>File Name</b>	<b>Description</b>
<b>Files in \DRAS</b>	
README.TXT	Release Notes
DRASMAN.EXE	DRAS Manager executable
DRASMAN.HLP	DRAS Manager online help
DRASRC.DLL	DRAS Manager Windows resources
DRASCOAR.DLL	Accounting database interface
DRASCOUR.DLL	User and server database interface
DRASCOSP.DLL	Static password authentication module
DRASCOWW.DLL	WatchWord authentication module
DRASCOCH.DLL	CHAP authentication module
DRASCODS.DLL	Defender authentication module
DRASCOHP.DLL	Host password authentication module
DRASCOSD.DLL	SecurID authentication module
DRASCOSK.DLL	OTP authentication module
SETUPDB.EXE	SetupDb utility
DRAS.INI	Initialization file
<b>Files in %SystemRoot%\System32</b>	
ADVAPI32.DLL	API for NT system services
GRID32.OCX	Access Hour grid control
MFC40.DLL	Microsoft Foundation Class library, Version 4.0
MFC42.DLL	Microsoft Foundation Class library, Version 4.2
MSVCRT.DLL	Microsoft Visual C++ Run Time library
MSVCIRT.DLL	Microsoft Visual C++ library

## Microsoft Windows NT and Windows 95 Installation

<b>File Name</b>	<b>Description</b>
OLEPRO32.DLL	Specific OLE grid control
REGSVR32.EXE	Creates entries in the Windows Registration Database

## Deinstallation

To remove the DRAS software, do the following:

<b>Step</b>	<b>Action</b>
<b>1</b>	Bring up the Control Panel.
<b>2</b>	Click Add/Remove Programs.
<b>3</b>	Click Digital Remote Access Security from the list of programs.
<b>4</b>	Click the Add/Remove... button to remove the software.

---

## OpenVMS Installation

### Before You Install

The following table lists the prerequisites required for installing the DRAS software on an OpenVMS system:

For This:	You Need This on VAX Systems	And This on Alpha Systems:
Operating system	OpenVMS 6.1 or later	OpenVMS 6.2 or later
Minimum disk space	1000 blocks	1700 blocks

### Management

To manage the DRAS server on an OpenVMS system, install the DRAS Manager on a Windows NT or Windows 95 system.

### Installing the Software

To install the DRAS software on an OpenVMS system, do the following:

Step	Action
1	Log in to the SYSTEM account.
2	Insert the CD into your CD-ROM drive and mount it using the following command: <pre>\$ MOUNT <i>ddcu</i>: DRAS</pre> The <i>ddcu</i> : variable is the CD-ROM drive. When you mount the CD-ROM drive, you can access the [DRAS022] directory that contains the DRAS kit for OpenVMS.
3	If you previously installed the DRAS software, terminate any active DRAS servers. Enter the following: <pre>\$ @SYS\$MANAGER:DRAS\$SHUTDOWN</pre>
4	Run the VMSINSTAL procedure: <pre>\$ @SYS\$UPDATE:VMSINSTAL DRAS022 <i>ddcu</i>: OPTIONS N</pre>
5	Follow the instructions that the DRAS installation procedure provides.

## OpenVMS Installation

### Initial Database

During installation, the procedure prompts you to enter information it needs to create the initial DRAS server database. The installation procedure populates the database with:

- An administration group object (default name is ADMIN).
- A users group object (default name is USERS).
- An administrator user object (default name is SYSTEM). The installation procedure prompts you to enter a password.
- Authentication objects for the standard authentication methods.
- A client object for a management station.

You can select the default names for these objects or enter different ones during the installation.

## Logicals

The installation procedure defines the following logicals:

Logical	Description
DRAS\$DIR	Defines the full path where the DRAS server stores its database files. <b>Default Path:</b> SYS\$COMMON:[SYSEXE]
DRAS\$COxx	Defines the full path where the DRAS callout images reside. <b>Default Path:</b> SYS\$COMMON:[SYSLIB]

## Starting the DRAS Server

Type the following at the DCL prompt:

```
@SYS$STARTUP:DRAS$STARTUP
```

## Running the DRAS Server in Debug Trace Mode

You can run the DRAS server from the console in debug trace mode. The trace often provides sufficient information to solve authentication and remote management connection problems. You can also verify that the server is able to start and initialize.

To run trace mode:

---

<b>Step</b>	<b>Action</b>
<b>1</b>	Stop the server if it is running as a detached process.
<b>2</b>	Make sure the logical name DRAS\$DIR resolves to the location of the server database files.
<b>3</b>	Define DRAS\$TRACE_LEVEL as 5.
<b>4</b>	Start the server using the following command: > \$ <b>MCR DRAS\$SERVER</b>

---

You can view more detailed trace information using a trace level of 6, 7, or 998.

## OpenVMS Installation

### Files Installed

The OpenVMS installation kit contains executable images for OpenVMS Alpha and OpenVMS VAX systems. During installation, the procedure installs the correct files for the system on which you are installing the software.

The following table lists the files that the installation procedure installs:

<b>File Name</b>	<b>Description</b>
<b>Files in DRAS\$DIR</b>	
DRAS\$CONFIG.INI	Initialization file
<b>Files in SYS\$COMMON:[SYSMGR]</b>	
DRAS\$SYSTARTUP.COM	Secondary startup command procedure
DRAS\$REGISTER_COS.COM	Authentication method registration procedure
DRAS\$RUN.COM	Secondary startup command procedure
DRAS\$SHUTDOWN.COM	DRAS server shutdown command procedure
<b>Files in SYS\$COMMON:[SYSHLP]</b>	
DRAS022.RELEASE_NOTES	Release Notes
<b>Files in SYS\$COMMON:[SYSEXE]</b>	
DRAS\$SERVER.EXE	DRAS server executable
DRAS\$MANAGER.EXE	Management utility executable
DRAS\$CONFIG.INI	Initialization file
<b>Files in SYS\$COMMON:[SYSLIB]</b>	
DRAS\$COARSHR.EXE	Accounting database interface
DRAS\$COCHSHR.EXE	CHAP authentication module
DRAS\$COSPSHR.EXE	Static password authentication module
DRAS\$COURSHR.EXE	User and server database interface
DRAS\$COWWSHR.EXE	WatchWord authentication module
DRAS\$COHPSHR.EXE	Host password authentication module

## OpenVMS Installation

---

<b>File Name</b>	<b>Description</b>
DRAS\$COSDSHR.EXE	SecurID authentication module
DRAS\$CODSSHR.EXE	Defender authentication module
DRAS\$COSKSHR.EXE	OTP authentication module
<b>Files in SYS\$COMMON:[SYS\$STARTUP]</b>	
DRAS\$STARTUP.COM	DRAS startup command procedure
<b>Files in SYS\$SYSROOT:[SYSTEXT]</b>	
DRAS\$IVP.COM	DRAS Installation Verification Procedure

---

## DIGITAL UNIX Installation

### Introduction

To manage the DRAS server on a DIGITAL UNIX system, install the DRAS Manager on a Windows NT or Windows 95 system.

### Installing the Software

To install the DRAS software on a DIGITAL UNIX system, do the following:

---

<b>Step</b>	<b>Action</b>
<b>1</b>	Log in as root or super user, and go to the root directory.
<b>2</b>	<p>Insert your CD into your CD-ROM drive and mount it using the following command:</p> <pre>% mount -rt cdfs -0 noversion,rrip /dev /dir</pre> <p>The <i>/dev</i> variable is the CD-ROM drive, the <i>/dir</i> variable is the kit directory name.</p> <p>The <i>rrip</i> option instructs the operating system to use the Rock Ridge extensions on the CD-ROM. If you omit the <i>rrip</i> option, you cannot install DRAS.</p> <p>The CD-ROM includes a WINNT and a DIGITAL UNIX directory. (This is because the CD-ROM is in ISO-9660 format). The <i>Digital_UNIX</i> directory contains a <i>dras022_install</i> directory, which the <i>setld</i> command uses to install DRAS.</p>
<b>3</b>	<p>Access the CD-ROM mounted directory:</p> <pre># cd /dev/Digital_UNIX</pre>
<b>4</b>	<p>Install the kit by entering the following command:</p> <pre># setld -l .</pre>



---

Step	Action
5	<p data-bbox="467 590 1203 646">Enter the management station's Internet address and its secret when prompted. The installation procedure creates a database that contains:</p> <ul data-bbox="467 659 1203 877" style="list-style-type: none"><li data-bbox="467 659 1084 688">•An administration group object (default name is Admin).</li><li data-bbox="467 701 959 730">•A users group object (default name is Users).</li><li data-bbox="467 743 1203 800">•An administrator user object. The procedure prompts you to enter a user name and password.</li><li data-bbox="467 812 915 842">•A client object for a management station.</li><li data-bbox="467 854 1154 884">•Authentication objects for the standard authentication methods.</li></ul> <p data-bbox="467 896 1203 940">You can select the default names for these objects or enter different ones during the configuration.</p>
6	<p data-bbox="467 968 1078 997">If necessary, install the libcxx.so shareable object library.</p> <p data-bbox="467 1010 1203 1094">DRAS for DIGITAL UNIX uses the libcxx.so shareable object library that is shipped with the operating system, which may not be installed on your system.</p> <p data-bbox="467 1106 1203 1255">On DIGITAL UNIX V3.<i>n</i> systems, libcxx.so is in the optional subset CXXSHRDA30<i>n</i>. On DIGITAL UNIX V4.0 systems, libcxx.so is in the mandatory subset OSFBASE400 (CXXSHRDA130 on DEC OSF/1 Version 1.3 systems and CXXSHRDA131 on Version 2.0 systems).</p>

---

## Environment Variables

The DRASD start/stop script defines the following environment variables:

Variable	Description
DRAS_DIR	Defines the full path where the DRAS server stores its database files. <b>Default Path:</b> /usr/opt/dras/database
DRAS_CALLOUT	Defines the full path where the DRAS callout images reside. <b>Default Path:</b> /usr/opt/dras/callout
DRAS-TRACE_LEVEL	Defines the trace level when the DRAS server is running. <b>Default Path:</b> 5

## Starting the DRAS Server as a Console

Do the following to start the DRAS server as a console:

Step	Action
1	Log in as root or user with permission to access the DRAS server database.
2	Enter the following command: # <b>DRASD console</b>

The DRAS server starts when you reboot the system.

## Starting the DRAS Server as a Daemon

Do the following to start the DRAS server as a daemon:

Step	Action
1	Log in as root or user with permission to access the DRAS server database.
2	Enter the following command: # <b>DRASD start</b>

The DRAS server starts when you reboot the system.

## Running the DRAS Server in Debug Trace Mode

You can run the DRAS server from the console in debug trace mode. The trace often provides sufficient information to solve authentication and remote management connection problems. You can also verify that the server is able to start and initialize.

To run trace mode:

Step	Action
1	Stop the server if it is running as a daemon.
2	Make sure the environment variable DRAS_DIR points to the location of the server database files.
3	Start the server using the following command: <pre>&gt; # DRASD console</pre> The DRAS_TRACE_LEVEL environment variable contains the trace level and the default 5.

You can view more detailed trace information using a trace level of 6, 7, or 998.

## Stopping the DRAS Server

Do the following to stop the DRAS server:

Step	Action
1	Log in as root or user with permission to access the DRAS server database.
2	Enter the following command: <pre># DRASD stop</pre>

**Files Installed**

The following table lists the files that the installation procedure installs:

<b>File Name</b>	<b>Description</b>
<b>Files in /usr/opt/dras</b>	
dras022.links	Installation/deinstallation script
dras022.release_notes	Release Notes
<b>Files in /usr/opt/dras/bin/</b>	
drasserver	Server executable
setupdb	SetupDb utility
DRASD	Start/stop script
<b>Files in /usr/opt/dras/callout</b>	
drascoar.so	Accounting database interface
drascour.so	User and server database interface
drascosp.so	Static password authentication module
drascoww.so	WatchWord authentication module
drascoch.so	CHAP authentication module
drascohp.so	Host password authentication module
drascosd.so	SecurId authentication module
drascosk.so	OTP authentication module
drascods.so	Defender authentication module
<b>Files in /usr/opt/dras/database</b>	
drasconfig.ini	Initialization file

### Notes About the Directory Structure

Keep the following in mind:

- All files in `/usr/opt/dras/bin` are soft-linked into `/usr/sbin`, which is the standard system executables directory.
- All shareable objects (`.so` files) are soft-linked into `/usr/shlib`, which is the default share library search path.
- Database files are located in `/usr/opt/dras/database`.

### Deinstallation

To remove the DRAS software, do the following:

---

<b>Step</b>	<b>Action</b>
<b>1</b>	Log in as root or super user.
<b>2</b>	Deinstall the software by entering the following command: # <code>setld -d DRAS022</code>

---

---

## Postinstallation

### Introduction

Ensure that your RADIUS clients are configured properly for RADIUS and IP operations. See the documentation for your clients for details.

### Configuring DECserver Units

To configure the DECserver unit, use DECserver console commands or the Access Server Manager. See the *Network Access Server Management* guide or the *DECserver Network Access Software Installation* guide for more information. The following table illustrates how to create a basic RADIUS configuration using the DECserver console commands:

Step	Action
1	<p>Define an authentication realm using the same DRAS server name for both the authentication and accounting host. Use the following command syntax:</p> <pre>Local&gt; CHANGE RADIUS REALM <i>realm-name</i> SECRET "secret_string" AUTHENTICATION HOST ACCOUNTING HOST radius_host</pre> <p><b>Example:</b> Local&gt; CHANGE RADIUS REALM SISCO SECRET "OBRIEN" AUTHENTICATION HOST ACCOUNTING HOST OBRIEN.MMG.ORG.COM</p>
2	<p>Set one or all ports to use the new authentication realm. Use one of the following command syntaxes:</p> <pre>Local&gt; DEFINE PORT ALL AUTHENTICATION ENABLED Local&gt; DEFINE PORT <i>port-number</i> AUTHENTICATION ENABLED</pre>
3	<p>Verify the realm setting. Use the following command syntax:</p> <pre>Local&gt; SHOW RADIUS</pre>
4	<p>Log in to the selected port using RADIUS authentication. Use the following command syntax (user names and passwords are case sensitive):</p> <pre>Username&gt; <i>username@realm-name</i> Password&gt; <i>password</i></pre> <p><b>Before Logging In:</b> Define the appropriate user accounts in the DRAS server database. See the <i>DIGITAL Remote Access Security Use</i> guide or the DRAS Manager online help for details.</p>

Step	Action
5	Verify the port authorization settings. Use the following command syntax: Local> <b>SHOW PORT AUTHORIZATION</b>

## Registering DECserver clients

Register DECserver clients by their network IP addresses, even if the DECservers are registered on a name server. A DECserver identifies itself in a RADIUS packet using the NAS-IP-Address attribute. The DRAS server does not translate the IP address to a host name.

## Troubleshooting Management Connection Failures

The following is a checklist to help determine why an attempt to create a management link between a workstation running the DRAS Manager and a remote system running a DRAS server may fail.

Step	Action
1	Verify that the remote DRAS server is running.
2	Verify that the management station is registered correctly as a client in the DRAS server database.  The management station name must be either the full system and domain name, or the client's IP address. You can use the domain name if your client is registered in a domain naming system. Otherwise, use the client's IP address as the name. The database must also contain the correct client secret for the management station and the client must be enabled.  To check the client registration on: <ul style="list-style-type: none"> <li>•OpenVMS: Use the unsupported CLI management utility.</li> <li>•Windows NT: Use the DRAS Manager to examine the "Local Database" entry for the client</li> <li>•DIGITAL UNIX: Use the setupDb utility to establish an initial remote management client entry in the database.</li> </ul>

## Postinstallation

---

<b>Step</b>	<b>Action</b>
<b>3</b>	<p>Verify that the remote management user is registered correctly in the DRAS server database.</p> <p>A user that requests a remote management connection must be registered in the DRAS server database with Administrator privilege. The Administrator privilege is assigned to a group and applies to each user that is a member of the group.</p> <p>The user must have PASSWORD authentication selected. Make sure that the user is enabled and the password has not expired.</p> <p>Note that case sensitivity can cause problems, particularly with cross-platform connections. On OpenVMS systems, use quotation marks around names and passwords to preserve lower case characters.</p>

---



# Appendix A

---

## DRAS Server Initialization File

---

### Overview

#### In This Appendix

This appendix describes the following sections of the DRAS server initialization file:

- [Storage] Section
- [Server] Section
- [Policy] Section
- [Ports] Section

## Initialization File Description

### File Names

The DRAS installation procedure installs a server initialization file in the same directory where you install the DRAS data files. For OpenVMS systems, this is the location that the DRAS\$DIR logical name defines. On all other platforms, this is the directory that the DRAS\_DIR environment variable defines.

The following table lists the initialization file name for each software platform:

Platform	Initialization File Name
DIGITAL UNIX	drasconfig.ini
OpenVMS	DRAS\$CONFIG.INI
Windows NT and Windows 95	DRAS.INI

### Initialization File Example

The following example shows the initialization file from a DIGITAL UNIX system. The following sections explain each part of the example.

#### DIGITAL UNIX drasconfig.ini File

The following example shows DRAS initialization file for a system running the DIGITAL UNIX operating system. This file specifies the default values.

```
! Digital UNIX drasconfig.ini file
[storage]

userdb=/usr/opt/dras/database/drasusers
usercallout=/usr/opt/dras/callout/drascour.so
serverdb=/usr/opt/dras/database/drasdb
servercallout=/usr/opt/dras/callout/drascour.so
accountingdb=/usr/opt/dras/database/drasaccounting
accountingcallout=/usr/opt/dras/callout/drascoar.so

[server]
RadiusThreads=3
AccountingThreads=3
MaxConsecutiveRejects=5
```

## Initialization File Description

```
[policy]
NoLoginSession=Continue
NoFramedSession=Continue
NoCallbackNumber=Continue
BlankPassword=Reject
NoAuthentication=Reject
```

```
[ports]
Radius=1645
Accounting=1646
Management=1645
```

[Storage] Section

---

## [Storage] Section

### Description

The entries in the [Storage] section specify the location of the DRAS data files (excluding the initialization file).

### Entry Descriptions

The following table describes the entries in the [Storage] section:

Entry	Default Value	Description
userdb	<ul style="list-style-type: none"><li>• <b>OpenVMS:</b> DRAS\$DIR:DRAS\$USERS.DAT</li><li>• <b>Windows NT:</b> %DRAS_DIR%DRASUSRS.*</li><li>• <b>DIGITAL UNIX:</b> %DRAS_DIR%drasusers.*</li></ul>	Defines the location of the DRAS user database.
usercallout	<ul style="list-style-type: none"><li>• <b>OpenVMS:</b> DRAS\$COUR</li><li>• <b>Windows NT:</b> %DRAS_CALLOUT%DRASCOUR.DLL</li><li>• <b>DIGITAL UNIX:</b> %DRAS_CALLOUT%cmancour.so</li></ul>	Defines the location of the user database interface routines. <b>For Windows NT and DIGITAL UNIX:</b> If the DRAS_CALLOUT environment variable has no definition, the DRAS software looks for the images in the directory to which DRAS_DIR points.
serverdb	<ul style="list-style-type: none"><li>• <b>OpenVMS:</b> DRAS\$DIR:DRAS\$DB.DAT</li><li>• <b>Windows NT:</b> %DRAS_DIR%DRASDB.*</li><li>• <b>DIGITAL UNIX:</b> %DRAS_DIR%drasdb.*</li></ul>	Defines the location of the server database.

Entry	Default Value	Description
servercallout	<ul style="list-style-type: none"> <li>• <b>OpenVMS:</b> DRAS\$COUR</li> <li>• <b>Windows NT:</b> %DRAS_CALLOUT%DRASCOUR.DLL</li> <li>• <b>DIGITAL UNIX:</b> %DRAS_CALLOUT%drascour.so</li> </ul>	<p>Defines the location of the server database interface routines.</p> <p><b>For Windows NT and DIGITAL UNIX:</b> If the DRAS_CALLOUT environment variable has no definition, the DRAS software looks for the images in the directory to which DRAS_DIR points.</p>
accountingdb	<ul style="list-style-type: none"> <li>• <b>OpenVMS:</b> DRAS\$DIR:DRAS\$ACCOUNTING.DAT</li> <li>• <b>Windows NT:</b> %DRAS_DIR%DRASACCT.DAT</li> <li>• <b>DIGITAL UNIX:</b> %DRAS_DIR%drasaccounting.dat</li> </ul>	<p>Defines the location of the accounting database interface routines.</p>
accounting callout	<ul style="list-style-type: none"> <li>• <b>OpenVMS:</b> DRAS\$COAR</li> <li>• <b>Windows NT:</b> %DRAS_CALLOUT%DRASCOAR.DLL</li> <li>• <b>DIGITAL UNIX:</b> %DRAS_CALLOUT%drascoar.so</li> </ul>	<p>Defines the location of the server database interface routines.</p> <p><b>For Windows NT and DIGITAL UNIX:</b> If the DRAS_CALLOUT environment variable has no definition, the DRAS software looks for the images in the directory to which DRAS_DIR points.</p>

[Server] Section

---

## [Server] Section

### Description

The entries in the [Server] section control the DRAS server operation.

### Entry Descriptions

The following table describes the entries in the [Server] section:

---

Entry	Default Value	Description
RadiusThreads	3	Defines the number of worker threads that the server creates to handle RADIUS requests.
AccountingThreads	3	Defines the number of worker threads that the server creates to handle RADIUS accounting requests.
MaxConsecutiveRejects	5	Defines the number of consecutive access rejects allowed for a user before the DRAS server disables the user object.

---

---

## [Policy] Section

### Description

The entries in the [Policy] section determine whether the DRAS server rejects a user's request for access when it cannot find expected information in the user database.

#### Policy Entry Values

Policy entries have a value of Reject or Continue:

- A policy entry value of Reject indicates that the DRAS server controls acceptance or rejection of a user's access request.
- A policy entry value of Continue indicates that the RADIUS client (for example, a DECserver remote access server) controls acceptance or rejection of a user's access request.

### Entry Descriptions

The following table describes the entries in the [Policy] section:

Entry	Default Value	Description
BlankPassword	Reject	<p>Defines the policy for access requests that contain a blank or null password.</p> <p><b>Recommendation:</b> Allowing users to be authenticated without a password is a security risk. Therefore, DIGITAL recommends that you set this policy to Reject.</p> <p><b>Note:</b> Setting this policy to Reject does not affect users who have an authentication method that allows them to supply a blank password. In this case, the authentication method usually supplies an alternate challenge. An example of this is WatchWord authentication.</p>

[Policy] Section

Entry	Default Value	Description
NoAuthentication	Reject	Defines the policy for access requests from users for whom no authentication method is set. <b>Recommendation:</b> Allowing a user access to the network without authentication is a security risk. Therefore, DIGITAL recommends that you set this policy to Reject.
NoCallbackNumber	Continue	Defines the policy for a user whose entry in the user database includes a service type of Callback, but not the expected session definitions.
NoFramedSession	Continue	Defines the policy for a user whose entry in the user database includes a service type of Framed, but not the expected session definitions.
NoLoginSession	Continue	Defines the policy for a user whose entry in the user database includes a service type of Login, but not the expected session definitions.



---

## [Ports] Section

### Description

The entries in the [Ports] section indicate the UDP ports on which the DRAS server listens for RADIUS and RADIUS-Accounting packets.

### Entry Descriptions

The following table describes the entries in the [Ports] section:

---

Entry	Default Value	Description
Radius	1645	<p>The UDP port on which the DRAS server listens for RADIUS packets. The default value is the value that the RADIUS Draft Specification defines.</p> <p>To ensure compatibility with RADIUS clients, DIGITAL recommends that you do not change this value.</p>
Accounting	1646	<p>The UDP port on which the DRAS server listens on for RADIUS-Accounting packets. The default value is the RADIUS port number plus one.</p> <p>To ensure compatibility with other RADIUS clients, DIGITAL recommends that you use caution if you change this value.</p>
Management	1645	<p>The TCP port on which the DRAS server listens for remote management connections.</p> <p>To ensure compatibility with other RADIUS clients, DIGITAL recommends that you use caution if you change this value.</p>

---

