

# MicroVAX 3100-90 / VAX 4000-100 Information Sheet

\*\*\*\*\*

## Important Maintenance Information

\*\*\*\*\*

When replacing the CPU module (54-21797-01) in a 47ZBM-A9/B9 (MicroVAX 3100-90) or 47DBM-B9 (VAX 4000-100), firmware changes may have to be made to configure the CPU module for the appropriate system type. All spare CPU modules will be configured for the KA52-AA (47DBM-B9). After replacing the KA50-AA (47ZBM-A9/B9) CPU module, at the console prompt, run the following console test to properly configure the CPU for correct operation.

To configure a KA50-AA:

```
>>>T 9D 50
```

To reconfigure a KA50-AA to a KA52-AA:

```
>>>T 9D 52
```

Order Number: EK-M3140-IS. A01